

LIFAN

Integrated Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Read immobiliser state

Read key code

Program function

Replace engine ECU

Replace immobiliser ECU

Program keys

Reset engine ECU

Reset immobiliser

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Write key number

Program WSC

Write programming Date

Write diagnosing Date

Program engine VIN

Program immobilizer VIN

Siemens Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5
Replace immobiliser ECU
Replace engine ECU
Program immobiliser VIN
Program engine VIN
Reset engine ECU
Reset immobiliser