
TOYOTA/LEXUS

Remote

Type 1

Add remote

Type 2

Add remote

Erase remote

Immobiliser

Type 1

Add a key

Erase keys

Reset immobiliser

Replace engine ECU

Type 2 (with G/H)

Add a key

Erase keys

Replace immobiliser ECU

Replace engine ECU

Type 3 (Avanza)

Add a key

Type 4 (4C chip)

Main key add

Deputy key add

Key erase

Dtc erase

Smart key system

Type 1

Add smart key

Erase smart key

Reset smart key ECU

Reset smart key ECU

Program smart key after resetting

Program ECU

Program ID box with steering lock

Remote engine start

Type 2 (12 crown)

Smart keys synchronization

Add remote

Reset immobiliser

Type 3

Add smart key

Erase smart key

Reset smart key ECU