Toyota Camry

(15-16/17YEARS)

Support more models

Toyota Corolla 、Prado、Levin、RAV etc.,

VVDI


PC
J1
电池正极
BAT+
电池
BATTERY
J2
电池负极
BAT-
J3
汽车保险盒
CAR FUSE BOX
J4
汽车OBD
CAR OBD
J6
J5
锁头插头
IGNITION PLUG
SCAN OBD
CAR/BOX

KEY TOOL MAX & MINI OBD


J1
电池正极
BAT+
电池
BATTERY
J2
电池负极
BAT-
J3
汽车保险盒
CAR FUSE BOX
J4
汽车OBD
CAR OBD
J5
锁头插头
IGNITION PLUG
J6
SCAN OBD
CAR/BOX

ⓘ Please update device to latest version for this function

During the process
don't insert the key,

please keep ignition off

---

① Disconnect the positive pole of the car battery to protect the connector and avoid short circuits



② Please connect to fuse box as the image

15-16 YEARS



Located in engine compartment fuse box

Unplug 10A fuse Number 1 connect to 10A(left)

J3 cable the number 1、2 connector, need to connect separately

J3 lock plug


FAN
EDU
ST NO.2
ST
H-LP
1
15A IGN
7.5A ECU-IG2 NO.3
7.5A INJ
7.5A EFI NO.3
15A EFI NO.2
5A WIPER-S
20A AMP
H-LP
15A H-LP LH-LO
30A BBC NO.2
10A STRG LOCK
15A TURN&HAZ
5A MAYDAY
10A
CU-B NO
DOME
D/C CUT
7.5A AM2
20A EFI-MAIN NO.2
7.5A EFI NO.1
20A ST NO.2
HTR 50A
PTC HTR NO.1 50A
EPS 80A
ABS NO.1 50A
20A EDU

10A(left)


7.5
15
20
10
7.5
10
10
7.5
7.5
15
30

Near vehicle OBD diagnose port fuse box

Unplug 7.5A fuse Number 2 connect to 7.5A(right)



J3 lock plug



	30A P/SEAT RR	20A S/HTR RR
7.5A BKUP LP		10A S/HTR&FAN F/R
25A WIPER	7.5A STOP	7.5A ECU-ACC
7.5A A/C-IG1	7.5A AM1	15A CIG&P/OUTLET
10A WASHER	20A DOOR NO.2	7.5A ECU-IG2 NO.2
7.5A H-LP LVL	10A ECU-B NO.2	[illegible]
10A S/HTR&FAN F/L	10A OBD	10A A/B
7.5A ECU-IG1 NO.3	20A DOOR R/L	20A TI&TE
7.5A EPS-IG1	20A DOOR R/R	20A D/L-AM1
	5A SFT LOCK-ACC	30A

7.5A(right)

17YEARS



Located in engine compartment fuse box

Unplug 7.5A fuse Number 2 connect to 7.5A(left)

Unplug 10A fuse Number 1 connect to 10A(left)

TOYOTA
15
5
10T
2-8
30
7.5
20
15
7.5
25
20
No.2
No.1

www.obdexpress.co.uk

J3 lock plug


FAN
EDU
ST NO.2
ST
H-LP
IGN
7.5A
CU-IG2 NO
10A
CU-B NO
5A
WIPER-S
20A
AMP
DOME
SHORT
D/C CUT
EFI NO.3
15A
EFI NO.2
30A
BBC NO.2
7.5A
AM2
HTR
50A
PTC HTR NO.1
50A
EPS
80A
ABS NO.1
50A
20A EDU
10A
STRG LOCK
20A
EFI-MAIN NO.2
15A
TURN&HAZ
7.5A
EFI NO.1
5A
MAYDAY
20A
ST NO.2

7.5A(left)

10A(left)

③ Please connect the ELV wires as shown



Please unplug the lock plug




plug
J5 lock plug

J5 lock plug

④ Please connect to car OBD,
all key lost cables and car battery



J4 lock plug

VVDI



J6 lock plug

KEY TOOL MAX &MINI OBD


J6 lock plug


All key lost cables
+
−

⑤ Please generate start chip referring to software interface

VVDI



Toyota 8A immobilizer-Not Sma

OBD Function-Require 8A adapter

Immobox(8A) all key lost-OBD Make master key directly
Immobox(8A) all key lost-File make master key directly
Combine VVDI2 with 8A adapter
Update 8A all key lost adaptor
8A all key lost adapter - Open power
8A all key lost adapter - Close power

OBD Function-Not Require 8A adapter

Add key
Delete key
Detect immobox status
Learn new immobox

KEY TOOL MAX &MINI OBD



8A all key lost

8A all key lost - Query calculation result



✓ Calculation online

Server calculation succeeded

✓ Generate master key

Master key generate successful, this key can start the car directly. please disconnect 8A all key lost adapter, recover the car status. if need to add other keys, please use MINI OBD for key programming!

⑥ Please disconnect all cables,recover all connection wires as car original status

If the connection wires not recovery to original status and start the car directly, the fuse boxe and device will be burnt ⚠

⑦ Test generated transponder