

防盗遥控匹配

品牌	菜单	应用	功能ID
PROTON	PROTON>Select from type\Type 1	Add key, Reset IMMO ECU,	822
	PROTON>Select from type\Type 2	Program key, Delete key,	821
	PROTON>Select from type\Type 3	Add key, Delete key, Key count,	819
	PROTON>Select from type\Type 4	Add key, Delete key, Odometer adjustment Reset	823
	PROTON>Select from type\Type 5	Program key, Program remote,	824
	PROTON>Select from vehicle\Savvy	Add key, Reset IMMO ECU,	822
	PROTON>Select from vehicle\Gen-2	Program key, Delete key,	821
	PROTON>Select from vehicle\Impian	Program key, Delete key,	821
	PROTON>Select from vehicle\Jump back\Type 1	Add key, Reset IMMO ECU,	822
	PROTON>Select from vehicle\Jump back\Type 2	Program key, Delete key,	821
	PROTON>Select from type\Type 6	Add key, Delete key, Program remote, Key count	835
	PROTON>Select from type\Type 7	Add one key, Add two keys, Program remote, Key count	836
	PROTON>Select from type\Type 8	Add key, Delete key, Program remote, Key count	837
	PROTON>Select from vehicle\X70\Smart key	Delete key, Program old key, Program new key,	598
DACIA	DACIA\Dokker\2012-	Program key, Read PIN code, Read key count,	1207
	DACIA\Duster\2010-2011	Add key,	1140
	DACIA\Lodgy\2013-	Program key, Read PIN code, Read key count,	1207
	DACIA\Logan\2013-	Program key, Read PIN code, Read key count,	1207
	DACIA\Sandero\2013-	Program key, Read PIN code, Read key count,	1207

DACIA	DACIA\Solenza	Add key,	1141
	DACIA\Duster\2013-	Program key, Read PIN code, Read key count,	1207
	DACIA\Logan\2004-2011	Add key,	1140
	DACIA\Sandero\2007-2011	Add key,	1140
	DACIA\Sandero stepway\2006-2012	Add key,	1140
SCION	SCION\xB\2012\Remote	Program remote, Delete remote,	741
	SCION\CH-R\2018\Mechanical key	Add key, Delete key, Program immo ECU, Program engine	727
	SCION\CH-R\2018\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
	SCION\FR-S\2013-2016\Mechanical key	Read key count, Add key, Program remote, Delete remote,	739
	SCION\FR-S\2013-2016\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
	SCION\iA\2016-2018\Smart key	Program remote, Add smart key, Reset immo ECU	725
	SCION\iM\2017-2018\Mechanical key	Add key, Delete key, Program immo ECU, Program engine	727
	SCION\iQ\2012-2015\Mechanical key	Add key, Delete key, Program immo ECU, Program engine	738
	SCION\tC\2011-2015\Mechanical key	Add key, Delete key, Program immo ECU, Program engine	738
	SCION\tC\2011-2015\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
	SCION\xB\2012-2013\Mechanical key	Add key, Delete key, Program immo ECU, Program engine	738
	SCION\xD\2012-2013\Mechanical key	Add key, Delete key, Program immo ECU, Program engine	738
	SCION\tC\2005-2010\Mechanical key	Add key, Delete key, All key lost, Reset immo ECU, Program engine ECU	735
	GENESIS	GENESIS\G80 (DH)\2017-2019	Program smart key, Read PIN code (8A),
GENESIS\G90 (HI)\2017-2019		Program smart key, Read PIN code (8A),	2016
	ABARTH\Europe\500\2008-(312)	Key count, Program key, Read PIN code, Make dealer key (46)	929

ABARTH	ABARTH\Europe\Grande Punto\2007-2010 (199)	Key count, Program key, Read PIN code, Make dealer key (46)	929
	ABARTH\Australia\500\2011-2014 (312)	Key count, Program key, Read PIN code, Make dealer key (46)	929
ACURA	ACURA>Select from type\Immobilizer\16 PIN\IMMO2	Add one key, All key lost, Reset key,	209
	ACURA>Select from type\Smart key\Knob type	Add one key, All key lost, Detect smart key,	212
	ACURA>Select from type\Smart key\Button type 1	Add one key, All key lost,	213
	ACURA>Select from type\Remote\IMMO9	Add remote, Delete remote,	214
	ACURA>Select from type\Immobilizer\16 PIN\IMMO3	Add key, All key lost, Reset immobiliser,	216
	ACURA>Select from type\Immobilizer\16 PIN\IMMO4	Reset immobox, Reset ECM,	215
	ACURA>Select from type\Immobilizer\16 PIN\Check_IMMO_type	Immo type,	217
	ACURA>Select from type\Smart key\Button type 2	Add 1 key, All key lost,	759
	ACURA>Select from type\Smart key\Button type 3	Add 1 key, All key lost,	760
	ACURA>Select from type\Immobilizer\3 PIN\Check_IMMO_type	Search IMMO type,	807
	ACURA>Select from type\Immobilizer\3 PIN\IMMO2	Add one key, All key lost, Reset key,	209
	ACURA>Select from type\Immobilizer\3 PIN\IMMO3	Add key, All key lost, Odometer adjustment	809
	ACURA>Select from type\Immobilizer\3 PIN\IMMO4	Reset immobox, Reset ECM,	810
	ACURA>Select from vehicle\ZDX\2010-\Mechanical key	Add one key, All key lost, Reset key,	209
	ACURA>Select from vehicle\ZDX\2010-\Smart key	Add 1 key, All key lost,	759
	ACURA>Select from type\Immobilizer\16 PIN\IMMO1	Add one key, All key lost, Reset key,	206
	ACURA>Select from type\Immobilizer\3 PIN\IMMO1	Add 1 key, All key lost, Reset key,	808
	ACURA>Select from vehicle\CL\1998-2003	Read key count, All key lost,	1377
	ACURA>Select from vehicle\CSX\2008-	Add one key, All key lost, Reset key,	209

	ACURA\Select from vehicle\EL\2001-2005	Add one key, All key lost, Reset key,	206
	ACURA\Select from vehicle\MDX\2001-2006	Add one key, All key lost, Reset key,	206
	ACURA\Select from vehicle\MDX\2007-2013	Add one key, All key lost, Reset key,	209
	ACURA\Select from vehicle\NSX\1995-2005	Read key count, All key lost,	1377
	ACURA\Select from vehicle\RDX\2007-2012	Add one key, All key lost, Reset key,	209
	ACURA\Select from vehicle\RL\1996-1999	Read key count, All key lost,	1377
	ACURA\Select from vehicle\RL\2005-2007	Add one key, All key lost, Reset key,	206
	ACURA\Select from vehicle\RSX\2002-2006	Add one key, All key lost, Reset key,	206
	ACURA\Select from vehicle\TL\1999-2003	Read key count, All key lost,	1377
	ACURA\Select from vehicle\TL\2004-2008	Add one key, All key lost, Reset key,	206
	ACURA\Select from vehicle\TL\2009-2012	Add one key, All key lost, Reset key,	209
	ACURA\Select from vehicle\TSX\2004-2008	Add one key, All key lost, Reset key,	206
	ACURA\Select from vehicle\TSX\2009-2013	Add one key, All key lost, Reset key,	209
	ACURA\Select from vehicle\RL\2008-2012	Add one key, All key lost, Reset key,	206
	ACURA\Select from vehicle\Integra	Read key count, All key lost,	1377
	ACURA\Select from type\Immobilizer\16 PIN\IMMO_5	Read key count, All key lost,	1377
ROLLS-ROYCE	ROLLS-ROYCE\Select from vehicle\Phantom	Program key, Disable and enable, Make key with EPROM data Backup &	1193
	ROLLS-ROYCE\Select from vehicle\Wraith	Generate ignition key, Disable key, Enable key	794
	ROLLS-ROYCE\Select from vehicle\Ghost	Generate ignition key, Disable key, Enable key	794
	SMART\BR453\Immobilizer	Read PIN code, Program key, Recover configured data	1104
	SMART\BR451\Immobilizer	Program key,	227

SMART	SMART\BR450\2002\Immobilizer	Program key,	229
	SMART\BR452\2003-2006\Immobilizer	Program key, Read key count,	1372
	SMART\BR454\2004-2006\Immobilizer	Program key,	1131
	SMART\BR450\2002-\Immobilizer	Program key, Read key count,	1372
	SSANG YONG\Select from type\Immobilizer\Type 3	Program key,	1105
	SSANG YONG\Select from vehicle\Actyon\Petrol	Program key,	1105
	SSANG YONG\Select from vehicle\Actyon\Diesel	Program key,	1105
	SSANG YONG\Select from vehicle\Actyon\XDi system	Program key,	12
	SSANG YONG\Select from vehicle\Chairman\Petrol\Immobilizer	Program key,	1105
	SSANG YONG\Select from vehicle\Chairman\Diesel	Program key,	1105
	SSANG YONG\Select from vehicle\Chairman\XDi system	Program key,	12
	SSANG YONG\Select from vehicle\Korando\Petrol	Program key,	1105
	SSANG YONG\Select from vehicle\Korando\Diesel	Program key,	1105
	SSANG YONG\Select from vehicle\Korando\XDi system	Program key,	12
	SSANG YONG\Select from vehicle\Kyron\Petrol	Program key,	1105
	SSANG YONG\Select from vehicle\Kyron\Diesel	Program key,	1105
	SSANG YONG\Select from vehicle\Kyron\XDi system	Program key,	12
	SSANG YONG\Select from vehicle\Musso\Petrol	Program key,	1105
	SSANG YONG\Select from vehicle\Musso\Diesel	Program key,	1105
	SSANG YONG\Select from vehicle\Musso\XDi system	Program key,	12
	SSANG YONG\Select from vehicle\Rexton\Petrol	Program key,	1105

SSANG YONG

SSANG YONG>Select from vehicle\Rexton\Diesel	Program key,	1105
SSANG YONG>Select from vehicle\Rexton\XDi system	Program key,	12
SSANG YONG>Select from vehicle\Stavic Rodius\Petrol	Program key,	1105
SSANG YONG>Select from vehicle\Stavic Rodius\Diesel	Program key,	1105
SSANG YONG>Select from vehicle\Stavic Rodius\XDi system	Program key,	12
SSANG YONG>Select from vehicle\Rodius\Petrol	Program key,	1105
SSANG YONG>Select from vehicle\Rodius\Diesel\T ype 1	Program key,	1105
SSANG YONG>Select from vehicle\Rodius\XDi system	Program key,	12
SSANG YONG>Select from vehicle\Rexton II\Petrol	Program key,	1105
SSANG YONG>Select from vehicle\Rexton II\Diesel	Program key,	1105
SSANG YONG>Select from vehicle\Rexton II\XDi system	Program key,	12
SSANG YONG>Select from vehicle\New Rexton\Petrol	Program key,	1105
SSANG YONG>Select from vehicle\New Rexton\Diesel	Program key,	1105
SSANG YONG>Select from vehicle\New Rexton\XDi system	Program key,	12
SSANG YONG>Select from type\Remote\Type 2	Program remote,	1135
SSANG YONG>Select from vehicle\New Korando\Petrol\Smart	Program smart key,	1685
SSANG YONG>Select from vehicle\ChairmanH\Petro l\Smart key	Program smart key,	1685
SSANG YONG>Select from vehicle\Rodius-Stavic II\Petrol\Smart key	Program smart key,	1685
SSANG YONG>Select from vehicle\Actyon sports (IT)\Petrol\Smart	Program smart key,	1685
SSANG YONG>Select from vehicle\XLV\Petrol\Sm art key	Program smart key,	1685
SSANG YONG>Select from vehicle\XLV\Petrol\Remo te	Program remote,	1684

SSANG YONG\Select from vehicle\Musso (Rexton sports)\Diesel\Remote	Program remote,	1684
SSANG YONG\Select from vehicle\Rexton (G4)\Petrol\Remote	Program remote,	1684
SSANG YONG\Select from vehicle\New Korando\Petrol\Remote	Program remote,	1684
SSANG YONG\Select from vehicle\Tivolan\Remote	Program remote,	1684
SSANG YONG\Select from vehicle\XLV\Petrol\Immobilizer	Program key,	1693
SSANG YONG\Select from vehicle\Musso (Rexton sports)\Diesel\Immobilizer	Program key,	1693
SSANG YONG\Select from vehicle\Rexton (G4)\Petrol\Immobilizer	Program key,	1693
SSANG YONG\Select from vehicle\New Korando\Petrol\Immobilizer	Program key,	1693
SSANG YONG\Select from vehicle\Tivolan\Immobilizer	Program key,	1693
SSANG YONG\Select from vehicle\Rexton (G4)\Petrol\Smart key	Program smart key,	1687
SSANG YONG\Select from vehicle\Musso (Rexton sports)\Diesel\Smart	Program smart key,	1687
SSANG YONG\Select from type\Smart key\Type 1	Program smart key,	1687
SSANG YONG\Select from type\Smart key\Type 2	Program smart key,	1685
SSANG YONG\Select from type\Immobilizer\Type 4	Program key,	1693
SSANG YONG\Select from type\Remote\Type 3	Program remote,	1684
SSANG YONG\Select from vehicle\New Korando\Diesel\Immobilizer	Program key,	1693
SSANG YONG\Select from vehicle\New Korando\Diesel\Remote	Program remote,	1684
SSANG YONG\Select from vehicle\New Korando\Diesel\Smart	Program smart key,	1685
SSANG YONG\Select from vehicle\Rexton W\Diesel\Smart key	Program smart key,	1685
SSANG YONG\Select from vehicle\Rexton W\Diesel\Immobilizer	Program key,	1693
SSANG YONG\Select from vehicle\Rodius\Diesel\Type 2\Immobilizer	Program key,	1693

	SSANG YONG\Select from vehicle\Rodius-Stavic II\Diesel\Immobilizer	Program key,	1693
	SSANG YONG\Select from vehicle\Rodius-Stavic II\Diesel\Smart key	Program smart key,	1685
	SSANG YONG\Select from vehicle\Actyon sports (II)\Diesel\Immobilizer	Program key,	1693
	SSANG YONG\Select from vehicle\Actyon sports (II)\Diesel\Smart key	Program smart key,	1685
	SSANG YONG\Select from vehicle\XLV\Diesel\Immobilizer	Program key,	1693
	SSANG YONG\Select from vehicle\XLV\Diesel\Remote	Program remote,	1684
	SSANG YONG\Select from vehicle\XLV\Diesel\Smart key	Program smart key,	1685
	SSANG YONG\Select from vehicle\Rexton (G4)\Diesel\Immobilizer	Program key,	1693
	SSANG YONG\Select from vehicle\Rexton (G4)\Diesel\Remote	Program remote,	1684
	SSANG YONG\Select from vehicle\Rexton (G4)\Diesel\Smart key	Program smart key,	1687
	SSANG YONG\Select from type\Immobilizer\Type 1	Program key,	12
	SSANG YONG\Select from type\Remote\Type 1	Program remote,	44
	SSANG YONG\Select from type\Immobilizer\Type 2	Program key,	170
	SSANG YONG\Select from vehicle\Tivolán\Smart key	Program smart key,	1685
IVECO	IVECO\Daily\2012-	Key info, Program key, Read PIN ocde, Make dealer key (46 chin)	931
	IVECO\Power Daily\Immobilizer	Learn key, Write VIN, Replace IMMO,	420
	IVECO\Exceed\Immobilizer	Learn key, Write VIN, Replace IMMO,	420
	IVECO\Power Daily\Remote	Learn remote, Write VIN,	421
	IVECO\Exceed\Remote	Learn remote, Write VIN,	421
	IVECO\Daily\2007-2012	Key count, Program key, Remote count Program	928
	IVECO\Eurocargo\2007-2012	Key count, Program key, Remote count Program	928



GMC	GMC\Canyon\IMMO\2015\Im mobilizer	All key lost, Add key, Read key count Clear fault code	284
	GMC\Sierra\IMMO\2015\Im mobilizer	All key lost, Add key, Read key count Clear fault code	284
	GMC\Sierra\IMMO\2015\Sm art key	Add smart key, All smart key lost, Read smart key count	295
	GMC\Sierra 1500\IMMO\2015\Immobi lizer	All key lost, Add key, Read key count Clear fault code	284
	GMC\Sierra 2500\IMMO\2014- \Immobilizer	All key lost, Add key, Read key count Clear fault code	284
	GMC\Sierra 3500\IMMO\2014- \Immobilizer	All key lost, Add key, Read key count Clear fault code	284
	GMC\Yukon\IMMO\2015\Imm obilizer	All key lost, Add key, Read key count Clear fault code	284
	GMC\Yukon\IMMO\2015\Sma rt key	Add smart key, All smart key lost, Read smart key count	295
	GMC\Terrain\2010- 2013\Immobilizer	All key lost, Add key, Read key count Clear fault code	284
	GMC\Yukon\Remote\2015	Add remote, Clear fault code,	1370
	GMC\Sierra 1500\Remote\2014-2015	Add remote, Clear fault code,	1370
	GMC\Sierra 2500\Remote\2014-	Add remote, Clear fault code,	1370
	GMC\Sierra 3500\Remote\2014-	Add remote, Clear fault code,	1370
	GMC\Acadia\IMMO\2007- 2014\Immobilizer	Lost all key,	297
	GMC\Savana\IMMO\2008- 2013\Immobilizer	Lost all key,	297
	GMC\Sierra\IMMO\2007- 2013\Immobilizer	Lost all key,	297
	GMC\Yukon\IMMO\2007- 2013\Immobilizer	Lost all key,	297
	GMC\Canyon\IMMO\2008- 2012\Immobilizer	All key lost,	617
	GMC\Acadia\Remote\2007- 2014	Program remote, Delete remote,	333
	GMC\Savana\Remote\2008- 2013	Program remote, Delete remote,	333
	GMC\Yukon\Remote\2007- 2013	Program remote, Delete remote,	333

	GMC\Sierra\Remote\2007-2013	Program remote, Delete remote,	333
	GMC\Read PIN code	Read pin code type6 (read via BCM) Read pin code	370
MERCEDES-BENZ	MERCEDES-BENZ\Remote\163-ML Class	Remote, Reset ECU,	966
	MERCEDES-BENZ\Tail box control\E series\213 148 F300	Trunk control,	975
	MERCEDES-BENZ\Key system\System 2 (2014-FRS4)	Disable key,	1777
	MERCEDES-BENZ\Key system\System 1	Disable key,	407
	MERCEDES-BENZ\Tail box control\C series\204	Trunk control,	408
	MERCEDES-BENZ\Tail box control\CLK series\204	Trunk control,	408
	MERCEDES-BENZ\Tail box control\E series\212	Trunk control,	408
	MERCEDES-BENZ\Tail box control\S series\221	Trunk control,	409
		ALFA ROMEO\Select from vehicle\IMMO\Giulietta\2010-2012\Immobilizer	Key count, Program key, Remote count Program
	ALFA ROMEO\Select from type\Type 9	Key count, Program key, Remote count Program	928
	ALFA ROMEO\Select from vehicle\IMMO\Giulia\2015-2018\Smart key	Add smart key, Delete smart key, Read PIN code	1119
	ALFA ROMEO\Select from vehicle\IMMO\Stelvio\2016-2018\Smart key	Add smart key, Delete smart key, Read PIN code	1119
	ALFA ROMEO\Select from vehicle\IMMO\159\Immobilizer	Key info., Program key, Backup immo data Make dealer key (46	703
	ALFA ROMEO\Select from vehicle\IMMO\Spider\Immobilizer	Key info., Program key, Backup immo data Make dealer key (46	703
	ALFA ROMEO\Select from vehicle\IMMO\Brera\Immobilizer	Key info., Program key, Backup immo data Make dealer key (46	703
	ALFA ROMEO\Select from vehicle\IMMO\147\Immobilizer	Read key count, Program key, Read remote count Program remote	704
	ALFA ROMEO\Select from vehicle\IMMO\GT\Immobilizer	Read key count, Program key, Read remote count Program remote	704
ALFA ROMEO	ALFA ROMEO\Select from vehicle\IMMO\Giulietta\2013-\Immobilizer	Read key count, All key lost, Read PIN code, Make dealer key (46 chip)	1223
	ALFA ROMEO\Select from vehicle\IMMO\Mito\Immobilizer	Read key count, All key lost, Read PIN code, Make dealer key (46 chip)	1222

	ALFA ROMEO>Select from type\Type 1	Key info., Program key, Backup immo data, Make dealer key (46	703
	ALFA ROMEO>Select from type\Type 2	Read key count, Program key, Read remote count, Program remote	704
	ALFA ROMEO>Select from type\Type 3	Read key count, All key lost, Read PIN code, Make dealer key (46 chin)	1222
	ALFA ROMEO>Select from type\Type 4	Key count, Program key, Delete key,	1083
	ALFA ROMEO>Select from type\Type 5	Key count, Program key, Delete key,	1084
	ALFA ROMEO>Select from type\Type 6	Program key, Delete key,	1085
	ALFA ROMEO>Select from type\Type 7	Program key, Delete key, Obtain immo ID,	1097
	ALFA ROMEO>Select from type\Type 8	Key info, Program key,	930
	ALFA ROMEO>Select from vehicle\IMMO\The Centenario/GT\2003-	Read key count, Program key, Read remote count, Program remote	704
LANCIA	LANCIA\IMMO\Ypsilon\2013-\Immobilizer	Key count, Program key, Read PIN code, Make dealer key (46	929
	LANCIA\IMMO\Thesis\02-09\Immobilizer	Read key count, Program key,	700
	LANCIA\IMMO\Ypsilon\2003-2006\Immobilizer	Read key count, Program key,	700
	LANCIA\IMMO\Phedra\2005-\Immobilizer	Program key,	699
	LANCIA\IMMO\Delta	Read PIN code, Backup EEPROM, Recover EEPROM, Backup	1075
	LANCIA\IMMO\Musa	Read PIN code, Backup EEPROM, Recover EEPROM, Backup	1075
	LANCIA\IMMO\Phedra\Type 1	Program key,	1076
	LANCIA\IMMO\Phedra\Type 2	Program key,	1082
	LANCIA\IMMO\Phedra\Type 3	Program key,	1081
	LANCIA\IMMO\Z\Type 1	Program key,	1076
	LANCIA\IMMO\Z\Type 2	Program key,	1082
	LANCIA\IMMO\Z\Type 3	Program key,	1081

	LANCIA\IMMO\Ypsilon\2007-2012\Immobilizer	Key count, Program key, Remote count, Program	928
AUDI	AUDI\Q3\2014-\Immobilizer	Make dealer key, Learn key (OBD), Backup EEPROM, Recover	1130
	AUDI\A3\2016\Immobilizer	Backup EEPROM, Recover EEPROM, Backup immo data, Recover immo	1064
	AUDI\A6L\2009-\Immobilizer	Backup immo data, Make dealer key, Learn key, Unlock key	163
	AUDI\A6L\2009-\Immobilizer	Backup immo data, Make dealer key, Learn key, Unlock key	82
	AUDI\IMMO5\Immobilizer/Smart key	Backup immo data, Make dealer key, Learn key, Clear airbag fault	48
	AUDI\Q7\2009-\Immobilizer	Backup immo data, Make dealer key, Learn key, Unlock key	82
	AUDI\Q7\2009-\Immobilizer	Backup immo data, Make dealer key, Learn key, Unlock key	163
	AUDI\A3\TT\R8-CDC32XX+24C32\Immobilizer	Backup EEPROM, Recover EEPROM, Backup immo data, Restore immo	974
	AUDI\Q3\2013\Immobilizer	Backup EEPROM, Recover EEPROM, Make dealer key, Learn	1129
	AUDI\A1\Immobilizer	Backup EEPROM, Recover EEPROM, Make dealer key, Key	973
	AUDI\IMMO5\Engineering mode (5th Gen)	Obtain data, Make dealer key, Learn key, Clear airbag fault code	901
	AUDI\A4L\Immobilizer/Smart key	Backup immo data, Make dealer key, Learn key, Clear airbag fault	48
	AUDI\Remote\Central locking (1281)	Add remote, Delete remote,	292
	AUDI\Remote\Central module (1281)	Add remote, Delete remote,	291
	AUDI\Remote\Remote	Add remote, Delete remote,	43
	AUDI\A6L\2012-\Immobilizer/Smart key	Backup immo data, Make dealer key, Learn key, Clear airbag fault	48
	AUDI\Q5\Immobilizer/Smart key	Backup immo data, Make dealer key, Learn key, Clear airbag fault	48
	SUBARU>Select from vehicle\Brz\2013-\Without smart	Key count, Add key, Delete key, Add remote, Delete remote	710
	SUBARU>Select from vehicle\Crosstrek\2014-\Without smart	Check key count, Add key, All key lost, Delete key, Register dashboard	789
	SUBARU>Select from vehicle\Forester\2013 -\Without smart	Check key count, Add key, All key lost, Delete key, Register dashboard	789

SUBARU>Select from vehicle\Impreza\Without smart\2012(4D 60/62	All key lost,	220
SUBARU>Select from vehicle\Impreza\Without smart\2013-(4D 82G	Check key count, Add key, All key lost, Delete key Register dashboard	789
SUBARU>Select from vehicle\Impreza\With smart\2012	Add smart key, Delete smart key, Key count Read PIN	981
SUBARU>Select from vehicle\Legacy\Without smart\4D 60/62 chip	All key lost,	220
SUBARU>Select from vehicle\Legacy\With smart	Add smart key, Delete smart key, Key count Read PIN	981
SUBARU>Select from vehicle\Outback\Without smart\2013-	Add key, Read PIN code,	706
SUBARU>Select from vehicle\Sti	All key lost,	220
SUBARU>Select from vehicle\Tribeca\Without smart\Type 1	All key lost,	220
SUBARU>Select from vehicle\Tribeca\Without smart\Type 2(North	Key count, Add key, Delete key, Add remote Delete remote	710
SUBARU>Select from vehicle\XV\2013-\Without smart	Check key count, Add key, All key lost, Delete key Register dashboard	789
SUBARU>Select from vehicle\XV Crosstrek\2013-\Without	Check key count, Add key, All key lost, Delete key Register dashboard	789
SUBARU>Select from vehicle\WRX\2013\Without smart\4D	All key lost,	220
SUBARU>Select from vehicle\WRX\2014-\Without smart\4D 82G	Check key count, Add key, All key lost, Delete key Register dashboard	789
SUBARU>Select from vehicle\Liberty\2014-\With smart	Add smart key, Delete smart key, Key count Read PIN	981
SUBARU>Select from vehicle\Liberty\2014-\Without smart\4D 60/62	All key lost,	220
SUBARU>Select from type\Immobilizer\Type 1	All key lost,	220
SUBARU>Select from type\Smart key\Type C	Add smart key, Delete smart key, Register smart ECM Register	221
SUBARU>Select from type\Smart key\Type D(XV)	Reset PEPS, Add smart key, Delete smart key Detect key	275
SUBARU>Select from type\Immobilizer\Type 2(XV)	Add key, Delete key, Detect key count Register	276
SUBARU>Select from type\Remote\Type 1	Add remote, Clear remote,	280
SUBARU>Select from type\Immobilizer\Type 3	Add key, Read PIN code,	706

SUBARU

SUBARU>Select from type\Immobilizer\Type 4	Key count, Add key,	709
SUBARU>Select from type\Immobilizer\Type 5	Key count, Add key, Delete key, Add remote Delete remote	710
SUBARU>Select from type\Smart key\Type 3	Key count, Add key, Delete key, Add remote Delete remote	710
SUBARU>Select from type\Smart key\Type 4	Key count, Add key,	712
SUBARU>Select from type\Remote\Type 2	Add remote,	716
SUBARU>Select from type\Remote\Type 3	Add remote,	718
SUBARU>Select from type\Immobilizer\Type 6(4D 82G chin)	Check key count, Add key, All key lost, Delete key Register dashboard	789
SUBARU>Select from type\Smart key\Type 5	Add smart key, Delete smart key, Generate LKE,	801
SUBARU>Select from vehicle\B4\2009-	Add smart key, Delete smart key, Key count Read PIN	981
SUBARU>Select from vehicle\Baja\2005-2007	All key lost,	220
SUBARU>Select from vehicle\Brz\2013-\With smart	Add smart key, Delete smart key, Generate LKE,	801
SUBARU>Select from vehicle\Crosstrek\2014-\With smart	Add smart key, Delete smart key, Detect key count Register smart	275
SUBARU>Select from vehicle\Forester\2013 -\With smart	Add smart key, Delete smart key, Detect key count Register smart	275
SUBARU>Select from vehicle\Impreza\With smart\2013-	Add smart key, Delete smart key, Detect key count Register smart	275
SUBARU>Select from vehicle\Levorg\2015-\With smart	Add smart key, Delete smart key, Detect key count Register smart	275
SUBARU>Select from vehicle\Outback\Without smart\2005-2012	All key lost,	220
SUBARU>Select from vehicle\Tribeca\With smart(North America)	Add smart key, Delete smart key, Generate LKE,	801
SUBARU>Select from vehicle\XV\2013-\With smart	Add smart key, Delete smart key, Detect key count Register smart	275
SUBARU>Select from vehicle\XV Crosstrek\2013-\With smart	Add smart key, Delete smart key, Detect key count Register smart	275
SUBARU>Select from vehicle\WRX\2014-\With smart	Add smart key, Delete smart key, Detect key count Register smart	275
SUBARU>Select from vehicle\Liberty\2009-2013\With smart	Add smart key, Delete smart key, Key count Read PIN	981

	SUBARU>Select from vehicle\Forester\2017- With smart	Add smart key, Delete smart key, Detect key count Register smart	275
	SUBARU>Select from vehicle\Outback\With smart\2017-	Add smart key, Delete smart key, Detect key count Register smart	275
BESTURN	BESTURN\IMMO\New besturn (B50)\2015 -	All key lost,	1178
	BESTURN\IMMO\Old besturn (CAN)	Read key count, Add key, All key lost,	547
	BESTURN\IMMO\B30	All key lost,	548
	BESTURN\PEPS\B70	Program key, Program PEPS,	549
	BESTURN\PEPS\B90	Program key, Program PEPS,	549
	BESTURN\PEPS\X80	Program key, Program PEPS,	549
	BESTURN\Remote\New B70	Program remote,	550
	BESTURN\Remote\B90	Program remote,	550
	BESTURN\Remote\X80	Program remote,	550
	BESTURN\Remote\0ley	Auto, Manual,	551
	BESTURN\IMMO\New besturn (B50)\- 2015	Key clear, Clear fault code, Program key,	603
	BESTURN\IMMO\New besturn (B70)	Key clear, Clear fault code, Program key,	603
	BESTURN\IMMO\B70 (2013)	Key clear, Clear fault code, Program key,	603
	BESTURN\IMMO\X80 (2013)	Key clear, Clear fault code, Program key,	603
	BESTURN\IMMO\B90 (2013)	Key clear, Clear fault code, Program key,	603
	BESTURN\IMMO\0ley	Key clear, Clear fault code, Program key,	603
		ROEWE\Read PIN code\550\2013-	Read PIN code,
	ROEWE\Read PIN code\950\2012-	Read pin code type6 (via BCM),	1111
	ROEWE\IMMO\350\2013-	Add key, Delete key, Check lock time,	359

ROEWE

ROEWE\IMMO\360\Without smart	Add key, Delete key, Check lock time,	359
ROEWE\IMMO\W5\2013-	Add key, Delete key, Check lock time,	359
ROEWE\IMMO\550\2012	Delete key, Add key,	360
ROEWE\IMMO\RX5\With smart	Delete key, Add key, Read key count,	363
ROEWE\IMMO\RX5\Without smart	Delete key, Add key, Read key count,	364
ROEWE\Remote\360	Add remote, Delete remote,	365
ROEWE\Remote\750	Enable remote, Disable remote, Program remote, Clear fault	424
ROEWE\IMMO\ERX5\With smart	Delete key, Add key, Read key count,	363
ROEWE\IMMO\950\Without smart\Type 1	All key lost, Read key count, Clear fault code, Add key	362
ROEWE\IMMO\950\With smart	All smart key lost, Read smart key count, Clear fault code, Add smart	361
ROEWE\IMMO\350\2012	Add key, Delete key, Check lock time,	636
ROEWE\IMMO\W5\2012	Add key, Delete key, Check lock time,	636
ROEWE\IMMO\550\2013-	Add key, Delete key, The rest unlock time,	637
ROEWE\IMMO\i6\With smart	Delete key, Read key count, Add key,	638
ROEWE\Remote\W5	Program remote,	677
ROEWE\IMMO\360\With smart\2017	Add key, Delete key,	688
ROEWE\IMMO\950\Without smart\Type 2	All key lost, Add key, Read key count, Clear fault code	284
ROEWE\IMMO\750(new)\2012	Delete key, Add key,	360
ROEWE\IMMO\750(new)\2013-	Add key, Delete key, The rest unlock time,	637
ROEWE\IMMO\ERX5\Without smart	Delete key, Add key, Read key count,	364
ROEWE\IMMO\E50\2012	Add key, Delete key, Check lock time,	636



	ROEWE\IMMO\E50\2013-	Add key, Delete key, Check lock time,	359
MG	MG\IMMO\MG6\2018-	Add key, Delete key,	639
	MG\IMMO\GT	Add key, Delete key, Check lock time,	359
	MG\IMMO\MG3\2011-	Add key, Delete key, Check lock time,	359
	MG\IMMO\MG5\2013-	Add key, Delete key, Check lock time,	359
	MG\IMMO\MG7\2013-	Add key, Delete key, Check lock time,	359
	MG\IMMO\MG6\2012	Delete key, Add key,	360
	MG\Remote\MG7	Enable remote, Disable remote, Program remote, Clear fault	424
	MG\Remote\Old MG3	Add remote, Clear remote, Read VIN code, Read immo	519
	MG\IMMO\MG3\2011	Add key, Delete key, Check lock time,	636
	MG\IMMO\MG5\2012	Add key, Delete key, Check lock time,	636
	MG\IMMO\MG6\2013-	Add key, Delete key, The rest unlock time,	637
	MG\IMMO\GS\2016 \With smart	Add key, Delete key,	639
	MG\IMMO\GS\2016 \Without smart	Add key, Delete key,	640
	MG\IMMO\GS\2017\Without smart	Delete key, Add key, Read key count,	364
	MG\Remote\MG TF	Add remote, Clear remote, Read VIN code, Read immo	519
	MG\Read PIN code\MG6\2013-	Read PIN code,	921
	MG\Remote\MG7-L	Enable remote, Disable remote, Program remote, Clear fault	424
	MG\IMMO\ZS\Without smart	Add key, Delete key, Key number,	1007
	MG\IMMO\ZS\With smart	Add smart key, Clear smart key, Key number,	1008
		INFINITI\Select from vehicle\North America\IX35\2013\Proxi	Program smart key,

INFINITI\Select from vehicle\North America\M37\2011-	Read BCM inner code, Program smart key,	1654
INFINITI\Select from vehicle\North America\M56\2011-	Read BCM inner code, Program smart key,	1654
INFINITI\Select from vehicle\North America\Q50\2014-	Program smart key,	1673
INFINITI\Select from vehicle\North America\QX50\2014-	Program smart key,	1673
INFINITI\Select from vehicle\North America\QX56\2011-	Read BCM inner code, Program smart key,	1654
INFINITI\Select from vehicle\North America\QX60\2014-	Program smart key,	1673
INFINITI\Select from vehicle\North America\QX70\2014\Proxi	Read BCM inner code, Program smart key,	1654
INFINITI\Select from vehicle\North America\QX80\2014\Proxi	Read BCM inner code, Program smart key,	1654
INFINITI\Select from vehicle\South America\JX35\2013\Proxi	Program smart key,	1673
INFINITI\Select from vehicle\South America\M37\2011-	Read BCM inner code, Program smart key,	1654
INFINITI\Select from vehicle\South America\M56\2011-	Read BCM inner code, Program smart key,	1654
INFINITI\Select from vehicle\South America\Q50\2014-	Program smart key,	1673
INFINITI\Select from vehicle\South America\QX50\2014-	Program smart key,	1673
INFINITI\Select from vehicle\South America\QX56\2011-	Read BCM inner code, Program smart key,	1654
INFINITI\Select from vehicle\South America\QX60\2014-	Program smart key,	1673
INFINITI\Select from vehicle\South America\QX70\2014\Proxi	Read BCM inner code, Program smart key,	1654
INFINITI\Select from vehicle\Asia\G25\2011-2012\Smart_key\insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Asia\JX35\2013\Proximity smart	Program smart key,	1673
INFINITI\Select from vehicle\Asia\M37\2011-2013\Proximity smart	Read BCM inner code, Program smart key,	1654
INFINITI\Select from vehicle\Asia\M56\2011-2013\Proximity smart	Read BCM inner code, Program smart key,	1654
INFINITI\Select from vehicle\Asia\Q50\2014-2015\Proximity smart	Program smart key,	1673

INFINITI\Select from vehicle\Asia\QX50\2014-2015\Proximity smart	Program smart key,	1673
INFINITI\Select from vehicle\Asia\QX56\2011-2013\Proximity smart	Read BCM inner code,Program smart key,	1654
INFINITI\Select from vehicle\Asia\QX60\2014-2015\Proximity smart	Program smart key,	1673
INFINITI\Select from vehicle\Asia\QX70\2014\Smart key[insert_start]	Read BCM inner code,Program smart key,	1634
INFINITI\Select from vehicle\Asia\QX70\2014\Proximity smart	Read BCM inner code,Program smart key,	1654
INFINITI\Select from vehicle\Africa\JX35\2013\Proximity smart	Program smart key,	1673
INFINITI\Select from vehicle\Africa\M37\2011-2013\Proximity smart	Read BCM inner code,Program smart key,	1654
INFINITI\Select from vehicle\Africa\M56\2011-2013\Proximity smart	Read BCM inner code,Program smart key,	1654
INFINITI\Select from vehicle\Africa\Q50\2014-2015\Proximity smart	Program smart key,	1673
INFINITI\Select from vehicle\Africa\QX50\2014-2015\Proximity smart	Program smart key,	1673
INFINITI\Select from vehicle\Africa\QX56\2011-2013\Proximity smart	Read BCM inner code,Program smart key,	1654
INFINITI\Select from vehicle\Africa\QX60\2014-2015\Proximity smart	Program smart key,	1673
INFINITI\Select from vehicle\Africa\QX70\2014\Proximity smart	Read BCM inner code,Program smart key,	1654
INFINITI\Select from vehicle\Europe\JX35\2013\Proximity smart	Program smart key,	1673
INFINITI\Select from vehicle\Europe\M37\2011-2013\Proximity smart	Read BCM inner code,Program smart key,	1654
INFINITI\Select from vehicle\Europe\M56\2011-2013\Proximity smart	Read BCM inner code,Program smart key,	1654
INFINITI\Select from vehicle\Europe\Q50\2014-2015\Proximity smart	Program smart key,	1673
INFINITI\Select from vehicle\Europe\QX50\2014-2015\Proximity smart	Program smart key,	1673
INFINITI\Select from vehicle\Europe\QX56\2011-2013\Proximity smart	Read BCM inner code,Program smart key,	1654
INFINITI\Select from vehicle\Europe\QX60\2014-2015\Proximity smart	Program smart key,	1673
INFINITI\Select from vehicle\Europe\QX70\2014\Proximity smart	Read BCM inner code,Program smart key,	1654

INFINITI\Select from vehicle\Australia\JX35\2013\Proximity smart	Program smart key,	1673
INFINITI\Select from vehicle\Australia\M37\2011-2013\Proximity	Read BCM inner code,Program smart key,	1654
INFINITI\Select from vehicle\Australia\M56\2011-2013\Proximity	Read BCM inner code,Program smart key,	1654
INFINITI\Select from vehicle\Australia\Q50\2014-2015\Proximity	Program smart key,	1673
INFINITI\Select from vehicle\Australia\QX50\2014-2015\Proximity	Program smart key,	1673
INFINITI\Select from vehicle\Australia\QX56\2011-2013\Proximity	Read BCM inner code,Program smart key,	1654
INFINITI\Select from vehicle\Australia\QX60\2014-2015\Proximity	Program smart key,	1673
INFINITI\Select from vehicle\Australia\QX70\2014\Proximity smart	Read BCM inner code,Program smart key,	1654
INFINITI\Select from vehicle\Middle East\JX35\2013\Proximity	Program smart key,	1673
INFINITI\Select from vehicle\Middle East\M37\2011-	Read BCM inner code,Program smart key,	1654
INFINITI\Select from vehicle\Middle East\M56\2011-	Read BCM inner code,Program smart key,	1654
INFINITI\Select from vehicle\Middle East\Q50\2014-	Program smart key,	1673
INFINITI\Select from vehicle\Middle East\QX50\2014-	Program smart key,	1673
INFINITI\Select from vehicle\Middle East\QX56\2011-	Read BCM inner code,Program smart key,	1654
INFINITI\Select from vehicle\Middle East\QX60\2014-	Program smart key,	1673
INFINITI\Select from vehicle\Middle East\QX70\2014\Proximity	Read BCM inner code,Program smart key,	1654
INFINITI\Select from type\Smart key\New 20-bit rolling	Program smart key,	165
INFINITI\Select from type\Smart key\New 20-bit rolling	Program smart key,	165
INFINITI\Select from type\Smart key\New 20-bit rolling	Program smart key,	165
INFINITI\Select from type\Smart key\New 20-bit rolling code\Teana-	Program smart key,	165
INFINITI\Select from type\Smart key\New 20-bit rolling	Program smart key,	167

INFINITI\Select from type\Smart key\New 20-bit rolling code\X-	Program smart key,	167
INFINITI\Select from vehicle\North America\FX35\2008-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\North America\FX35\2003\Smart	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\North America\FX35\2004-	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\North America\FX35\2008-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\North America\FX37\2008-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\North America\FX45\2003\Smart	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\North America\FX45\2003\Smart	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\North America\FX50\2008-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\North America\G20\2000-	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\North America\G25\2011-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\North America\G35\2	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\North America\G35\2	Read BCM inner code, Program key, Delete remote Add remote	1625
INFINITI\Select from vehicle\North America\G35\2	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\North America\G35\2	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\North America\G35\4	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\North America\G35\4	Read BCM inner code, Program key, Delete remote Add remote	1625
INFINITI\Select from vehicle\North America\G35\4	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\North America\G35\4	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\North America\G37\2008-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\North America\M35\2009-	Read BCM inner code, Program smart key,	1634

INFINITI\Select from vehicle\North America\M45\2006-	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\North America\M45\2009-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\North America\QX56\2004-	Read BCM inner code, Program key, Delete remote Add remote	1625
INFINITI\Select from vehicle\North America\QX56\2008-	Read BCM inner code, Program key, Delete remote Add remote	1630
INFINITI\Select from vehicle\North America\QX70\2014\Smart	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\North America\I35\2000-	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\North America\M35\2006-	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\North America\M45\2003-	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\North America\QX4\2001-	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\North America\Q45\2002-	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\South America\FX35\2008-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\South America\FX35\2003\Smart	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\South America\FX35\2004-	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\South America\FX35\2008-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\South America\FX37\2008-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\South America\FX45\2003\Smart	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\South America\FX45\2003\Smart	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\South America\FX50\2008-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\South America\G20\2000-	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\South America\G25\2011-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\South America\G35\2	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594

INFINITI\Select from vehicle\South America\G35\2	Read BCM inner code, Program key, Delete remote Add remote	1625
INFINITI\Select from vehicle\South America\G35\2	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\South America\G35\4	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\South America\G35\4	Read BCM inner code, Program key, Delete remote Add remote	1625
INFINITI\Select from vehicle\South America\G35\4	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\South America\G37\2008-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\South America\I30\2000-	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\South America\I35\2000-	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\South America\M35\2006-	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\South America\M35\2009-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\South America\M45\2003-	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\South America\M45\2006-	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\South America\M45\2009-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\South America\QX4\2001-	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\South America\Q45\2002-	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\South America\QX56\2004-	Read BCM inner code, Program key, Delete remote Add remote	1625
INFINITI\Select from vehicle\South America\QX56\2008-	Read BCM inner code, Program key, Delete remote Add remote	1630
INFINITI\Select from vehicle\South America\QX70\2014\Smart	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Asia\EX35\2008-2012\Smart key[insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Asia\FX35\2003\Smart key(bar type)	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Asia\FX35\2004-2007\Smart key(knob	Read BCM inner code, Program key, Delete smart key Add smart	1627

INFINITI\Select from vehicle\Asia\FX35\2008-2012\Smart_key\insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Asia\FX37\2008-2012\Smart_key\insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Asia\FX45\2003\Smart_key(bar_type)	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Asia\FX45\2003\Smart_key(knob_type)	Read BCM inner code, Program key, Delete smart_key Add smart	1627
INFINITI\Select from vehicle\Asia\FX50\2008-2012\Smart_key\insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Asia\G20\2000-2003\Smart_key(bar)	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Asia\G35\2Doors\2003-2007\Bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Asia\G35\2Doors\2003-2007\Smart	Read BCM inner code, Program key, Delete remote Add remote	1625
INFINITI\Select from vehicle\Asia\G35\2Doors\2003-2007\Smart	Read BCM inner code, Program key, Delete smart_key Add smart	1627
INFINITI\Select from vehicle\Asia\G35\4Doors\2002-2006\Bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Asia\G35\4Doors\2002-2006\Smart	Read BCM inner code, Program key, Delete remote Add remote	1625
INFINITI\Select from vehicle\Asia\G35\4Doors\2002-2006\Smart	Read BCM inner code, Program key, Delete smart_key Add smart	1627
INFINITI\Select from vehicle\Asia\G37\2008-2013\Smart_key\insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Asia\I30\2000-2004\Smart_key(bar)	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Asia\I35\2000-2004\Smart_key(bar)	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Asia\M35\2006-2008\Smart_key\insert	Read BCM inner code, Program key, Delete smart_key Add smart	1627
INFINITI\Select from vehicle\Asia\M35\2009-2010\Smart_key\insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Asia\M45\2003-2004\Smart_key(bar)	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Asia\M45\2006-2008\Smart_key\insert	Read BCM inner code, Program key, Delete smart_key Add smart	1627
INFINITI\Select from vehicle\Asia\M45\2009-2010\Smart_key\insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Asia\QX4\2001-2003\Smart_key(bar)	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594

INFINITI



INFINITI\Select from vehicle\Asia\Q45\2002-2006\Smart key(bar	Program key, Clear fault code, Read BCM inner code, Add remote, Delete	1594
INFINITI\Select from vehicle\Asia\QX56\2004-2007\Smart key(bar	Read BCM inner code, Program key, Delete remote, Add remote	1625
INFINITI\Select from vehicle\Asia\QX56\2008-2010\Smart key(knob	Read BCM inner code, Program key, Delete remote, Add remote	1630
INFINITI\Read BCM code and release directional Lock(4-digit PIN)	Release steering lock, Read BCM inner code	785
INFINITI\PIN calculator	Type 1, Type 2, Type 3 (20-bit rolling code/PIN)	1675
INFINITI\Select from vehicle\Africa\EX35\2008-2012\Smart key[insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Africa\FX35\2003\Smart key(bar type)	Program key, Clear fault code, Read BCM inner code, Add remote, Delete	1594
INFINITI\Select from vehicle\Africa\FX35\2004-2007\Smart key(knob	Read BCM inner code, Program key, Delete smart key, Add smart	1627
INFINITI\Select from vehicle\Africa\FX35\2008-2012\Smart key[insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Africa\FX37\2008-2012\Smart key[insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Africa\FX45\2003\Smart key(bar type)	Program key, Clear fault code, Read BCM inner code, Add remote, Delete	1594
INFINITI\Select from vehicle\Africa\FX45\2003\Smart key(knob type)	Read BCM inner code, Program key, Delete smart key, Add smart	1627
INFINITI\Select from vehicle\Africa\FX50\2008-2012\Smart key[insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Africa\G20\2000-2003\Smart key(bar	Program key, Clear fault code, Read BCM inner code, Add remote, Delete	1594
INFINITI\Select from vehicle\Africa\G25\2011-2012\Smart key[insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Africa\G35\2 Doors\2003-2007\Bar	Program key, Clear fault code, Read BCM inner code, Add remote, Delete	1594
INFINITI\Select from vehicle\Africa\G35\2 Doors\2003-2007\Smart	Read BCM inner code, Program key, Delete remote, Add remote	1625
INFINITI\Select from vehicle\Africa\G35\2 Doors\2003-2007\Smart	Read BCM inner code, Program key, Delete smart key, Add smart	1627
INFINITI\Select from vehicle\Africa\G35\4 Doors\2002-2006\Bar	Program key, Clear fault code, Read BCM inner code, Add remote, Delete	1594
INFINITI\Select from vehicle\Africa\G35\4 Doors\2002-2006\Smart	Read BCM inner code, Program key, Delete remote, Add remote	1625
INFINITI\Select from vehicle\Africa\G35\4 Doors\2007-2008\Smart	Read BCM inner code, Program smart key,	1634

INFINITI\Select from vehicle\Africa\G35\4 Doors\2002-2006\Smart	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\Africa\G37\2008-2013\Smart key[insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Africa\I30\2000-2004\Smart key(bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Africa\I35\2000-2004\Smart key(bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Africa\M35\2006-2008\Smart key[insert	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\Africa\M35\2009-2010\Smart key[insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Africa\M45\2003-2004\Smart key(bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Africa\M45\2006-2008\Smart key[insert	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\Africa\M45\2009-2010\Smart key[insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Africa\QX4\2001-2003\Smart key(bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Africa\Q45\2002-2006\Smart key(bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Africa\QX56\2004-2007\Smart key(bar	Read BCM inner code, Program key, Delete remote Add remote	1625
INFINITI\Select from vehicle\Africa\QX56\2008-2010\Smart key(knob	Read BCM inner code, Program key, Delete remote Add remote	1630
INFINITI\Select from vehicle\Africa\QX70\2014\Smart key[insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Europe\EX35\2008-2012\Smart key[insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Europe\FX35\2003\Smart key(bar type)	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Europe\FX35\2004-2007\Smart key(knob	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\Europe\FX35\2008-2012\Smart key[insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Europe\FX37\2008-2012\Smart key[insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Europe\FX45\2003\Smart key(bar type)	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Europe\FX45\2003\Smart key(knob type)	Read BCM inner code, Program key, Delete smart key Add smart	1627

INFINITI\Select from vehicle\Europe\FX50\2008-2012\Smart_key[insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Europe\G20\2000-2003\Smart_key(bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Europe\G25\2011-2012\Smart_key[insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Europe\G35\2Doors\2003-2007\Bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Europe\G35\2Doors\2003-2007\Smart	Read BCM inner code, Program key, Delete remote Add remote	1625
INFINITI\Select from vehicle\Europe\G35\2Doors\2003-2007\Smart	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\Europe\G35\4Doors\2002-2006\Bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Europe\G35\4Doors\2002-2006\Smart	Read BCM inner code, Program key, Delete remote Add remote	1625
INFINITI\Select from vehicle\Europe\G35\4Doors\2007-2008\Smart	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Europe\G35\4Doors\2002-2006\Smart	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\Europe\G37\2008-2013\Smart_key[insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Europe\I30\2000-2004\Smart_key(bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Europe\I35\2000-2004\Smart_key(bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Europe\M35\2006-2008\Smart_key[insert	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\Europe\M35\2009-2010\Smart_key[insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Europe\M45\2003-2004\Smart_key(bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Europe\M45\2006-2008\Smart_key[insert	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\Europe\M45\2009-2010\Smart_key[insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Europe\QX4\2001-2003\Smart_key(bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Europe\Q45\2002-2006\Smart_key(bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Europe\QX56\2004-2007\Smart_key(bar	Read BCM inner code, Program key, Delete remote Add remote	1625

INFINITI\Select from vehicle\Europe\QX56\2008-2010\Smart key(knob	Read BCM inner code, Program key, Delete remote Add remote	1630
INFINITI\Select from vehicle\Europe\QX70\2014\Smart key[insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Australia\EX35\2008-2012\Smart	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Australia\FX35\2003\Smart key(bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Australia\FX35\2004-2007\Smart	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\Australia\FX35\2008-2012\Smart	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Australia\FX37\2008-2012\Smart	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Australia\FX45\2003\Smart key(bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Australia\FX45\2003\Smart key(knob	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\Australia\FX50\2008-2012\Smart	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Australia\G20\2000-2003\Smart key(bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Australia\G25\2011-2012\Smart	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Australia\G35\2003-2007\Bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Australia\G35\2003-2007\Smart	Read BCM inner code, Program key, Delete remote Add remote	1625
INFINITI\Select from vehicle\Australia\G35\2003-2007\Smart	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\Australia\G35\4Doors\2002-2006\Bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Australia\G35\4Doors\2002-2006\Smart	Read BCM inner code, Program key, Delete remote Add remote	1625
INFINITI\Select from vehicle\Australia\G35\4Doors\2007-2008\Smart	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Australia\G35\4Doors\2002-2006\Smart	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\Australia\G37\2008-2013\Smart	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Australia\I30\2000-2004\Smart key(bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594

INFINITI\Select from vehicle\Australia\I35\2000-2004\Smart_key(bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Australia\M35\2006-2008\Smart	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\Australia\M35\2009-2010\Smart	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Australia\M45\2003-2004\Smart_key(bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Australia\M45\2006-2008\Smart	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\Australia\M45\2009-2010\Smart	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Australia\QX4\2001-2003\Smart_key(bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Australia\Q45\2002-2006\Smart_key(bar	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Australia\QX56\2004-2007\Smart_key(bar	Read BCM inner code, Program key, Delete remote Add remote	1625
INFINITI\Select from vehicle\Australia\QX56\2008-2010\Smart	Read BCM inner code, Program key, Delete remote Add remote	1630
INFINITI\Select from vehicle\Australia\QX70\2014\Smart_key(insert	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Middle East\FX35\2008-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Middle East\FX35\2003\Smart	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Middle East\FX35\2004-	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\Middle East\FX35\2008-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Middle East\FX37\2008-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Middle East\FX45\2003\Smart	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Middle East\FX45\2003\Smart	Read BCM inner code, Program key, Delete smart key Add smart	1627
INFINITI\Select from vehicle\Middle East\FX50\2008-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Middle East\G20\2000-	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
INFINITI\Select from vehicle\Middle East\G25\2011-	Read BCM inner code, Program smart key,	1634

INFINITI\Select from vehicle\Middle East\G35\2 Doors\2003-	Program key, Clear fault code, Read BCM inner code, Add remote, Delete	1594
INFINITI\Select from vehicle\Middle East\G35\2 Doors\2003-	Read BCM inner code, Program key, Delete remote, Add remote	1625
INFINITI\Select from vehicle\Middle East\G35\2 Doors\2003-	Read BCM inner code, Program key, Delete smart key, Add smart	1627
INFINITI\Select from vehicle\Middle East\G35\4 Doors\2002-	Program key, Clear fault code, Read BCM inner code, Add remote, Delete	1594
INFINITI\Select from vehicle\Middle East\G35\4 Doors\2002-	Read BCM inner code, Program key, Delete remote, Add remote	1625
INFINITI\Select from vehicle\Middle East\G35\4 Doors\2007-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Middle East\G35\4 Doors\2002-	Read BCM inner code, Program key, Delete smart key, Add smart	1627
INFINITI\Select from vehicle\Middle East\G37\2008-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Middle East\I30\2000-	Program key, Clear fault code, Read BCM inner code, Add remote, Delete	1594
INFINITI\Select from vehicle\Middle East\I35\2000-	Program key, Clear fault code, Read BCM inner code, Add remote, Delete	1594
INFINITI\Select from vehicle\Middle East\M35\2006-	Read BCM inner code, Program key, Delete smart key, Add smart	1627
INFINITI\Select from vehicle\Middle East\M35\2009-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Middle East\M45\2003-	Program key, Clear fault code, Read BCM inner code, Add remote, Delete	1594
INFINITI\Select from vehicle\Middle East\M45\2006-	Read BCM inner code, Program key, Delete smart key, Add smart	1627
INFINITI\Select from vehicle\Middle East\M45\2009-	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Middle East\QX4\2001-	Program key, Clear fault code, Read BCM inner code, Add remote, Delete	1594
INFINITI\Select from vehicle\Middle East\Q45\2002-	Program key, Clear fault code, Read BCM inner code, Add remote, Delete	1594
INFINITI\Select from vehicle\Middle East\QX56\2004-	Read BCM inner code, Program key, Delete remote, Add remote	1625
INFINITI\Select from vehicle\Middle East\QX56\2008-	Read BCM inner code, Program key, Delete remote, Add remote	1630
INFINITI\Select from vehicle\Middle East\QX70\2014\Smart	Read BCM inner code, Program smart key,	1634
INFINITI\Select from vehicle\Europe\FX30D\2010-\Smart key\insert	Read BCM inner code, Program smart key,	1634

INFINITI\Select from type\Smart key\4-bit PIN\Without key slot-	Read BCM inner code, Release steering lock Program smart key	814
INFINITI\Select from type\Immobilizer\12-bit PIN-type 1(KWP)	Program key, Key count,	723
INFINITI\Select from type\Immobilizer\12-bit PIN-type 2(CAN)	Smart key, Key count,	720
INFINITI\Select from type\Smart key\12-bit PIN\All	Smart key, Key count,	720
INFINITI\Select from type\Smart key\4-bit PIN\Activate direction	Activate steering wheel lock,	219
INFINITI\Select from type\Immobilizer\Activate direction lock	Activate steering wheel lock,	219
INFINITI\Select from type\Immobilizer\New 20-bit rolling code	Add key,	174
INFINITI\Select from type\Smart key\4-bit PIN\Without key slot-	Program smart key,	160
INFINITI\Select from type\Smart key\4-bit PIN\With key slot-	Program smart key, Clear fault code,	159
INFINITI\Select from type\Smart key\4-bit PIN\With key slot-	Program smart key,	161
INFINITI\Select from type\Smart key\4-bit PIN\Without key slot-	Program smart key, Delete smart key,	162
INFINITI\Select from type\Smart key\New 20-bit rolling	Program smart key,	166
INFINITI\Select from type\Smart key\New 20-bit rolling	Program smart key,	165
INFINITI\Select from type\Smart key\4-bit PIN\Without key slot-	Program smart key, Delete smart key Program steering	164
INFINITI\Select from type\Remote\Type 1	Add remote, Delete remote,	158
INFINITI\Select from type\Immobilizer\Auto retrieve type	Add key,	157
INFINITI\Select from type\Immobilizer\Electronic key(12)	Add key, Add key(fixed code),	156
INFINITI\Select from type\Immobilizer\Electronic key(E0)	Program key,	150
INFINITI\Select from type\Immobilizer\Electronic key(10)	Add key, Activate steering wheel lock, Add key(fixed code)	149
INFINITI\Select from type\Remote\Type 2	Delete remote, Add remote,	1746
INFINITI\Select from type\Smart key\New 20-bit rolling code\QX50	Program smart key,	167

JAGUAR

JAGUAR\Select from vehicle\New Jaguar (2015-)\Smart	Add smart key,	1179
JAGUAR\Select from vehicle\New Jaguar (2015-)\Smart	Add smart key,	1180
JAGUAR\Select from vehicle\New Jaguar (2015-)\Smart	Write a workable key, Read key ID,	1196
JAGUAR\Select from vehicle\XF\2013-\Smart key	Add smart key, All smart key lost,	59
JAGUAR\Select from vehicle\XF\2012\Smart key	Add smart key, All smart key lost,	58
JAGUAR\Select from vehicle\XJ\Smart key	Add smart key, All smart key lost,	57
JAGUAR\Select from vehicle\F-type\Smart key	Add smart key, All smart key lost,	57
JAGUAR\Select from vehicle\S-Type\Immobilizer	All key lost,	74
JAGUAR\Select from vehicle\XF\2012\Smart key	Delete smart key, Add smart key,	175
JAGUAR\Select from vehicle\S-Type\Remote	Program remote, Delete remote,	73
JAGUAR\Select from vehicle\X-TYPE\Immobilizer	All key lost,	74
JAGUAR\Select from vehicle\SOVERIGN\Immobilizer	All key lost,	74
JAGUAR\Select from vehicle\XJ6\2003-2007\Immobilizer	All key lost,	74
JAGUAR\Select from vehicle\XJ8\2003-2007\Immobilizer	All key lost,	74
JAGUAR\Select from vehicle\XJR\2004-\Immobilizer	All key lost,	74
JAGUAR\Select from vehicle\XK\2006-2014\Smart remote	Program remote, Remote count,	1102
JAGUAR\Select from vehicle\XKR\2006-2014\Smart remote	Program remote, Remote count,	1102
JAGUAR\Select from type\Immobilizer\Type 1	All key lost,	74
JAGUAR\Select from type\Smart key\Type 1	Delete smart key, Add smart key,	175
JAGUAR\Select from type\Smart key\Type 2	Add smart key, All smart key lost,	58
JAGUAR\Select from type\Smart key\Type 3	Add smart key, All smart key lost,	59



	JAGUAR>Select from type\Smart key\Type 4	Add smart key,All smart key lost,	57
	JAGUAR>Select from type\Remote\Type 1	Program remote,Remote count,	1102
	JAGUAR>Select from type\Remote\Type 2	Program remote,Delete remote,	73
LAND ROVER	LAND ROVER>Select from vehicle\New LandRover (2015-)\Smart	Add smart key,	1179
	LAND ROVER>Select from vehicle\New LandRover (2015-)\Smart	Add smart key,	1180
	LAND ROVER>Select from vehicle\New LandRover (2015-)\Smart	Write a workable key,Read key ID,	1196
	LAND ROVER>Select from vehicle\Range Rover\Smart key\Smart	Add smart key,All smart key lost,	56
	LAND ROVER>Select from vehicle\Discovery 3\Immobilizer	Generate LKE,Program key,Read VIN code,	115
	LAND ROVER>Select from vehicle\Freelander 2\Smart key\2012	Program old smart key,Read VIN code Program new smart	116
	LAND ROVER>Select from vehicle\Freelander\Remote\2003-2005	Program remote,	114
	LAND ROVER>Select from vehicle\Discovery4\Smart key	Add smart key,All smart key lost,	56
	LAND ROVER>Select from vehicle\Evoque\Smart key	Add smart key,All smart key lost,	56
	LAND ROVER>Select from vehicle\Freelander 2\Smart key\2013-	Add smart key,All smart key lost,	56
	LAND ROVER>Select from vehicle\Range Rover\Immobilizer\Type	Generate LKE,Program key,Read VIN code,	115
	LAND ROVER>Select from vehicle\Range Rover\Immobilizer\Type	Program key,	1079
	LAND ROVER>Select from vehicle\Freelander 2\Immobilizer\2006-2012	Add old key,Add new key,Reset engine ECU,	1077
	LAND ROVER>Select from vehicle\Freelander\Smart key	Program old smart key,Read VIN code Program new smart	116
	LAND ROVER>Select from vehicle\Freelander\Remote	Program remote,	114
	LAND ROVER>Select from vehicle\Defender\Remote\2010-2014	Program remote,	114
	LAND ROVER>Select from type\Immobilizer\Type 1	Add old key,Add new key,Reset engine ECU,	1077
	LAND ROVER>Select from type\Immobilizer\Type 2	Generate LKE,Program key,Read VIN code,	115

	LAND ROVER>Select from type\Immobilizer\Type 3	Program key,	1079
	LAND ROVER>Select from type\Smart key\Type 1	Program old smart key, Read VIN code Program new smart	116
	LAND ROVER>Select from type\Smart key\Type 2	Add smart key, All smart key lost,	56
	LAND ROVER>Select from type\Remote\Type 1	Program remote,	114
	FIAT>Select from type\Immobilizer\Type 1	Program key,	1076
	FIAT>Select from type\Immobilizer\Type 2	Program key,	1082
	FIAT>Select from type\Immobilizer\Type 3	Program key,	1081
	FIAT>Select from type\Immobilizer\Type 4	Program key,	1120
	FIAT>Select from type\Immobilizer\Type 5	Key info, Program key,	930
	FIAT>Select from type\Immobilizer\Type 6	Key count, Program key, Delete key,	1083
	FIAT>Select from type\Immobilizer\Type 7	Key count, Program key, Delete key,	1084
	FIAT>Select from type\Immobilizer\Type 8	Key count, Program key, Remote count Program	928
	FIAT>Select from type\Immobilizer\Type 9	Program key, Delete key,	1085
	FIAT>Select from type\Immobilizer\Type 10	Program key, Delete key, Obtain immo ID,	1097
	FIAT>Select from type\Smart key\Type 1	Add smart key, Delete smart key, Read PIN code	1121
	FIAT>Select from type\Smart key\Type 2	Add smart key, Delete smart key, Read PIN code	1119
	FIAT\Asia\500	Key count, Program key, Read PIN code, Make dealer key(46	929
	FIAT\Asia\Linea	Key count, Program key, Remote count Program	928
	FIAT\Asia\Punto	Key count, Program key, Remote count Program	928
	FIAT\Asia\Viaggio\2013-	Key count, Program key, Read PIN code, Make dealer key(46	929
	FIAT\Europe\500X\2014-2018(334)	Add smart key, Delete smart key, Read PIN code	1119

FIAT\Europe\Freemont\Smart key	Add smart key, Delete smart key, Read PIN code	1121
FIAT\Europe\Palio (178)	Key count, Program key, Remote count Program	928
FIAT\Europe\Panda\2011-312)	Key count, Program key, Read PIN code, Make dealer key (46)	929
FIAT\Europe\Sedici\Petro1\2010	Key count, Program key, Delete key,	1084
FIAT\Europe\Viaggio\2012-	Key count, Program key, Read PIN code, Make dealer key (46)	929
FIAT\South America\500\2010-2012	Key count, Program key, Read PIN code, Make dealer key (46)	929
FIAT>Select from type\Immobilizer\Type 11	Key count, Program key, Read PIN code, Make dealer key (46)	929
FIAT\Europe\Sedici\Diesel\2010-	Program key,	1192
FIAT\Europe\500L\2012-(199)	Key info, Program key, Read PIN code, Make dealer key (46 chin)	931
FIAT\North America\UNO	Key count, Program key, Remote count Program	1912
FIAT\Europe\Talento\2016	Read PIN code, Recover backup data, Program key	1699
FIAT\Europe\500X\2018-2019 (334)	Add smart key, Delete smart key, Read PIN code	1119
FIAT\North America\500X\2014-2018 (334)	Add smart key, Delete smart key, Read PIN code	1119
FIAT\North America\500X\2018-2019 (334)	Add smart key, Delete smart key, Read PIN code	1119
FIAT\China\500X\2014-2018 (334)	Add smart key, Delete smart key, Read PIN code	1119
FIAT\China\500X\2018-2019 (334)	Add smart key, Delete smart key, Read PIN code	1119
FIAT\Europe\124\2017-	All smart key lost, Turn ignition ON, Add smart key	1694
FIAT\North America\124\2017	All smart key lost, Turn ignition ON, Add smart key	1694
FIAT\North America\124\2018-2019	All smart key lost, Turn ignition ON, Add smart key	1694
FIAT\North America\Spider\2017-2018	All smart key lost, Turn ignition ON, Add smart key	1694
FIAT\China\Viaggio\Fobik	Backup immo data, Make dealer key, Program key Key	536

FIAT

FIAT\China\Palio\Immobilizer	Backup immo data, Make dealer key (48 chip) Program	537
FIAT\China\Siena\Immobilizer	Backup immo data, Make dealer key (48 chip) Program	537
FIAT\China\Bravo\Immobilizer	Backup immo data, Program key, Make dealer key (46)	538
FIAT\China\Perla\Immobilizer	Backup immo data, Make dealer key (48 chip) Program	539
FIAT\China\Freemont\Smart key	Read PIN code, Add smart key, Delete smart key,	540
FIAT\China\Ottimo\Smart key	Program smart key, Read PIN code,	628
FIAT\China\Viaggio\Smart key	Program smart key, Read PIN code,	628
FIAT\China\Ottimo\Fobik	Backup immo data, Make dealer key, Program key Key	536
FIAT\Africa\Siena\2002-2008	Key count, Program key, Remote count Program	928
FIAT\Asia\Fiorino\2008-	Key count, Program key, Read PIN code, Make dealer key (46)	929
FIAT\Europe\500\2007-2016 (312)	Key count, Program key, Read PIN code, Make dealer key (46)	929
FIAT\Europe\Albea\2002-(172)	Key count, Program key, Remote count Program	928
FIAT\Europe\Bravo\2007 (198)	Key count, Program key, Remote count Program	928
FIAT\Europe\Croma\2005-2007 (194)	Key info, Program key,	930
FIAT\Europe\Doblo\2009-(263)	Key count, Program key, Read PIN code, Make dealer key (46)	929
FIAT\Europe\Ducato\2006-2012 (250)	Key count, Program key, Remote count Program	928
FIAT\Europe\Ducato\2012-(250)	Key info, Program key, Read PIN code, Make dealer key (46 chip)	931
FIAT\Europe\Fiorino\2008-(225)	Key count, Program key, Read PIN code, Make dealer key (46)	929
FIAT\South America\Punto\2008-2014	Key count, Program key, Remote count Program	928
FIAT\South America\Stilo\2002-2006	Key count, Program key, Remote count Program	928
FIAT\South America\Doblo\2000-	Key count, Program key, Remote count Program	928

FIAT\South America\Fiorino\2014-2015	Read PIN code, Backup EEPROM, Recover EEPROM, Backup	928
FIAT\South America\Idea\2004-2012	Key count, Program key, Remote count Program	928
FIAT\South America\Linea\2004-2012	Key count, Program key, Remote count Program	928
FIAT\South America\Palio\2000-2003	Key count, Program key, Remote count Program	928
FIAT\South America\Palio\2004-2012	Key count, Program key, Remote count Program	928
FIAT\Asia\Grande Punto\2006-2011	Key count, Program key, Read PIN code, Make dealer key(46	929
FIAT\Europe\Idea\2003-2012 (135)	Key count, Program key, Remote count Program	928
FIAT\Europe\Linea\2007-(323)	Key count, Program key, Remote count Program	928
FIAT\Europe\Panda\2005-2011 (169)	Key count, Program key, Remote count Program	928
FIAT\Europe\Punto\2000-2006 (188)	Key count, Program key, Remote count Program	928
FIAT\Europe\Punto\2006-2011 (199)	Key count, Program key, Read PIN code, Make dealer key(46	929
FIAT\Europe\Qubo\2008-(300)	Key count, Program key, Read PIN code, Make dealer key(46	929
FIAT\Europe\Scudo\2007 (220) \Type 1	Program key,	1076
FIAT\Europe\Scudo\2007 (220) \Type 2	Program key,	1082
FIAT\Europe\Scudo\2007 (220) \Type 3	Program key,	1081
FIAT\Europe\Scudo\2008-(270)	Program key,	1120
FIAT\Europe\Stilo\2000-2006 (192)	Key count, Program key, Remote count Program	928
FIAT\Europe\Ulysee\2002-2010 (179)	Program key,	1120
FIAT\Middle East\500\2007-	Key count, Program key, Read PIN code, Make dealer key(46	929
FIAT\Middle East\Doblo\2009	Key count, Program key, Remote count Program	928
FIAT\South America\Bravo\2007-	Key count, Program key, Remote count Program	928

FIAT\South America\Siena\2008-2012	Key count, Program key, Remote count Program	928
FIAT\South America\Strada\2000-2003	Key count, Program key, Remote count Program	928
FIAT\Europe\Sedici\Diesel\2006-2010	Add new key, Add old key, Delete key,	1191
FIAT\Europe\Phedra\2005-	Program key,	1194
FIAT\Europe\Ulysse\2002-2005 (179)	Program key,	1195
FIAT\Europe\Ulysse\2005-2010 (179)	Program key,	1194
FIAT\Europe\Doblo\2005-2009 (223)	Program key, Key count, Program remote Remote	1713
FIAT\China\Linea\Immobilizer	Backup immo data, Program key, Make dealer key (46	538
CADILLAC\China\XTS\2018\Smart key	All smart key lost, Add smart key, Read smart key count Clear fault	282
CADILLAC\China\ATS\2017-\Smart key	All smart key lost, Add smart key, Read smart key count Clear fault	282
CADILLAC\China\XT4\2018-\Smart key	All smart key lost, Add smart key, Read smart key count Clear fault	282
CADILLAC\China\Escalade\2018-\Smart key	All smart key lost, Add smart key, Read smart key count Clear fault	282
CADILLAC\China\ATS\Mechanical key	All key lost, Add key, Read key count Clear fault code	284
CADILLAC\China\ATSL\2015-2017\Mechanical key	All key lost, Add key, Read key count Clear fault code	284
CADILLAC\China\SRX\2010-2014\Mechanical key	All key lost, Add key, Read key count Clear fault code	284
CADILLAC\China\SRX\2015-\Mechanical key	All key lost, Add key, Read key count Clear fault code	284
CADILLAC\China\XTS\2015-\Mechanical key	All key lost, Add key, Read key count Clear fault code	284
CADILLAC\China\ATS\2016\Smart key	All smart key lost, Add smart key, Read key count Clear fault code	285
CADILLAC\China\ATSL\2015-2017\Smart key\Type 1	All smart key lost, Add smart key, Read key count Clear fault code	285
CADILLAC\China\SRX\2010-2014\Smart key\Type 1	All smart key lost, Add smart key, Read key count Clear fault code	285
CADILLAC\China\SRX\2015-\Smart key	All smart key lost, Add smart key, Read key count Clear fault code	285

CADILLAC

CADILLAC\China\CT6\2016 \Smart key	Add smart key,All smart key lost,Read smart key count	295
CADILLAC\China\CTS\2013 -\Smart key	Add smart key,All smart key lost,Read smart key count	295
CADILLAC\China\Escalade \-2017\Smart key	Add smart key,All smart key lost,Read smart key count	295
CADILLAC\China\CT6\2017 \Smart key	All smart key lost,Add smart key,Read smart key count Clear fault	282
CADILLAC\China\XT5\2017 \Smart key	All smart key lost,Add smart key,Read smart key count Clear fault	282
CADILLAC\China\CTS\2008 -2012\One- click\Mechanical key	Lost all key,	297
CADILLAC\China\DTS\2006 -2013\Mechanical key	Lost all key,	297
CADILLAC\China\Escalade \-2017\Mechanical key	Lost all key,	297
CADILLAC\China\SRX\2004 -2009\Mechanical key	Lost all key,	297
CADILLAC\China\SLS\2005 -2009\Mechanical key	All key lost,	318
CADILLAC\China\SLS\2013 \Mechanical key	All key lost,	318
CADILLAC\China\SLS\2009 -\Mechanical key	All key lost,	319
CADILLAC\China\Escalade \-2017\Remote	Program remote,Delete remote,	332
CADILLAC\China\CTS\Remo te	Program remote,	337
CADILLAC\China\Read PIN code	Read pin code type1,Read pin code type2 Read pin code	370
CADILLAC\China\CTS\2003 -2007\Mechanical key	All key lost,	617
CADILLAC\China\CTS\2008 -2012\Knob type\Smart key	All key lost,	321
CADILLAC\China\ATSL\201 7-\Smart key	All smart key lost,Add smart key,Read smart key count Clear fault	282
CADILLAC\China\XTS\2016 -\Smart key	Add smart key,All smart key lost,Read smart key count	295
CADILLAC\China\XTS\-\ 2015\Smart key	Add smart key,All smart key lost,Read smart key count	295
CADILLAC\China\SRX\2010 -2014\Smart key\Type 2	Add smart key,All smart key lost,Read smart key count	295

CADILLAC\China\ATSL\2015-2017\Smart key\Type 2	Add smart key, All smart key lost, Read smart key count	295
CADILLAC\China\Catera\1997-2002\Mechanical key	Clear fault code, Program key, Delete key	614
CADILLAC\China\CTS\2008-2013 (Prox)\Mechanical key	All key lost,	1353
CADILLAC\China\Deville\ -2003\Mechanical key	All key lost,	617
CADILLAC\China\Deville STS\Mechanical key	All key lost,	617
CADILLAC\China\STS\2007-2012\Mechanical key	All key lost,	319
CADILLAC\China\XLR\2004-2009\Mechanical key	All key lost,	1353
CADILLAC\China\XT6\Smart key	All smart key lost, Add smart key, Read smart key count Clear fault	282
OPEL\Remote\Antara	Program remote, Delete remote,	941
OPEL\IMMO>Select from vehicle\Antara\2010-2013\Flip key	All key lost,	940
OPEL\IMMO>Select from vehicle\Omega-B\Immobilizer\Type	All key lost, Add key, Read key count Clear fault	621
OPEL\IMMO>Select from vehicle\Omega-B\Smart key	Add smart key, All smart key lost, Read smart key count	1002
OPEL\IMMO>Select from type\Type 6	All key lost,	1032
OPEL\IMMO>Select from vehicle\Astra\Astra-T\2010-2016\Smart key	All smart key lost, Add smart key, Read key count Clear fault	620
OPEL\IMMO>Select from vehicle\Astra\Astra-T\2010-2016\Immobilizer	All key lost, Add key, Read key count Clear fault	621
OPEL\IMMO>Select from vehicle\Zafira\Zafira-C\2012-2016\Smart key	All smart key lost, Add smart key, Read key count Clear fault	620
OPEL\IMMO>Select from vehicle\Zafira\Zafira-C\2012-2016\Immobilizer	All key lost, Add key, Read key count Clear fault	621
OPEL\IMMO>Select from vehicle\Meriva\Meriva-B\Immobilizer	Add key, Delete key, Read PIN code,	1199
OPEL\IMMO>Select from vehicle\Corsa\Corsa-D\Immobilizer	Add key, Delete key, Read PIN code,	1200
OPEL\IMMO>Select from vehicle\Mokka\2012-2018\Smart key	All smart key lost, Add smart key, Read key count Clear fault	620
OPEL\IMMO>Select from vehicle\Mokka\2012-2018\Immobilizer	All key lost, Add key, Read key count Clear fault	621



OPEL

OPEL\Remote\Meriva	Program remote, Delete remote,	1201
OPEL\IMMO>Select from vehicle\Vivaro\2014-\System 1	Read PIN code, Program key, Recover backup data	1197
OPEL\Remote\Corsa\Corsa-C	Program remote, Delete remote,	1201
OPEL\IMMO>Select from vehicle\Vivaro\2014-\System 2	Program key,	1695
OPEL\Read PIN code	Switch ignition on, Read pin code type1, Read pin code type2(via	619
OPEL\IMMO>Select from type\Type 1\Smart key	All smart key lost, Add smart key, Read key count Clear fault	620
OPEL\IMMO>Select from vehicle\Insignia\2009-2016\Smart key	All smart key lost, Add smart key, Read key count Clear fault	620
OPEL\IMMO>Select from type\Type 1\Immobilizer	All key lost, Add key, Read key count Clear fault	621
OPEL\IMMO>Select from vehicle\Insignia\2009-2016\Immobilizer	All key lost, Add key, Read key count Clear fault	621
OPEL\IMMO>Select from type\Type 2	Clear fault code, Program key, Delete key Program immo	622
OPEL\IMMO>Select from vehicle\Agila	Clear fault code, Program key, Delete key Program immo	622
OPEL\IMMO>Select from vehicle\Astra\Astra-G	Clear fault code, Program key, Delete key Program immo	622
OPEL\IMMO>Select from vehicle\Calibra	Clear fault code, Program key, Delete key Program immo	622
OPEL\IMMO>Select from vehicle\Combo\1998-	Clear fault code, Program key, Delete key Program immo	622
OPEL\IMMO>Select from vehicle\Corsa\Corsa-B	Clear fault code, Program key, Delete key Program immo	622
OPEL\IMMO>Select from vehicle\Corsa\Corsa-C	Clear fault code, Program key, Delete key Program immo	622
OPEL\IMMO>Select from vehicle\Meriva\Meriva	Clear fault code, Program key, Delete key Program immo	622
OPEL\IMMO>Select from vehicle\Movano\1998-2001	Clear fault code, Program key, Delete key Program immo	622
OPEL\IMMO>Select from vehicle\Omega-B\Immobilizer\Type	Clear fault code, Program key, Delete key Program immo	622
OPEL\IMMO>Select from vehicle\Sintra	Clear fault code, Program key, Delete key Program immo	622
OPEL\IMMO>Select from vehicle\Tigra-B	Clear fault code, Program key, Delete key Program immo	622

OPEL\IMMO>Select from vehicle\Vectra-B	Clear fault code, Program key, Delete key, Program immo	622
OPEL\IMMO>Select from type\Type 3	Program key, Delete key,	623
OPEL\IMMO>Select from vehicle\Astra\Astra-H\Immobilizer	Program key, Delete key, Read PIN code, Read PIN code(type 6)	1212
OPEL\IMMO>Select from type\Type 4	Read key count, Program key,	624
OPEL\IMMO>Select from vehicle\Agila B\2009	Read key count, Program key,	624
OPEL\IMMO>Select from type\Type 5	Read key count, Program key,	625
OPEL\IMMO>Select from vehicle\Agila B\2009-	Read key count, Program key,	625
OPEL\Remote\Astra-H	Delete remote, Program remote,	626
OPEL\Remote\Zafira-B	Delete remote, Program remote,	626
OPEL\Remote\Vectra-C/Signum	Delete remote, Program remote,	626
OPEL\Remote\Corsa\Corsa-D	Delete remote, Program remote,	627
OPEL\IMMO>Select from vehicle\Astra\Astra-H\Smart key\Program key	Program key, Delete key, Key count,	890
OPEL\IMMO>Select from vehicle\Astra\Astra-H\Smart key\All key	All key lost,	891
OPEL\IMMO>Select from vehicle\Astra\Astra\2007\Smart key	Learn smart key, Delete all smart keys,	897
OPEL\Remote\Astra\07	Program remote, Delete remote,	898
OPEL\IMMO>Select from vehicle\Signum\2003-2007	Program key, Delete key, Read PIN code (ECU), Read PIN	1211
OPEL\IMMO>Select from vehicle\Antara\2006-2009\Bar key	All key lost,	1538
OPEL\IMMO>Select from vehicle\Zafira\Zafira-A\1995-2006\Immobilizer	Clear fault code, Program key, Delete key, Program immo	622
OPEL\IMMO>Select from vehicle\Astra\Astra-K\Immobilizer	All key lost, Add key, Read key count, Clear fault	621
OPEL\IMMO>Select from vehicle\Astra\Astra-K\Smart key	All smart key lost, Add smart key, Read key count, Clear fault	620
OPEL\IMMO>Select from vehicle\Astra\Astra-F\1995-2004\Immobilizer	Clear fault code, Program key, Delete key, Program immo	622

	OPEL\IMMO>Select from vehicle\Astra\Astra\1995-2004\Immobilizer	Clear fault code, Program key, Delete key Program immo	622
	OPEL\IMMO>Select from vehicle\Zafira\Zafira-B\Mechanical key (2005-	Program key, Delete key, Read PIN code (ECU) Read PIN	1211
	VW\IMMO4>Select IMMO manually\NEC24C64 (2014-)\Immobilizer	Make dealer key, Learn key (OBD), Backup EEPROM Recover	1130
	VW\IMMO4>Select IMMO manually\MQB-35XX (Mainland/VDO)\Immo	Backup EEPROM, Recover EEPROM, Backup immo data Recover immo	1064
	VW\IMMO4>Select IMMO manually\NEC 24C32\Immobilizer	Backup EEPROM, Recover EEPROM, Read immo data Make dealer	13
	VW\IMMO4>Select IMMO manually\NEC 95320\Immobilizer	Backup EEPROM, Recover EEPROM, Read immo data Make dealer	11
	VW\IMMO4>Select IMMO manually\NEC 24C64 (2013)\Immobilizer	Backup EEPROM, Recover EEPROM, Read immo data Make dealer	45
	VW\IMMO5\Immobilizer/Smart key	Backup immo data, Make dealer key, Learn key Clear airbag fault	48
	VW\IMMO4>Select IMMO manually\NEC 24C64\Immobilizer	Backup EEPROM, Recover EEPROM, Read immo data Make dealer	51
	VW\IMMO4>Select IMMO manually\NEC+24C64 color	Backup EEPROM, Recover EEPROM, Read immo data Make dealer	54
	VW\IMMO4>Select IMMO manually\9S12XHZ512\Immobilizer	Backup EEPROM, Recover EEPROM, Read immo data Make dealer	60
	VW\ Touareg\2003-2007\Immobilizer	Read PIN code, Learn key,	68
	VW\Phaeton\2008-\Immobilizer	Learn key, Read PIN code,	71
	VW\IMMO4>Select IMMO manually\CDC+24C32\Immobilizer	Read immo data, Make dealer key, Directly add key Delete key Learn Immo	66
	VW\IMMO2 & IMMO3 \Immobilizer	box, Dashboard, Jetta (2010)	143
	VW\Remote\Polo/Jetta (2015)\Remote	Program remote,	171
	VW\IMMO4\Auto identify IMMO	Identify immo4 type,	176
	VW\Remote \Remote	Add remote, Delete remote,	43
	VW\ Touareg\2008-2011\Immobilizer	Learn key, Read PIN code,	71
	VW\Phaeton\2003-2007\Immobilizer	Read PIN code, Learn key,	68
	VW\IMMO4>Select IMMO manually\NEC+24C64 color	Backup EEPROM, Recover EEPROM, Read immo data Make dealer	210

VW

VW\Remote \Central door lock (1281)	Add remote, Delete remote,	292
VW\Remote \Central module (1281)	Add remote, Delete remote,	291
VW\IMMO4\Select IMMO manually\NEC35XX\Immobilizer	Backup EEPROM, Recover EEPROM, Read immo data Make dealer	647
VW\IMMO4\Select IMMO manually\NEC95320 (Bora Jetta)\Immobilizer	Backup EEPROM, Recover EEPROM, Backup immo data Restore immo	971
VW\IMMO4\Select IMMO manually\Magotan/CC\Immobilizer	Make dealer key, Learn key, Unlock 46 chip key,	851
VW\IMMO4\Select IMMO manually\Engineering mode (4th Gen)	Obtain data, Obtain data (MQB), Make dealer key Add key	1080
VW\IMMO3.5\Immobilizer	Immobiliser, Dashboard,	1182
VW\IMMO3.5\Remote	Add remote, Delete remote,	43
VW\IMMO2 & IMMO3\Read PIN code (OBD)\Read PIN manually	Dashboard, IMMO, Engine, Touareg 3.0 diesel,	1294
VW\IMMO3.5\Read PIN code (OBD)\Read PIN manually	Dashboard, IMMO, Engine, Touareg 3.0 diesel,	1294
VW\IMMO2 & IMMO3\Read PIN code (OBD)\Read PIN automatically	Read PIN code,	1574
VW\IMMO4\Select IMMO manually\A3/TT/R8-CDC32XX+24C32\Immobilizer	Backup EEPROM, Recover EEPROM, Backup immo data Restore immo	974
VW\IMMO4\Select IMMO manually\2013 (Q3) NEC+24C64\Immobilizer	Backup EEPROM, Recover EEPROM, Make dealer key Learn	1129
VW\IMMO4\Select IMMO manually\NEC95320 (JCI)\Immobilizer	Backup EEPROM, Recover EEPROM, Backup immo data Recover immo	1732
VW\IMMO4\Select IMMO manually\Magotan/CC\Remote	Add remote, Delete remote,	43
VW\IMMO3.5\Read PIN code (OBD)\Read PIN automatically	Read PIN code,	1574
VW\IMMO2 & IMMO3\Read PIN code (EEPROM)\Immobox\24	Read PIN code,	1905
VW\IMMO2 & IMMO3\Read PIN code (EEPROM)\Immobox\93	Read pin code type1, Read pin code type2	1906
VW\IMMO2 & IMMO3\Read PIN code (EEPROM)\Dashboard\	Read pin code type1, Read pin code type2 Read pin code	1907
VW\IMMO2 & IMMO3\Read PIN code (EEPROM)\Engine\950	Read PIN code,	1908
VW\IMMO2 & IMMO3\Read PIN code (EEPROM)\Engine\950	Read PIN code,	1909

	VW\IMMO2 & IMMO3\Read PIN code(EEPROM)\Engine\951	Read PIN code,	1910
	VW\IMMO2 & IMMO3\Read PIN code(EEPROM)\Engine\951	Read PIN code,	1911
SKODA	SKODA\IMMO4>Select IMMO manually\NEC24C64 (2014-)\Immobilizer	Make dealer key, Learn key (OBD), Backup EEPROM Recover	1130
	SKODA\IMMO4>Select IMMO manually\MQB-35XX (Mainland/VDO)\Immobilizer	Backup EEPROM, Recover EEPROM, Backup immo data Recover immo	1064
	SKODA\IMMO4>Select IMMO manually\NEC 24C32\Immobilizer	Backup EEPROM, Recover EEPROM, Read immo data Make dealer	13
	SKODA\IMMO4>Select IMMO manually\NEC 95320\Immobilizer	Backup EEPROM, Recover EEPROM, Read immo data Make dealer	11
	SKODA\IMMO4>Select IMMO manually\NEC 24C64 (2013)\Immobilizer	Backup EEPROM, Recover EEPROM, Read immo data Make dealer	45
	SKODA\IMMO 5\Smart key	Backup immo data, Make dealer key, Learn key Clear airbag fault	48
	SKODA\IMMO4>Select IMMO manually\NEC 24C64\Immobilizer	Backup EEPROM, Recover EEPROM, Read immo data Make dealer	51
	SKODA\IMMO4>Select IMMO manually\NEC+24C64 color	Backup EEPROM, Recover EEPROM, Read immo data Make dealer	54
	SKODA\IMMO4>Select IMMO manually\9S12XHZ512\Immobilizer	Backup EEPROM, Recover EEPROM, Read immo data Make dealer	60
	SKODA\IMMO4>Select IMMO manually\CDC+24C32\Immobilizer	Read immo data, Make dealer key, Directly add key Delete key Learn Immo	66
	SKODA\IMMO2 & IMMO3\Immobilizer	box, Dashboard, Jetta (2010)	143
	SKODA\Remote\Polo (2015)\Remote	Program remote,	171
	SKODA\IMMO4\Auto identify IMMO	Identify immo4 type,	176
	SKODA\Remote\Remote	Add remote, Delete remote,	43
	SKODA\IMMO4>Select IMMO manually\NEC+24C64 color	Backup EEPROM, Recover EEPROM, Read immo data Make dealer	210
	SKODA\Remote\Central door lock (1281)	Add remote, Delete remote,	292
	SKODA\Remote\Central module (1281)	Add remote, Delete remote,	291
SKODA\IMMO4>Select IMMO manually\NEC35XX\Immobilizer	Backup EEPROM, Recover EEPROM, Read immo data Make dealer	647	
SKODA\IMMO4>Select IMMO manually\NEC95320 (Bora Jetta)\Immobilizer	Backup EEPROM, Recover EEPROM, Backup immo data Restore immo	971	

SKODA\IMMO4>Select IMMO manually\Magotan/CC\Immobilizer	Make dealer key, Learn key, Unlock 46 chip key,	851
SKODA\IMMO4>Select IMMO manually\Engineering mode(4th Gen)	Obtain data, Obtain data (MQB), Make dealer key Add key	1080
SKODA\IMMO 3.5\Immobilizer	Immobiliser, Dashboard,	1182
SKODA\IMMO 3.5\Remote	Add remote, Delete remote,	43
SKODA\IMMO3.5\Read PIN code	Dashboard, IMMO, Engine, Touareg 3.0 diesel,	1294
SKODA\IMMO2 & IMMO3\Read PIN code	Dashboard, IMMO, Engine, Touareg 3.0 diesel,	1294
CHEVROLET\China\Cruze\2017-\Smart key	All smart key lost, Add smart key, Read smart key count Clear fault	282
CHEVROLET\China\Cruze\2014-2016\Smart key	Add smart key, All smart key lost, Read smart key count	295
CHEVROLET\China\Cruze\2014-2016\Immobilizer	All key lost, Add key, Read key count Clear fault code	284
CHEVROLET\China\Camaro\2014-2015\Immobilizer	All key lost, Add key, Read key count Clear fault code	284
CHEVROLET\China\Camaro\2014-2015\Smart key	Add smart key, All smart key lost, Read smart key count	295
CHEVROLET\China\Equinox\2017-\Smart key	All smart key lost, Add smart key, Read smart key count Clear fault	282
CHEVROLET\China\Monza\2019-\Immobilizer	Read key count, All key lost, Add key,	649
CHEVROLET\China\Orlando\2018-\With smart	Add smart key, All smart key lost, Read key count	1696
CHEVROLET\China\Trailblazer\2019-\Smart key	All smart key lost, Add smart key, Read smart key count Clear fault	282
CHEVROLET\China\Spark\2013-2014\Smart key	All smart key lost, Add smart key, Read key count Clear fault code	285
CHEVROLET\China\Spark\2013-2014\Immobilizer	All key lost, Add key, Read key count Clear fault code	284
CHEVROLET\China\Corvette\2017-\Smart key	All smart key lost, Add smart key, Read smart key count Clear fault	282
CHEVROLET\China\Corvette\2014-2015\Smart key	All smart key lost, Add smart key, Read key count Clear fault code	285
CHEVROLET\China\Corvette\2014-2015\Immobilizer	All key lost, Add key, Read key count Clear fault code	284
CHEVROLET\China\Cruze\2013\Immobilizer	All key lost, Add key, Read key count Clear fault code	284

CHEVROLET

CHEVROLET\China\Malibu\ -2015\Immobilizer	All key lost, Add key, Read key count Clear fault code	284
CHEVROLET\China\Trax\Im mobilizer	All key lost, Add key, Read key count Clear fault code	284
CHEVROLET\China\Aveo\Ty pe 2\Smart key	All smart key lost, Add smart key, Read key count Clear fault code	285
CHEVROLET\China\Cruze\ -2013\Smart key	All smart key lost, Add smart key, Read key count Clear fault code	285
CHEVROLET\China\Malibu\ -2015\Smart key	All smart key lost, Add smart key, Read key count Clear fault code	285
CHEVROLET\China\Trax\Sm art key	All smart key lost, Add smart key, Read key count Clear fault code	285
CHEVROLET\China\Malibu\ 2016-\Smart key	Add smart key, All smart key lost, Read smart key count	295
CHEVROLET\China\Lova\20 16\Immobilizer	All key lost, Add key,	256
CHEVROLET\China\Lova\20 16\Smart key	All smart key lost, Add smart key,	257
CHEVROLET\China\Epica\2 013-\Immobilizer	Program key, Delete key, Read key count,	279
CHEVROLET\China\Captiva \IMMO\Without smart\Type 2	Lost all key,	297
CHEVROLET\China\Captiva \IMMO\Without smart\Type 1	Program key,	320
CHEVROLET\China\Aveo\Ty pe 1\Immobilizer	Program key, Switch neutral mode,	322
CHEVROLET\China\Lova\ -2015\Immobilizer	Program key, Switch neutral mode,	322
CHEVROLET\China\Epica\ -2012\Immobilizer	All key lost, Read PIN code for Epica(-2009),	324
CHEVROLET\China\Lova\ -2015\Remote	Program remote,	328
CHEVROLET\China\Sail\Re mote	Program remote, Read key count,	329
CHEVROLET\China\Epica\2 013-\Remote	Program remote, Read remote count,	331
CHEVROLET\China\Captiva \Remote\Type 1	Program remote, Delete remote,	332
CHEVROLET\China\Captiva \Remote\Type 2	Program remote, Delete remote,	333
CHEVROLET\China\Malibu\ 2007-2011\Remote	Program remote, Delete remote,	333

CHEVROLET\China\Sail 3\Remote	Program remote, Read remote count,	330
CHEVROLET\China\Lumina\ 2006-2011\Immobilizer	Program key,	320
CHEVROLET\China\Read PIN code	Read pin code type1, Read pin code type2 Read pin code	370
CHEVROLET\China\Lova\20 16\Remote	Program remote, Read remote count,	521
CHEVROLET\China\Sail\IM MO	Clear fault code, Program key, Delete key	614
CHEVROLET\China\Captiva \IMMO\With smart\Smart key	All key lost,	321
CHEVROLET\China\Cavalie r\Immobilizer	Read key count, All key lost, Add key,	649
CHEVROLET\China\Camaro\ -2013\Immobilizer	All key lost, Add key, Read key count Clear fault code	284
CHEVROLET\China\Camaro\ -2013\Smart key	All smart key lost, Add smart key, Read key count Clear fault code	285
CHEVROLET\China\Camaro\ 2016-\Smart key	All smart key lost, Add smart key, Read smart key count Clear fault	282
CHEVROLET\China\Malibu XL\2016\Immobilizer	All key lost, Add key, Read key count Clear fault code	284
CHEVROLET\China\Malibu XL\2016\Smart key	All smart key lost, Add smart key, Read key count Clear fault code	285
CHEVROLET\China\Malibu XL\2017\Smart key	All smart key lost, Add smart key, Read smart key count Clear fault	282
CHEVROLET\China\Aveo (ol d)\Immobilizer	Program key, Switch neutral mode,	322
CHEVROLET\China\Zafira\ 99-	Program key, Delete key,	842
CHEVROLET\China\Colorad o\IMMO\Without smart	All key lost, Clear fault code, Read key count Add key	422
CHEVROLET\China\Colorad o\IMMO\With smart	All key lost, Add key, Read key count Clear fault code	857
CHEVROLET\China\Aveo\Ty pe 2\Immobilizer	All key lost, Add key, Read key count Clear fault code	1775
CHEVROLET\China\Aveo (ol d)\Remote	Program remote,	328
CHEVROLET\China\Spark\2 005-2009\Immobilizer	Program key, Switch neutral mode,	322
CHEVROLET\China\Corvett e\2005-2013\Immobilizer	All key lost,	1353



MAZDA\China\Atenza\2017 \Smart key	Add smart key,All smart key lost,Switch ignition on	584
MAZDA\China\MX-5\2017- \Smart key	Add smart key,All smart key lost,Switch ignition on	584
MAZDA\China\M2\2017- \Smart key	Add smart key,All smart key lost,Switch ignition on	1088
MAZDA\China\M3\Smart key\Type 2(2017-)	Add smart key,All smart key lost,Switch ignition on	1088
MAZDA\China\CX-3\2017- \Smart key	Add smart key,All smart key lost,Switch ignition on	584
MAZDA\China\Axela\2018- \Smart key	All smart key lost,Turn ignition ON,Add smart key	1694
MAZDA\China\CX-5\2018- \Smart key	All smart key lost,Turn ignition ON,Add smart key	1694
MAZDA\China\CX-4\2018- \Smart key	All smart key lost,Turn ignition ON,Add smart key	1694
MAZDA\China\M2\2018- \Smart key	All smart key lost,Turn ignition ON,Add smart key	1694
MAZDA\China\CX-9\With smart\2018-	All smart key lost,Turn ignition ON,Add smart key	1694
MAZDA\China\CX-7\With smart\2018-	All smart key lost,Turn ignition ON,Add smart key	1694
MAZDA\China\CX-7\With smart\2017-2018	Add smart key,All smart key lost,Switch ignition on	584
MAZDA\China\CX-9\With smart\2017-2018	Add smart key,All smart key lost,Switch ignition on	584
MAZDA\China\Atenza\2018 -\Smart key	All smart key lost,Turn ignition ON,Add smart key	1694
MAZDA\China\MX-5\2018- \Smart key	All smart key lost,Turn ignition ON,Add smart key	1694
MAZDA\China\CX-8\2018- \Smart key	All smart key lost,Turn ignition ON,Add smart key	1694
MAZDA\South America\Mx5\With smart\2017	All smart key lost,Turn ignition ON,Add smart key	1694
MAZDA\South America\Demio\With smart\2017	All smart key lost,Turn ignition ON,Add smart key	1694
MAZDA\South America\CX- 9\With smart\2017	All smart key lost,Turn ignition ON,Add smart key	1694
MAZDA\South America\CX- 5\With smart\2017-	All smart key lost,Turn ignition ON,Add smart key	1694
MAZDA\South America\CX- 3\With smart\2017-	All smart key lost,Turn ignition ON,Add smart key	1694

MAZDA\South America\M6\With smart\2017-	All smart key lost, Turn ignition ON, Add smart key	1694
MAZDA\South America\M3\With smart\2017-	All smart key lost, Turn ignition ON, Add smart key	1694
MAZDA\South America\M2\With smart\2017	All smart key lost, Turn ignition ON, Add smart key	1694
MAZDA\China\Axela\2016\Smart key	Add smart key, All smart key lost, Switch ignition on	69
MAZDA\China\Atenza\2013-2016\Smart key	Add smart key, All smart key lost, Switch ignition on	69
MAZDA\China\CX-5\2016\Smart key	Add smart key, All smart key lost, Switch ignition on	69
MAZDA\China\M6\Immobilizer	Add key, All key lost, Valid backup key setting, Invalid backup	122
MAZDA\China\M6\Smart key	Add smart key, Delete smart key,	123
MAZDA\China\M3\Immobilizer\Type 1	Add key, Read key count, All key lost,	132
MAZDA\China\M2\2008-2014\Immobilizer	Add key, All key lost,	133
MAZDA\China\Mazda6\Immobilizer	All key lost,	137
MAZDA\China\Mazda6\Smart key	Delete & program smart key, All key/smart key lost, Steering lock	138
MAZDA\China\M3\Immobilizer\Type 2	Add key, All key lost,	133
MAZDA\China\M5\Immobilizer\Type 2	Add key, All key lost,	133
MAZDA\China\M8\Smart key	Add key, All key lost, Add smart key, Lost all smart key	139
MAZDA\China\M5\Immobilizer\Type 1	Add key, All key lost, Read key count,	224
MAZDA\China\M3\Smart key\Type 1	Add smart key, All smart key lost, Switch ignition on	69
MAZDA\China\Axela\2017-2018\Smart key	Add smart key, All smart key lost, Switch ignition on	584
MAZDA\China\M8\Immobilizer	Add key, All key lost, Setup spare key valid Setup spare key	762
MAZDA\China\CX-7\With smart\2016	Add key, All key lost, Add smart key, Lost all smart key	139
MAZDA\China\CX-3\2017\Smart key	Add smart key, All smart key lost, Switch ignition on	69

MAZDA

MAZDA\China\CX-4\2016\Smart key	Add smart key, All smart key lost, Switch ignition on	69
MAZDA\China\CX-4\2017\Smart key	Add smart key, All smart key lost, Switch ignition on	584
MAZDA\China\M2\2014-2016\Smart key	Add smart key, All smart key lost, Switch ignition on	69
MAZDA\China\B series\2007-\Immobilizer	Key count, Add key, All key lost,	827
MAZDA\China\CX-9\Without smart\2004-2009	Add key, Read key count, All key lost,	132
MAZDA\China\CX-9\Without smart\2009-	Add key, All key lost,	133
MAZDA\China\MX-5\2004-2009\Immobilizer	Add key, Read key count, All key lost,	132
MAZDA\China\MX-5\2009-2016\Immobilizer	Keys count, Add key, All key lost,	829
MAZDA\China\BT50\2012-\Immobilizer	Add key, Erase key, All key lost,	830
MAZDA\China\CX-7\With smart\2016	All smart key lost, Add smart key, Switch ignition on	840
MAZDA\China\CX-9\With smart\2016	All smart key lost, Add smart key, Switch ignition on	840
MAZDA\China\CX-5\2017\Smart key	Add smart key, All smart key lost, Switch ignition on	584
MAZDA\China\M121\Immobilizer	Key count, Delete key, Add key,	1006
MAZDA\China\M2\2008-2014\PEPS\Type 1	Add key, Clear key, Add remote, Delete remote Key	1009
MAZDA\China\Demio\2001\Immobilizer	Key number, Delete key, Add key,	1010
MAZDA\China\Demio\2002-2007\Immobilizer	Key number, Delete key, Add key,	1011
MAZDA\China\Demio\2008-2013\Smart key	Add key, Clear key, Add remote, Delete remote Key number	1012
MAZDA\China\Demio\2008-2013\Immobilizer	Key number, Delete key, Add key,	1014
MAZDA\China\Demio\2014-\Smart key	Add smart key, All smart key lost, Switch ignition on	69
MAZDA\China\MX-5 Miata\2005-2013\Immobilizer	Key number, Delete key, Add key,	1014
MAZDA\China\Premacy\2005\Smart key	Key number, Delete key, Add key,	1015

MAZDA\China\RX-8\2004-2009\Immobilizer	Key count, Delete key, Add key,	1016
MAZDA\China\RX-8\2009\Smart key	Add key, Clear key, Add remote, Delete remote Key number	1017
MAZDA\China\RX-8\2009\Immobilizer	Key number, Delete key, Add key,	1014
MAZDA\China\Tribute\Immobilizer\2001-2004	Key number, Delete key, Add key,	1010
MAZDA\China\Tribute\Immobilizer\2005-2008	Key number, Delete key, Add key,	1011
MAZDA\China\Tribute\Immobilizer\2009-2011	Key count, Delete key, Add key,	1019
MAZDA\China\M2\2002-2008\Mechanical key	Add key, All key lost, Valid backup key setting Invalid backup	122
MAZDA\China\M2\2008-2014\PEPS\Type 2	All key lost, Add key, All smart key lost Add smart	1686
MAZDA\South America\BT-50\2011-	Add key, Erase key, All key lost,	830
MAZDA\South America\M121	Key count, Delete key, Add key,	1006
MAZDA\South America\M2\With smart\2008-2014	All key lost, Add key, All smart key lost Add smart	1686
MAZDA\South America\M2\Without smart\2002-2008	Add key, All key lost, Valid backup key setting Invalid backup	122
MAZDA\South America\M2\Without smart\2008-2014	Add key, All key lost,	133
MAZDA\South America\M3\With smart\2004-2008	Add smart key, Delete smart key,	123
MAZDA\South America\M3\With smart\2009-2013	All key lost, Add key, All smart key lost Add smart	1686
MAZDA\South America\M3\Without smart\2004-2008	Add key, Read key count, All key lost,	132
MAZDA\South America\M3\Without smart\2009-2013	Add key, All key lost,	133
MAZDA\South America\M5\Without smart\2011	Add key, Read key count, All key lost,	132
MAZDA\South America\M5\Without smart\2012-	Add key, All key lost,	133
MAZDA\South America\M6\With smart\2008-2012	All key lost, Add key, All smart key lost Add smart	1686
MAZDA\South America\M6\Without smart\2002-2008	Add key, All key lost, Valid backup key setting Invalid backup	122

MAZDA\South America\CX-7\With smart\2016	Add key, All key lost, Add smart key, Lost all smart key	139
MAZDA\South America\CX-7\Without smart\2004-2009	Add key, Read key count, All key lost,	132
MAZDA\South America\CX-7\Without smart\2009-	Add key, All key lost,	133
MAZDA\South America\CX-9\Without smart\2004-2009	Add key, Read key count, All key lost,	132
MAZDA\South America\CX-9\Without smart\2009-	Add key, All key lost,	133
MAZDA\South America\Demio\With smart\2008-2013	All key lost, Add key, All smart key lost Add smart	1686
MAZDA\South America\Demio\Without smart\2001	Key number, Delete key, Add key,	1010
MAZDA\South America\Demio\Without smart\2002-2007	Add key, Read key count, All key lost,	132
MAZDA\South America\Demio\Without smart\2008-2013	Add key, All key lost, Valid backup key setting Invalid backup	122
MAZDA\South America\Mx5\Without smart\2005-2009	Add key, Read key count, All key lost,	132
MAZDA\South America\Mx5\Without smart\2009-2015	Add key, All key lost,	133
MAZDA\South America\Premacy\2005-\With smart	All key lost, Add key, All smart key lost Add smart	1686
MAZDA\South America\Premacy\2005-\Without smart	Add key, Read key count, All key lost,	132
MAZDA\South America\RX-8\With smart\2009-	All key lost,	137
MAZDA\South America\RX-8\Without smart\2004-2009	Add key, Read key count, All key lost,	132
MAZDA\South America\RX-8\Without smart\2009-	Add key, All key lost,	133
MAZDA\South America\Mx5\With smart\2016	All smart key lost, Add smart key, Switch ignition on	840
MAZDA\South America\Demio\With smart\2014-2016	All smart key lost, Add smart key, Switch ignition on	840
MAZDA\South America\CX-9\With smart\2009-2016	All smart key lost, Add smart key, Switch ignition on	840
MAZDA\South America\CX-5\With smart\2013-2016	All smart key lost, Add smart key, Switch ignition on	840
MAZDA\South America\CX-3\With smart\2016-	All smart key lost, Add smart key, Switch ignition on	840

	MAZDA\South America\M6\With smart\2012-2016	All smart key lost,Add smart key,Switch ignition on	840
	MAZDA\South America\M3\With smart\2014-2016	All smart key lost,Add smart key,Switch ignition on	840
	MAZDA\South America\M2\With smart\2014-2016	All smart key lost,Add smart key,Switch ignition on	840
	MAZDA\China\CX-7\Without smart\2009-	Add key,All key lost,	133
	MAZDA\China\CX-7\Without smart\2004-2009	Add key,Read key count,All key lost,	132
	JEEP\Select from vehicle\North America\Rubicon\2011\Im	Read PIN code,Add new key,Delete key,Key count Add old key	264
	JEEP\Select from type\Smart key\Type 3(CAN)	Add smart key,Delete smart key,Read PIN code	1492
	JEEP\Select from type\Smart key\Type 4(CAN)	Sync smart function,	1493
	JEEP\Select from type\Smart key\Type 5(CAN)	Add smart key,Delete smart key,Read PIN code	1494
	JEEP\Select from type\Immobilizer\Type 7(VPW)	Add key,Delete key,	1489
	JEEP\Select from type\Immobilizer\Type 8(CAN)	Add new key,Add old key,Add remote,Delete key Key count Read PIN	1483
	JEEP\Select from vehicle\Asia\Cherokee\2014-2018\Keyless-go	Read pin code,Add key,Delete key,	396
	JEEP\Select from vehicle\Asia\Cherokee\2014-2018\FORIK	Read pin code,Add key,Delete key,	395
	JEEP\Select from vehicle\Asia\Grand Cherokee\2014-	Add smart key,Delete smart key,Key count Read PIN code	269
	JEEP\Select from vehicle\Asia\Renegade\2014-2017\Smart key	Read PIN code,Add key,Delete key,	788
	JEEP\Select from vehicle\Europe\Grand Cherokee\2011-	Read pin code,Add key,Delete key,Key count Modify VIN code	266
	JEEP\Select from vehicle\Europe\Cherokee\2014-2018\Keyless-go	Read pin code,Add key,Delete key,	396
	JEEP\Select from vehicle\Europe\Cherokee\2014-2018\FORIK	Read pin code,Add key,Delete key,	395
	JEEP\Select from vehicle\Europe\Grand Cherokee\2014-\Smart	Add smart key,Delete smart key,Key count Read PIN code	269
	JEEP\Select from vehicle\Europe\Renegade\2014-2017\Smart key	Read PIN code,Add key,Delete key,	788
	JEEP\Select from vehicle\South America\Grand	Read pin code,Add key,Delete key,Key count Modify VIN code	266

JEEP\Select from vehicle\South America\Rubicon\2011\Im	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\South America\Cherokee\2014-	Read pin code, Add key, Delete key,	396
JEEP\Select from vehicle\South America\Cherokee\2014-	Read pin code, Add key, Delete key,	395
JEEP\Select from vehicle\South America\Grand	Add smart key, Delete smart key, Key count Read PIN code	269
JEEP\Select from vehicle\South America\Renegade\2014-	Read PIN code, Add key, Delete key,	788
JEEP\Select from vehicle\Australia\Grand Cherokee\2011-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
JEEP\Select from vehicle\Australia\Rubicon\2011\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\Australia\Cherokee\2014-2018\Keyless-	Read pin code, Add key, Delete key,	396
JEEP\Select from vehicle\Australia\Cherokee\2014-2018\FORIK	Read pin code, Add key, Delete key,	395
JEEP\Select from vehicle\Australia\Grand Cherokee\2014-\Smart	Add smart key, Delete smart key, Key count Read PIN code	269
JEEP\Select from vehicle\Australia\Renegade\2014-2017\Smart key	Read PIN code, Add key, Delete key,	788
JEEP\Select from vehicle\Middle East\Grand	Read pin code, Add key, Delete key, Key count Modify VIN code	266
JEEP\Select from vehicle\Middle East\Rubicon\2011\Immoh	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\Middle East\Cherokee\2014-	Read pin code, Add key, Delete key,	396
JEEP\Select from vehicle\Middle East\Cherokee\2014-	Read pin code, Add key, Delete key,	395
JEEP\Select from vehicle\Middle East\Grand	Add smart key, Delete smart key, Key count Read PIN code	269
JEEP\Select from vehicle\Middle East\Renegade\2014-	Read PIN code, Add key, Delete key,	788
JEEP\Select from vehicle\Africa\Grand Cherokee\2011-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
JEEP\Select from vehicle\Africa\Rubicon\2011\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\Africa\Cherokee\2014-2018\Keyless-go	Read pin code, Add key, Delete key,	396
JEEP\Select from vehicle\Africa\Cherokee\2014-2018\FORIK	Read pin code, Add key, Delete key,	395

JEEP\Select from vehicle\Africa\Grand Cherokee\2014-\Smart	Add smart key,Delete smart key,Key count,Read PIN code	269
JEEP\Select from vehicle\Africa\Renegade\2014-2017\Smart key	Read PIN code,Add key,Delete key,	788
JEEP\Select from vehicle\Asia\Cherokee\2014\Immobilizer	Read pin code,Add key,Delete key,Key count	265
JEEP\Select from vehicle\Middle East\Cherokee\2014\Immobilizer	Read pin code,Add key,Delete key,Key count	265
JEEP\Select from vehicle\Australia\Cherokee\2014\Immobilizer	Read pin code,Add key,Delete key,Key count	265
JEEP\Select from vehicle\South America\Cherokee\2014\Immobilizer	Read pin code,Add key,Delete key,Key count	265
JEEP\Select from type\Immobilizer\Type 9(CAN)	Key count,Program key,Delete key,Program remote	1304
JEEP\Select from type\Smart key\Type 6(CAN)	Read PIN code,Add key,Delete key,	788
JEEP\Select from type\Smart key\Type 7(CAN)	Read PIN code,Add smart key,Delete smart key,	990
JEEP\Select from vehicle\Africa\Grand Cherokee\2011-	Sync smart function,	1493
JEEP\Select from vehicle\Australia\Grand Cherokee\2011-	Sync smart function,	1493
JEEP\Select from vehicle\South America\Grand Cherokee\2011-	Sync smart function,	1493
JEEP\Select from vehicle\Middle East\Grand Cherokee\2011-	Sync smart function,	1493
JEEP\Select from vehicle\Europe\Grand Cherokee\2011-	Sync smart function,	1493
JEEP\Select from vehicle\Asia\Renegade\2014-2017\Immobilizer	Program key,Read PIN code,	850
JEEP\Select from vehicle\Asia\Compass\2018-\Smart key	Program smart key,Delete smart key,Key count	1715
JEEP\Select from type\Smart key\Type 9(CAN)	Program smart key,Delete smart key,Key count	1715
JEEP\Select from type\Remote\Type 9(VPW)	Program remote,	1737
JEEP\Select from vehicle\Asia\Laredo\2012\FORIK PEPS	Read PIN code,Add key,Delete key,Sync smart key	1886
JEEP\Select from vehicle\Asia\Grand Cherokee\2018-	Add smart key,Delete smart key,	1884



JEEP\Select from vehicle\Asia\Wrangler\2018-2020\Smart key	Add smart key, Delete smart key, Key count,	1883
JEEP\Select from vehicle\North America\Compass\2018\Sm	Program smart key, Delete smart key Key count	1715
JEEP\Select from vehicle\Africa\Renegade\2014-2017\Immobilizer	Program key, Read PIN code,	850
JEEP\Select from vehicle\Australia\Renegade\2014-	Program key, Read PIN code,	850
JEEP\Select from vehicle\Europe\Renegade\2014-2017\Immobilizer	Program key, Read PIN code,	850
JEEP\Select from vehicle\South America\Renegade\2014-	Program key, Read PIN code,	850
JEEP\Select from vehicle\Asia\Cherokee\2019\Smart key	Read PIN code, Program key, Delete key,	1990
JEEP\Select from vehicle\Asia\Commander\2018-\Smart key	Read PIN code, Program key, Delete key,	1990
JEEP\Select from vehicle\Asia\Cherokee\2019\FORIK	Read PIN code, Program key, Delete key,	2003
JEEP\Select from vehicle\Asia\Gladiator\2020\Smart key	Add smart key, Delete smart key, Key count,	1883
JEEP\Select from vehicle\North America\Cherokee\2014-	Read pin code, Add key, Delete key,	396
JEEP\Select from vehicle\North America\Cherokee\2014-	Read pin code, Add key, Delete key,	395
JEEP\Select from vehicle\North America\Grand	Read PIN code, Add smart key, Delete smart key Key count	269
JEEP\Select from vehicle\North America\Compass\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\North America\Renegade\2014-	Read PIN code, Add key, Delete key,	788
JEEP\Select from vehicle\Asia\Grand Cherokee\2011-	Read PIN code, Sync smart key, Add key Delete key Modify	783
JEEP\Select from type\IMMO-Fobik	Read PIN code, Sync smart key, Add key Delete key Modify	783
JEEP\Select from type\Smart key\Type 1 (CAN)	Add smart key, Delete smart key, Read PIN code	268
JEEP\Select from type\Smart key\Type 2 (CAN)	Read PIN code, Add smart key, Delete smart key Key count	269
JEEP\Select from type\Immobilizer\Type 1 (CAN)	Add new key, Add old key, Add remote, Detect key count Delete key	263
JEEP\Select from type\Immobilizer\Type 2 (CAN)	Read PIN code, Add new key, Delete key, Key count Add old key	264

JEEP\Select from type\Immobilizer\Type 3 (CAN)	Read pin code, Add key, Delete key, Key count	265
JEEP\Select from type\Immobilizer\Type 4 (CAN)	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
JEEP\Select from type\Immobilizer\Type 5 (CAN)	Add key, Delete key, Key count, Add remote, Read PIN code	267
JEEP\Select from type\Immobilizer\Type 6 (VPW)	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from type\Remote\Type 1 (VPW)	Add remote,	270
JEEP\Select from type\Remote\Type 2 (VPW)	Add remote,	271
JEEP\Select from type\Remote\Type 3 (VPW)	Add remote,	272
JEEP\Select from type\Remote\Type 4 (CAN)	Add remote, Read pin code,	273
JEEP\Select from type\Remote\Type 5 (VPW)	Add remote, Delete remote,	802
JEEP\Select from type\Remote\Type 6 (VPW)	Add remote,	803
JEEP\Select from type\Remote\Type 7 (VPW)	Add remote,	804
JEEP\Select from type\Remote\Type 8 (VPW)	Add remote,	805
JEEP\Select from vehicle\Asia\Wrangler\2007-2017\Immobilizer	Read PIN code, Add new key, Delete key, Key count, Add old key	264
JEEP\Select from vehicle\North America\Commander\2006-	Add key, Delete key, Key count, Add remote, Read PIN code	267
JEEP\Select from vehicle\North America\Commander\2008\	Read pin code, Add key, Delete key, Key count	265
JEEP\Select from vehicle\North America\Commander\2009-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
JEEP\Select from vehicle\North America\Grand	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from vehicle\North America\Grand	Add remote,	271
JEEP\Select from vehicle\North America\Grand	Add key, Delete key, Key count, Add remote, Read PIN code	267
JEEP\Select from vehicle\North America\Grand	Read pin code, Add key, Delete key, Key count	265
JEEP\Select from vehicle\North America\Grand	Read pin code, Add key, Delete key, Key count, Modify VIN code	266

JEEP

JEEP\Select from vehicle\North America\Laredo\1999-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from vehicle\North America\Laredo\2005-	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
JEEP\Select from vehicle\North America\Laredo\2008-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
JEEP\Select from vehicle\North America\Liberty\2002-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from vehicle\North America\Liberty\2002-	Add remote,	272
JEEP\Select from vehicle\North America\Liberty\2005-	Add key, Delete key,	1489
JEEP\Select from vehicle\North America\Liberty\2008-	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\North America\Patriot\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\North America\Wrangler\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from vehicle\North America\Wrangler\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\Asia\Commander\2006-2007\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
JEEP\Select from vehicle\Asia\Commander\2008\FORIK	Read pin code, Add key, Delete key, Key count	265
JEEP\Select from vehicle\Asia\Commander\2009-2010\FORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
JEEP\Select from vehicle\Asia\Grand Cherokee\1999-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from vehicle\Asia\Grand Cherokee\1999-	Add remote,	271
JEEP\Select from vehicle\Asia\Grand Cherokee\2005-	Add key, Delete key, Key count, Add remote, Read PIN code	267
JEEP\Select from vehicle\Asia\Grand Cherokee\2008-	Read pin code, Add key, Delete key, Key count	265
JEEP\Select from vehicle\Asia\Laredo\1999-2004\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from vehicle\Asia\Laredo\2005-2007\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
JEEP\Select from vehicle\Asia\Laredo\2008-2010\Immobilizer	Read pin code, Add key, Delete key, Key count Modify VIN code	266
JEEP\Select from vehicle\Asia\Liberty\2002-2004\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274

JEEP\Select from vehicle\Asia\Liberty\2002-2004\Remote	Add remote,	272
JEEP\Select from vehicle\Asia\Liberty\2005-2007\Immobilizer	Add key,Delete key,	1489
JEEP\Select from vehicle\Asia\Liberty\2008-2013\Immobilizer	Read PIN code,Add new key,Delete key,Key count Add old key	264
JEEP\Select from vehicle\Asia\Patriot\2007-2015\Immobilizer	Read PIN code,Add new key,Delete key,Key count Add old key	264
JEEP\Select from vehicle\Asia\Rubicon\2007-2011\Immobilizer	Read PIN code,Add new key,Delete key,Key count Add old key	264
JEEP\Select from vehicle\Asia\Wrangler\2001-2006\Immobilizer	Add key,Delete key,Key count,Read PIN code(OBD) Read PIN	274
JEEP\Select from vehicle\Asia\Compass\2007-2017\Immobilizer	Read PIN code,Add new key,Delete key,Key count Add old key	264
JEEP\Select from vehicle\Europe\Commander\2007\Immobilizer	Add key,Delete key,Key count,Add remote,Read PIN code	267
JEEP\Select from vehicle\Europe\Commander\2008\FORIK	Read pin code,Add key,Delete key,Key count	265
JEEP\Select from vehicle\Europe\Commander\2009-2010\FORIK	Read pin code,Add key,Delete key,Key count Modify VIN code	266
JEEP\Select from vehicle\Europe\Grand Cherokee\1999-	Add key,Delete key,Key count,Read PIN code(OBD) Read PIN	274
JEEP\Select from vehicle\Europe\Grand Cherokee\1999-	Add remote,	271
JEEP\Select from vehicle\Europe\Grand Cherokee\2005-	Add key,Delete key,Key count,Add remote,Read PIN code	267
JEEP\Select from vehicle\Europe\Grand Cherokee\2008-	Read pin code,Add key,Delete key,Key count	265
JEEP\Select from vehicle\Europe\Laredo\1999-2004\Immobilizer	Add key,Delete key,Key count,Read PIN code(OBD) Read PIN	274
JEEP\Select from vehicle\Europe\Laredo\2005-2007\Immobilizer	Add new key,Add old key,Add remote,Delete key Key count Read PIN	1483
JEEP\Select from vehicle\Europe\Laredo\2008-2010\Immobilizer	Read pin code,Add key,Delete key,Key count Modify VIN code	266
JEEP\Select from vehicle\Europe\Liberty\2002-2004\Immobilizer	Add key,Delete key,Key count,Read PIN code(OBD) Read PIN	274
JEEP\Select from vehicle\Europe\Liberty\2002-2004\Remote	Add remote,	272
JEEP\Select from vehicle\Europe\Liberty\2005-2007\Immobilizer	Add key,Delete key,	1489
JEEP\Select from vehicle\Europe\Liberty\2008-2013\Immobilizer	Read PIN code,Add new key,Delete key,Key count Add old key	264

JEEP\Select from vehicle\Europe\Patriot\2007-2015\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\Europe\Rubicon\2007-2009\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\Europe\Wrangler\2001-2006\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from vehicle\Europe\Wrangler\2007-2017\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\Europe\Compass\2007-2017\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\South America\Commander\2006-	Add key, Delete key, Key count, Add remote, Read PIN code	267
JEEP\Select from vehicle\South America\Commander\2008\	Read pin code, Add key, Delete key, Key count	265
JEEP\Select from vehicle\South America\Commander\2009-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
JEEP\Select from vehicle\South America\Grand	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from vehicle\South America\Grand	Add remote,	271
JEEP\Select from vehicle\South America\Grand	Add key, Delete key, Key count, Add remote, Read PIN code	267
JEEP\Select from vehicle\South America\Grand	Read pin code, Add key, Delete key, Key count	265
JEEP\Select from vehicle\South America\Laredo\1999-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from vehicle\South America\Laredo\2005-	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
JEEP\Select from vehicle\South America\Laredo\2008-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
JEEP\Select from vehicle\South America\Liberty\2002-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from vehicle\South America\Liberty\2002-	Add remote,	272
JEEP\Select from vehicle\South America\Liberty\2005-	Add key, Delete key,	1489
JEEP\Select from vehicle\South America\Liberty\2008-	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\South America\Patriot\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\South America\Wrangler\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274

JEEP\Select from vehicle\South America\Wrangler\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\South America\Compass\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\Australia\Commander\2006-	Add key, Delete key, Key count, Add remote, Read PIN code	267
JEEP\Select from vehicle\Australia\Commander\2008\FORIK	Read pin code, Add key, Delete key, Key count	265
JEEP\Select from vehicle\Australia\Commander\2009-2010\FORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
JEEP\Select from vehicle\Australia\Grand Cherokee\1999-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from vehicle\Australia\Grand Cherokee\1999-	Add remote,	271
JEEP\Select from vehicle\Australia\Grand Cherokee\2005-	Add key, Delete key, Key count, Add remote, Read PIN code	267
JEEP\Select from vehicle\Australia\Grand Cherokee\2008-	Read pin code, Add key, Delete key, Key count	265
JEEP\Select from vehicle\Australia\Laredo\1999-2004\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from vehicle\Australia\Laredo\2005-2007\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
JEEP\Select from vehicle\Australia\Laredo\2008-2010\Immobilizer	Read pin code, Add key, Delete key, Key count Modify VIN code	266
JEEP\Select from vehicle\Australia\Liberty\2002-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from vehicle\Australia\Liberty\2002-2004\Remote	Add remote,	272
JEEP\Select from vehicle\Australia\Liberty\2005-	Add key, Delete key,	1489
JEEP\Select from vehicle\Australia\Liberty\2008-	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\Australia\Patriot\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\Australia\Wrangler\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from vehicle\Australia\Wrangler\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\Australia\Compass\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\Middle East\Commander\2006-	Add key, Delete key, Key count, Add remote, Read PIN code	267

JEEP\Select from vehicle\Middle East\Commander\2008\FOR	Read pin code, Add key, Delete key, Key count	265
JEEP\Select from vehicle\Middle East\Commander\2009-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
JEEP\Select from vehicle\Middle East\Grand	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from vehicle\Middle East\Grand	Add remote,	271
JEEP\Select from vehicle\Middle East\Grand	Add key, Delete key, Key count, Add remote, Read PIN code	267
JEEP\Select from vehicle\Middle East\Grand	Read pin code, Add key, Delete key, Key count	265
JEEP\Select from vehicle\Middle East\Laredo\1999-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from vehicle\Middle East\Laredo\2005-	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
JEEP\Select from vehicle\Middle East\Laredo\2008-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
JEEP\Select from vehicle\Middle East\Liberty\2002-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from vehicle\Middle East\Liberty\2002-	Add remote,	272
JEEP\Select from vehicle\Middle East\Liberty\2005-	Add key, Delete key,	1489
JEEP\Select from vehicle\Middle East\Liberty\2008-	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\Middle East\Patriot\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\Middle East\Wrangler\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from vehicle\Middle East\Wrangler\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\Middle East\Compass\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\Africa\Commander\2006-2007\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
JEEP\Select from vehicle\Africa\Commander\2008\FORIK	Read pin code, Add key, Delete key, Key count	265
JEEP\Select from vehicle\Africa\Commander\2009-2010\FORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
JEEP\Select from vehicle\Africa\Grand Cherokee\1999-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274

JEEP\Select from vehicle\Africa\Grand Cherokee\1999-	Add remote,	271
JEEP\Select from vehicle\Africa\Grand Cherokee\2005-	Add key, Delete key, Key count, Add remote, Read PIN code	267
JEEP\Select from vehicle\Africa\Grand Cherokee\2008-	Read pin code, Add key, Delete key, Key count	265
JEEP\Select from vehicle\Africa\Laredo\1999-2004\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from vehicle\Africa\Laredo\2005-2007\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
JEEP\Select from vehicle\Africa\Laredo\2008-2010\Immobilizer	Read pin code, Add key, Delete key, Key count Modify VIN code	266
JEEP\Select from vehicle\Africa\Liberty\2002-2004\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from vehicle\Africa\Liberty\2002-2004\Remote	Add remote,	272
JEEP\Select from vehicle\Africa\Liberty\2005-2007\Immobilizer	Add key, Delete key,	1489
JEEP\Select from vehicle\Africa\Liberty\2008-2013\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\Africa\Patriot\2007-2015\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\Africa\Wrangler\2001-2006\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
JEEP\Select from vehicle\Africa\Wrangler\2007-2017\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\Africa\Compass\2007-2017\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
JEEP\Select from vehicle\Europe\Cherokee\2002-2007\Immobilizer	Add key, Delete key,	1489
JEEP\Select from vehicle\North America\Cherokee\-	Read pin code, Add key, Delete key, Key count	265
JEEP\Select from type\Smart key\Type 8 (CAN)\Keyless-go	Read pin code, Add key, Delete key,	396
JEEP\Select from type\Smart key\Type 8 (CAN)\Mechanical key	Read pin code, Add key, Delete key,	395
JEEP\Select from vehicle\North America\Grand	Sync smart function,	1493
JEEP\Select from vehicle\North America\Grand	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
JEEP\Select from vehicle\North America\Grand	Add new key, Add old key, Add remote, Detect key count Delete key	263



BUICK\China\Regal\2017-\Smart key	All smart key lost,Add smart key,Read smart key count Clear fault	282
BUICK\China\GL8\2017-\Smart key\Type 2(2.5L)	All smart key lost,Add smart key,Read smart key count Clear fault	282
BUICK\China\Verano\2017-\Mechanical key	All key lost,Clear fault code,Read key count	1322
BUICK\China\Verano\2017-\Smart key	All smart key lost,Add smart key,Read smart key count	1324
BUICK\China\GL6\2017-\Smart key	Add smart key,All smart key lost,Read key count	1696
BUICK\China\Regal\2017-\Mechanical key	All key lost,Add key,Read key count Clear fault code	284
BUICK\China\GL6\2017-\Mechanical key	Add key,All key lost,Read key count,	1799
BUICK\China\Excelle\2018-\Mechanical key	All key lost,Add key,Read key count Clear fault code	284
BUICK\China\Excelle\2018-\Smart key	Add smart key,All smart key lost,Read key count Recover car data	1578
BUICK\China\Excelle GX\2018-\Smart key	Add smart key,All smart key lost,Read key count Recover car data	1578
BUICK\China\GL8\2017-\Smart key\Type 3	Read key count,Program smart key,	1867
BUICK\China\Excelle\2018-\Smart key	All smart key lost,Add smart key,Read smart key count	1324
BUICK\China\Excelle\2015\Mechanical key	All key lost,Add key,Read key count Clear fault code	284
BUICK\China\Excelle\2015\Smart key	All smart key lost,Add smart key,Read key count Clear fault code	285
BUICK\China\Envision\Mechanical key	All key lost,Add key,Read key count Clear fault code	284
BUICK\China\Encore\Mechanical key	All key lost,Add key,Read key count Clear fault code	284
BUICK\China\GL8\2011-2016\Mechanical key	All key lost,Add key,Read key count Clear fault code	284
BUICK\China\Lacrosse\2010-2016\Mechanical key	All key lost,Add key,Read key count Clear fault code	284
BUICK\China\Regal\2016\Mechanical key	All key lost,Add key,Read key count Clear fault code	284
BUICK\China\Verano\2015-\Mechanical key	All key lost,Add key,Read key count Clear fault code	284
BUICK\China\Encore\Smart key	All smart key lost,Add smart key,Read key count Clear fault code	285

BUICK

BUICK\China\GL8\2011-2016\Smart key\Type 1	All smart key lost,Add smart key,Read key count Clear fault code	285
BUICK\China\Lacrosse\2010-2016\Smart key	All smart key lost,Add smart key,Read key count Clear fault code	285
BUICK\China\Regal\2016\Smart key	All smart key lost,Add smart key,Read key count Clear fault code	285
BUICK\China\Verano\2015-\Smart key	All smart key lost,Add smart key,Read key count Clear fault code	285
BUICK\China\Excelle\2015-2017\Mechanical key	All key lost,Add key,	256
BUICK\China\Excelle\2015-2017\Smart key	All smart key lost,Add smart key,	257
BUICK\China\Excelle\2013-2017\Mechanical key\Type 1	Program key,Delete key,Read key count,	279
BUICK\China\Lacrosse\2017-\Smart key	All smart key lost,Add smart key,Read smart key count Clear fault	282
BUICK\China\Allure\2005-2008\Mechanical key	Lost all key,	297
BUICK\China\Enclave\Mechanical key	Lost all key,	297
BUICK\China\Lucerne\Mechanical key	Lost all key,	297
BUICK\China\Park Avenue\2005-\Mechanical key	Lost all key,	297
BUICK\China\Terraza\Mechanical key	Lost all key,	297
BUICK\China\Excelle\2012\Mechanical key	Program key,Switch neutral mode,	322
BUICK\China\GL8\2004-2010\Mechanical key	All key lost,	327
BUICK\China\Excelle\2012\Remote\Type 1	Program remote,	328
BUICK\China\Excelle\2013-2017\Remote	Program remote,Read remote count,	331
BUICK\China\Enclave\Remote	Program remote,Delete remote,	332
BUICK\China\Park Avenue\Remote	Program remote,Delete remote,	332
BUICK\China\Lacrosse\Remote	Program remote,	334
BUICK\China\Century\Remote	Program remote,	336

BUICK\China\Regal\2016\Remote	Program remote,	336
BUICK\China\FirstLand\Remote	Program remote,	334
BUICK\China\Read PIN code	Read pin code type1, Read pin code type2 Read pin code	370
BUICK\China\Royaum\Mechanical key	Program key,	326
BUICK\China\GL8\2017-\Smart key\Type 1	Read key count, All smart key lost, Add smart key	690
BUICK\China\Envision\Smart key\2017	Add smart key, All smart key lost, Read smart key count	295
BUICK\China\Lacrosse\2005-2009\Mechanical key	All key lost,	327
BUICK\China\Excelle\2012\Remote\Type 2	Remote,	924
BUICK\China\Excelle\2013-2017\Mechanical key\Type 2	All key lost, Add key,	256
BUICK\China\GL8\2011-2016\Smart key\Type 2	Add smart key, All smart key lost, Read smart key count	295
BUICK\China\Envision\Smart key\2017-	All smart key lost, Add smart key, Read smart key count Clear fault	282
BUICK\China\Excelle\2018-\Mechanical key	Read key count, All key lost, Add key,	649
BUICK\China\Park Avenue\2004\Mechanical key	All key lost,	617
BUICK\China\Lesabre\2000-2005\Mechanical key	All key lost,	617
BUICK\China\Rendezous\2002-2004\Mechanical key	All key lost,	617
BUICK\China\Sail\Mechanical key	Clear fault code, Program key, Delete key	614
DODGE\Select from vehicle\North America\Caravan\2010-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\North America\Caravan\2010-	Sync smart function,	1493
DODGE\Select from vehicle\North America\Challenger\2015	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\North America\Charger\2011-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\North America\Charger\2011-	Add smart key, Delete smart key, Read PIN code	268

DODGE\Select from vehicle\North America\Dart\2013-	Add smart key, Delete smart key, Read PIN code	1492
DODGE\Select from vehicle\North America\Durango\2011-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\North America\Durango\2011-	Sync smart function,	1493
DODGE\Select from vehicle\North America\Durango\2014-	Add smart key, Delete smart key, Key count, Read PIN code	269
DODGE\Select from vehicle\North America\Grand	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\North America\Ram\2013-	Add smart key, Delete smart key, Read PIN code	1494
DODGE\Select from vehicle\North America\Magnum\2011-	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\North America\Viper\2013-	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\North America\Dart\2013-	Add key, Delete key, Read PIN code,	988
DODGE\Select from vehicle\Asia\Charger\2011-2014\FORIK	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\Asia\Durango\2011-2013\FORIK	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\Asia\Durango\2011-2013\Keyless-go(sync	Sync smart function,	1493
DODGE\Select from vehicle\Asia\Durango\2014-2017\Smart_key	Add smart key, Delete smart key, Key count, Read PIN code	269
DODGE\Select from vehicle\Asia\Journey\2011-2014\Immobilizer	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\Europe\Caravan\2010-2019\FORIK	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\Europe\Caravan\2010-2019\Keyless-	Sync smart function,	1493
DODGE\Select from vehicle\Europe\Challenger\2015-2017\PEPS\Type	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Europe\Charger\2011-2014\FORIK	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\Europe\Charger\2011-2014\Smart_key	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Europe\Dart\2013-2016\Smart_key	Add smart key, Delete smart key, Read PIN code	1492
DODGE\Select from vehicle\Europe\Durango\2011-2013\FORIK	Read pin code, Add key, Delete key, Key count, Modify VIN code	266

DODGE\Select from vehicle\Europe\Durango\2011-2013\Keyless-	Sync smart function,	1493
DODGE\Select from vehicle\Europe\Durango\2014-2017\Smart_key	Add smart key, Delete smart key, Key count Read PIN code	269
DODGE\Select from vehicle\Europe\Grand Caravan\2010-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Europe\Journey\2011-2014\Immobilizer	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Europe\Ram\2013-\Smart_key	Add smart key, Delete smart key, Read PIN code	1494
DODGE\Select from vehicle\Europe\Magnum\2011-\Smart_key	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Europe\Dart\2013-2016\EOBTK	Add key, Delete key, Read PIN code,	988
DODGE\Select from vehicle\South America\Caravan\2010-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\South America\Caravan\2010-	Sync smart function,	1493
DODGE\Select from vehicle\South America\Challenger\2015	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\South America\Charger\2011-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\South America\Charger\2011-	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\South America\Dart\2013-	Add smart key, Delete smart key, Read PIN code	1492
DODGE\Select from vehicle\South America\Durango\2011-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\South America\Durango\2011-	Sync smart function,	1493
DODGE\Select from vehicle\South America\Durango\2014-	Add smart key, Delete smart key, Key count Read PIN code	269
DODGE\Select from vehicle\South America\Grand	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\South America\Journey\2011-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\South America\Ram\2013-\Smart	Add smart key, Delete smart key, Read PIN code	1494
DODGE\Select from vehicle\South America\Magnum\2011-	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\South America\Dart\2013-	Add key, Delete key, Read PIN code,	988

DODGE\Select from vehicle\Middle East\Caravan\2010-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\Middle East\Caravan\2010-	Sync smart function,	1493
DODGE\Select from vehicle\Middle East\Challenger\2015-	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Middle East\Charger\2011-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\Middle East\Charger\2011-	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Middle East\Dart\2013-	Add smart key, Delete smart key, Read PIN code	1492
DODGE\Select from vehicle\Middle East\Durango\2011-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\Middle East\Durango\2011-	Sync smart function,	1493
DODGE\Select from vehicle\Middle East\Durango\2014-	Add smart key, Delete smart key, Key count, Read PIN code	269
DODGE\Select from vehicle\Middle East\Grand	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\Middle East\Journey\2011-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\Middle East\Ram\2013-\Smart	Add smart key, Delete smart key, Read PIN code	1494
DODGE\Select from vehicle\Middle East\Magnum\2011-\Smart	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Middle East\Dart\2013-	Add key, Delete key, Read PIN code,	988
DODGE\Select from vehicle\Australia\Caravan\2010-2019\EORTK	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\Australia\Caravan\2010-2019\Keyless-	Sync smart function,	1493
DODGE\Select from vehicle\Australia\Challenger\2015-	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Australia\Charger\2011-2014\EORTK	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\Australia\Charger\2011-2014\Smart key	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Australia\Dart\2013-2016\Keyless-go	Add smart key, Delete smart key, Read PIN code	1492
DODGE\Select from vehicle\Australia\Durango\2011-2013\EORTK	Read pin code, Add key, Delete key, Key count, Modify VIN code	266

DODGE\Select from vehicle\Australia\Durango\2011-2013\Keyless-	Sync smart function,	1493
DODGE\Select from vehicle\Australia\Durango\2014-2017\Smart_key	Add smart key, Delete smart key, Key count Read PIN code	269
DODGE\Select from vehicle\Australia\Grand Caravan\2010-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Australia\Journey\2011-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Australia\Ram\2013-\Smart_key	Add smart key, Delete smart key, Read PIN code	1494
DODGE\Select from vehicle\Australia\Magnum\2011-\Smart_key	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Australia\Dart\2013-2016\FORIK	Add key, Delete key, Read PIN code,	988
DODGE\Select from vehicle\Africa\Caravan\2010-2019\FORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Africa\Caravan\2010-2019\Keyless-	Sync smart function,	1493
DODGE\Select from vehicle\Africa\Challenger\2015-2017\PEPS\Type	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Africa\Charger\2011-2014\FORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Africa\Charger\2011-2014\Smart_key	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Africa\Dart\2013-2016\Smart_key	Add smart key, Delete smart key, Read PIN code	1492
DODGE\Select from vehicle\Africa\Durango\2011-2013\FORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Africa\Durango\2011-2013\Keyless-	Sync smart function,	1493
DODGE\Select from vehicle\Africa\Durango\2014-2017\Smart_key	Add smart key, Delete smart key, Key count Read PIN code	269
DODGE\Select from vehicle\Africa\Grand Caravan\2010-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Africa\Journey\2011-2014\Immobilizer	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Africa\Ram\2013-\Smart_key	Add smart key, Delete smart key, Read PIN code	1494
DODGE\Select from vehicle\Africa\Magnum\2011-\Smart_key	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Africa\Dart\2013-2016\FORIK	Add key, Delete key, Read PIN code,	988

DODGE\Select from vehicle\Asia\Dart\2013-2016\Smart key	Add smart key, Delete smart key, Read PIN code	1492
DODGE\Select from vehicle\North America\Ram\2013-	Add key, Delete key, Read PIN code,	989
DODGE\Select from vehicle\Europe\Ram\2013-\EORIK	Add key, Delete key, Read PIN code,	989
DODGE\Select from vehicle\Australia\Ram\2013-\EORIK	Add key, Delete key, Read PIN code,	989
DODGE\Select from vehicle\Africa\Ram\2013-\EORIK	Add key, Delete key, Read PIN code,	989
DODGE\Select from vehicle\South America\Ram\2013-\EORIK	Add key, Delete key, Read PIN code,	989
DODGE\Select from vehicle\Middle East\Ram\2013-\EORIK	Add key, Delete key, Read PIN code,	989
DODGE\Select from vehicle\North America\Ram Truck\2013-	Read pin code, Add key, Delete key,	396
DODGE\Select from vehicle\North America\Ram Truck\2013-	Read pin code, Add key, Delete key,	395
DODGE\Select from vehicle\Asia\Ram Truck\2013-\Keyless-go	Read pin code, Add key, Delete key,	396
DODGE\Select from vehicle\Asia\Ram Truck\2013-\Mechanical	Read pin code, Add key, Delete key,	395
DODGE\Select from vehicle\Europe\Ram Truck\2013-\Keyless-go	Read pin code, Add key, Delete key,	396
DODGE\Select from vehicle\Europe\Ram Truck\2013-\Mechanical	Read pin code, Add key, Delete key,	395
DODGE\Select from vehicle\Australia\Ram Truck\2013-\Keyless-go	Read pin code, Add key, Delete key,	396
DODGE\Select from vehicle\Australia\Ram Truck\2013-\Mechanical	Read pin code, Add key, Delete key,	395
DODGE\Select from vehicle\Africa\Ram Truck\2013-\Keyless-go	Read pin code, Add key, Delete key,	396
DODGE\Select from vehicle\Africa\Ram Truck\2013-\Mechanical	Read pin code, Add key, Delete key,	395
DODGE\Select from vehicle\South America\Ram Truck\2013-	Read pin code, Add key, Delete key,	396
DODGE\Select from vehicle\South America\Ram Truck\2013-	Read pin code, Add key, Delete key,	395
DODGE\Select from vehicle\Middle East\Ram Truck\2013-\Keyless-go	Read pin code, Add key, Delete key,	396
DODGE\Select from vehicle\Middle East\Ram Truck\2013-\Mechanical	Read pin code, Add key, Delete key,	395



DODGE\Select from vehicle\North America\Ram	Add smart key,Key count,	1885
DODGE\Select from vehicle\Asia\Ram\2018\PEPS	Add key,Delete key,	1887
DODGE\Select from vehicle\Asia\Viper\2015-2017\PEPS\Type 2	Add smart key,Delete smart key,	1891
DODGE\Select from vehicle\Asia\Challenger\2018\Smart key	Add smart key,Delete smart key,Key count,	1901
DODGE\Select from vehicle\Asia\Challenger\2019\Smart key	Add smart key,Delete smart key,Key count,	1880
DODGE\Select from vehicle\Asia\Charger\2018\Smart key	Add smart key,Delete smart key,Key count,	1901
DODGE\Select from vehicle\Asia\Charger\2019-2020\Smart key	Add smart key,Delete smart key,Key count,	1880
DODGE\Select from vehicle\Asia\Ram\2018\IMMO-Fobik	Program key,Delete key,	1996
DODGE\Select from vehicle\Asia\Ram\2019-2020\PEPS	Add smart key,Delete smart key,	2007
DODGE\Select from vehicle\Asia\Viper\2015-2017\PEPS\Type 1	Add smart key,Delete smart key,Read PIN code	268
DODGE\Select from vehicle\Asia\Challenger\2015-2017\PEPS\Type 2	Add smart key,Delete smart key,	1891
DODGE\Select from vehicle\Asia\Charger\2015-2017\PEPS\Type 1	Add smart key,Delete smart key,Read PIN code	268
DODGE\Select from vehicle\Asia\Charger\2015-2017\PEPS\Type 2	Add smart key,Delete smart key,	1891
DODGE\Select from vehicle\North America\Charger\2015-	Add smart key,Delete smart key,Read PIN code	268
DODGE\Select from vehicle\North America\Charger\2015-	Add smart key,Delete smart key,	1891
DODGE\Select from vehicle\Europe\Charger\2015-2017\PEPS\Type 1	Add smart key,Delete smart key,Read PIN code	268
DODGE\Select from vehicle\Europe\Charger\2015-2017\PEPS\Type 2	Add smart key,Delete smart key,	1891
DODGE\Select from vehicle\South America\Charger\2015-	Add smart key,Delete smart key,Read PIN code	268
DODGE\Select from vehicle\South America\Charger\2015-	Add smart key,Delete smart key,	1891
DODGE\Select from vehicle\Middle East\Charger\2015-	Add smart key,Delete smart key,Read PIN code	268
DODGE\Select from vehicle\Middle East\Charger\2015-	Add smart key,Delete smart key,	1891

DODGE\Select from vehicle\Australia\Charger\2015-2017\PEPS\Type	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Australia\Charger\2015-2017\PEPS\Type	Add smart key, Delete smart key,	1891
DODGE\Select from vehicle\Africa\Charger\2015-2017\PEPS\Type_1	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Africa\Charger\2015-2017\PEPS\Type_2	Add smart key, Delete smart key,	1891
DODGE\Select from vehicle\Asia\Durango\2018-2019\Smart_key	Add smart key, Delete smart key,	1884
DODGE\Select from vehicle\North America\Durango\2018-	Add smart key, Delete smart key,	1884
DODGE\Select from type\Remote\Type 1 (VPW)	Add remote,	270
DODGE\Select from type\Remote\Type 2 (VPW)	Add remote,	271
DODGE\Select from type\Remote\Type 3 (VPW)	Add remote,	272
DODGE\Select from type\Remote\Type 4 (CAN)	Add remote, Read pin code,	273
DODGE\Select from type\Remote\Type 5 (VPW)	Add remote, Delete remote,	802
DODGE\Select from type\Remote\Type 6 (VPW)	Add remote,	803
DODGE\Select from type\Remote\Type 7 (VPW)	Add remote,	804
DODGE\Select from type\Remote\Type 8 (VPW)	Add remote,	805
DODGE\Select from vehicle\Asia\Caravan\2001-2003\Remote	Add remote, Delete remote,	802
DODGE\Select from vehicle\Asia\Dakota\2001-2004\Remote	Add remote,	804
DODGE\Select from vehicle\Asia\Durango\2001-2003\Remote	Add remote,	804
DODGE\Select from vehicle\Asia\Interpid\1997-2004\Remote	Add remote,	803
DODGE\Select from vehicle\Asia\Neon\2000-2005\Remote	Add remote,	270
DODGE\Select from vehicle\Asia\Ram\2002-2005\Remote	Add remote,	805
DODGE\Select from vehicle\Asia\Stratus\4 door\2001-2006\Remote	Add remote,	803

DODGE\Select from type\Smart key\Type 1(CAN)	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from type\Smart key\Type 2(CAN)	Read PIN code, Add smart key, Delete smart key Key count	269
DODGE\Select from vehicle\Asia\Challenger\2015-2017\PEPS\Type 1	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Asia\Charger\2011-2014\Smart key	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Asia\Magnum\2011-\Smart key	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Asia\Viper\2013-2014\Smart key	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from type\Immobilizer\Type 1(CAN)	Add new key, Add old key, Add remote, Detect key count Delete key	263
DODGE\Select from type\Immobilizer\Type 2(CAN)	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from type\Immobilizer\Type 3(CAN)	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from type\Immobilizer\Type 4(CAN)	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from type\Immobilizer\Type 5(CAN)	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from type\Immobilizer\Type 6(VPW)	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Asia\Dart\2013-2016\FORIK	Add key, Delete key, Read PIN code,	988
DODGE\Select from vehicle\Asia\Ram\2013-2017\FORIK	Add key, Delete key, Read PIN code,	989
DODGE\Select from type\Smart key\Type 3(CAN)	Add smart key, Delete smart key, Read PIN code	1492
DODGE\Select from type\Smart key\Type 4(CAN)	Sync smart function,	1493
DODGE\Select from type\Smart key\Type 5(CAN)	Add smart key, Delete smart key, Read PIN code	1494
DODGE\Select from type\Immobilizer\Type 7(VPW)	Add key, Delete key,	1489
DODGE\Select from type\Immobilizer\Type 8(CAN)	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\North America\Avenger\2008-	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\North America\Caliber\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264

DODGE\Select from vehicle\North America\Caravan\2001-	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\North America\Caravan\2001-	Add remote,	272
DODGE\Select from vehicle\North America\Caravan\2004-	Add key, Delete key,	1489
DODGE\Select from vehicle\North America\Caravan\2008-	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\North America\Challenger\2008-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\North America\Challenger\2008-	Sync smart function,	1493
DODGE\Select from vehicle\North America\Charger\2005-	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\North America\Charger\2006-	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\North America\Charger\2008\EO	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\North America\Charger\2008\Ke	Sync smart function,	1493
DODGE\Select from vehicle\North America\Charger\2009-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\North America\Charger\2009-	Sync smart function,	1493
DODGE\Select from vehicle\North America\Dakota\2001-	Add remote,	804
DODGE\Select from vehicle\North America\Dakota\2005-	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\North America\Dakota\2007-	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\North America\Dakota\2009-	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\North America\Durango\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\North America\Durango\2001-	Add remote,	804
DODGE\Select from vehicle\North America\Durango\2004-	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\North America\Durango\2007-	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\North America\Grand	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274

DODGE\Select from vehicle\North America\Grand	Add key, Delete key,	1489
DODGE\Select from vehicle\North America\Grand	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\North America\Internid\1997-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\North America\Internid\1997-	Add remote,	803
DODGE\Select from vehicle\North America\Journey\2008-	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\North America\Journey\2008-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\North America\Journey\2011-	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\North America\Magnum\2005-	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\North America\Magnum\2006-	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\North America\Magnum\2008-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\North America\Neon\2000-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\North America\Neon\2000-	Add remote,	270
DODGE\Select from vehicle\North America\Neon\2005-	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\North America\Neon\2005-	Add remote,	270
DODGE\Select from vehicle\North America\Nitro\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\North America\Ram\2002-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\North America\Ram\2002-	Add remote,	805
DODGE\Select from vehicle\North America\Ram\2006-	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\North America\Ram\2009-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\North America\Stratus\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\North America\Stratus\2001-	Add remote,	803

DODGE\Select from type\IMMO-Fobik	Read PIN code, Sync smart key, Add key, Delete key, Modify	783
DODGE\Select from vehicle\North America\Dakota\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Asia\Avenger\2008-2014\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\Asia\Caliber\2007-2012\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\Asia\Caravan\2001-2003\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\Asia\Caravan\2004-2007\Immobilizer	Add key, Delete key,	1489
DODGE\Select from vehicle\Asia\Caravan\2008-2009\FOBTK\Type	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\Asia\Caravan\2010-2019\FOBTK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Asia\Caravan\2010-2019\Keyless-go (sync	Sync smart function,	1493
DODGE\Select from vehicle\Asia\Challenger\2008-2014\Immobilizer	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Asia\Challenger\2008-2014\Keyless-	Sync smart function,	1493
DODGE\Select from vehicle\Asia\Charger\2005-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\Asia\Charger\2006-2007\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Asia\Charger\2008\FOBTK	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\Asia\Charger\2008\Keyless-go (sync	Sync smart function,	1493
DODGE\Select from vehicle\Asia\Charger\2009-2010\FOBTK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Asia\Charger\2009-2010\Keyless-go (sync	Sync smart function,	1493
DODGE\Select from vehicle\Asia\Dakota\2005-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\Asia\Dakota\2007-2009\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Asia\Dakota\2009-2012\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Asia\Durango\2001-2003\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274

DODGE

DODGE\Select from vehicle\Asia\Durango\2004-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key, Key count, Read PIN	1483
DODGE\Select from vehicle\Asia\Durango\2007-2009\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Asia\Grand Caravan\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Asia\Grand Caravan\2004-	Add key, Delete key,	1489
DODGE\Select from vehicle\Asia\Grand Caravan\2008-	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\Asia\Grand Caravan\2010-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\Asia\Interpid\1997-2004\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Asia\Journey\2008-2010\FORTR	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\Asia\Magnum\2005-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key, Key count, Read PIN	1483
DODGE\Select from vehicle\Asia\Magnum\2006-2007\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Asia\Magnum\2008-2010\FORTR	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\Asia\Neon\2000-2005\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Asia\Neon\2005-\Immobilizer	Add new key, Add old key, Add remote, Delete key, Key count, Read PIN	1483
DODGE\Select from vehicle\Asia\Neon\2005-\Remote	Add remote,	270
DODGE\Select from vehicle\Asia\Nitro\2007-2011\Immobilizer	Read PIN code, Add new key, Delete key, Key count, Add old key	264
DODGE\Select from vehicle\Asia\Ram\2002-2005\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Asia\Stratus\4 door\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Asia\Dakota\2001-2004\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Europe\Avenger\2008-2014\Immobilizer	Read PIN code, Add new key, Delete key, Key count, Add old key	264
DODGE\Select from vehicle\Europe\Caliber\2007-2012\Immobilizer	Read PIN code, Add new key, Delete key, Key count, Add old key	264
DODGE\Select from vehicle\Europe\Caravan\2001-2003\Immobilizer	Read PIN code, Add new key, Delete key, Key count, Add old key	264

DODGE\Select from vehicle\Europe\Caravan\2001-2003\Remote	Add remote,	272
DODGE\Select from vehicle\Europe\Caravan\2004-2007\Immobilizer	Add key, Delete key,	1489
DODGE\Select from vehicle\Europe\Caravan\2008-2009\FORIK\Type	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\Europe\Challenger\2008-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\Europe\Challenger\2008-2014\Keyless-	Sync smart function,	1493
DODGE\Select from vehicle\Europe\Charger\2005-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key, Key count, Read PIN	1483
DODGE\Select from vehicle\Europe\Charger\2006-2007\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Europe\Charger\2008\FORIK	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\Europe\Charger\2008\Keyless-go(sync	Sync smart function,	1493
DODGE\Select from vehicle\Europe\Charger\2009-2010\FORIK	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\Europe\Charger\2009-2010\Keyless-	Sync smart function,	1493
DODGE\Select from vehicle\Europe\Dakota\2001-2004\Remote	Add remote,	804
DODGE\Select from vehicle\Europe\Dakota\2005-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key, Key count, Read PIN	1483
DODGE\Select from vehicle\Europe\Dakota\2007-2009\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Europe\Dakota\2009-2012\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Europe\Durango\2001-2003\Immobilizer	Add key, Delete key, Key count, Read PIN code (ORD), Read PIN	274
DODGE\Select from vehicle\Europe\Durango\2001-2003\Remote	Add remote,	804
DODGE\Select from vehicle\Europe\Durango\2004-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key, Key count, Read PIN	1483
DODGE\Select from vehicle\Europe\Durango\2007-2009\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Europe\Grand Caravan\2001-	Add key, Delete key, Key count, Read PIN code (ORD), Read PIN	274
DODGE\Select from vehicle\Europe\Grand Caravan\2004-	Add key, Delete key,	1489



DODGE\Select from vehicle\Europe\Grand Caravan\2008-	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\Europe\Interpid\1997-2004\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Europe\Interpid\1997-2004\Remote	Add remote,	803
DODGE\Select from vehicle\Europe\Journey\2008-2010\FORIK	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\Europe\Journey\2011-2014\Smart key	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Europe\Magnum\2005-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\Europe\Magnum\2006-2007\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Europe\Magnum\2008-2010\FORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Europe\Neon\2000-2005\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Europe\Neon\2000-2005\Remote	Add remote,	270
DODGE\Select from vehicle\Europe\Neon\2005-\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\Europe\Neon\2005-\Remote	Add remote,	270
DODGE\Select from vehicle\Europe\Nitro\2007-2011\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\Europe\Ram\2002-2005\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Europe\Ram\2002-2005\Remote	Add remote,	805
DODGE\Select from vehicle\Europe\Ram\2006-2008\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\Europe\Ram\2009-2012\FORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Europe\Stratus\2001-2006\4	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Europe\Stratus\2001-2006\4 door\Remote	Add remote,	803
DODGE\Select from vehicle\Europe\Dakota\2001-2004\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\South America\Avenger\2008-	Read PIN code, Add new key, Delete key, Key count Add old key	264

DODGE\Select from vehicle\South America\Caliber\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\South America\Caravan\2001-	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\South America\Caravan\2001-	Add remote,	272
DODGE\Select from vehicle\South America\Caravan\2004-	Add key, Delete key,	1489
DODGE\Select from vehicle\South America\Caravan\2008-	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\South America\Challenger\2008	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\South America\Challenger\2008	Sync smart function,	1493
DODGE\Select from vehicle\South America\Charger\2005-	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\South America\Charger\2006-	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\South America\Charger\2008\VE0	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\South America\Charger\2008\Ke	Sync smart function,	1493
DODGE\Select from vehicle\South America\Charger\2009-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\South America\Charger\2009-	Sync smart function,	1493
DODGE\Select from vehicle\South America\Dakota\2001-	Add remote,	804
DODGE\Select from vehicle\South America\Dakota\2005-	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\South America\Dakota\2007-	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\South America\Dakota\2009-	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\South America\Durango\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\South America\Durango\2001-	Add remote,	804
DODGE\Select from vehicle\South America\Durango\2004-	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\South America\Durango\2007-	Add key, Delete key, Key count, Add remote, Read PIN code	267

DODGE\Select from vehicle\South America\Grand	Add key, Delete key, Key count, Read PIN code (ORD) Read PIN	274
DODGE\Select from vehicle\South America\Grand	Add key, Delete key,	1489
DODGE\Select from vehicle\South America\Grand	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\South America\Internid\1997-	Add key, Delete key, Key count, Read PIN code (ORD) Read PIN	274
DODGE\Select from vehicle\South America\Internid\1997-	Add remote,	803
DODGE\Select from vehicle\South America\Journey\2008-	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\South America\Journey\2011-	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\South America\Magnum\2005-	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\South America\Magnum\2006-	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\South America\Magnum\2008-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\South America\Neon\2000-	Add key, Delete key, Key count, Read PIN code (ORD) Read PIN	274
DODGE\Select from vehicle\South America\Neon\2000-	Add remote,	270
DODGE\Select from vehicle\South America\Neon\2005-	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\South America\Neon\2005-	Add remote,	270
DODGE\Select from vehicle\South America\Nitro\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\South America\Ram\2002-	Add key, Delete key, Key count, Read PIN code (ORD) Read PIN	274
DODGE\Select from vehicle\South America\Ram\2002-	Add remote,	805
DODGE\Select from vehicle\South America\Ram\2006-	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\South America\Ram\2009-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\South America\Stratus\2001-	Add key, Delete key, Key count, Read PIN code (ORD) Read PIN	274
DODGE\Select from vehicle\South America\Stratus\2001-	Add remote,	803

DODGE\Select from vehicle\South America\Dakota\2001-	Add key, Delete key, Key count, Read PIN code (ORD) Read PIN	274
DODGE\Select from vehicle\Middle East\Avenger\2008-	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\Middle East\Caliber\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\Middle East\Caravan\2001-	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\Middle East\Caravan\2001-	Add remote,	272
DODGE\Select from vehicle\Middle East\Caravan\2004-	Add key, Delete key,	1489
DODGE\Select from vehicle\Middle East\Caravan\2008-	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\Middle East\Challenger\2008-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Middle East\Challenger\2008-	Sync smart function,	1493
DODGE\Select from vehicle\Middle East\Charger\2005-	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\Middle East\Charger\2006-	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Middle East\Charger\2008\FORIK	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\Middle East\Charger\2008\Keyle	Sync smart function,	1493
DODGE\Select from vehicle\Middle East\Charger\2009-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Middle East\Charger\2009-	Sync smart function,	1493
DODGE\Select from vehicle\Middle East\Dakota\2001-	Add remote,	804
DODGE\Select from vehicle\Middle East\Dakota\2005-	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\Middle East\Dakota\2007-	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Middle East\Dakota\2009-	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Middle East\Durango\2001-	Add key, Delete key, Key count, Read PIN code (ORD) Read PIN	274
DODGE\Select from vehicle\Middle East\Durango\2001-	Add remote,	804

DODGE\Select from vehicle\Middle East\Durango\2004-	Add new key, Add old key, Add remote, Delete key, Key count, Read PIN	1483
DODGE\Select from vehicle\Middle East\Durango\2007-	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Middle East\Grand	Add key, Delete key, Key count, Read PIN code (OBD), Read PIN	274
DODGE\Select from vehicle\Middle East\Grand	Add key, Delete key,	1489
DODGE\Select from vehicle\Middle East\Grand	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\Middle East\Intrepid\1997-	Add key, Delete key, Key count, Read PIN code (OBD), Read PIN	274
DODGE\Select from vehicle\Middle East\Intrepid\1997-	Add remote,	803
DODGE\Select from vehicle\Middle East\Journey\2008-	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\Middle East\Journey\2011-	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Middle East\Magnum\2005-	Add new key, Add old key, Add remote, Delete key, Key count, Read PIN	1483
DODGE\Select from vehicle\Middle East\Magnum\2006-	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Middle East\Magnum\2008-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\Middle East\Neon\2000-	Add key, Delete key, Key count, Read PIN code (OBD), Read PIN	274
DODGE\Select from vehicle\Middle East\Neon\2000-	Add remote,	270
DODGE\Select from vehicle\Middle East\Neon\2005-	Add new key, Add old key, Add remote, Delete key, Key count, Read PIN	1483
DODGE\Select from vehicle\Middle East\Neon\2005-\Remote	Add remote,	270
DODGE\Select from vehicle\Middle East\Nitro\2007-	Read PIN code, Add new key, Delete key, Key count, Add old key	264
DODGE\Select from vehicle\Middle East\Ram\2002-	Add key, Delete key, Key count, Read PIN code (OBD), Read PIN	274
DODGE\Select from vehicle\Middle East\Ram\2002-	Add remote,	805
DODGE\Select from vehicle\Middle East\Ram\2006-	Read PIN code, Add new key, Delete key, Key count, Add old key	264
DODGE\Select from vehicle\Middle East\Ram\2009-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266

DODGE\Select from vehicle\Middle East\Stratus\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Middle East\Stratus\2001-	Add remote,	803
DODGE\Select from vehicle\Middle East\Dakota\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Australia\Avenger\2008-	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\Australia\Caliber\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\Australia\Caravan\2001-	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\Australia\Caravan\2001-2003\Remote	Add remote,	272
DODGE\Select from vehicle\Australia\Caravan\2004-	Add key, Delete key,	1489
DODGE\Select from vehicle\Australia\Caravan\2008-2009\FORIK\Type	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\Australia\Challenger\2008-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Australia\Challenger\2008-	Sync smart function,	1493
DODGE\Select from vehicle\Australia\Charger\2005-	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\Australia\Charger\2006-	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Australia\Charger\2008\FORIK	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\Australia\Charger\2008\KeyLess-go (sync	Sync smart function,	1493
DODGE\Select from vehicle\Australia\Charger\2009-2010\FORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Australia\Charger\2009-2010\KeyLess-	Sync smart function,	1493
DODGE\Select from vehicle\Australia\Dakota\2001-2004\Remote	Add remote,	804
DODGE\Select from vehicle\Australia\Dakota\2005-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\Australia\Dakota\2007-2009\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Australia\Dakota\2009-2012\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267

DODGE\Select from vehicle\Australia\Durango\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Australia\Durango\2001-2003\Remote	Add remote,	804
DODGE\Select from vehicle\Australia\Durango\2004-	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\Australia\Durango\2007-	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Australia\Grand Caravan\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Australia\Grand Caravan\2004-	Add key, Delete key,	1489
DODGE\Select from vehicle\Australia\Grand Caravan\2008-	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\Australia\Intermidia\1997-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Australia\Intermidia\1997-2004\Remote	Add remote,	803
DODGE\Select from vehicle\Australia\Journey\2008-2010\FORIK	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\Australia\Journey\2011-2014\Smart key	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Australia\Magnum\2005-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\Australia\Magnum\2006-2007\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Australia\Magnum\2008-2010\FORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Australia\Neon\2000-2005\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Australia\Neon\2000-2005\Remote	Add remote,	270
DODGE\Select from vehicle\Australia\Neon\2005-\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\Australia\Neon\2005-\Remote	Add remote,	270
DODGE\Select from vehicle\Australia\Nitro\2007-2011\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\Australia\Ram\2002-2005\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Australia\Ram\2002-2005\Remote	Add remote,	805

DODGE\Select from vehicle\Australia\Ram\2006-2008\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\Australia\Ram\2009-2012\FORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Australia\Stratus\2001-2006\4	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Australia\Stratus\2001-2006\4	Add remote,	803
DODGE\Select from vehicle\Australia\Dakota\2001-2004\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Africa\Avenger\2008-2014\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\Africa\Caliber\2007-2012\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\Africa\Caravan\2001-2003\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\Africa\Caravan\2001-2003\Remote	Add remote,	272
DODGE\Select from vehicle\Africa\Caravan\2004-2007\Immobilizer	Add key, Delete key,	1489
DODGE\Select from vehicle\Africa\Caravan\2008-2009\FORIK\Type	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\Africa\Challenger\2008-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Africa\Challenger\2008-2014\Keyless-	Sync smart function,	1493
DODGE\Select from vehicle\Africa\Charger\2005-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\Africa\Charger\2006-2007\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Africa\Charger\2008\FORIK	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\Africa\Charger\2008\Keyless-go (sync	Sync smart function,	1493
DODGE\Select from vehicle\Africa\Charger\2009-2010\FORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Africa\Charger\2009-2010\Keyless-	Sync smart function,	1493
DODGE\Select from vehicle\Africa\Dakota\2001-2004\Remote	Add remote,	804
DODGE\Select from vehicle\Africa\Dakota\2005-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483



DODGE\Select from vehicle\Africa\Dakota\2007-2009\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Africa\Dakota\2009-2012\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Africa\Durango\2001-2003\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Africa\Durango\2001-2003\Remote	Add remote,	804
DODGE\Select from vehicle\Africa\Durango\2004-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\Africa\Durango\2007-2009\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Africa\Grand Caravan\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Africa\Grand Caravan\2004-	Add key, Delete key,	1489
DODGE\Select from vehicle\Africa\Grand Caravan\2008-	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\Africa\Interpid\1997-2004\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Africa\Interpid\1997-2004\Remote	Add remote,	803
DODGE\Select from vehicle\Africa\Journey\2008-2010\FORIK	Read pin code, Add key, Delete key, Key count	265
DODGE\Select from vehicle\Africa\Journey\2011-2014\Smart key	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Africa\Magnum\2005-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\Africa\Magnum\2006-2007\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
DODGE\Select from vehicle\Africa\Magnum\2008-2010\FORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Africa\Neon\2000-2005\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Africa\Neon\2000-2005\Remote	Add remote,	270
DODGE\Select from vehicle\Africa\Neon\2005-\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
DODGE\Select from vehicle\Africa\Neon\2005-\Remote	Add remote,	270
DODGE\Select from vehicle\Africa\Nitro\2007-2011\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264

DODGE\Select from vehicle\Africa\Ram\2002-2005\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Africa\Ram\2002-2005\Remote	Add remote,	805
DODGE\Select from vehicle\Africa\Ram\2006-2008\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\Africa\Ram\2009-2012\FORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Africa\Stratus\2001-2006\4	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\Africa\Stratus\2001-2006\4 door\Remote	Add remote,	803
DODGE\Select from vehicle\Africa\Dakota\2001-2004\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from type\Immobilizer\Type 9 (CAN)	Key count, Program key, Delete key, Program remote	1304
DODGE\Select from type\Smart key\Type 6 (CAN)	Read PIN code, Add key, Delete key,	788
DODGE\Select from vehicle\Asia\Ram\2006-2008\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
DODGE\Select from vehicle\Asia\Ram\2009-2012\FORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
DODGE\Select from vehicle\Asia\Journey\2011-2014\Smart key	Add smart key, Delete smart key, Read PIN code	268
DODGE\Select from vehicle\Asia\Ram\2013-2017\Smart key	Add smart key, Delete smart key, Read PIN code	1494
DODGE\Select from type\Smart key\Type 7 (CAN)	Read PIN code, Add smart key, Delete smart key,	990
DODGE\Select from type\Smart key\Type 8 (CAN)\Keyless-go	Read pin code, Add key, Delete key,	396
DODGE\Select from type\Smart key\Type 8 (CAN)\Mechanical key	Read pin code, Add key, Delete key,	395
DODGE\Select from type\Remote\Type 9 (VPW)	Program remote,	1737
DODGE\Select from vehicle\Asia\Ram Pickup\2002-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
DODGE\Select from vehicle\North America\Grand	Read PIN code, Sync smart key, Add key Delete key Modify	783
DODGE\Select from vehicle\North America\Charger\2005-	Add new key, Add old key, Add remote, Detect key count Delete key	263
DODGE\Select from vehicle\North America\Journey\2018-	Add smart key, Delete smart key, Read PIN code	268

DODGE\Select from vehicle\Asia\Caravan\2008-2009\FORIK\Type	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\North America\Caravan\2008-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\Europe\Caravan\2008-2009\FORIK\Type	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\South America\Caravan\2008-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\Middle East\Caravan\2008-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\Australia\Caravan\2008-2009\FORIK\Type	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
DODGE\Select from vehicle\Africa\Caravan\2008-2009\FORIK\Type	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
RENAULT\Select from vehicle\Symbol\Symbol. \Type 1	Add key,	1140
RENAULT\Select from vehicle\Thalia\Thalia. \Type 1	Add key,	1140
RENAULT\Select from vehicle\Trafic\Trafic II Ph2	Add key,	1141
RENAULT\Select from vehicle\Master\Master.	Add key,	1141
RENAULT\Select from vehicle\Primastar\Primastar	Add key,	1141
RENAULT\Select from vehicle\Clio\Clio II Ph2	Add key,	1141
RENAULT\Select from vehicle\Kangoo\Kangoo I	Add key,	1141
RENAULT\Select from vehicle\Symbol\Symbol. \Type 2	Program key,	1142
RENAULT\Select from vehicle\Thalia\Thalia. \Type 2	Program key,	1142
RENAULT\Select from vehicle\Dacia\Duster\2010-2012	Program key,	1142
RENAULT\Select from vehicle\Laguna\Laguna II	Add key,	1144
RENAULT\Select from vehicle\Espace\Espace IV	Add key,	1144
RENAULT\Select from vehicle\Laguna\Laguna II Ph2	Add key,	1145
RENAULT\Select from vehicle\Espace\Espace IV Ph2	Add key,	1145

RENAULT\Select from vehicle\Clio\CLIO III \Without smart	Add key,	1149
RENAULT\Select from vehicle\Modus\Modus. \Without smart	Add key,	1149
RENAULT\Select from vehicle\Clio\CLIO III \With smart	Add key,	1146
RENAULT\Select from vehicle\Trafic\Trafic II Ph3 \2010-2014	Add key, Revise VIN code, Clear fault code,	1150
RENAULT\Select from vehicle\Master\Master III\2010-2015	Add key, Revise VIN code, Clear fault code,	1150
RENAULT\Select from vehicle\Wind\2010-2013.	Add key,	1147
RENAULT\Select from type\All\Type 0	Add key,	1140
RENAULT\Select from type\All\Type 1	Add key,	1141
RENAULT\Select from type\All\Type 2	Program key,	1142
RENAULT\Select from type\All\Type 3	Add key,	1144
RENAULT\Select from type\All\Type 4	Add key,	1145
RENAULT\Select from type\All\Type 5	Add key,	1149
RENAULT\Select from type\All\Type 6	Add key,	1146
RENAULT\Select from type\All\Type 7	Add key, Revise VIN code, Clear fault code,	1150
RENAULT\Select from type\All\Type 8	Add key,	1147
RENAULT\Select from type\All\Type 9	Program key,	1148
RENAULT\Select from type\All\Type A	Add key,	1153
RENAULT\Select from type\All\Type B	Read PIN code, Program key, Recover backup data	1197
RENAULT\Select from vehicle\Trafic\Trafic III (4A) \2014-\System 1	Read PIN code, Program key, Recover backup data	1197
RENAULT\Select from vehicle\Clio\Clio IV \2012-	Add key, Recover data, All key lost, Make dealer key	1202
RENAULT\Select from vehicle\Captur	Add key, Recover data, All key lost, Make dealer key	1202

RENAULT\Select from vehicle\Symbol\2013-2018	Program key, Read PIN code, Read key count,	1207
RENAULT\Select from vehicle\Dacia\Logan\2013-	Program key, Read PIN code, Read key count,	1207
RENAULT\Select from vehicle\Trafic\Trafic III (4A)\2014-\System 2	Program key,	1695
RENAULT\Select from vehicle\Twingo\Twingo III	Read PIN code, Recover backup data, Program key	1699
RENAULT\Select from vehicle\Espace\2015-\Smart key	Program smart key, Make dealer key,	1702
RENAULT\Select from vehicle\Espace\2015-\Mechanical key	Program key, Make dealer key,	1704
RENAULT\Select from vehicle\Megane\Megane IV \2015-\Smart key	Program smart key, Make dealer key,	1702
RENAULT\Select from vehicle\Megane\Megane IV \2015-\Mechanical key	Program key, Make dealer key,	1704
RENAULT\Select from vehicle\Scenic\Scenic IV \2015-\Mechanical key	Program key, Make dealer key,	1704
RENAULT\Select from vehicle\Scenic\Scenic IV \2015-\Smart key	Program smart key, Make dealer key,	1702
RENAULT\Select from vehicle\Dacia\Dokker\2012-	Program key, Read PIN code, Read key count,	1207
RENAULT\Select from vehicle\Dacia\Duster\2013-	Program key, Read PIN code, Read key count,	1207
RENAULT\Select from vehicle\Dacia\Solenza	Add key,	1141
RENAULT\Select from vehicle\Dacia\Lodgy\2013-	Program key, Read PIN code, Read key count,	1207
RENAULT\Select from vehicle\Dacia\Sandero\2013-	Program key, Read PIN code, Read key count,	1207
RENAULT\Select from vehicle\Trafic\Trafic III (4A)\2014-\System 3	Read PIN code, Recover backup data, Program key	1699
RENAULT\Select from vehicle\Koleos\2016-\Mechanical key	Read DFLASH, Add key, Make dealer key, All key lost Unlock key	1980
RENAULT\Select from vehicle\Koleos\2016-\Smart key	Read DFLASH, Add smart key, All smart key lost Make dealer	1995
RENAULT\Select from vehicle\Kadjar\2016-\Mechanical key	Read DFLASH, Add key, Make dealer key, All key lost Unlock key	1980
RENAULT\Select from vehicle\Kadjar\2016-\Smart key	Read DFLASH, Add smart key, All smart key lost Make dealer	1995
RENAULT\Select from type\Smart key\IMMO2	Program smart key, Collision recovery,	208

RENAULT

RENAULT\Select from type\Smart key\IMM01	Program smart key, Collision recovery,	207
RENAULT\Select from vehicle\Fluence\2008 - \Smart key	Program key,	895
RENAULT\Select from vehicle\Clio\1997-1999	Set IMMO unit, Initialize new immobilizer	906
RENAULT\Select from vehicle\Clio\2000-2008 VIN with VE1*B	Program key,	907
RENAULT\Select from vehicle\Clio\2006-2012 VIN with VE1*R\With	Program smart key,	908
RENAULT\Select from vehicle\Clio\2006-2012 VIN with VE1*R\Without	Program key,	909
RENAULT\Select from vehicle\Espace\2002- VIN with VE1*K\2	Program smart key,	911
RENAULT\Select from vehicle\Espace\2002- VIN with VE1*K\3	Program smart key,	910
RENAULT\Select from vehicle\Kangoo\1999-2002\Type 1	Set IMMO unit,	912
RENAULT\Select from vehicle\Kangoo\1999-2002\Type 2	Set IMMO unit, Initialize new immobilizer	906
RENAULT\Select from vehicle\Kangoo\2003-2008 VIN with VE1*C	Program key,	907
RENAULT\Select from vehicle\Koleos\2008-2010 VIN with VE1*V	Program smart key,	914
RENAULT\Select from vehicle\Laguna\ -2007/2007 VIN with	Program smart key,	911
RENAULT\Select from vehicle\Laguna\ -2007/2007 VIN with	Program smart key,	910
RENAULT\Select from vehicle\Laguna\2007-2011 VIN with VE1*T	Program smart key,	914
RENAULT\Select from vehicle\Master\ -2003	Set IMMO unit, Initialize new immobilizer	906
RENAULT\Select from vehicle\Master\2003-2010 VIN (VE1*D)	Program key,	907
RENAULT\Select from vehicle\Maxity	Read BCM, Program remote, Delete remote,	915
RENAULT\Select from vehicle\Megane\2002-2008 VIN with VE1*M	Program smart key,	916
RENAULT\Select from vehicle\Megane\02-08 (Q3VLM)	Program smart key,	916
RENAULT\Select from vehicle\Megane\2008 -	Program key,	895

RENAULT\Select from vehicle\Scenic\2002-2006 VIN with VF1*M	Program smart key,	916
RENAULT\Select from vehicle\Scenic\2006-2009 VIN with VF1*M	Program smart key,	910
RENAULT\Select from vehicle\Scenic\2008-2011	Program key,	895
RENAULT\Select from vehicle\Modus\2004-2012 VIN with VF1*P\Without	Program key,	909
RENAULT\Select from vehicle\Modus\2004-2012 VIN with VF1*P\With	Program smart key, Program remote Delete remote	917
RENAULT\Select from vehicle\Safrane\2008-VIN with VF1AR\Smart	Program smart key,	914
RENAULT\Select from vehicle\Scala\2011-	Read BCM, Program key, Program remote Delete remote	918
RENAULT\Select from vehicle\Trafic\2002-VIN with VF1*I	Program key,	907
RENAULT\Select from vehicle\Trafic\2002	Set IMMO unit, Initialize new immobilizer	906
RENAULT\Select from vehicle\Twingo\2007 VIN with VF1*O\Type 1	Set IMMO unit,	912
RENAULT\Select from vehicle\Twingo\2007 VIN with VF1*O\Type 2	Set IMMO unit, Initialize new immobilizer	906
RENAULT\Select from vehicle\Twingo\2007-VIN with VF1*N	Program key,	919
RENAULT\Select from vehicle\Velsatis\2002-2010 VIN with VF1*I\2	Program smart key,	911
RENAULT\Select from vehicle\Velsatis\2002-2010 VIN with VF1*I\3	Program smart key,	910
RENAULT\Select from vehicle\Wind\2010- VIN with VF1*N	Program key,	919
RENAULT\Select from vehicle\Safrane\ (KNMG4) 2009-\Ignition switch	Read BCM, Program key, Program remote Delete remote	918
RENAULT\Select from vehicle\Koleos\2010-2016 VIN with VF1*Y	Program smart key, Collision recovery,	208
RENAULT\Select from vehicle\Latitude	Program key,	948
RENAULT\Select from vehicle\Scenic\1999-2002	Read PIN code, Program key,	1139
RENAULT\Select from vehicle\Scenic\2008	Program key,	1148
RENAULT\Select from vehicle\Twingo\Twingo I Ph3 \2001-2006	Add key,	1140

RENAULT\Select from vehicle\Velsatis\2005-	Add key,	1144
RENAULT\Select from vehicle\Velsatis\2005-	Add key,	1145
RENAULT\Select from vehicle\Kangoo\Kangoo II \2007-2012	Add key,	1141
RENAULT\Select from vehicle\Twingo\Twingo II \2007-2014	Add key,	1147
RENAULT\Select from vehicle\Laguna\Laguna III \2007-2015	Add key,	1153
RENAULT\Select from vehicle\Megane\Megane III \2009-2015	Add key,	1154
RENAULT\Select from vehicle\Fluence\2009-2015	Add key,	1154
RENAULT\Select from vehicle\Koleos\2008 -.	Add key,	1156
RENAULT\Select from vehicle\Scenic\Scenic III (2009-2015)	Add key,	1154
RENAULT\Select from vehicle\Avantime\2001-2003	Add key,	1141
RENAULT\Select from vehicle\Kangoo\Kangoo II \2007-2012 (VEI*W)	Add key, Revise VIN code, Clear fault code,	1150
RENAULT\Select from vehicle\Megane\Megane CC \-2008	Program key,	1148
RENAULT\Select from vehicle\Dacia\Sandero stepway\2006-2011	Add key,	1140
RENAULT\Select from vehicle\Dacia\Sandero\2007-2012	Add key,	1140
RENAULT\Select from vehicle\Dacia\LOGAN\2004-2012	Add key,	1140
RENAULT\Select from vehicle\Dacia\LOGAN (MA1 IS)\2006-2009	Add key,	1140
RENAULT\Select from vehicle\Fluence\2008 - \Mechanical key	Program key,	1707
RENAULT\Modify VIN code	Modify VIN code,	1914
SUZUKI\China\Swift\2015 -\Type 3\Smart key	Program smart key,	1953
SUZUKI\China\Swift\2005 -	All key lost,	252
SUZUKI\China\Vitara\Immobilizer\Type 1	All key lost,	252



## SUZUKI

SUZUKI\China\Vitara\Immobilizer\Type 2	Program key, Obtain immoID,	255
SUZUKI\China\Alto\Immobilizer	Program key, Obtain immoID,	255
SUZUKI\China\SX4\Immobilizer	Program key, Obtain immoID,	255
SUZUKI\China\Vitara\Immobilizer\Type 3	Program key, Read immoID, Program key (without PIN)	258
SUZUKI\China\Vitara\Smart key\Type 1	Program smart key (PIN required), Program smart key (without	259
SUZUKI\China\Alivio\Smart key	Program smart key (PIN required), Program smart key (without	259
SUZUKI\China\Alivio\Immobilizer	Program key, Read immoID, Program key (without PIN)	258
SUZUKI\China\Liana\Immobilizer\Type 1	All key lost,	252
SUZUKI\China\S-Cross\Smart key	Program smart key (PIN required), Program smart key (without	259
SUZUKI\China\Jimny\Immobilizer\Type 1	Program key, Delete key, Register immobiliser	260
SUZUKI\Japan\Ignis\Immobilizer	Program key, Delete key, Register immobiliser	260
SUZUKI\China\Liana\Immobilizer\Type 2	Program key, Delete key, Register immobiliser	260
SUZUKI\China\Jimny\Immobilizer\Type 2	All key lost,	252
SUZUKI\China\Swift\2012-	Program smart key (PIN required), Program smart key (without	259
SUZUKI\USA\XL7 (USA) \2007-2009\Immobilizer	All key lost,	792
SUZUKI\China\Swift\2015-\Type 1	Program key, Read immoID, Program key (without PIN)	258
SUZUKI\Japan\Baleno\Immobilizer\1996-2001	Program key, Delete ey,	992
SUZUKI\China\Kizashi\Smart key	Program smart key (PIN required), Program smart key (without	259
SUZUKI\Japan\Wagon R\Immobilizer\1998-	Program key, Delete key, Register immobiliser	260
SUZUKI\China\Swift\2015-\Type 2	All key lost,	252
SUZUKI\Japan\Swift\Immobilizer\1996-2004	Program key, Delete ey,	992

SUZUKI\Japan\Alto\Immobilizer\1996-2002	Program key, Delete ey,	992
SUZUKI\Japan\Grand Vitara\Immobilizer\1996-2002	Program key, Delete ey,	992
SUZUKI\Japan\Grand Vitara\Immobilizer\2002-	Program key, Delete ey,	992
SUZUKI\Japan\Vitara\Immobilizer\1996-2002	Program key, Delete ey,	992
SUZUKI\Japan\Vitara\Immobilizer\2002-	Program key, Delete ey,	992
SUZUKI\Japan\Jimmy\Immobilizer	Program key, Delete ey,	992
SUZUKI\China\New Alto	Program key, Obtain immo ID,	1031
SUZUKI\China\Xiao Tu\Smart key	Program smart key (PIN required), Program smart key (without	259
FORD\USA\C-MAX\Immobilizer\2014-	Add key, Delete key, All key lost,	201
FORD\USA\Edge\Smart key\2015-2019	Add smart key, All smart key lost,	812
FORD\USA\Escape\Immobilizer\2014-2019	Add key, Delete key, All key lost,	201
FORD\USA\Expedition\2015-2017\Immobilizer	Delete key, Add key, Read key count,	179
FORD\USA\Expedition\2015-2017\Smart key	Erase smart key, Add smart key, Read smart key count,	278
FORD\USA\Explorer\2016-2019\Smart key	Add smart key, All smart key lost,	812
FORD\USA\Focus\Immobilizer\2014-2018	Add key, Delete key, All key lost,	201
FORD\USA\Fusion\2013-2019\Smart key	Add smart key, All smart key lost,	812
FORD\USA\F-150\2015-2017\Smart key	Add smart key, All smart key lost,	812
FORD\USA\F-150\2018-2020\Immobilizer	Add key, Delete key, Read key count,	1188
FORD\USA\F-250\2017-2019\Immobilizer	Add key, Delete key, Read key count,	1188
FORD\USA\F-250\2017-2019\Smart key	Add smart key, All smart key lost,	811
FORD\USA\F-350\2017-2019\Immobilizer	Add key, Delete key, Read key count,	1188

FORD\USA\F-550\2017-2019\Immobilizer	Add key, Delete key, Read key count,	1188
FORD\USA\Mustang\2015-2019\Smart key	Add smart key, All smart key lost,	812
FORD\USA\Ranger\2017\Immobilizer	Read key count, Add key, All key lost,	841
FORD\USA\Taurus\Immobilizer\2013-2018	Delete key, Add key, Read key count,	179
FORD\USA\Transit T250\2015-\Immobilizer	Add key, Delete key, All key lost,	201
FORD\USA\Transit Connect\2014-2018\Immobilizer\Type 1	Add key, Delete key, All key lost,	201
FORD\Europe\Transit Custom\2014-\Immobilizer	Key count, Delete key, Add key,	1521
FORD\Europe\Transit\2014-\Immobilizer	Key count, Delete key, Add key,	1521
FORD\Europe\Tourneo Custom\2014-\Immobilizer	Key count, Delete key, Add key,	1521
FORD\Europe\Focus\2015-2016\Immobilizer	Add key, Delete key, All key lost,	201
FORD\Europe\C-Max\2015-2016\Immobilizer	Add key, Delete key, All key lost,	201
FORD\Europe\Vignale\2015-\Smart key	Read key count, Add key, All key lost,	841
FORD\Europe\Transit Custom\2017-\Immobilizer	Read key count, Add key, All key lost,	841
FORD\Europe\S-Max\2015-\Smart key	Read key count, Add key, All key lost,	841
FORD\Europe\Mustang\2015-\Smart key	Read key count, Add key, All key lost,	841
FORD\Europe\Mondeo\2015-\Immobilizer	Read key count, Add key, All key lost,	841
FORD\Europe\Mondeo\2015-\Smart key	Read key count, Add key, All key lost,	841
FORD\Europe\Galaxy\2015\Smart key	Read key count, Add key, All key lost,	841
FORD\Africa\Transit\2014-	Key count, Delete key, Add key,	1521
FORD\China\Explorer\2017-\Smart key	Add smart key, All smart key lost,	811
FORD\South America\F350\2017\Cummins (diesel)	Key count, Delete key,	1575

FORD\Europe\Tourneo Courier\2014-\Immobilizer	Add key, Delete key, All key lost,	1705
FORD\China\Transit\2013-\Immobilizer\Type 2	Key count, Delete key, Add key,	1521
FORD\China\Remote\Type 2(Transit 2014-)	Program remote,	1720
FORD\China\Tourneo\2014-\Immobilizer	Key count, Delete key, Add key,	1521
FORD\Europe\Kuga\2016-2018\Smart key	Add smart key, All smart key lost,	251
FORD\China\Everest\Smart key\2017-	Add smart key, All smart key lost,	811
FORD\China\Mustang\Smart key\2017-	Add smart key, All smart key lost,	811
FORD\China\Raptor F250\2017-\Smart key	Add smart key, All smart key lost,	811
FORD\China\Everest\Immobilizer\2017-	Add key, Delete key, Read key count,	1188
FORD\India\Aspire\2017-\Immobilizer	Add key, Delete key, Read key count,	1188
FORD\Europe\KA\2016-2018\Immobilizer	Key count, Add key, All key lost,	2018
FORD\USA\Expedition\2018-2019	Add smart key, All smart key lost,	812
FORD\USA\Explorer\2016-2019\Immobilizer	Key count, Add key, All key lost,	2018
FORD\USA\F-150\2018-2020\Smart key	Add smart key, All smart key lost,	812
FORD\USA\F-350\2017-2019\Smart key	Add smart key, All smart key lost,	812
FORD\USA\F-650\2016-2019\Immobilizer	Delete key, Add key, Read key count,	179
FORD\USA\Ranger\2019-2020\Immobilizer	Add key, Delete key, Read key count,	1188
FORD\USA\Ranger\2019-2020\Smart key	Add smart key, All smart key lost,	812
FORD\Europe\Transit\2017-\Immobilizer	Key count, Add key, All key lost,	2018
FORD\Europe\Tourneo Custom\2016-\Immobilizer	Key count, Add key, All key lost,	2018
FORD\Europe\Tourneo Connect\2015-2018\Immobilizer	Add key, Delete key, All key lost,	201

FORD\Europe\Ranger\2016-2019\Immobilizer	Key count, Add key, All key lost,	2018
FORD\Europe\Ranger\2019-2020\Smart key	Add smart key, All smart key lost,	812
FORD\USA\Focus\Smart key\2014-2018	Add smart key, All smart key lost,	251
FORD\USA\Escape\Smart key\2017-2018	Add smart key, All smart key lost,	251
FORD\China\New Mondeo\2017\Immobilizer	Add key, All key lost, Read key count,	83
FORD\China\New Mondeo\2017\Smart key	Add smart key, All smart key lost,	812
FORD\China\Escort\2017\Immobilizer	Add key, All key lost, Read key count,	83
FORD\China\Edge\2015-2017\Smart key	Add smart key, All smart key lost,	812
FORD\China\Mustang\Smart key\2017	Add smart key, All smart key lost,	812
FORD\China\Escape\2005-2007\Immobilizer	All key lost, Add key, Read key count,	136
FORD\China\Raptor F350\Immobilizer	Delete key, Add key, Read key count,	179
FORD\China\Transit\2000-2013\Immobilizer	Add key, Delete key, All key lost,	180
FORD\China\Mondeo CHIA-X\PEPS\Smart key	Smart key all lost, Add smart key,	189
FORD\China\Mondeo CHIA-X\IMMO\Type 2\Immobilizer	Add key, Delete key, All key lost,	186
FORD\China\Mondeo CHIA-X\IMMO\Type 1\Immobilizer	Add key, Delete key, All key lost,	184
FORD\China\Focus\Classic Focus\Type 1\Immobilizer	Add key, All key lost,	195
FORD\China\Focus\New Focus\2011-2013\Immobilizer	Add key, Delete key, All key lost,	200
FORD\China\Kuga\2015\Immobilizer	Add key, Delete key, All key lost,	201
FORD\China\Ecosport\Immobilizer	Add key, Delete key, All key lost,	202
FORD\China\Fiesta\IMMO\2013\Immobilizer	Add key, Delete key,	204
FORD\China\Focus\Classic Focus\Type 2\Immobilizer	Add key, Delete key, All key lost,	205

FORD\China\Mondeo\Immobilizer	All key lost, Read key count,	218
FORD\China\Ecosport\Smart key	All smart key lost, Add smart key,	222
FORD\China\Fiesta\PEPS\Smart key	All smart key lost, Add smart key,	222
FORD\China\Focus\New Focus\2014-\Immobilizer	Add key, Delete key, All key lost,	201
FORD\China\Explorer\2011-\Immobilizer	Delete key, Add key, Read key count,	179
FORD\China\Classic Focus\Type 2\Immobilizer	Add key, Delete key, All key lost,	205
FORD\China\Kuga\2015\Smart key	Add key, Delete key, All key lost, Add smart key, Delete smart key	246
FORD\China\Kuga\2016-\Smart key	Add smart key, All smart key lost,	251
FORD\China\Edge\2015\Smart key	Erase smart key, Add smart key, Read smart key count	278
FORD\China\Raptor F150\2011-2014\Immobilizer	Delete key, Add key, Read key count,	179
FORD\China\Raptor F150\2009-2010\Immobilizer	Add key, Delete key, Read key count, Sync PCM-PATS	428
FORD\China\Raptor F250\2009-2010\Immobilizer	Add key, Delete key, Read key count, Sync PCM-PATS	428
FORD\China\Everest\Smart key\2017	Add smart key, All smart key lost,	812
FORD\China\Classic Focus\Type 1\Immobilizer	Add key, All key lost,	195
FORD\China\Explorer\2015-\Smart key	Add smart key, All smart key lost,	812
FORD\China\Taurus\2015-2016\Smart key	Add smart key, All smart key lost,	812
FORD\China\Everest\Immobilizer\2017	Add key, All key lost, Read key count,	83
FORD\China\S-MAX\IMMO\Type 2\Immobilizer	Add key, Delete key, All key lost,	186
FORD\China\S-MAX\IMMO\Type 1\Immobilizer	Add key, Delete key, All key lost,	184
FORD\China\Focus\New Focus\2011-2013\Smart key	Add key, Delete key, All key lost, Add smart key, Delete smart key	246
FORD\China\Fiesta\IMMO\2013-\Immobilizer	Add key, Delete key, All key lost,	202

FORD\China\New Mondeo\2017-\Smart key	Add smart key,All smart key lost,	811
FORD\China\Taurus\2017-\Smart key	Add smart key,All smart key lost,	811
FORD\China\Ranger\2007-2010\Immobilizer	Read key numbers,Add key,All key lost,	831
FORD\China\Ranger\2015\Immobilizer	Add key,Delete key,All key lost,Read key numbers,Program immo	832
FORD\China\Ranger\2017\Immobilizer	Read key count,Add key,All key lost,	841
FORD\China\Escape\2008-2009\Immobilizer	Read key numbers,Add key,All key lost,	831
FORD\China\Raptor F150\2015-\Smart key	Add smart key,All smart key lost,	812
FORD\China\Raptor F250\2015-\Smart key	Add smart key,All smart key lost,	812
FORD\China\C-MAX\Smart key	Add key,Delete key,All key lost,Add smart key,Delete smart key	950
FORD\China\Focus\New Focus\2014-\Smart key	Add smart key,All smart key lost,	251
FORD\China\Remote\Type 1	Remote,Delete remote,	987
FORD\China\Edge\2015\Immobilizer	Delete key,Add key,Read key count,	179
FORD\China\Edge\2017-\Smart key	Add smart key,All smart key lost,	811
FORD\China\Escort\2017-\Immobilizer	Add key,Delete key,Read key count,	1188
FORD\China\Raptor F150\2015-\Immobilizer	Add key,All key lost,Read key count,	83
FORD\China\Transit\2013-\Immobilizer\Type 1	Add key,Delete key,All key lost,	201
FORD\China\Fusion\2006-2009\Immobilizer	Program key,Delete key,Key count,	1206
FORD\China\Mustang\Immobilizer\2011-2014	Program key,All key lost,Key count,	1320
FORD\USA\C-MAX\Immobilizer\2013	Add key,Delete key,All key lost,	200
FORD\USA\C-MAX\Smart key	Add key,Delete key,All key lost,Add smart key,Delete smart key	950
FORD\USA\Contour\1997-1998\Immobilizer	All key lost,Key count,	1316

FORD\USA\Contour\1999-2000\Immobilizer	Program key, All key lost, Key count,	1314
FORD\USA\Cougar\1999-2002\Immobilizer	Program key, All key lost, Key count,	1314
FORD\USA\Crown Victoria\1998-2002\Immobilizer	Program key, All key lost, Key count,	1317
FORD\USA\Crown Victoria\2003-2004\Immobilizer	Program key, All key lost, Key count,	1314
FORD\USA\Crown Victoria\2005-2012\Immobilizer	Program remote, All key lost, Key count,	1318
FORD\USA\E-Series Van\2008-2009\Immobilizer	Program key, All key lost, Key count,	1319
FORD\USA\E-Series Van\2010-2017\Immobilizer	Program key, All key lost, Key count,	1320
FORD\USA\E-250 Van\Immobilizer	Program key, All key lost, Key count,	1320
FORD\USA\E-350 Van\Immobilizer	Program key, All key lost, Key count,	1320
FORD\USA\Econoline\2008-\Immobilizer	Program key, All key lost, Key count,	1321
FORD\USA\Edge\Immobilizer\2007-2010	Program key, All key lost, Key count,	1319
FORD\USA\Edge\Immobilizer\2011-2014	Delete key, Add key, Read key count,	179
FORD\USA\Edge\Smart key\2011-2014	Erase smart key, Add smart key, Read smart key count,	278
FORD\USA\Escape\Immobilizer\2001-2004	Program key, All key lost, Key count,	1314
FORD\USA\Escape\Immobilizer\2005-2007	Program remote, All key lost, Key count,	1318
FORD\USA\Escape\Immobilizer\2008-2012\Type 1	Program key, All key lost, Key count,	1319
FORD\USA\Escape\Immobilizer\2008-2012\Type 2	Program key, All key lost, Key count,	1321
FORD\USA\Escape\Immobilizer\2013	Add key, Delete key, All key lost,	200
FORD\USA\Escape\Smart key\2013-2016	Add key, Delete key, All key lost, Add smart key, Delete smart key,	950
FORD\USA\Escape Titanium\Smart key	Add smart key, All smart key lost,	251
FORD\USA\Excursion\2000-2005\Immobilizer	Program key, All key lost, Key count,	1317



FORD\USA\Expedition\1997-1998\Immobilizer	All key lost,Key count,	1316
FORD\USA\Expedition\1999-2002\Immobilizer	Program key, All key lost,Key count,	1315
FORD\USA\Expedition\2003-2004\Immobilizer	Program key, All key lost,Key count,	1314
FORD\USA\Expedition\2005-2006\Immobilizer	Program remote, All key lost,Key count,	1318
FORD\USA\Expedition\2007-2008\Immobilizer	Program key, All key lost,Key count,	1319
FORD\USA\Expedition\2009-2013\Immobilizer	Program key, All key lost,Key count,	1321
FORD\USA\Expedition\2014\Immobilizer	Program key, All key lost,Key count,	1320
FORD\USA\Explorer\1998-2001\Immobilizer	Program key, All key lost,Key count,	1317
FORD\USA\Explorer\2001-2003\Immobilizer	Program key, All key lost,Key count,	1314
FORD\USA\Explorer\2004-2005\Immobilizer	Program remote, All key lost,Key count,	1318
FORD\USA\Explorer\2006-2010\Immobilizer	Program key, All key lost,Key count,	1319
FORD\USA\Explorer\2010\Immobilizer	Program key, All key lost,Key count,	1320
FORD\USA\Explorer\2011-2015\Immobilizer	Delete key, Add key, Read key count,	179
FORD\USA\Explorer\2011-2015\Smart key	Erase smart key, Add smart key, Read smart key count,	278
FORD\USA\Explorer Sport Trac\2001\Immobilizer	Program key, All key lost,Key count,	1317
FORD\USA\Explorer Sport Trac\2001-2005\Immobilizer	Program key, All key lost,Key count,	1314
FORD\USA\Explorer Sport Trac\2006-2009\Immobilizer	Program key, All key lost,Key count,	1319
FORD\USA\Explorer Sport Trac\2010\Immobilizer	Program key, All key lost,Key count,	1320
FORD\USA\Explorer Sport Trac\2011-\Immobilizer	Delete key, Add key, Read key count,	179
FORD\USA\Explorer Sport Trac\2011-\Smart key	Erase smart key, Add smart key, Read smart key count,	278
FORD\USA\Fiesta\2014\Immobilizer	Add key, Delete key,	204

FORD\USA\Fiesta\2014-2019\Immobilizer	Add key, Delete key, All key lost,	202
FORD\USA\Fiesta\2014-2019\Smart key	All smart key lost, Add smart key,	222
FORD\USA\Five Hundred\2005-2007\Immobilizer	Program remote, All key lost, Key count,	1318
FORD\USA\Flex\2009-2012\Immobilizer	Program key, All key lost, Key count,	1321
FORD\USA\Flex\2013-\Immobilizer	Delete key, Add key, Read key count,	179
FORD\USA\Flex\2013-2019\Smart key\Type 1	Erase smart key, Add smart key, Read smart key count	278
FORD\USA\Focus\Immobilizer\2000-2004\Type 1	Program key, All key lost, Key count,	1314
FORD\USA\Focus\Immobilizer\2005-2007	Program remote, All key lost, Key count,	1318
FORD\USA\Focus\Immobilizer\2008-2011	Add key, Delete key, Read key count, Sync PCMPATS	428
FORD\USA\Focus\Immobilizer\2012-2013	Add key, Delete key, All key lost,	200
FORD\USA\Focus\Smart key\2012-2014	Add key, Delete key, All key lost, Add smart key Delete smart key	246
FORD\USA\Ford GT\2005-2006\Immobilizer	Program key, All key lost, Key count,	1317
FORD\USA\FreeStar\2004-2005\Immobilizer	Program key, All key lost, Key count,	1314
FORD\USA\FreeStar\2006-2007\Immobilizer	Program remote, All key lost, Key count,	1318
FORD\USA\Freestyle\2005-2006\Immobilizer	Program remote, All key lost, Key count,	1318
FORD\USA\Freestyle\2007-\Immobilizer	Program key, All key lost, Key count,	1319
FORD\USA\Focus ST\Smart key	Add smart key, All smart key lost,	251
FORD\USA\Focus Titanium\Smart key	Add smart key, All smart key lost,	251
FORD\USA\Fusion\2006-2009\Immobilizer	Program key, All key lost, Key count,	1319
FORD\USA\Fusion\2010-2012\Immobilizer	Program key, All key lost, Key count,	1320
FORD\USA\Fusion\2013-2019\Immobilizer	Add key, All key lost, Read key count,	83

FORD\USA\F-150\1999-2003\Immobilizer	Program key, All key lost, Key count,	1315
FORD\USA\F-150\2004-2008\Immobilizer\Type 1	Program remote, All key lost, Key count,	1318
FORD\USA\F-150\2009-2010\Immobilizer\Type 1	Program key, All key lost, Key count,	1319
FORD\USA\F-150\2009-2010\Immobilizer\Type 2	Add key, Delete key, Read key count, Sync PCM-PATS	428
FORD\USA\F-150\2011-2014\Immobilizer	Delete key, Add key, Read key count,	179
FORD\USA\F-150\2015-2017\Immobilizer	Add key, All key lost, Read key count,	83
FORD\USA\F-250\2008-2010\Immobilizer\Type 1	Program key, All key lost, Key count,	1319
FORD\USA\F-250\2008-2010\Immobilizer\Type 2	Program key, All key lost, Key count,	1321
FORD\USA\F-250\2010\Immobilizer	Program key, All key lost, Key count,	1320
FORD\USA\F-250\2011-2016\Immobilizer\Type 1	Delete key, Add key, Read key count,	179
FORD\USA\F-250\2011-2016\Smart key	Erase smart key, Add smart key, Read smart key count	278
FORD\USA\F-350\2008-2009\Immobilizer	Program key, All key lost, Key count,	1319
FORD\USA\F-350\2010\Immobilizer	Program key, All key lost, Key count,	1320
FORD\USA\F-350\2011-\Immobilizer	Delete key, Add key, Read key count,	179
FORD\USA\F-550\2011-\Immobilizer	Program key, All key lost, Key count,	1320
FORD\USA\Mustang\1996-1997\Immobilizer	All key lost, Key count,	1316
FORD\USA\Mustang\1998\Immobilizer	Program key, All key lost, Key count,	1317
FORD\USA\Mustang\1999-2004\Immobilizer	Program key, All key lost, Key count,	1315
FORD\USA\Mustang\2005-2009\Immobilizer	Program remote, All key lost, Key count,	1318
FORD\USA\Mustang\2009-2014\Immobilizer	Program key, All key lost, Key count,	1320
FORD\USA\Ranger\1999-2000\Immobilizer	Program key, All key lost, Key count,	1317

FORD\USA\Ranger\2001-2006\Immobilizer	Program key, All key lost, Key count,	1314
FORD\USA\Ranger\2007-2012\Immobilizer	Program key, All key lost, Key count,	1319
FORD\USA\Ranger\2013-\Immobilizer	Add key, Delete key, All key lost, Read key numbers, Program immo	832
FORD\USA\Taurus\Immobilizer\1996-1997	All key lost, Key count,	1316
FORD\USA\Taurus\Immobilizer\1998-1999	Program key, All key lost, Key count,	1317
FORD\USA\Taurus\Immobilizer\2000-2003	Program key, All key lost, Key count,	1314
FORD\USA\Taurus\Immobilizer\2004-2007	Program remote, All key lost, Key count,	1318
FORD\USA\Taurus\Immobilizer\2008-2009	Program key, All key lost, Key count,	1319
FORD\USA\Taurus\Immobilizer\2010-2012	Program key, All key lost, Key count,	1320
FORD\USA\Taurus\Smart key\2010-2019	Erase smart key, Add smart key, Read smart key count	278
FORD\USA\Thunderbird\2002-2005\Immobilizer	Program key, All key lost, Key count,	1315
FORD\USA\Transit\Immobilizer	Program key, All key lost, Key count,	1320
FORD\USA\Transit Connect\2010-2013\Immobilizer\Type 1	Program key, All key lost, Key count,	1321
FORD\USA\Windstar\1999-2000\Immobilizer	Program key, All key lost, Key count,	1315
FORD\USA\Windstar\2001-2004\Immobilizer	Program key, All key lost, Key count,	1314
FORD\Europe\Transit Courier\2014\Immobilizer	Key count, Delete key, Add key,	1521
FORD\Europe\Tourneo Connect\2013-2014\Immobilizer	Key count, Delete key, Add key,	1521
FORD\Europe\C-Max\2010-2015\Smart key\Prox-Rem Part	Add smart key, Delete smart key,	1523
FORD\Europe\Focus\2011-2014\Smart key\Prox-Rem Part	Add smart key, Delete smart key,	1523
FORD\Europe\Kuga\2013-2015\Smart key\Prox-Rem Part	Add smart key, Delete smart key,	1523
FORD\Europe\Focus\2005-2011\Smart key	Add smart key, Delete smart key, Read smart key count	1524

FORD

FORD\Europe\Kuga\2009-2013\Smart key	Add smart key, Delete smart key, Read smart key count,	1524
FORD\Europe\Kuga\2007-2009\Immobilizer	Add key, Delete key, Read key count,	1530
FORD\Europe\Windstar\1997-1998\Immobilizer	Delete key, Add key, Key count,	1534
FORD\Europe\Transit\2000-2007\Immobilizer\Dura-	Delete key, Add key, Key count,	1534
FORD\Europe\Transit\1998-2000\Immobilizer\Petrol	Delete key, Add key, Key count,	1534
FORD\Europe\Transit\1997-1998\Immobilizer\Petrol	Delete key, Add key, Key count,	1534
FORD\Europe\Scorpio\1997\Immobilizer\Petrol-Automatic-Type1	Delete key, Add key, Key count,	1534
FORD\Europe\Granada\1997-\Immobilizer\Petrol-Automatic-Type1	Delete key, Add key, Key count,	1534
FORD\Europe\Galaxy\2000-2006\Immobilizer\Petrol	Delete key, Add key, Key count,	1534
FORD\Europe\Explorer\1997-2001\Immobilizer\Type	Delete key, Add key, Key count,	1534
FORD\Europe\Explorer\1997-2001\Immobilizer\Type 2	Delete key, Add key, Key count,	1536
FORD\Europe\Galaxy\1997-2000\Immobilizer\Petrol	Delete key, Key count,	1537
FORD\Europe\Windstar\1998-\Immobilizer	All key lost, Add key, Key count,	1539
FORD\Europe\Courier\2001-2007\Immobilizer\Petrol	Program remote, All key lost, Key count,	1318
FORD\Europe\Courier\2001-2007\Immobilizer\Petrol	Program remote, All key lost, Key count,	1318
FORD\Europe\Courier\2001-2007\Immobilizer\Diesel	Program remote, All key lost, Key count,	1318
FORD\Europe\Fiesta\2001-2007\Immobilizer\Petrol	Program remote, All key lost, Key count,	1318
FORD\Europe\Fiesta\2001-2007\Immobilizer\Petrol	Program remote, All key lost, Key count,	1318
FORD\Europe\Fiesta\2001-2007\Immobilizer\Diesel	Program remote, All key lost, Key count,	1318
FORD\Europe\Fusion\2002-2011\Immobilizer	Program remote, All key lost, Key count,	1318
FORD\Europe\KA\2002-2008\Immobilizer	Program remote, All key lost, Key count,	1318

FORD\Europe\C-Max\ 2010\Immobilizer\Type 1	Program key, All key lost, Key count,	1319
FORD\Europe\C-Max\ 2010\Immobilizer\Type 2	Program key, All key lost, Key count,	1319
FORD\Europe\Focus\2005- 2011\Immobilizer	Program key, All key lost, Key count,	1319
FORD\Europe\Tourneo\200 7-2010\Immobilizer	Program key, All key lost, Key count,	1319
FORD\Europe\Transit Connect\2007- 2013\Immobilizer	Program key, All key lost, Key count,	1319
FORD\Europe\Ranger\2012 -2014\Immobilizer	Add key, Delete key, All key lost, Read key numbers, Program immo	832
FORD\Europe\Cougar\Immo bilizer	Program key, All key lost, Key count,	1314
FORD\Europe\Courier\199 9-2001\Immobilizer	Program key, All key lost, Key count,	1314
FORD\Europe\Escape\Immo bilizer	Program key, All key lost, Key count,	1314
FORD\Europe\Fiesta\1999 -2001\Immobilizer	Program key, All key lost, Key count,	1314
FORD\Europe\Focus\1995- 1998\Immobilizer\Diesel	Program key, All key lost, Key count,	1314
FORD\Europe\Focus\1998- 2004\Immobilizer	Program key, All key lost, Key count,	1314
FORD\Europe\Galaxy\2000 - 2006\Immobilizer\Petrol	Program key, All key lost, Key count,	1314
FORD\Europe\KA\1998- 2001\Immobilizer	Program key, All key lost, Key count,	1314
FORD\Europe\Mondeo\1997 - 1998\Immobilizer\Petrol	Program key, All key lost, Key count,	1314
FORD\Europe\Mondeo\1998 -2007\Immobilizer	Program key, All key lost, Key count,	1314
FORD\Europe\Puma\1996- 2001\Immobilizer\Petrol - 1.7L Zetec	Program key, All key lost, Key count,	1314
FORD\Europe\Transit\199 8- 2000\Immobilizer\Diesel	Program key, All key lost, Key count,	1314
FORD\Europe\Transit\199 8-2000\Immobilizer\EPIC - Type 2	Program key, All key lost, Key count,	1314
FORD\Europe\Transit\200 0- 2007\Immobilizer\Petrol	Program key, All key lost, Key count,	1314
FORD\Europe\Transit\200 0- 2007\Immobilizer\Diesel	Program key, All key lost, Key count,	1314

FORD\Europe\Transit\2000-2007\Immobilizer\Dura-	Program key, All key lost, Key count,	1314
FORD\Europe\Transit Connect\2006\Immobilizer	Program key, All key lost, Key count,	1314
FORD\Europe\Ranger\2012\Immobilizer	Program key, All key lost, Key count,	1315
FORD\Europe\Ranger\2012\Manual PIN	Program key, All key lost, Key count,	1315
FORD\Europe\Explorer\1997-2001\Immobilizer\Type 3	Program key, All key lost, Key count,	1317
FORD\Europe\B-Max\2012-\Smart key	Smart key all lost, Add smart key,	189
FORD\Europe\Courier\2008-2013\Smart key	Smart key all lost, Add smart key,	189
FORD\Europe\Courier\2013-\Smart key	Smart key all lost, Add smart key,	189
FORD\Europe\Fiesta\2008-2013\Smart key	Smart key all lost, Add smart key,	189
FORD\Europe\Fiesta\2013-\Smart key	Smart key all lost, Add smart key,	189
FORD\Europe\Galaxy\2007-2010\Smart key	Smart key all lost, Add smart key,	189
FORD\Europe\Galaxy\2010-2015\Smart key	Smart key all lost, Add smart key,	189
FORD\Europe\Mondeo\2007-2010\Smart key	Smart key all lost, Add smart key,	189
FORD\Europe\Mondeo\2010-2014\Smart key	Smart key all lost, Add smart key,	189
FORD\Europe\S-Max\2007-2010\Smart key	Smart key all lost, Add smart key,	189
FORD\Europe\S-Max\2010-2015\Smart key	Smart key all lost, Add smart key,	189
FORD\Europe\Courier\2013-\Immobilizer	Add key, Delete key, All key lost,	202
FORD\Europe\Ecosport\2013\Immobilizer	Add key, Delete key, All key lost,	202
FORD\Europe\Edge\2011-2013\Immobilizer	Delete key, Add key, Read key count,	179
FORD\Europe\Explorer\2011-2015\Immobilizer	Delete key, Add key, Read key count,	179
FORD\Europe\Courier\2008-2013\Immobilizer	Add key, Delete key,	204

FORD\Europe\Fiesta\2008-2013\Immobilizer	Add key, Delete key,	204
FORD\Europe\Transit\2007-2013\Immobilizer	Add key, Delete key, All key lost,	180
FORD\Europe\S-Max\2010-2015\Immobilizer	Add key, Delete key, Key count,	1532
FORD\Europe\Mondeo\2010-2014\Immobilizer	Add key, Delete key, Key count,	1532
FORD\Europe\Galaxy\2010-2015\Immobilizer	Add key, Delete key, Key count,	1532
FORD\Europe\Transit Connect\2013-\Immobilizer	Add key, Delete key, All key lost,	201
FORD\Europe\Kuga\2013-2015\Immobilizer	Add key, Delete key, All key lost,	201
FORD\Europe\Focus\2011-2014\Immobilizer	Add key, Delete key, All key lost,	201
FORD\Europe\C-Max\2010-2015\Immobilizer	Add key, Delete key, All key lost,	201
FORD\Europe\Edge\2013-\Smart key	Read key count, Add key, All key lost,	841
FORD\Europe\S-Max\2007-2010\Immobilizer	Add key, Delete key, All key lost,	184
FORD\Europe\Mondeo\2007-2010\Immobilizer	Add key, Delete key, All key lost,	184
FORD\Europe\Galaxy\2007-2010\Immobilizer	Add key, Delete key, All key lost,	184
FORD\Europe\Transit\1998-2000\Immobilizer\EPIC - Type 1 (PATS 3 ISO	Key count, Add key, Delete key,	1556
FORD\Europe\Scorpio\1997\Immobilizer\Petrol - Manual (PATS 3 ISO	Key count, Add key, Delete key,	1556
FORD\Europe\Puma\1996-2001\Immobilizer\Petrol - 1.4L Zetec (PATS 3 ISO	Key count, Add key, Delete key,	1556
FORD\Europe\Mondeo\1997-1998\Immobilizer\Petrol	Key count, Add key, Delete key,	1556
FORD\Europe\KA\1997-1998\Immobilizer\PATS 3 ISO Petrol	Key count, Add key, Delete key,	1556
FORD\Europe\Granada\1997-\Immobilizer\Petrol - Manual (PATS 3 ISO	Key count, Add key, Delete key,	1556
FORD\Europe\Galaxy\2000-2006\Immobilizer\Petrol	Key count, Add key, Delete key,	1556
FORD\Europe\Fiesta\1997-1998\Immobilizer\Petrol	Key count, Add key, Delete key,	1556



FORD\Europe\Courier\1997-1998\Immobilizer\Petrol	Key count, Add key, Delete key,	1556
FORD\Europe\Transit\1997-1998\Immobilizer\Diesel	Add key, Delete key, Key count,	1557
FORD\Europe\Scorpio\1997\Immobilizer\Diesel (PATTS 3 ISO Diesel)	Add key, Delete key, Key count,	1557
FORD\Europe\Mondeo\1997-1998\Immobilizer\Diesel	Add key, Delete key, Key count,	1557
FORD\Europe\Granada\1997-1998\Immobilizer\Diesel (PATTS 3 ISO Diesel)	Add key, Delete key, Key count,	1557
FORD\Europe\Fiesta\1997-1998\Immobilizer\Diesel	Add key, Delete key, Key count,	1557
FORD\Europe\Fiesta\1996-1997\Immobilizer\Diesel	Add key, Delete key, Key count,	1557
FORD\Europe\Courier\1997-1998\Immobilizer\Diesel	Add key, Delete key, Key count,	1557
FORD\Europe\Courier\1996-1997\Immobilizer\Diesel	Add key, Delete key, Key count,	1557
FORD\Europe\Kuga\2013-2015\Smart key\Immochip part	Add key, Delete key, All key lost,	200
FORD\Europe\Focus\2011-2014\Smart key\Immochip part	Add key, Delete key, All key lost,	200
FORD\Europe\C-Max\2010-2015\Smart key\Immochip part	Add key, Delete key, All key lost,	200
FORD\Europe\Galaxy\2000-2006\Immobilizer\Diesel	Add key, Delete key, Key count,	1560
FORD\Europe\Galaxy\2000-2006\Immobilizer\Petrol	Add key, Delete key, Key count,	1560
FORD\Australia\C-Max\Immobilizer\Type 1	Program key, All key lost, Key count,	1319
FORD\Australia\C-Max\Immobilizer\Type 2	Program key, All key lost, Key count,	1319
FORD\Australia\Cougar\Immobilizer	Program key, All key lost, Key count,	1314
FORD\Australia\Courier\Petrol\1997-1998	Key count, Add key, Delete key,	1556
FORD\Australia\Courier\Petrol\1998-2000	Program key, All key lost, Key count,	1314
FORD\Australia\Courier\Petrol\2001-2008\Type 1	Program remote, All key lost, Key count,	1318
FORD\Australia\Courier\Petrol\2001-2008\Type 2	Program remote, All key lost, Key count,	1318

FORD\Australia\Courier\ Petrol\2008- \Immobilizer	Add key,Delete key,	204
FORD\Australia\Courier\ Petrol\2008-\Smart key	Smart key all lost,Add smart key,	189
FORD\Australia\Courier\ Diesel\2008-\Smart key	Smart key all lost,Add smart key,	189
FORD\Australia\Courier\ Diesel\2008- \Immobilizer	Add key,Delete key,	204
FORD\Australia\Courier\ Diesel\2001- 2008\Immobilizer	Program remote,All key lost,Key count,	1318
FORD\Australia\Courier\ Diesel\1999-2001	Program key,All key lost,Key count,	1314
FORD\Australia\Courier\ Diesel\1997-	Add key,Delete key,Key count,	1557
FORD\Australia\Escape ZD	Program remote,All key lost,Key count,	1318
FORD\Australia\Escape	Program key,All key lost,Key count,	1314
FORD\Australia\Explorer \1997-\Type 3	Program key,All key lost,Key count,	1317
FORD\Australia\Explorer \1997-\Type 2	Delete key,Add key,Key count,	1536
FORD\Australia\Explorer \1997-\Type 1	Delete key,Add key,Key count,	1534
FORD\Australia\Fiesta\D iesel\2008-2012\Smart key	Smart key all lost,Add smart key,	189
FORD\Australia\Fiesta\D iesel\2008- 2012\Immobilizer	Add key,Delete key,	204
FORD\Australia\Fiesta\D iesel\2001- 2008\Immobilizer	Program remote,All key lost,Key count,	1318
FORD\Australia\Fiesta\D iesel\1999-2001	Program key,All key lost,Key count,	1314
FORD\Australia\Fiesta\D iesel\1997-	Add key,Delete key,Key count,	1557
FORD\Australia\Fiesta\P etrol\2008-2012\Smart key	Smart key all lost,Add smart key,	189
FORD\Australia\Fiesta\P etrol\2008- 2012\Immobilizer	Add key,Delete key,	204
FORD\Australia\Fiesta\P etrol\2001-2008\Type 2	Program remote,All key lost,Key count,	1318
FORD\Australia\Fiesta\P etrol\2001-2008\Type 1	Program remote,All key lost,Key count,	1318

FORD\Australia\Fiesta\Petrol\1998-2000	Program key, All key lost, Key count,	1314
FORD\Australia\Fiesta\Petrol\1997-1998	Key count, Add key, Delete key,	1556
FORD\Australia\Focus\Diesel\2011-\Immobilizer	Add key, Delete key, All key lost,	201
FORD\Australia\Focus\Diesel\2005-2011\Smart key	Add smart key, Delete smart key, Read smart key count	1524
FORD\Australia\Focus\Diesel\2005-2011\Immobilizer	Delete key, Add key, Read key count,	1546
FORD\Australia\Focus\Diesel\1998-2004	Program key, All key lost, Key count,	1314
FORD\Australia\Focus\Diesel\1995-1998	Program key, All key lost, Key count,	1314
FORD\Australia\Focus\Petrol\2011-\Immobilizer	Add key, Delete key, All key lost,	201
FORD\Australia\Focus\Petrol\2005-2011\Smart key	Add smart key, Delete smart key, Read smart key count	1524
FORD\Australia\Focus\Petrol\2005-2011\Immobilizer	Delete key, Add key, Read key count,	1546
FORD\Australia\Focus\Petrol\1998-2004	Program key, All key lost, Key count,	1314
FORD\Australia\Fusion	Program remote, All key lost, Key count,	1318
FORD\Australia\Galaxy\Diesel\2000-\Type 1\PATS SCP	Add key, Delete key, Key count,	1560
FORD\Australia\Galaxy\Petrol\2000-\V6	Add key, Delete key, Key count,	1560
FORD\Australia\Galaxy\Petrol\2000-\NOT V6\Type 1 (PATS SCP)	Delete key, Add key, Key count,	1534
FORD\Australia\Galaxy\Petrol\1997-2000\NOT V6\Type 1 (PATS SCP)	Delete key, Key count,	1537
FORD\Australia\Galaxy\Petrol\1997\NOT V6\PATS 2 SCP	Delete key, Add key, Key count,	1534
FORD\Australia\Granada Scorpio\Diesel\1997-\PATS 3 ISO Diesel	Add key, Delete key, Key count,	1557
FORD\Australia\Granada Scorpio\Petrol\Automatic\1997-\Type 1 (PATS SCP)	Delete key, Add key, Key count,	1534
FORD\Australia\Granada Scorpio\Petrol\Manual\1997-\PATS 3 ISO Petrol	Key count, Add key, Delete key,	1556
FORD\Australia\KA\Petrol\2002-2008	Program remote, All key lost, Key count,	1318

FORD\Australia\KA\Petro 1\1998-2000	Program key, All key lost, Key count,	1314
FORD\Australia\KA\Petro 1\1997-1998	Key count, Add key, Delete key,	1556
FORD\Australia\Maverick \2001-	Program key, All key lost, Key count,	1314
FORD\Australia\Mondeo\D iesel\2007-\Smart key	Smart key all lost, Add smart key,	189
FORD\Australia\Mondeo\D iesel\2007-\Immobilizer	Add key, Delete key, All key lost,	184
FORD\Australia\Mondeo\D iesel\1998-\Type 1\PATS SCP	Program key, All key lost, Key count,	1314
FORD\Australia\Mondeo\D iesel\1997-1998\Type 1\PATS_SCP	Add key, Delete key, Key count,	1557
FORD\Australia\Mondeo\P etrol\Automatic\2007- \Smart key	Smart key all lost, Add smart key,	189
FORD\Australia\Mondeo\P etrol\Automatic\2007- \Immobilizer	Add key, Delete key, All key lost,	184
FORD\Australia\Mondeo\P etrol\Automatic\1997-	Program key, All key lost, Key count,	1314
FORD\Australia\Mondeo\P etrol\Manual\2007- \Smart key	Smart key all lost, Add smart key,	189
FORD\Australia\Mondeo\P etrol\Manual\2007- \Immobilizer	Add key, Delete key, All key lost,	184
FORD\Australia\Mondeo\P etrol\Manual\1998-\PATS SCP	Program key, All key lost, Key count,	1314
FORD\Australia\Mondeo\P etrol\Manual\1997- 1998\PATS_3_ISO_Petrol	Key count, Add key, Delete key,	1556
FORD\Australia\Puma\Pet rol\14 Zetec\1997-\PATS 3_ISO_Petrol	Key count, Add key, Delete key,	1556
FORD\Australia\Puma\Pet rol\14 Zetec\1996-	Program key, All key lost, Key count,	1314
FORD\Australia\Ranger\2 012-	Add key, Delete key, All key lost, Read key numbers, Program immo	832
FORD\Australia\Ranger\2 012	Program key, All key lost, Key count,	1315
FORD\Australia\Transit Connect\2007-\Type 2	Add key, Delete key, All key lost,	184
FORD\Australia\Transit Connect\2007-\Type 1	Program key, All key lost, Key count,	1319
FORD\Australia\Transit Connect\2007	Program key, All key lost, Key count,	1314

FORD\Australia\Transit\Epic\1998-\Type 2	Program key, All key lost, Key count,	1314
FORD\Australia\Transit\Epic\1998-\Type 1	Key count, Add key, Delete key,	1556
FORD\Australia\Transit\Dura Torque\Type 2	Program key, All key lost, Key count,	1314
FORD\Australia\Transit\Dura Torque\Type 1	Delete key, Add key, Key count,	1534
FORD\Australia\Transit\Diesel\2007-	Add key, Delete key, All key lost,	180
FORD\Australia\Transit\Diesel\1998-	Program key, All key lost, Key count,	1314
FORD\Australia\Transit\Diesel\1997-1998	Add key, Delete key, Key count,	1557
FORD\Australia\Transit\Petrol\2007-	Add key, Delete key, All key lost,	180
FORD\Australia\Transit\Petrol\2000-	Program key, All key lost, Key count,	1314
FORD\Australia\Transit\Petrol\1997-2000	Delete key, Add key, Key count,	1534
FORD\Australia\Windstar\1998-	All key lost, Add key, Key count,	1539
FORD\Australia\Windstar\1997-1998	Delete key, Add key, Key count,	1534
FORD\Africa\Mondeo\1997-1998	Program key, All key lost, Key count,	1314
FORD\Africa\Icon\2002-2008	Program remote, All key lost, Key count,	1318
FORD\Africa\Figo\2007-	Program remote, All key lost, Key count,	1318
FORD\Africa\Fiesta\2012-2014	Add key, Delete key, All key lost,	202
FORD\Africa\Fiesta\2002-2008	Program remote, All key lost, Key count,	1318
FORD\Africa\Bantam\2007-	Program remote, All key lost, Key count,	1318
FORD\South America\F250\Diesel (Cummins)	Key count, Delete key,	1575
FORD\India\Ecosport\2012-\Immobilizer	Add key, Delete key, All key lost,	202
FORD\India\Fiesta\2008-\Smart key	Smart key all lost, Add smart key,	189

FORD\India\Fiesta\2008-\Immobilizer	Add key, Delete key,	204
FORD\India\Fiesta\2004-	Program key, All key lost, Key count,	1319
FORD\India\Figo\2008-\Smart key	Smart key all lost, Add smart key,	189
FORD\India\Figo\2008-\Immobilizer	Add key, Delete key,	204
FORD\India\Figo\2004-	Program key, All key lost, Key count,	1319
FORD\India\Fusion\1318	Program remote, All key lost, Key count,	1318
FORD\India\Mondeo\Diesel\2007-\Smart key	Smart key all lost, Add smart key,	189
FORD\India\Mondeo\Diesel\2007-\Immobilizer	Add key, Delete key, All key lost,	184
FORD\India\Mondeo\Diesel\1998-2007	Program key, All key lost, Key count,	1314
FORD\India\Mondeo\Diesel\1997-1998	Add key, Delete key, Key count,	1557
FORD\India\Mondeo\Petrol\Automatic\2007-	Add key, Delete key, All key lost,	184
FORD\India\Mondeo\Petrol\Automatic\1997-2006	Program key, All key lost, Key count,	1314
FORD\India\Mondeo\Petrol\Manual\2007-\Smart key	Smart key all lost, Add smart key,	189
FORD\India\Mondeo\Petrol\Manual\2007-\Immobilizer	Add key, Delete key, All key lost,	184
FORD\India\Mondeo\Petrol\Manual\1998-2006	Program key, All key lost, Key count,	1314
FORD\India\Mondeo\Petrol\Manual\1997-1998	Key count, Add key, Delete key,	1556
FORD\South America\Ecosport\2011-2015\Smart key	Smart key all lost, Add smart key,	189
FORD\South America\Ecosport\2011-2015\Immobilizer	Add key, Delete key, All key lost,	202
FORD\South America\Ecosport\2010-2011\Immobilizer	Program remote, All key lost, Key count,	1318
FORD\South America\Ecosport\2009-2010\Immobilizer	Program remote, All key lost, Key count,	1318
FORD\South America\Ecosport\2003-2008\Immobilizer	Program remote, All key lost, Key count,	1318

FORD\South America\Edge\2007-2011\Immobilizer	Program key, All key lost, Key count,	1319
FORD\South America\F250\Petrol	Program key, All key lost, Key count,	1317
FORD\South America\Ranger\2012-2014	Add key, Delete key, All key lost, Read key numbers, Program immo	832
FORD\South America\Fusion\2010-\Hybrid	Program key, All key lost, Key count,	1320
FORD\South America\Focus\2005-2010\Immobilizer	Program key, All key lost, Key count,	1319
FORD\Israel\Edge\2011-\Smart key	Delete key, Add key, Read count of smart key,	1577
FORD\Israel\Edge\2011-\Immobilizer	Delete key, Add key, Read key count,	179
FORD\Israel\Explorer\2011-\Smart key	Delete key, Add key, Read count of smart key,	1577
FORD\Israel\Explorer\2011-\Immobilizer	Delete key, Add key, Read key count,	179
FORD\Israel\Focus\2011-2014\Immobilizer	Add key, Delete key, All key lost,	201
FORD\China\HEC\Immobilizer	All key lost, Key count, Reset system,	1628
FORD\China\PCM\Immobilizer	All key lost, Read key count,	218
FORD\USA\HEC\Immobilizer	All key lost, Key count, Reset system,	1628
FORD\USA\PCM\Immobilizer	All key lost, Read key count,	218
FORD\China\Raptor F150\2017-\Smart key	Add smart key, All smart key lost,	811
FORD\India\Aspire\2017\Immobilizer	Add key, All key lost, Read key count,	83
FORD\India\Endeavour\2014-2017\Immobilizer	Add key, All key lost, Read key count,	83
FORD\India\Ecosport\2012-\Smart key	All smart key lost, Add smart key,	222
FORD\USA\F-150\2004-2008\Immobilizer\Type 2	Program key, All key lost, Key count,	1315
FORD\USA\F-250\2011-2016\Immobilizer\Type 2	Add key, Delete key, Read key count,	1188
FORD\USA\Focus\Immobilizer\2000-2004\Type 2	Program remote, All key lost, Key count,	1318

FORD\USA\Taurus X\2008-2009\Immobilizer	Program key, All key lost, Key count,	1319
FORD\USA\Transit Connect\2010-2013\Immobilizer\Type 2	Program key, All key lost, Key count,	1319
FORD\USA\Fiesta\2014\Smart key	Smart key all lost, Add smart key,	189
FORD\USA\F-550 SD\2008-2010\Immobilizer	Add key, Delete key, All key lost,	205
NISSAN\Select from vehicle\North America\NV200\2012-	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\North America\Juke\2011-	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\North America\Rogue\2014-\Bar	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\South America\Livina\2011-	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\North America\Rogue\2014-	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\South America\Frontier\2013-	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\North America\Armada\2017-	Read BCM inner code, Program smart key,	1654
NISSAN\Select from vehicle\North America\Juke\2011-	Read BCM inner code, Program smart key,	1654
NISSAN\Select from vehicle\North America\Leaf\2011-	Read BCM inner code, Program smart key,	1654
NISSAN\Select from vehicle\North America\Quest\2011-	Read BCM inner code, Program smart key,	1654
NISSAN\Select from vehicle\North America\Sentra\2013-	Read BCM inner code, Program smart key,	1654
NISSAN\Select from vehicle\North America\Versa\2013\Prox	Read BCM inner code, Program smart key,	1654
NISSAN\Select from vehicle\North America\Rogue\2014-\Bar	Program key,	1670
NISSAN\Select from vehicle\North America\Rogue\2014-	Program smart key,	1672
NISSAN\Select from vehicle\North America\Maxima\2016-	Program smart key,	1673
NISSAN\Select from vehicle\North America\Pathfinder\2013	Program smart key,	1673
NISSAN\Select from vehicle\North America\Murano\2015-	Program smart key,	1673





NISSAN\Select from type\Smart key\New 20-digit rolling code\X-	Program smart key,	167
NISSAN\Select from type\Smart key\New 20-digit rolling	Program smart key,	167
NISSAN\Select from type\Smart key\4-digit PIN code\Without key	Program smart key, Delete smart key,	162
NISSAN\Select from type\Smart key\4-digit PIN code\With slot-	Program smart key,	161
NISSAN\Select from type\Smart key\4-digit PIN code\With slot-	Program smart key, Clear fault code,	159
NISSAN\Select from type\Smart key\4-digit PIN code\Without slot-	Program smart key,	160
NISSAN\Select from type\Immobilizer\New 20-bit rolling code	Add key,	174
NISSAN\Select from type\Immobilizer\Activate direction lock	Activate steering wheel lock,	219
NISSAN\Select from type\Smart key\4-digit PIN code\Activate	Activate steering wheel lock,	219
NISSAN\Select from type\Smart key\12-digit PIN\All	Smart key, Key count,	720
NISSAN\Select from type\Immobilizer\12-digit PIN=type2(CAN)	Smart key, Key count,	720
NISSAN\Select from type\Immobilizer\12-digit PIN=type1(KWP)	Program key, Key count,	723
NISSAN\Read BCM code and release directional Lock(4-digit PIN)	Release steering lock, Read BCM inner code	785
NISSAN\Select from type\Smart key\4-digit PIN code\Without	Read BCM inner code, Release steering lock Program smart key	814
NISSAN\Select from vehicle\Asia\Sunny\Smart key	Read BCM inner code, Release steering lock Program smart key	814
NISSAN\Select from vehicle\Asia\350Z\2003-\NATS_5	Add key, Add key(fixed code),	815
NISSAN\Select from vehicle\Asia\X-Trail\2017\With smart	Program smart key,	920
NISSAN\Select from vehicle\North America\350Z\2003-	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Asia\Almera\N16\Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Asia\350Z\Z33	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Asia\Almera\N16\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594

NISSAN\Select from vehicle\Asia\Almera Tina\V10\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Asia\Cabstar\Petrol\NATS 5 (petrol)	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Asia\Fairlady 350Z\Z33\2003-2006	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Asia\Maxima\A34	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Asia\Micra\K11\2000-2003	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Asia\Patrol\Y61\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Asia\Primera\P12\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Asia\Pulsar\N16	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Asia\Skyline\V35	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Asia\Terrano II\R20\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Asia\X-Trail\T30\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\North America\Altima\2001-	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\North America\Frontier\2002-	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\North America\Maxima\2000-	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\North America\Murano\2003-	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\North America\Sentra\2000-	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\North America\X-Trail\2005-	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\South America\350Z\Z33	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\South America\Almera\N16\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\South America\Almera	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\South America\Cabstar\Petrol\	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594

NISSAN\Select from vehicle\South America\Maxima\A34	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\South America\Micra\K11\2000-	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\South America\Patrol\Y61\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\South America\Primera\P12\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\South America\Pulsar\N16	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\South America\Skyline\Y35	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\South America\Terrano II\R20	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\South America\X-Trail\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Asia\Almera Tino\Y10\Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Asia\Cabstar\Diesel\NATS_5 (diesel)	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Asia\Navara\D40 (SIEMENS)\NATS_5	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Asia\Primera\P12\Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Asia\Tiida\Diesel\Y2000-	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Asia\X-Trail\T30\Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\South America\Almera\N16\Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\South America\Almera	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\South America\Cabstar\Diesel\	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\South America\Navara\D40 (SIEMENS)	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\South America\Primera\P12\Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\South America\Tiida\Diesel\Y2000-	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\South America\X-Trail\Diesel	Program key, Clear fault code,	1623

NISSAN\Select from vehicle\Asia\Micra\K13\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Asia\Pathfinder\R51\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Asia\Fairlady 350Z\2007-	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Asia\Atlas\F24	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Asia\Cube\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Asia\Juke\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Asia\Latio\2003-2009\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Asia\March\2011\4-Bit PIN	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Asia\Navara\D40 (CONTINENTAL)\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Asia\X-Trail\T31\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\North America\350Z\2007-	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\North America\Cube\2009-	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\North America\Armada\2008-	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\North America\Armada\2008-	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\North America\Frontier\2008-	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\North America\Pathfinder\2008-	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\North America\Quest\2008-	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\North America\Rogue\2008-	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\North America\Sentra\2007-	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\North America\Titan\2008-	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\North America\Versa\2007-	Read BCM inner code, Program key, Delete remote Add remote	1624

NISSAN\Select from vehicle\North America\Xterra\2008-	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\South America\Cube\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\South America\Frontier\2006-	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\South America\March\2011\4-	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\South America\Navara\D40 (CONT	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\South America\Micra\K13\Bar	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\South America\Pathfinder\R51\	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Asia\Navara\D40 (SIEMENS)\Petrol	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\Asia\Qashqai\J10\Petrol\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\South America\Navara\D40 (STEM	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\South America\Qashqai\J10\Pet	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\North America\Altima\2005-	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\North America\Armada\2004-	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\North America\Frontier\2005-	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\North America\Maxima\2004-	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\North America\Pathfinder\2004	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\North America\Quest\2004-	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\North America\Titan\2004-	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\North America\Xterra\2005-	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\Asia\Qashqai\J10\Diesel\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1626
NISSAN\Select from vehicle\Asia\Navara\D40 (SIEMENS)\Diesel	Read BCM inner code, Program key, Delete remote Add remote	1626

NISSAN\Select from vehicle\South America\Qashqai\110\Die	Read BCM inner code, Program key, Delete remote Add remote	1626
NISSAN\Select from vehicle\South America\Navara\D40(STEM	Read BCM inner code, Program key, Delete remote Add remote	1626
NISSAN\Select from vehicle\North America\Murano\2005-	Read BCM inner code, Program key, Delete smart key Add smart	1627
NISSAN\Select from vehicle\Asia\Navara\D40 (CONTINENTAL)\Smart	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Asia\Latio\2003-2009\Smart key(knob	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Asia\Pathfinder\R51\Smart key(knob	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Asia\X-Trail\T31\Smart	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Asia\Qashqai\J10\Petrol\Smart key(knob	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Asia\Qashqai\J10\Diesel\Smart key(knob	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Asia\Teana\2010-2013\Proximity smart	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\North America\Maxima\2007-	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\North America\Armada\2008-	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\North America\Roma\2008-	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\North America\Pathfinder\2008	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\North America\Qashqai\2007-	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\North America\Qashqai\2009-	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\North America\Versa\2007-	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\North America\Sentra\2007-	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\South America\Navara\D40(CONT	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\South America\Pathfinder\R51\	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\South America\Qashqai\110\Pet	Read BCM inner code, Program key, Delete remote Add remote	1630

NISSAN\Select from vehicle\South America\Qashqai\110\Die	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\South America\Rogue\2008-	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\South America\Sentra\2007-	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\North America\Altima	Read BCM inner code, Program smart key,	1633
NISSAN\Select from vehicle\Asia\370Z\Z34\P roximity smart	Read BCM inner code, Program smart key,	1634
NISSAN\Select from vehicle\Asia\Sylphy\G11 \2003-2009\Proximity	Read BCM inner code, Program smart key,	1634
NISSAN\Select from vehicle\Asia\X- Trail\T31\Proximity	Read BCM inner code, Program smart key,	1634
NISSAN\Select from vehicle\Asia\Note\E11\P roximity smart	Read BCM inner code, Program smart key,	1634
NISSAN\Select from vehicle\North America\370Z\2009-	Read BCM inner code, Program smart key,	1634
NISSAN\Select from vehicle\North America\Maxima\2009-	Read BCM inner code, Program smart key,	1634
NISSAN\Select from vehicle\North America\Altima\2007-	Read BCM inner code, Program smart key,	1634
NISSAN\Select from vehicle\North America\GTR\2007-	Read BCM inner code, Program smart key,	1634
NISSAN\Select from vehicle\North America\Murano\2009-	Read BCM inner code, Program smart key,	1634
NISSAN\Select from vehicle\North America\Altima\2013-\2	Read BCM inner code, Program smart key,	1634
NISSAN\Select from vehicle\Asia\Leaf	Read BCM inner code, Program smart key,	1654
NISSAN\Select from vehicle\South America\Leaf	Read BCM inner code, Program smart key,	1654
NISSAN\Select from vehicle\Asia\Serana\C26 \Proximity smart	Read BCM inner code, Program smart key,	1654
NISSAN\Select from vehicle\Asia\Cube\Proxi mity smart	Read BCM inner code, Program smart key,	1660
NISSAN\Select from vehicle\Asia\Juke\Proxi mity smart	Read BCM inner code, Program smart key,	1660
NISSAN\Select from vehicle\Asia\Micra\K13\ Proximity smart	Read BCM inner code, Program smart key,	1660
NISSAN\Select from vehicle\South America\Cube\Proximity	Read BCM inner code, Program smart key,	1660



NISSAN\Select from vehicle\South America\Micra\K13\Proxi	Read BCM inner code, Program smart key,	1660
NISSAN\Select from vehicle\North America\Cube\2009-	Read BCM inner code, Program smart key,	1660
NISSAN\Select from vehicle\Asia\InterStar\X70	Program key, Clear fault code,	1665
NISSAN\Select from vehicle\Asia\Terrano 3\2012-\Bar_type	Program key, Clear fault code,	1665
NISSAN\Select from vehicle\Asia\Micra\K12\Bar_type	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\Asia\Note\E11\Bar_type	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\Asia\NV200\Bar_type	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\Asia\Tiida\Petr	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\South America\Micra\K12\Bar	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\South America\Note\E11\Bar	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\South America\NV200\Bar_type	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\South America\Tiida\Petrol	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\Asia\Micra\K12\Smart_key(knob_type)	Read key count, Program smart key, Add remote Delete	1667
NISSAN\Select from vehicle\Asia\Note\E11\Smart_key(knob_type)	Read key count, Program smart key, Add remote Delete	1667
NISSAN\Select from vehicle\South America\Micra\K12\Smart	Read key count, Program smart key, Add remote Delete	1667
NISSAN\Select from vehicle\South America\Note\E11\Smart	Read key count, Program smart key, Add remote Delete	1667
NISSAN\Select from vehicle\Asia\Qashqai\J11\Bar_type	Program key,	1670
NISSAN\Select from vehicle\South America\Qashqai\J11\Bar	Program key,	1670
NISSAN\Select from vehicle\Asia\Qashqai\J11\Proximity_smart	Program smart key,	1672
NISSAN\Select from vehicle\Asia\Teana\2013-\Proximity_smart	Program smart key,	1673
NISSAN\Select from vehicle\North America\Altima\2013-\4	Program smart key,	1673

NISSAN

NISSAN\Select from vehicle\North America\Titan\2007\Prox	Program smart key,	1673
NISSAN\PIN calculator	Type 1, Type 2, Type 3 (20-bit rolling code/PIN)	1675
NISSAN\Select from vehicle\North America\Altima\2005-	Read BCM inner code, Program key,	1689
NISSAN\Select from vehicle\Africa\350Z\Z33	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Africa\Almera\N16\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Africa\Almera\N16\Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Africa\Almera\Tino\V10\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Africa\Almera\Tino\V10\Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Africa\Bluebird\Sylphy\2005-2012\Smart	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Africa\Cabstar\Petrol\NATS_5 (petrol)	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Africa\Cabstar\Diesel\NATS_5 (diesel)	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Africa\Cube\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Africa\Cube\Proximity smart	Read BCM inner code, Program smart key,	1660
NISSAN\Select from vehicle\Africa\InterStar\Y70	Program key, Clear fault code,	1665
NISSAN\Select from vehicle\Africa\Juke\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Africa\Leaf	Read BCM inner code, Program smart key,	1654
NISSAN\Select from vehicle\Africa\Livina\2006-2012\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\Africa\Maxima\A34	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Africa\March\K12\Bar type	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\Africa\Micra\K11\2000-2003	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Africa\Micra\K12\Bar type	Program key, Clear fault code,	1664

NISSAN\Select from vehicle\Africa\Micra\K12\Smart key(knob type)	Read key count, Program smart key, Add remote Delete	1667
NISSAN\Select from vehicle\Africa\Micra\K13\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Africa\Micra\K13\Proximity smart	Read BCM inner code, Program smart key,	1660
NISSAN\Select from vehicle\Africa\Navara\D40(SIEMENS)\Petrol	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\Africa\Navara\D40(SIEMENS)\Diesel	Read BCM inner code, Program key, Delete remote Add remote	1626
NISSAN\Select from vehicle\Africa\Navara\D40(SIEMENS)\NATS_5	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Africa\Navara\D40(CONTINENTAL)\Bar	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Africa\Navara\D40(CONTINENTAL)\Smart	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Africa\NV200\Bar type	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\Africa\Note\E11\Bar type	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\Africa\Note\E11\Smart key(knob type)	Read key count, Program smart key, Add remote Delete	1667
NISSAN\Select from vehicle\Africa\NP30\Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Africa\Pathfinder\R51\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Africa\Pathfinder\R51\Smart key(knob type)	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Africa\Petrol\Y61\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Africa\Primera\P12\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Africa\Primera\P12\Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Africa\Pulsar\N16	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Africa\Qashqai\T10\Petrol\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\Africa\Qashqai\T10\Petrol\Smart	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Africa\Qashqai\T10\Diesel\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1626

NISSAN\Select from vehicle\Africa\Qashqai\T10\Diesel\Smart	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Africa\Qashqai\T11\Bar type	Program key,	1670
NISSAN\Select from vehicle\Africa\Qashqai\T11\Proximity smart	Program smart key,	1672
NISSAN\Select from vehicle\Africa\Rogue\2008-2011\Smart key(knob	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Africa\Skyline\V35	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Africa\Terrano T1\B20\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Africa\Tiida\Petrol	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\Africa\Tiida\Diesel\2000-	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Africa\X-Trail\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Africa\X-Trail\Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Australia\350Z\733	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Australia\370Z\2009-2010\Smart	Read BCM inner code, Program smart key,	1634
NISSAN\Select from vehicle\Australia\Almera\N16\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Australia\Almera\N16\Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Australia\Almera\Tino\V10\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Australia\Almera\Tino\V10\Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Australia\Cabstar\Petrol\NATS_5	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Australia\Cabstar\Diesel\NATS_5	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Australia\Cube\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Australia\Cube\Proximity	Read BCM inner code, Program smart key,	1660
NISSAN\Select from vehicle\Australia\Dualis\2007-2013\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624

NISSAN\Select from vehicle\Australia\Dualis\2007-2013\Proximity	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Australia\Dualis\2007-2013\Smart	Read BCM inner code, Program key, Delete smart key Add smart	1627
NISSAN\Select from vehicle\Australia\InterStar\X70	Program key, Clear fault code,	1665
NISSAN\Select from vehicle\Australia\Juke\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Australia\Juke\2011-2014\Proximity	Read BCM inner code, Program smart key,	1654
NISSAN\Select from vehicle\Australia\Leaf	Read BCM inner code, Program smart key,	1654
NISSAN\Select from vehicle\Australia\Maxima\A34	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Australia\March\K12\Bar type	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\Australia\Micra\K11\2000-2003	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Australia\Micra\K12\Bar type	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\Australia\Micra\K12\Smart key (knob)	Read key count, Program smart key, Add remote Delete	1667
NISSAN\Select from vehicle\Australia\Micra\K13\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Australia\Micra\K13\Proximity	Read BCM inner code, Program smart key,	1660
NISSAN\Select from vehicle\Australia\Murano\2010-\Proximity	Read BCM inner code, Program smart key,	1634
NISSAN\Select from vehicle\Australia\Navara\D40 (SIEMENS)\Petrol	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\Australia\Navara\D40 (SIEMENS)\Diesel	Read BCM inner code, Program key, Delete remote Add remote	1626
NISSAN\Select from vehicle\Australia\Navara\D40 (SIEMENS)\NATS_5	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Australia\Navara\D40 (CONTINENTAL)\Bar	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Australia\Navara\D40 (CONTINENTAL)\Smart	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Australia\NV200\Bar type	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\Australia\Note\F11\Bar type	Program key, Clear fault code,	1664

NISSAN\Select from vehicle\Australia\NP30\ Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Australia\Pathfinder\R51\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Australia\Pathfinder\R51\Smart	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Australia\Patrol\V61\Petrol\2001-2007	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Australia\Primeira\P12\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Australia\Primeira\P12\Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Australia\Pulsar\N16	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Australia\Pulsar\R17\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Australia\Pulsar\C12\Proximity	Read BCM inner code, Program smart key,	1660
NISSAN\Select from vehicle\Australia\Qashqai\I10\Petrol\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\Australia\Qashqai\I10\Petrol\Smart	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Australia\Qashqai\I10\Diesel\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1626
NISSAN\Select from vehicle\Australia\Qashqai\I10\Diesel\Smart	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Australia\Qashqai\I11\Bar type	Program key,	1670
NISSAN\Select from vehicle\Australia\Qashqai\I11\Proximity	Program smart key,	1672
NISSAN\Select from vehicle\Australia\Skylia\N35	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Australia\Terrano\II\R20\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Australia\Tiida\2000\Petrol\Bar type	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\Australia\Tiida\2000-2005\Bar type	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Australia\Tiida\2006-2012\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\Australia\X-Trail\T30\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594

NISSAN\Select from vehicle\Australia\X-Trail\T30\Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Australia\X-Trail\T31\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Australia\X-Trail\T31\Smart	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Australia\X-Trail\T31\Proximity	Read BCM inner code, Program smart key,	1634
NISSAN\Select from vehicle\Australia\Tiida\2006-2012\Remote	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Europe\350Z\Z33	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Europe\370Z\Z34\Smart key\insert	Read BCM inner code, Program smart key,	1634
NISSAN\Select from vehicle\Europe\Almera\N16\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Europe\Almera\N16\Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Europe\Almera\Tino\V10\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Europe\Almera\Tino\V10\Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Europe\Armada\2004-2007\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\Europe\Cabstar\Petrol\NATS_5 (petrol)	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Europe\Cabstar\Diesel\NATS_5 (diesel)	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Europe\Cube\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Europe\Cube\Proximity smart	Read BCM inner code, Program smart key,	1660
NISSAN\Select from vehicle\Europe\Juke\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Europe\Juke\Proximity smart	Read BCM inner code, Program smart key,	1660
NISSAN\Select from vehicle\Europe\March\K13\Proximity smart	Read BCM inner code, Program smart key,	1660
NISSAN\Select from vehicle\Europe\Leaf	Read BCM inner code, Program smart key,	1654
NISSAN\Select from vehicle\Europe\Leaf\A34	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594

NISSAN\Select from vehicle\Europe\Micra\K11\2000-2003	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Europe\Micra\K12\Bar type	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\Europe\Micra\K12\Smart key(knob type)	Read key count, Program smart key, Add remote Delete	1667
NISSAN\Select from vehicle\Europe\Micra\K13\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Europe\Micra\K13\Proximity smart	Read BCM inner code, Program smart key,	1660
NISSAN\Select from vehicle\Europe\Navara\D40(SIEMENS)\Petrol	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\Europe\Navara\D40(SIEMENS)\Diesel	Read BCM inner code, Program key, Delete remote Add remote	1626
NISSAN\Select from vehicle\Europe\Navara\D40(SIEMENS)\NATS_5	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Europe\Navara\D40(CONTINENTAL)\Bar	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Europe\Navara\D40(CONTINENTAL)\Smart	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Europe\NV200\Bar type	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\Europe\Note\E11\Bar type	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\Europe\Note\E11\Smart key(knob type)	Read key count, Program smart key, Add remote Delete	1667
NISSAN\Select from vehicle\Europe\Note\E2\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Europe\Pathfinder\R51\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Europe\Pathfinder\R51\Smart key(knob	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Europe\Petrol\Y61\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Europe\Primera\P12\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Europe\Primera\P12\Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Europe\Pulsar\N16	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Europe\Qashqai\T10-2009\Petrol\Bar	Read BCM inner code, Program key, Delete remote Add remote	1625



NISSAN\Select from vehicle\Europe\Qashqai\T10\2009\Petrol\Smart	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Europe\Qashqai\T10\2009\Diesel\Bar	Read BCM inner code, Program key, Delete remote Add remote	1626
NISSAN\Select from vehicle\Europe\Qashqai\T10\2009\Diesel\Smart	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Europe\Qashqai\T11\Bar type	Program key,	1670
NISSAN\Select from vehicle\Europe\Qashqai\T11\Proximity smart	Program smart key,	1672
NISSAN\Select from vehicle\Europe\Quest\V28	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\Europe\Sentra\B16	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Europe\Skyline\V35	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Europe\Skyline\JPM	Read BCM inner code, Program smart key,	1634
NISSAN\Select from vehicle\Europe\Terrano\T1\B20\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Europe\Tiida\Petrol	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\Europe\Tiida\Diesel\2000-	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Europe\Xterra\W D22	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Europe\Xterra\N50	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\Europe\X-Trail\T30\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Europe\X-Trail\T30\Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Europe\X-Trail\T31\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Europe\X-Trail\T31\Smart	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Europe\X-Trail\T32\Bar type	Program key,	1670
NISSAN\Select from vehicle\Europe\X-Trail\T32\Proximity	Program smart key,	1672
NISSAN\Select from vehicle\Middle East\3507\733	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594

NISSAN\Select from vehicle\Middle East\Almera\N16\Petrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Middle East\Almera\N16\Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Middle East\Almera	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Middle East\Almera	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Middle East\Cabstar\Petrol\NAT	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Middle East\Cabstar\Diesel\NAT	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Middle East\Cube\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Middle East\Cube\Proximity	Read BCM inner code, Program smart key,	1660
NISSAN\Select from vehicle\Middle East\Juke\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Middle East\Juke\Proximity	Read BCM inner code, Program smart key,	1660
NISSAN\Select from vehicle\Middle East\Leaf	Read BCM inner code, Program smart key,	1654
NISSAN\Select from vehicle\Middle East\Maxima\A34	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Middle East\Micra\K11\2000-	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Middle East\Micra\K12\Bar type	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\Middle East\Micra\K12\Smart	Read key count, Program smart key, Add remote Delete	1667
NISSAN\Select from vehicle\Middle East\Micra\K13\Bar type	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Middle East\Micra\K13\Proximity	Read BCM inner code, Program smart key,	1660
NISSAN\Select from vehicle\Middle East\Navara\D40	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\Middle East\Navara\D40	Read BCM inner code, Program key, Delete remote Add remote	1626
NISSAN\Select from vehicle\Middle East\Navara\D40	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Middle East\Navara\D40 (CONTINUE)	Read BCM inner code, Program key, Delete remote Add remote	1624

NISSAN\Select from vehicle\Middle East\Navara\D40(CONTINUE)	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Middle East\NV200\Bar type	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\Middle East\Note\E11\Bar type	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\Middle East\Note\E11\Smart	Read key count, Program smart key, Add remote Delete	1667
NISSAN\Select from vehicle\Middle East\Pathfinder\R51\Bar	Read BCM inner code, Program key, Delete remote Add remote	1624
NISSAN\Select from vehicle\Middle East\Pathfinder\R51\Smart	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Middle East\Patrol\Y61\Patrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Middle East\Primera\P12\Patrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Middle East\Primera\P12\Diesel	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Middle East\Pulsar\N16	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Middle East\Qashqai\J10\Patrol	Read BCM inner code, Program key, Delete remote Add remote	1625
NISSAN\Select from vehicle\Middle East\Qashqai\J10\Patrol	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Middle East\Qashqai\J10\Diesel	Read BCM inner code, Program key, Delete remote Add remote	1626
NISSAN\Select from vehicle\Middle East\Qashqai\J10\Diesel	Read BCM inner code, Program key, Delete remote Add remote	1630
NISSAN\Select from vehicle\Middle East\Qashqai\J11\Bar	Program key,	1670
NISSAN\Select from vehicle\Middle East\Qashqai\J11\Proxim	Program smart key,	1672
NISSAN\Select from vehicle\Middle East\Skyline\Y35	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Middle East\Terrano	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594
NISSAN\Select from vehicle\Middle East\Tiida\Patrol	Program key, Clear fault code,	1664
NISSAN\Select from vehicle\Middle East\Tiida\Diesel\2000-	Program key, Clear fault code,	1623
NISSAN\Select from vehicle\Middle East\X-Trail\Patrol	Program key, Clear fault code, Read BCM inner code Add remote Delete	1594

NISSAN>Select from vehicle\Middle East\X-Trail\Diesel	Program key,Clear fault code,	1623
NISSAN>Select from vehicle\Asia\X-Trail\T32\Replace BCM	Replace BCM,Configure data in read and write module Register TPMS	1728
NISSAN>Select from vehicle\Asia\X-Trail\T32\Proximity	Program smart key,	167
NISSAN>Select from type\Remote\Type 2	Delete remote,Add remote,	1746
NISSAN>Select from vehicle\North America\MIRANO\2005-	Read BCM inner code,Program key,Add remote Delete remote	1899
NISSAN>Select from vehicle\India\Remote\Type 1	Add remote,Delete remote,	158
HONDA>Select from vehicle\Europe\Insight\2010-	Add one key,All key lost,Reset key,	209
HONDA>Select from vehicle\Europe\Crz\2010-	Add one key,All key lost,Reset key,	209
HONDA>Select from vehicle\Europe\Crv\2013-\Mechanical key	Add one key,All key lost,Reset key,	209
HONDA>Select from vehicle\Middle East\Jazz\2012-HEV	Add one key,All key lost,Reset key,	209
HONDA>Select from vehicle\Middle East\Crv\2014-	Add one key,All key lost,Reset key,	209
HONDA>Select from vehicle\Australia\Insight\2010-	Add one key,All key lost,Reset key,	209
HONDA>Select from vehicle\Asia\Hrv\2014-	Add one key,All key lost,Reset key,	209
HONDA>Select from vehicle\South America\Crv\2012-	Add one key,All key lost,Reset key,	209
HONDA>Select from vehicle\South America\Odyssey\2011-	Add one key,All key lost,Reset key,	209
HONDA>Select from vehicle\USA\Accord\2013-\Mechanical key	Add one key,All key lost,Reset key,	209
HONDA>Select from vehicle\USA\Accord\2014-2015\Mechanical key	Add one key,All key lost,Reset key,	209
HONDA>Select from vehicle\USA\Accord\2016-\Mechanical key	Add one key,All key lost,Reset key,	209
HONDA>Select from vehicle\USA\Crv\2015-2016\Mechanical key	Add one key,All key lost,Reset key,	209
HONDA>Select from vehicle\USA\Crv\2015-2016\Remote	Add remote,Delete remote,	214
HONDA>Select from vehicle\USA\Crz\2013	Add one key,All key lost,Reset key,	209

HONDA\Select from vehicle\USA\Civic\2014-2016\Mechanical key	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\USA\Civic\2014-2016\Remote	Add remote, Delete remote,	214
HONDA\Select from vehicle\USA\Crosstour\2010-2014\Mechanical key	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\USA\Crosstour\2010-2014\Remote	Add remote, Delete remote,	214
HONDA\Select from vehicle\USA\Fit\2014-2016\Mechanical key	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\USA\Fit\2014-2016\Remote	Add remote, Delete remote,	214
HONDA\Select from vehicle\USA\Hrv\2016\Mechanical key	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\USA\Hrv\2016\Remote	Add remote, Delete remote,	214
HONDA\Select from vehicle\USA\Insight\2010-2013	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\USA\Odyssey\2011-2013\Mechanical key	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\USA\Odyssey\2011-2013\Remote	Add remote, Delete remote,	214
HONDA\Select from vehicle\USA\Xrv\2010-\Mechanical key	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\USA\Xrv\2010-\Remote	Add remote, Delete remote,	214
HONDA\Select from vehicle\USA\Veze\2010-\Mechanical key	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\USA\Veze\2010-\Remote	Add remote, Delete remote,	214
HONDA\Select from type\Immobilizer\16-Pin connector\IMMO1	Add one key, All key lost, Reset key,	206
HONDA\Select from type\Immobilizer\16-Pin connector\IMMO2	Add one key, All key lost, Reset key,	209
HONDA\Select from type\Smart key\Knob type	Add one key, All key lost, Detect smart key,	212
HONDA\Select from type\Smart key\Button type 1	Add one key, All key lost,	213
HONDA\Select from type\Remote\IMMO9	Add remote, Delete remote,	214
HONDA\Select from type\Immobilizer\16-Pin connector\IMMO3	Add key, All key lost, Reset immobiliser,	216

HONDA>Select from type\Immobilizer\16-Pin connector\IMMO4	Reset immobox, Reset ECM,	215
HONDA>Select from type\Immobilizer\16-Pin connector\Check IMMO	Immo type,	217
HONDA>Select from type\Smart key\Button type 2	Add 1 key, All key lost,	759
HONDA>Select from type\Smart key\Button type 3	Add 1 key, All key lost,	760
HONDA>Select from type\Immobilizer\3-Pin connector\Check IMMO	Search IMMO type,	807
HONDA>Select from type\Immobilizer\3-Pin connector\IMMO1	Add 1 key, All key lost, Reset key,	808
HONDA>Select from type\Immobilizer\3-Pin connector\IMMO2	Add one key, All key lost, Reset key,	209
HONDA>Select from type\Immobilizer\3-Pin connector\IMMO3	Add key, All key lost, Odometer adjustment	809
HONDA>Select from type\Immobilizer\3-Pin connector\IMMO4	Reset immobox, Reset ECM,	810
HONDA>Select from vehicle\Europe\S2000\2007-	Add one key, All key lost, Reset key,	206
HONDA>Select from vehicle\Europe\S2000\2003	Read key count, All key lost,	1377
HONDA>Select from vehicle\Europe\Legend\2006-	Add one key, All key lost, Reset key,	206
HONDA>Select from vehicle\Europe\Legend\1994-1996	Reset immobox, Reset ECM,	215
HONDA>Select from vehicle\Europe\Jazz\2008-	Add one key, All key lost, Reset key,	209
HONDA>Select from vehicle\Europe\Jazz\2008	Add one key, All key lost, Reset key,	206
HONDA>Select from vehicle\Europe\Insight\1999	Read key count, All key lost,	1377
HONDA>Select from vehicle\Europe\Hrv\2000-	Read key count, All key lost,	1377
HONDA>Select from vehicle\Europe\Hrv\2000	Add key, All key lost, Reset immobiliser,	216
HONDA>Select from vehicle\Europe\Frv	Add one key, All key lost, Reset key,	206
HONDA>Select from vehicle\Europe\Element\2003-2006	Add one key, All key lost, Reset key,	206
HONDA>Select from vehicle\Europe\Crv\2007-2012	Add one key, All key lost, Reset key,	209

HONDA\Select from vehicle\Europe\Crv\2002-2006	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Europe\Crv\2001	Read key count, All key lost,	1377
HONDA\Select from vehicle\Europe\Crv\2001	Add key, All key lost, Reset immobiliser,	216
HONDA\Select from vehicle\Europe\Civic\2006-2013	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\Europe\Civic\2001-2005	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Europe\City\2008-	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\Europe\Accord\2009-	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\Europe\Accord\2003-2008	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Europe\Accord\2002	Add key, All key lost, Reset immobiliser,	216
HONDA\Select from vehicle\India\Mobilo	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\India\Jazz	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\India\Crv\2007-	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\India\Crv\2006	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\India\Civic	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\India\City	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\India\Brio	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\India\Accord\2008-	Add key, All key lost, Reset immobiliser,	216
HONDA\Select from vehicle\India\Accord\2003-2007	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\India\Accord\1997-2002	Read key count, All key lost,	1377
HONDA\Select from vehicle\India\Amaze	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\Australia\S2000	Add one key, All key lost, Reset key,	206

HONDA

HONDA>Select from vehicle\Australia\Prelude\1997-	Reset immobox, Reset ECM,	215
HONDA>Select from vehicle\Australia\Odyssey\2009-	Add one key, All key lost, Reset key,	209
HONDA>Select from vehicle\Australia\Odyssey\2004-2008\T <sub>yp</sub> e 2	Add one key, All key lost, Reset key,	209
HONDA>Select from vehicle\Australia\Odyssey\2004-2008\T <sub>yp</sub> e 1	Add one key, All key lost, Reset key,	206
HONDA>Select from vehicle\Australia\Odyssey\2000-2004	Add one key, All key lost, Reset key,	206
HONDA>Select from vehicle\Australia\Odyssey\1999-2000\T <sub>yp</sub> e 2	Reset immobox, Reset ECM,	215
HONDA>Select from vehicle\Australia\Odyssey\1999-2000\T <sub>yp</sub> e 1	Add one key, All key lost, Reset key,	206
HONDA>Select from vehicle\Australia\Odyssey\1995-1998	Add one key, All key lost, Reset key,	206
HONDA>Select from vehicle\Australia\NSX\T <sub>yp</sub> e 2	Reset immobox, Reset ECM,	215
HONDA>Select from vehicle\Australia\NSX\T <sub>yp</sub> e 1	Add one key, All key lost, Reset key,	206
HONDA>Select from vehicle\Australia\MDX\2003-	Add one key, All key lost, Reset key,	206
HONDA>Select from vehicle\Australia\Legend\2008-	Add one key, All key lost, Reset key,	209
HONDA>Select from vehicle\Australia\Legend\2006-2008	Add one key, All key lost, Reset key,	206
HONDA>Select from vehicle\Australia\Legend\1996-2005\T <sub>yp</sub> e 2	Reset immobox, Reset ECM,	215
HONDA>Select from vehicle\Australia\Legend\1996-2005\T <sub>yp</sub> e 1	Add one key, All key lost, Reset key,	206
HONDA>Select from vehicle\Australia\Jazz\2008-	Add one key, All key lost, Reset key,	209
HONDA>Select from vehicle\Australia\Jazz\2002-2008	Add one key, All key lost, Reset key,	206
HONDA>Select from vehicle\Australia\Integra\2001-	Add one key, All key lost, Reset key,	206
HONDA>Select from vehicle\Australia\Integra\1999-2001	Reset immobox, Reset ECM,	215
HONDA>Select from vehicle\Australia\Insight\2001-2009	Add one key, All key lost, Reset key,	206
HONDA>Select from vehicle\Australia\Hrv\1999-	Add one key, All key lost, Reset key,	206



HONDA\Select from vehicle\Australia\Crv\2007-	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\Australia\Crv\2002-2006	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Australia\Crv\1999-2001\Other chin	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Australia\Crv\1999-2001\48 chin	Add key, All key lost, Reset immobiliser,	216
HONDA\Select from vehicle\Australia\Crv\1997-1999\Other chin	Reset immobox, Reset ECM,	215
HONDA\Select from vehicle\Australia\Crv\1997-1999\48 chin	Add key, All key lost, Reset immobiliser,	216
HONDA\Select from vehicle\Australia\Civic type R\2005-2011	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\Australia\Civic\2008-	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\Australia\Civic\1999-2006	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Australia\Civic\1995-1999	Reset immobox, Reset ECM,	215
HONDA\Select from vehicle\Australia\City\2009-	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\Australia\Accord\2008-	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\Australia\Accord\2002-2008	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Australia\Accord\2000-2001	Add key, All key lost, Reset immobiliser,	216
HONDA\Select from vehicle\Australia\Accord\1997-1999\Type 2	Reset immobox, Reset ECM,	215
HONDA\Select from vehicle\Australia\Accord\1997-1999\Type 1	Add key, All key lost, Reset immobiliser,	216
HONDA\Select from vehicle\Asia\Stepwagon\2005-	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Asia\Stream\Remote\2007-	Add remote, Delete remote,	214
HONDA\Select from vehicle\Asia\Stream\Mechanical key\2007-	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\Asia\Stream\Mechanical key\2007-	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Asia\S2000\2007-	Add one key, All key lost, Reset key,	206

HONDA\Select from vehicle\Asia\Odyssey\2008-	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\Asia\Odyssey\1999-2008	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Asia\Integra\2002	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Asia\Jazz\Mechanical key\2007-	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\Asia\Jazz\Mechanical key\2007-	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Asia\Fit\2007-	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\Asia\Fit\2007-	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Asia\Elysion\2005-	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Asia>Edit\2006-	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Asia\Crv\2006-	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\Asia\Crv\2002-2006	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Asia\Civic type R\2007-	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\Asia\Civic type R\2002	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Asia\Civic\2006-	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\Asia\Civic\2005-	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Asia\City\Mechanical key\2009-2012	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\Asia\City\Mechanical key\2007-2008	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Asia\Airwave\2006-	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Asia\Accord\2008-	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\Asia\Accord\1998-2008	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Africa\Jazz\2009-	Add one key, All key lost, Reset key,	209

HONDA\Select from vehicle\Africa\Jazz\2006-2008	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\Africa\Brio	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\South America\Accord\1998-	Reset immobox, Reset ECM,	215
HONDA\Select from vehicle\South America\City\2008-	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\South America\Civic\2005-	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\South America\Crv\2006-2009	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\USA\Accord\1998-2002	Read key count, All key lost,	1377
HONDA\Select from vehicle\USA\Accord\2003-2007	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\USA\Accord\2008-2012\Mechanical key	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\USA\Accord\2008-2012\Remote	Add remote, Delete remote,	214
HONDA\Select from vehicle\USA\Crv\2002-2006	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\USA\Crv\2007-2014\Mechanical key	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\USA\Crv\2007-2014\Remote	Add remote, Delete remote,	214
HONDA\Select from vehicle\USA\Civic\2001-2005	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\USA\Civic\2006-2013\Mechanical key	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\USA\Civic\2006-2013\Remote	Add remote, Delete remote,	214
HONDA\Select from vehicle\USA\Element\2003-2011	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\USA\Fit\2007-2008	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\USA\Fit\2009-2013	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\USA\Insight\2000-2006	Read key count, All key lost,	1377
HONDA\Select from vehicle\USA\Odyssey\1998-2002	Read key count, All key lost,	1377

HONDA\Select from vehicle\USA\Odyssey\2003-2010	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\USA\Pilot\2005-2008	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\USA\Pilot\2009-2015\Mechanical key	Add one key, All key lost, Reset key,	209
HONDA\Select from vehicle\USA\Pilot\2009-2015\Remote	Add remote, Delete remote,	214
HONDA\Select from vehicle\USA\Prelude	Read key count, All key lost,	1377
HONDA\Select from vehicle\USA\Ridgeline\2006-2013	Add one key, All key lost, Reset key,	206
HONDA\Select from vehicle\USA\S2000\2000-2005	Read key count, All key lost,	1377
HONDA\Select from vehicle\USA\S2000\2006-2008	Add one key, All key lost, Reset key,	206
HONDA\Select from type\Immobilizer\16-Pin connector\IMM05	Read key count, All key lost,	1377
MITSUBISHI\Select from vehicle\China\Pajero Sport\2017-\Smart key	Program smart key, Turn ignition on forcibly, Turn ignition on forcibly, Turn ignition on forcibly,	984
MITSUBISHI\Select from vehicle\China\TRITON\2017-\Smart key	Program smart key, Turn ignition on forcibly, Turn ignition on forcibly,	984
MITSUBISHI\Select from vehicle\China\Attraga\2015\Immobilizer	All key lost,	766
MITSUBISHI\Select from vehicle\China\Attraga\2015\Remote	Program remote,	191
MITSUBISHI\Select from vehicle\China\Phantom\Without	All key lost,	766
MITSUBISHI\Select from vehicle\China\Phantom\Without smart\Remote	Program remote,	191
MITSUBISHI\Select from vehicle\China\Phantom\With smart\2014\Smart	Program smart key,	188
MITSUBISHI\Select from vehicle\China\Phantom\With smart\2015-\Smart	Program key,	1620
MITSUBISHI\Select from vehicle\China\Phantom\With smart\2015-\Remote	Program remote,	1621
MITSUBISHI\Select from vehicle\China\Outlander\2016-\Immobilizer	Add key,	1631
MITSUBISHI\Select from vehicle\China\Outlander\2016-\Remote	Program remote,	1632
MITSUBISHI\Select from vehicle\China\Outlander\2014-\Immobilizer	Add key,	782

MITSUBISHI\Select from vehicle\China\Outlander \2014-\Remote	Program remote,	800
MITSUBISHI\Select from vehicle\China\Mirage\Wi th smart\2014-	Program smart key,	1089
MITSUBISHI\Generate LKE for all key lost	Generate LKE for all key lost,	1559
MITSUBISHI\Register key ID and VIN to engine	Register key ID to engine,Register VIN to engine	1955
MITSUBISHI\Select from vehicle\China\Xpander\2 018 -\Smart key	Program smart key,Turn ignition on forcibly Turn ignition	1977
MITSUBISHI\Select from vehicle\China\Attraga\ 2015\Smart key	Program smart key,	1989
MITSUBISHI\Select from type\Immobilizer\Type 1	All key lost,Register key ID,	181
MITSUBISHI\Select from type\Remote\Type 1	Program remote,	182
MITSUBISHI\Select from type\Smart key\Type 1	Program smart key,	183
MITSUBISHI\Select from type\Immobilizer\Type 2	Program key,	185
MITSUBISHI\Select from type\Remote\Type 2	Program remote,	187
MITSUBISHI\Select from type\Smart key\Type 2	Program smart key,	188
MITSUBISHI\Select from type\Immobilizer\Type 3	Program key,	190
MITSUBISHI\Select from type\Remote\Type 3	Program remote,	191
MITSUBISHI\Select from type\Remote\Type 4	Program remote,	193
MITSUBISHI\Select from type\Immobilizer\Type 4	Program key,	192
MITSUBISHI\Select from vehicle\China\Lancer- ex\Smart key\Type 1	Program smart key,	183
MITSUBISHI\Select from vehicle\China\Lancer- ex\Immobilizer\Type 1	All key lost,Register key ID,	181
MITSUBISHI\Select from vehicle\China\Lancer- ex\Remote\Type 1	Program remote,	182
MITSUBISHI\Select from vehicle\China\Outlander \2013\Smart key\Type 1	Program smart key,	183
MITSUBISHI\Select from vehicle\China\ASX\Smart key\Type 2	Program smart key,	188

MITSUBISHI\Select from vehicle\China\ASX\Immobilizer\Type 4	Program key,	192
MITSUBISHI\Select from vehicle\China\ASX\Remote\Type 4	Program remote,	193
MITSUBISHI\Select from vehicle\China\TRITON\2010\Immobilizer\Type 2	Program key,	185
MITSUBISHI\Select from vehicle\China\TRITON\2010\Immobilizer\Type 3	Program key,	190
MITSUBISHI\Select from vehicle\China\TRITON\2010\Remote\Type 2	Program remote,	187
MITSUBISHI\Select from vehicle\China\TRITON\2010\Remote\Type 3	Program remote,	191
MITSUBISHI\Select from vehicle\China\TRITON\2011\Immobilizer\Type 2	Program key,	185
MITSUBISHI\Select from vehicle\China\TRITON\2011\Immobilizer\Type 3	Program key,	190
MITSUBISHI\Select from vehicle\China\TRITON\2011\Remote\Type 2	Program remote,	187
MITSUBISHI\Select from vehicle\China\TRITON\2011\Remote\Type 3	Program remote,	191
MITSUBISHI\Select from vehicle\China\Pajero Sport\2010-	Program key,	185
MITSUBISHI\Select from vehicle\China\Pajero Sport\2010-\Remote\Type	Program remote,	187
MITSUBISHI\Select from type\Immobilizer\Type 5	Add key,	194
MITSUBISHI\Select from vehicle\China\V73\Immobilizer\Type 5	Add key,	194
MITSUBISHI\Select from vehicle\China\V97\Immobilizer\Type 5	Add key,	194
MITSUBISHI\Select from vehicle\China\Galant\Immobilizer\Type 5	Add key,	194
MITSUBISHI\Select from vehicle\China\Grandis\Immobilizer\Type 5	Add key,	194
MITSUBISHI\Select from vehicle\China\Pajero Sport\	Add key,	194
MITSUBISHI\Select from vehicle\China\Pajero Sport\	Program key,	1356
MITSUBISHI\Select from vehicle\China\Pajero Sport\2010\Remote\Type	Program remote,	193
MITSUBISHI\Select from vehicle\China\Pajero v93\2011-	Add key,	194

MITSUBISHI\Select from vehicle\China\Outlander \2014-\Smart key\Type 2	Program smart key,	691
MITSUBISHI\Select from type\Immobilizer\Type 6	Program key,	765
MITSUBISHI\Select from type\Immobilizer\Type 7	All key lost,	766
MITSUBISHI\Select from type\Immobilizer\Type 8	Add key,	782
MITSUBISHI\Select from type\Immobilizer\Type 9	All key lost,Key count,	796
MITSUBISHI\Select from type\Immobilizer\Type 10	All key lost,Key count,	769
MITSUBISHI\Select from type\Smart key\Type 3	Program smart key,	691
MITSUBISHI\Select from type\Smart key\Type 4	Add smart key,Key count,	767
MITSUBISHI\Select from type\Remote\Type 5	Program remote,	797
MITSUBISHI\Select from type\Remote\Type 6	Program remote,	798
MITSUBISHI\Select from type\Remote\Type 7	Program remote,	774
MITSUBISHI\Select from type\Remote\Type 8	Program remote,	800
MITSUBISHI\Select from type\Immobilizer\Type 1	Program key,	818
MITSUBISHI\Select from vehicle\China\Mirage\Wi th smart\=2014	Add smart key,Key count,	767
MITSUBISHI\Select from vehicle\China\Mirage\Wi thout smart	Add key,Program remote,	771
MITSUBISHI\Select from type\Immobilizer\Type 12	Program key,	833
MITSUBISHI\Select from type\Immobilizer\Type 13	Program key,	834
MITSUBISHI\Select from vehicle\China\Lancer\Im mobilizer	Program key,	192
MITSUBISHI\Select from vehicle\China\Lancer\Re mote	Program remote,	193
MITSUBISHI\Select from vehicle\China\Outlander \=2013\Immobilizer	Program key,	954
MITSUBISHI\Select from vehicle\China\Outlander \=2013\Remote	Program remote,	955

mitsubishi\Select from vehicle\Australia\3000gt	Add key, Reset immo ECU,	775
mitsubishi\Select from vehicle\Australia\Airtr	Add key, Reset immo ECU,	775
mitsubishi\Select from vehicle\Australia\ASX\W	Program smart key,	188
mitsubishi\Select from vehicle\Australia\ASX\W	Program key,	192
mitsubishi\Select from vehicle\Australia\Colt	Add key, Reset immo ECU,	775
mitsubishi\Select from vehicle\Australia\Challenger\1999-2003	Add key, Reset immobiliser,	870
mitsubishi\Select from vehicle\Australia\Express\1996-	Add key, Reset immobiliser,	883
mitsubishi\Select from vehicle\Australia\Express	Add key, Reset immo ECU,	775
mitsubishi\Select from vehicle\Australia\EVO\T	Add key, Reset immo ECU,	775
mitsubishi\Select from vehicle\Australia\EVO\T	Program key,	192
mitsubishi\Select from vehicle\Australia\Galan	Add key, Reset immo ECU,	775
mitsubishi\Select from vehicle\Australia\Lancer\1996-2003	Add key, Reset immobiliser,	874
mitsubishi\Select from vehicle\Australia\Lancer\2003-2006	Add key, Reset immobiliser,	873
mitsubishi\Select from vehicle\Australia\Lancer(CAN)	Program key,	192
mitsubishi\Select from vehicle\Australia\Lancer SW\1996-2003	Add key, Reset immobiliser,	872
mitsubishi\Select from vehicle\Australia\Lancer(sport)\Without smart	Program key,	192
mitsubishi\Select from vehicle\Australia\Lancer Wagon	Add key, Reset immo ECU,	775
mitsubishi\Select from vehicle\Australia\Lancer Sport back	Program key,	192
mitsubishi\Select from vehicle\Australia\Mirage\1996-2005	Add key, Reset immobiliser,	882
mitsubishi\Select from vehicle\Australia\Mirage\1996-2002	Add key, Reset immobiliser,	874
mitsubishi\Select from vehicle\Australia\Mirage\2004-2012	Add key, Reset immo ECU,	775



MITSUBISHI\Select from vehicle\Australia\Mirag e\2012-\With smart	Program smart key,	188
MITSUBISHI\Select from vehicle\Australia\Nimbu s\1998-1999	Add key, Reset immobiliser,	881
MITSUBISHI\Select from vehicle\Australia\Nimbu s\1999-2002	Add key, Reset immobiliser,	875
MITSUBISHI\Select from vehicle\Australia\CJ Lancer\Sedan	Program key,	192
MITSUBISHI\Select from vehicle\Australia\CJ Lancer\Sportback	Program key,	192
MITSUBISHI\Select from vehicle\Australia\CJ Ralliart\Sedan	Program key,	192
MITSUBISHI\Select from vehicle\Australia\CJ Ralliart\Sportback	Program key,	192
MITSUBISHI\Select from vehicle\Australia\CJ Evolution	Program key,	192
MITSUBISHI\Select from vehicle\Australia\Outla nder\Without smart	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Australia\Outla nder(CAN)\Without	All key lost, Program remote,	860
MITSUBISHI\Select from vehicle\Australia\Outla nder\With smart\2013	Program smart key,	188
MITSUBISHI\Select from vehicle\Australia\Pajer o\1996-2000	Add key, Reset immobiliser,	880
MITSUBISHI\Select from vehicle\Australia\Pajer o\2000-2005	Add key, Reset immobiliser,	867
MITSUBISHI\Select from vehicle\Australia\Pajer o\IO\1999-	Add key, Reset immobiliser,	871
MITSUBISHI\Select from vehicle\Australia\Star Wagon	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Australia\Trion Challenger\Type PIN	Add key, Reset immobiliser,	870
MITSUBISHI\Select from vehicle\Australia\Trion Challenger\Type PIN	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Australia\Trion Challenger\Type 3	Program key,	765
MITSUBISHI\Select from vehicle\Australia\Verad a\1996-2002	Add key, Reset immobiliser,	882
MITSUBISHI\Select from vehicle\Africa\Lancer\2 006-2012	Program key,	192
MITSUBISHI\Select from vehicle\Africa\L200 Triton\2006	Add key, Reset immobiliser,	870

MITSUBISHI\Select from vehicle\Africa\Outlander\2006	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Africa\Pajero\1999-2006	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Africa\Shogun\2001-2006	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\America\USA\Diamond\2000-2006	Add key, Reset immobiliser,	882
MITSUBISHI\Select from vehicle\America\USA\Eclipse\1996-2005	Add key, Reset immobiliser,	888
MITSUBISHI\Select from vehicle\America\USA\Eclipse[CAN]\2006-2009	All key lost, Key count,	769
MITSUBISHI\Select from vehicle\America\USA\Endeavor	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\America\USA\Endeavor[CAN]\2006-2009	All key lost, Key count,	769
MITSUBISHI\Select from vehicle\America\USA\EVO	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\America\USA\Galant\2000-2003	Add key, Reset immobiliser,	887
MITSUBISHI\Select from vehicle\America\USA\Galant[CAN]\2006-2009	All key lost, Key count,	769
MITSUBISHI\Select from vehicle\America\USA\Galant[PTN1]\1996-2000	Add key, Reset immobiliser,	876
MITSUBISHI\Select from vehicle\America\USA\Galant[PTN1]\2000-2003	Add key, Reset immobiliser,	886
MITSUBISHI\Select from vehicle\America\USA\Galant[PTN2]\1996-2000	Add key, Reset immobiliser,	875
MITSUBISHI\Select from vehicle\America\USA\Galant[PTN2]\2000-2003	Add key, Reset immobiliser,	876
MITSUBISHI\Select from vehicle\America\USA\Lancer\Type 1	Add key, Reset immobiliser,	874
MITSUBISHI\Select from vehicle\America\USA\Lancer\Type 2(CAN)	Program key,	192
MITSUBISHI\Select from vehicle\America\USA\Mirage\2012	Program smart key,	188
MITSUBISHI\Select from vehicle\America\USA\Montero\1999-2000	Add key, Reset immobiliser,	880
MITSUBISHI\Select from vehicle\America\USA\Montero\2001-2006	Add key, Reset immobiliser,	867
MITSUBISHI\Select from vehicle\America\USA\Montero Sport\1999-2004	Add key, Reset immobiliser,	870

MITSUBISHI

MITSUBISHI\Select from vehicle\America\USA\Outlander\2000-2003	Add key, Reset immobiliser,	867
MITSUBISHI\Select from vehicle\America\USA\Outlander\2004-2006	Add key, Reset immobiliser,	885
MITSUBISHI\Select from vehicle\America\USA\Outlander[CAN]\2007-2009	All key lost, Key count,	769
MITSUBISHI\Select from vehicle\America\USA\Outlander\2014	Program smart key,	188
MITSUBISHI\Select from vehicle\America\USA\Outlander (Sport)\With	Program smart key,	188
MITSUBISHI\Select from vehicle\America\USA\Outlander (Sport)\Without	Program key,	192
MITSUBISHI\Select from vehicle\America\USA\RVR\Without smart\2012	Program key,	192
MITSUBISHI\Select from vehicle\America\USA\RVR\Without smart\2012-	Program key,	192
MITSUBISHI\Select from vehicle\America\South America\ASX	Program key,	192
MITSUBISHI\Select from vehicle\America\South America\Diamante	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\America\South America\Eclipse	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\America\South America\Eclipse[CAN]	All key lost, Key count,	769
MITSUBISHI\Select from vehicle\America\South America\Endeavor	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\America\South America\Endeavor[CAN]	All key lost, Key count,	769
MITSUBISHI\Select from vehicle\America\South America\EVO	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\America\South America\Galant	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\America\South America\Galant[CAN]	All key lost, Key count,	769
MITSUBISHI\Select from vehicle\America\South America\Lancer	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\America\South America\Lancer[CAN]	Program key,	192
MITSUBISHI\Select from vehicle\America\South America\Montero	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\America\South America\Montero[CAN]\20	Program key,	765

MITSUBISHI\Select from vehicle\America\South America\Outlander	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\America\South America\Outlander [CAN]	Program key,	192
MITSUBISHI\Select from vehicle\America\South America\Outlander (2013)	Program smart key,	188
MITSUBISHI\Select from vehicle\America\South America\RVR\2012	Program key,	192
MITSUBISHI\Select from vehicle\America\South America\Pajero\v97/v98	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Europe\3000gt	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Europe\ASX\With smart	Program smart key,	188
MITSUBISHI\Select from vehicle\Europe\ASX\With out smart	Program key,	192
MITSUBISHI\Select from vehicle\Europe\Carisma	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Europe\Colt Lander	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Europe\Eclipse	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Europe\EVO\Type 1	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Europe\EVO\Type 2	Program key,	192
MITSUBISHI\Select from vehicle\Europe\Galant Wagon	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Europe\Galant\1 996-2004	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Europe\Grandis	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Europe\I-miev	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Europe\L200	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Europe\L200 [CAN]\2011-	Program key,	765
MITSUBISHI\Select from vehicle\Europe\L400	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Europe\Lancer	Add key, Reset immo ECU,	775

MITSUBISHI\Select from vehicle\Europe\Lancer Wagon	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Europe\Lancer Sportback	Program key,	192
MITSUBISHI\Select from vehicle\Europe\Lancer [C AN]	Program key,	192
MITSUBISHI\Select from vehicle\Europe\Lancer sport	Program key,	192
MITSUBISHI\Select from vehicle\Europe\Mirage\2 013\With smart	Program smart key,	188
MITSUBISHI\Select from vehicle\Europe\Magnum	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Europe\Outlande r\Without smart	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Europe\Outlande r\With smart\2013	Program smart key,	188
MITSUBISHI\Select from vehicle\Europe\Outlande r [CAN]	Program key,	192
MITSUBISHI\Select from vehicle\Europe\Pajero\1 999-2006	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Europe\Pajero Pinin	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Europe\Shogun	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Europe\Sigma	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Europe\Space Wagon	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Asia\Japan\Cari sma\1996-2004	Add key, Reset immobillser,	878
MITSUBISHI\Select from vehicle\Asia\Japan\Colt \1996-2000	Add key, Reset immobillser,	874
MITSUBISHI\Select from vehicle\Asia\Japan\Ecli pse\1996-2003	Add key, Reset immobillser,	877
MITSUBISHI\Select from vehicle\Asia\Japan\Gala nt [PIN1]\1996-2003	Add key, Reset immobillser,	876
MITSUBISHI\Select from vehicle\Asia\Japan\Gala nt [PIN2]\1996-2003	Add key, Reset immobillser,	875
MITSUBISHI\Select from vehicle\Asia\Japan\Lanc er\1996-2003	Add key, Reset immobillser,	874
MITSUBISHI\Select from vehicle\Asia\Japan\Lanc er\2003-2006	Add key, Reset immobillser,	873

MITSUBISHI\Select from vehicle\Asia\Japan\Lanc er SW\1996-2003	Add key, Reset immobillser,	872
MITSUBISHI\Select from vehicle\Asia\Japan\L200 \1999-2006	Add key, Reset immobillser,	870
MITSUBISHI\Select from vehicle\Asia\Japan\Mont ero\1999-2000	Add key, Reset immobillser,	880
MITSUBISHI\Select from vehicle\Asia\Japan\Mont ero\2001-2006	Add key, Reset immobillser,	867
MITSUBISHI\Select from vehicle\Asia\Japan\Mont ero IO\1999-	Add key, Reset immobillser,	871
MITSUBISHI\Select from vehicle\Asia\Japan\Mont ero Sport\1999-2004	Add key, Reset immobillser,	870
MITSUBISHI\Select from vehicle\Asia\Japan\Nati va\2001-2003	Add key, Reset immobillser,	870
MITSUBISHI\Select from vehicle\Asia\Japan\Paje ro\1999-2000	Add key, Reset immobillser,	880
MITSUBISHI\Select from vehicle\Asia\Japan\Paje ro\2000-2005	Add key, Reset immobillser,	867
MITSUBISHI\Select from vehicle\Asia\Japan\Paje ro IO\1999-	Add key, Reset immobillser,	871
MITSUBISHI\Select from vehicle\Asia\Japan\Paje ro Pinin\1999-	Add key, Reset immobillser,	871
MITSUBISHI\Select from vehicle\Asia\Japan\Paje ro sport\1999-2003	Add key, Reset immobillser,	870
MITSUBISHI\Select from vehicle\Asia\Japan\Shog un\1996-2000	Add key, Reset immobillser,	880
MITSUBISHI\Select from vehicle\Asia\Japan\Shog un\2000-2005	Add key, Reset immobillser,	867
MITSUBISHI\Select from vehicle\Asia\Japan\Shog un PINTN\1999-	Add key, Reset immobillser,	871
MITSUBISHI\Select from vehicle\Asia\Japan\Shog un Sport\1999-2003	Add key, Reset immobillser,	870
MITSUBISHI\Select from vehicle\Asia\Japan\Spac e Gear\1996-	Add key, Reset immobillser,	883
MITSUBISHI\Select from vehicle\Asia\Japan\Spac e Runner\1998-1999	Add key, Reset immobillser,	881
MITSUBISHI\Select from vehicle\Asia\Japan\Spac e Runner\1999-2002	Add key, Reset immobillser,	875
MITSUBISHI\Select from vehicle\Asia\Japan\Spac e Start [PIN1]\1999-	Add key, Reset immobillser,	875
MITSUBISHI\Select from vehicle\Asia\Japan\Spac e Start [PIN2]\1999-	Add key, Reset immobillser,	884

mitsubishi\Select from vehicle\Asia\Japan\Space Wagon\1998-1999	Add key, Reset immobiliser,	881
mitsubishi\Select from vehicle\Asia\Japan\Space Wagon\1999-2002	Add key, Reset immobiliser,	875
mitsubishi\Select from vehicle\Asia\Japan\3000GT\1996-2001	Add key, Reset immobiliser,	879
mitsubishi\Select from vehicle\Asia\Israel\Carisma	Add key, Reset immo ECU,	775
mitsubishi\Select from vehicle\Asia\Israel\Eclipse	Add key, Reset immo ECU,	775
mitsubishi\Select from vehicle\Asia\Israel\EclipseDis mma	Add key, Reset immo ECU,	775
mitsubishi\Select from vehicle\Asia\Israel\Endeavor	Add key, Reset immo ECU,	775
mitsubishi\Select from vehicle\Asia\Israel\Galant\1994-2004	Add key, Reset immo ECU,	775
mitsubishi\Select from vehicle\Asia\Israel\Grandis	Add key, Reset immo ECU,	775
mitsubishi\Select from vehicle\Asia\Israel\GT3000	Add key, Reset immo ECU,	775
mitsubishi\Select from vehicle\Asia\Israel\L200\2011	Program key,	765
mitsubishi\Select from vehicle\Asia\Israel\L400	Add key, Reset immo ECU,	775
mitsubishi\Select from vehicle\Asia\Israel\Lancer\ck/cs/sw/Sport back	Add key, Reset immo ECU,	775
mitsubishi\Select from vehicle\Asia\Israel\Lancer\cy/Sport/Y	Program key,	192
mitsubishi\Select from vehicle\Asia\Israel\Mirage	Add key, Reset immo ECU,	775
mitsubishi\Select from vehicle\Asia\Israel\Magnum	Add key, Reset immo ECU,	775
mitsubishi\Select from vehicle\Asia\Israel\Nativity	Add key, Reset immo ECU,	775
mitsubishi\Select from vehicle\Asia\Israel\Outlander\2013	Add key, Reset immo ECU,	775
mitsubishi\Select from vehicle\Asia\Israel\Outlander[CAN]\With smart	Program smart key,	188
mitsubishi\Select from vehicle\Asia\Israel\Pajero	Add key, Reset immo ECU,	775
mitsubishi\Select from vehicle\Asia\Israel\Sigma	Add key, Reset immo ECU,	775

MITSUBISHI\Select from vehicle\Asia\Israel\Space wagon\Without smart	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Asia\Israel\Space wagon\With	Program smart key,	188
MITSUBISHI\Select from vehicle\Asia\Israel\Space\Star\gear	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Asia\Israel\Strada	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Asia\Other\Delica\2007-2015	Program key,	192
MITSUBISHI\Select from vehicle\Asia\Other\EVO8	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Asia\Other\EVO9	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Asia\Other\EVO10\Immobilizer\2008-2010	Program key,	192
MITSUBISHI\Select from vehicle\Asia\Other\EVO10\Smart key	Program key,	192
MITSUBISHI\Select from vehicle\Asia\Other\Grandis	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Asia\Other\Lancer\CS	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Asia\Other\Lancer\CY	Program key,	192
MITSUBISHI\Select from vehicle\Asia\Other\L200 Triton\=2016	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Asia\Other\L200 Triton\2016-Type 1	Program key,	765
MITSUBISHI\Select from vehicle\Asia\Other\L200 Triton\2016-Type 2	Program key,	190
MITSUBISHI\Select from vehicle\Asia\Other\L200 Triton\2016-Type 3	All key lost,	766
MITSUBISHI\Select from vehicle\Asia\Other\Outlander\2005-2012	Program key,	192
MITSUBISHI\Select from vehicle\Asia\Other\Pajero\CK\2000-2010	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Greece\Carisma\1996-2004	Add key, Reset immobiliser,	878
MITSUBISHI\Select from vehicle\Greece\Colt\1996-2000	Add key, Reset immobiliser,	874
MITSUBISHI\Select from vehicle\Greece\Colt New\2002-	Add key, Reset immobiliser,	873



MITSUBISHI\Select from vehicle\Greece\Galant\1 996-2003	Add key, Reset immobiliser,	876
MITSUBISHI\Select from vehicle\Greece\Lancer\1 996-2003	Add key, Reset immobiliser,	874
MITSUBISHI\Select from vehicle\Greece\Lancer SW\1996-2003	Add key, Reset immobiliser,	872
MITSUBISHI\Select from vehicle\Greece\L200\199 9-2006	Add key, Reset immobiliser,	870
MITSUBISHI\Select from vehicle\Greece\Pajero\1 996-2000	Add key, Reset immobiliser,	880
MITSUBISHI\Select from vehicle\Greece\Pajero New\2000-2003	Add key, Reset immobiliser,	867
MITSUBISHI\Select from vehicle\Greece\Pajero Pinin\1999-	Add key, Reset immobiliser,	871
MITSUBISHI\Select from vehicle\Greece\Pajero sport\1999-2003	Add key, Reset immobiliser,	870
MITSUBISHI\Select from vehicle\Greece\Space Gear\1996-	Add key, Reset immobiliser,	883
MITSUBISHI\Select from vehicle\Greece\Space Runner\1998-1999	Add key, Reset immobiliser,	881
MITSUBISHI\Select from vehicle\Greece\Space Runner\1999-2002	Add key, Reset immobiliser,	875
MITSUBISHI\Select from vehicle\Greece\Space Start\1999-	Add key, Reset immobiliser,	889
MITSUBISHI\Select from vehicle\Greece\3000gt\1 996-	Add key, Reset immobiliser,	879
MITSUBISHI\Select from vehicle\Middle East\Eclipse	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Middle East\Eclipse Dic mma	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Middle East\Endeavor	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Middle East\GT3000	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Middle East\Galant\E50/EA/D11/	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Middle East\Grandis	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Middle East\Lancer\ck/cs/sw	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Middle East\Lancer\cy/X/Sport/	Program key,	192

MITSUBISHI\Select from vehicle\Middle East\I 200\–2007	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Middle East\Magna	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Middle East\Nativa	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Middle East\Outlander\cu/cw	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Middle East\Pajero\Q/CK/BK/TO/	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Middle East\Strada	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Middle East\Space\Star/gear/wa	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\Middle East\Sigma	Add key, Reset immo ECU,	775
MITSUBISHI\Select from vehicle\China\Attraga\2 015-\Smart key	Program smart key,	1089
MITSUBISHI\Select from vehicle\Australia\Outla nder (CAN)\Without	Program remote, Add key,	1368
MITSUBISHI\Select from vehicle\Australia\Outla nder (CAN)\With smart\–	Program smart key,	183
MITSUBISHI\Select from vehicle\Australia\Outla nder (CAN)\With	Program smart key,	691
MITSUBISHI\Select from vehicle\America\USA\Gal ant\2004–2005	Add key, Reset immobillser,	886
MITSUBISHI\Select from vehicle\America\USA\Gal ant\2006–	All key lost, Key count,	769
MITSUBISHI\Help (Mitsubishi's PIN)	Help (Mitsubishi's PIN),	1992
KIA\Select from vehicle\China\KX3 (KC)\2 018-\Smart key	Smart key, ECM neutral mode, SMK neutral mode, ESCL neutral mode	997
KIA\Select from vehicle\China\KX Cross\2017-\Smart key	Smart key, ECM neutral mode, SMK neutral mode, ESCL neutral mode	997
KIA\Select from vehicle\China\Forte (TDC)\2017–2019\Smart	Smart key, ECM neutral mode, SMK neutral mode, ESCL neutral mode	997
KIA\Select from vehicle\China\Forte (TDC)\2017–	Program key, ECM neutral mode, Read key count,	148
KIA\Select from vehicle\China\KX1\2018– 2019\Remote	Program remote,	253
KIA\Select from vehicle\China\Forte (TDC)\2017–2019\Remote	Program remote,	253

KIA\Select from vehicle\China\KX1\2018-2019\Immobilizer	Program key, ECM neutral mode,	1968
KIA\Select from vehicle\China\KX1\2018-2019\Smart key	Smart key, ECM neutral mode, SMK neutral mode, ESCL neutral mode	997
KIA\Select from vehicle\China\Horki 300\2018-2019\Smart key	Smart key, ECM neutral mode, SMK neutral mode, ESCL neutral mode	997
KIA\Select from vehicle\China\Optima (MC)\2004-	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\China\Sportage (KMC)\2007-	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\China\Sportage (KMC)\2007-	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Picanto (SA)\2006-	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Cerato (LD)\2003-	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Carens (FI)\2003-	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Carens (FI)\2006-	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Carens (FI)\2006-	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Sportage (KM)\Diese	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Sportage (KM)\2006-	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Sportage (KM)\2006-	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Sportage (KM)\2006-	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Optima/Magentis	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Sorento (BI)\2002-	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Sorento (BI)\2006-	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Carnival/Sedona	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\China\K3 (YDC)\2012-\Immobilizer	Program key, ECM neutral mode, Read key count,	147
KIA\Select from vehicle\China\K3 (YD)\2014-\Immobilizer	Program key, ECM neutral mode, Read key count,	147

KIA\Select from vehicle\General area\Carens/Rondo(RP)\2	Program key, ECM neutral mode, Read key count,	147
KIA\Select from vehicle\General area\Sorento(IIM)\2015-	Program key, ECM neutral mode, Read key count,	147
KIA\Select from vehicle\General area\Clarus/Forte(TD)\2	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\China\Sportage(KMC)\2007-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\China\Sportage R(SIC)\2010-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\China\K5(TFC)\2011-2012\Immobilizer	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\China\K5(TFC)\2013-2016\Immobilizer	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\China\K2(QBC)\2011-\Immobilizer\Type 1	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\USA\Forte/Forte koun(TD)\2009-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Carens(IIN)\2007-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Carnival/Sedona	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Mohave/Borrego(HM)	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Sorento(XM)\2009-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Sorento(XM)\2013-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\China\K5 HEV\2013-\Immobilizer	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Cadenza(VG)\2010-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Cadenza(VG)\2013-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\USA\AMANTI(GH)\2007-2008\Immobilizer	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Clarus/Forte(TD)\2	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
KIA\Select from vehicle\General area\Soul(AM)\2011-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
KIA\Select from vehicle\USA\Forte/Forte koun(TD)\2009-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151

KIA>Select from vehicle\General area\Sorento(XM)\2009-	Program smart key, ECM neutral mode, SMK neutral mode ESCL	151
KIA>Select from vehicle\General area\Mohave/Borrego(HM)	Program smart key, ECM neutral mode, SMK neutral mode ESCL	151
KIA>Select from vehicle\General area\Cadenza(VG)\2010-	Program smart key, ECM neutral mode, SMK neutral mode ESCL	151
KIA>Select from vehicle\China\K5(TFC)\2011-2012\Smart_key	Program smart key, ECM neutral mode, ESCL neutral mode PDM	81
KIA>Select from vehicle\China\K5 HEV\2013-\Smart_key	Program smart key, ECM neutral mode, ESCL neutral mode PDM	81
KIA>Select from vehicle\China\Sportage(KMC)\2013-2015\Smart	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
KIA>Select from vehicle\China\K2(QBC)\2011-\Smart_key	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
KIA>Select from vehicle\General area\Sorento(XM)\2013-	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
KIA>Select from vehicle\China\K4(PFC)\2015-\Smart_key	Program smart key, ECM neutral mode, SMK neutral mode ESCL	142
KIA>Select from vehicle\China\K5(TFC)\2013-2016\Smart_key	Program smart key, ECM neutral mode, SMK neutral mode ESCL	142
KIA>Select from vehicle\China\K3(YDC)\2012-\Smart_key	Program smart key, ECM neutral mode, SMK neutral mode ESCL	142
KIA>Select from vehicle\China\K3(YD)\2014-\Smart_key	Program smart key, ECM neutral mode, SMK neutral mode ESCL	142
KIA>Select from vehicle\China\KX3(KC)\2015-\Smart_key\Type_1	Program smart key, ECM neutral mode, SMK neutral mode ESCL	142
KIA>Select from vehicle\General area\Carens/Rondo(RP)\2	Program smart key, ECM neutral mode, SMK neutral mode ESCL	142
KIA>Select from vehicle\General area\Sorento(IIM)\2015-	Program smart key, ECM neutral mode, SMK neutral mode ESCL	142
KIA>Select from vehicle\General area\Cadenza(VG)\2013-	Program smart key, ECM neutral mode, SMK neutral mode ESCL	142
KIA>Select from vehicle\China\KX3(KC)\2015-\Smart_key\Type_2	Program smart key, ECM neutral mode, SMK neutral mode ESCL	144
KIA>Select from vehicle\China\Sportage(KMC)\2007-	Program key, ECM neutral mode, Read key count,	172
KIA>Select from vehicle\General area\Picanto(SA)\2006-	Program key, ECM neutral mode, Read key count,	172
KIA>Select from vehicle\General area\Rio(IR)\2005-	Program key, ECM neutral mode, Read key count,	172
KIA>Select from vehicle\General area\Carens(ET)\2006-	Program key, ECM neutral mode, Read key count,	172

KIA\Select from vehicle\General area\Carens (IN)\2007-	Program key, ECM neutral mode, Read key count,	172
KIA\Select from vehicle\General area\Sportage (KM)\2006-	Program key, ECM neutral mode, Read key count,	172
KIA\Select from vehicle\General area\Optima/Magentis	Program key, ECM neutral mode, Read key count,	172
KIA\Select from vehicle\General area\Mohave/Borrego (HM)	Program key, ECM neutral mode, Read key count,	172
KIA\Select from vehicle\China\Sportage (KMC)\2013-	Program key, ECM neutral mode, Read key count,	173
KIA\Select from vehicle\China\Sportage (KMC)\2013-	Program remote,	197
KIA\Select from vehicle\China\Sportage R(SLC)\2015-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA\Select from vehicle\China\Sportage R(SLC)\2015-\Smart key	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
KIA\Select from vehicle\China\Sportage R(SLC)\2010-2014\Smart	Program smart key, ECM neutral mode, ESCL neutral mode PDM	81
KIA\Select from vehicle\China\K2(QBC)\2011-\Remote	Program remote,	197
KIA\Select from vehicle\China\K3(YD)\2014-\Remote	Program remote,	197
KIA\Select from vehicle\China\K3(YDC)\2012-\Remote\Type 1	Program remote,	197
KIA\Select from vehicle\China\K5(TFC)\2013-2016\Remote	Program remote,	197
KIA\Select from vehicle\China\K5(TFC)\2011-2012\Remote	Program remote,	197
KIA\Select from vehicle\General area\Clarus/Forte (TD)\2	Program remote,	197
KIA\Select from vehicle\General area\Carens (IN)\2007-	Program remote,	197
KIA\Select from vehicle\General area\Soul (AM)\2011-	Program remote,	197
KIA\Select from vehicle\China\Optima (MSC)\2004-	Program remote,	197
KIA\Select from type\Immobilizer\Type 3 (K)	Program key, ECM neutral mode, Read key count,	146
KIA\Select from type\Immobilizer\Type 4 (K)	Program key, ECM neutral mode, Read key count,	148
KIA\Select from type\Immobilizer\Type 5 (K)	Program key, ECM neutral mode, Read key count,	147

KIA>Select from type\Immobilizer\Type 6(K)	Program key, ECM neutral mode, Read key count,	173
KIA>Select from type\Immobilizer\Type 1(CAN)	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA>Select from type\Immobilizer\Type 2(CAN)	Program key, ECM neutral mode, Read key count,	172
KIA>Select from type\Smart key\China\Type 1(with neutral mode ESCI)	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
KIA>Select from type\Smart key\China\Type 2(with neutral mode PDM)	Program smart key, ECM neutral mode, ESCL neutral mode PDM	81
KIA>Select from type\Smart key\China\Type 3(with neutral mode PDM)	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
KIA>Select from type\Smart key\China\Type 3(with neutral mode MSI)	Program smart key, ECM neutral mode, SMK neutral mode MSI	155
KIA>Select from type\Smart key\China\Type 4(with neutral mode ESCI)	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
KIA>Select from type\Smart key\China\Type 5(with neutral mode ESCI)	Program smart key, ECM neutral mode, SMK neutral mode ESCI	144
KIA>Select from type\Remote\16 PIN\Type 1(K)	Program remote,	197
KIA>Select from type\Remote\16 PIN\Type 2(CAN)	Program remote,	253
KIA\Read PIN code	Read PIN code(46 chip), 46 smart card Read PIN	427
KIA>Select from type\Remote\16 PIN\Type 3	Program remote,	659
KIA>Select from type\Remote\16 PIN\Type 4	Program remote,	660
KIA>Select from type\Remote\16 PIN\Type 5(K)	Program remote,	661
KIA>Select from vehicle\China\K2(QBC)\2011-\Immobilizer\Type 2	Program key, ECM neutral mode, Read key count,	147
KIA>Select from vehicle\China\KX5(QLC)\2016-\Immobilizer	Program key, ECM neutral mode, Read key count,	147
KIA>Select from vehicle\China\KX7(QMC)\2017-\Immobilizer	Program key, ECM neutral mode, Read key count,	147
KIA>Select from vehicle\China\KX5(QLC)\2016-\Smart key	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
KIA>Select from type\Remote\10 PIN\Type 1	Program remote,	843
KIA>Select from type\Remote\20 PIN\Type 1	Program remote,	844

KIA\Select from vehicle\China\Optima (MC)\2004-	Program remote,	844
KIA\Select from vehicle\China\Sportage (KMC)\2007-	Program key, ECM neutral mode, Read key count,	148
KIA\Select from vehicle\China\Sportage (KMC)\2013-	Program remote,	253
KIA\Select from vehicle\China\Sportage (KMC)\2013-	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\China\Sportage (KMC)\2013-	Program key, ECM neutral mode, Read key count,	148
KIA\Select from vehicle\China\Sportage (KMC)\2007-	Program remote,	197
KIA\Select from vehicle\China\Sportage (KMC)\2007-	Program remote,	253
KIA\Select from vehicle\General area\Sportage (KM)\Diese	Program key, ECM neutral mode, Read key count,	148
KIA\Select from vehicle\General area\Sportage (KM)\Diese	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Sportage (KM)\Diese	Program remote,	197
KIA\Select from vehicle\General area\Sportage (KM)\2006-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Sportage (KM)\2006-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Sportage (KM)\2006-	Program key, ECM neutral mode, Read key count,	148
KIA\Select from vehicle\General area\Sportage (KM)\2006-	Program remote,	197
KIA\Select from vehicle\General area\Soul (AM)\2011-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA\Select from vehicle\China\K4 (PFC)\2015-\Immobilizer	Program key, ECM neutral mode, Read key count,	147
KIA\Select from vehicle\China\K4 (PFC)\2015-\Remote	Program remote,	253
KIA\Select from vehicle\China\K3 (YDC)\2012-\Remote\Type 2	Program remote,	253
KIA\Select from vehicle\USA\Forte/Forte coup (TD)\2009-	Program remote,	253
KIA\Select from vehicle\China\KX3 (KC)\2015-\Immobilizer	Program key, ECM neutral mode, Read key count,	147
KIA\Select from vehicle\China\KX3 (KC)\2015-\Remote	Program remote,	197



KIA\Select from vehicle\China\KX5(QLC)\2016-\Remote	Program remote,	253
KIA\Select from vehicle\China\KX7(QMC)\2017-\Remote	Program remote,	253
KIA\Select from vehicle\General area\Picanto(SA)\2006-	Program remote,	659
KIA\Select from vehicle\General area\Picanto(SA)\2003-	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Picanto(SA)\2003-	Program remote,	659
KIA\Select from vehicle\General area\Rio(IB)\2005-	Program remote,	659
KIA\Select from vehicle\General area\Cerato(ID)\2003-	Program remote,	844
KIA\Select from vehicle\General area\Cerato(ID)\2007-	Program key, ECM neutral mode, Read key count,	172
KIA\Select from vehicle\General area\Cerato(ID)\2007-	Program remote,	659
KIA\Select from vehicle\General area\Carens/Rondo(RP)\2	Program remote,	197
KIA\Select from vehicle\General area\Carens(EI)\2003-	Program remote,	844
KIA\Select from vehicle\General area\Carens(EI)\2006-	Program remote,	844
KIA\Select from vehicle\General area\Carens(IN)\2007-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Optima/Magentis	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Optima/Magentis	Program remote,	197
KIA\Select from vehicle\General area\Optima/Magentis	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
KIA\Select from vehicle\General area\Carnival/Sedona	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Carnival/Sedona	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Carnival/Sedona	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Carnival/Sedona	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Carnival/Sedona	Program remote,	197

KIA\Select from vehicle\General area\Sorento(BI)\2002-	Program remote,	844
KIA\Select from vehicle\General area\Sorento(BI)\2006-	Program key, ECM neutral mode, Read key count,	172
KIA\Select from vehicle\General area\Sorento(BI)\2006-	Program remote,	197
KIA\Select from vehicle\General area\Sorento(XM)\2009-	Program remote,	197
KIA\Select from vehicle\General area\Sorento(XM)\2013-	Program remote,	197
KIA\Select from vehicle\General area\Sorento(IIM)\2015-	Program remote,	253
KIA\Select from vehicle\General area\Mohave/Borrego(HM)	Program remote,	197
KIA\Select from vehicle\General area\Cadenza(VG)\2010-	Program remote,	197
KIA\Select from vehicle\General area\Cadenza(VG)\2013-	Program remote,	197
KIA\Select from vehicle\China\K5(JFC)\2015-2018\Immobilizer	Program key, ECM neutral mode, Read key count,	147
KIA\Select from vehicle\China\K5(JFC)\2015-2018\Remote	Program remote,	253
KIA\Select from vehicle\China\K5(JFC)\2015-2018\Smart key	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
KIA\Select from vehicle\China\K5 HEV(IEC HEV)\2016-	Program key, ECM neutral mode, Read key count,	147
KIA\Select from vehicle\China\K5 HEV(IEC HEV)\2016-	Program remote,	253
KIA\Select from vehicle\China\K5 HEV(IEC HEV)\2016-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
KIA\Select from vehicle\China\Sportage R(SLC)\2015-\Remote	Program remote,	197
KIA\Select from vehicle\China\Sportage R(SLC)\2010-2014\Remote	Program remote,	197
KIA\Select from vehicle\China\Forte(TDC)\2009-\Immobilizer	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\China\Forte(TDC)\2009-\Remote	Program remote,	253
KIA\Select from vehicle\China\Forte(TDC)\2009-\Smart key	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
KIA\Select from vehicle\China\Rio(LCC)\2004-2008\Remote	Program remote,	659

KIA

KIA>Select from vehicle\China\Rio (JBC)\2007-2014\Remote	Program remote,	659
KIA>Select from vehicle\China\Cerato (LD C)\2005-2017\Remote	Program remote,	659
KIA>Select from vehicle\China\Soul (AMC)\2012-2015\Immobilizer	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA>Select from vehicle\China\Soul (AMC)\2012-2015\Remote	Program remote,	253
KIA>Select from vehicle\China\Soul (AMC)\2012-2015\Smart key	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
KIA>Select from vehicle\China\Soul (AMC)\2010\Immobilizer	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA>Select from vehicle\China\Soul (AMC)\2010\Remote	Program remote,	253
KIA>Select from vehicle\General area\Cadenza (YG)\2017\I	Program key, ECM neutral mode, Read key count,	147
KIA>Select from vehicle\General area\Cadenza (YG)\2017\R	Program remote,	253
KIA>Select from vehicle\General area\Cadenza (YG)\2017\S	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
KIA>Select from vehicle\General area\Carnival/Sedona	Program key, ECM neutral mode, Read key count,	146
KIA>Select from vehicle\General area\Carnival/Sedona	Program remote,	844
KIA>Select from vehicle\General area\Carnival/Sedona	Program key, ECM neutral mode, Read key count,	147
KIA>Select from vehicle\General area\Carnival/Sedona	Program remote,	253
KIA>Select from vehicle\General area\Carnival/Sedona	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
KIA>Select from vehicle\General area\Cee'd (FD)\2006-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA>Select from vehicle\General area\Cee'd (FD)\2006-	Program key, ECM neutral mode, Read key count,	172
KIA>Select from vehicle\General area\Cee'd (FD)\2006-	Program remote,	197
KIA>Select from vehicle\General area\Cee'd (ID)\2013-	Program key, ECM neutral mode, Read key count,	147
KIA>Select from vehicle\General area\Cee'd (ID)\2013-	Program remote,	197
KIA>Select from vehicle\General area\Cee'd (ID)\2013-	Program smart key, ECM neutral mode, SMK neutral mode PDM	152

KIA\Select from vehicle\General area\Clarus/Forte(YD)\2	Program key, ECM neutral mode, Read key count,	147
KIA\Select from vehicle\General area\Clarus/Forte(YD)\2	Program remote,	253
KIA\Select from vehicle\General area\Clarus/Forte(YD)\2	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
KIA\Select from vehicle\General area\K2500/K2700/K3000/	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\K2500/K2700/K3000/	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\K2500/K2700/K3000/	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\K2500/K2700/K3000/	Program remote,	659
KIA\Select from vehicle\General area\K2500/K2700/K3000/	Program remote,	659
KIA\Select from vehicle\General area\Mohave/Borrego(HM)	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Mohave/Borrego(HM)	Program key, ECM neutral mode, Read key count,	147
KIA\Select from vehicle\General area\Mohave/Borrego(HM)	Program remote,	253
KIA\Select from vehicle\General area\Mohave/Borrego(HM)	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
KIA\Select from vehicle\General area\Onirus(GH)\2009=	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Onirus(GH)\2009=	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Onirus(GH)\2009=	Program remote,	661
KIA\Select from vehicle\General area\Onirus(GH)\2009=	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
KIA\Select from vehicle\General area\Onirus(GH)\2007=	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Onirus(GH)\2007=	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Onirus(GH)\2007=	Program remote,	661
KIA\Select from vehicle\General area\Optima HEV(TF	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
KIA\Select from vehicle\General area\Optima HEV(TF	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142

KIA\Select from vehicle\General area\Optima HEV(TF)	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Optima HEV(TF)	Program remote,	197
KIA\Select from vehicle\General area\Optima HEV(TF)	Program smart key, ECM neutral mode, ESCL neutral mode PDM	81
KIA\Select from vehicle\General area\Optima (TF)\2016\Im	Program key, ECM neutral mode, Read key count,	147
KIA\Select from vehicle\General area\Optima (TF)\2016\Re	Program remote,	253
KIA\Select from vehicle\General area\Optima (TF)\2016\Sm	Program smart key, ECM neutral mode, SMK neutral mode ESCL	142
KIA\Select from vehicle\General area\Optima (TF)\2014-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Optima (TF)\2014-	Program remote,	197
KIA\Select from vehicle\General area\Optima (TF)\2014-	Program smart key, ECM neutral mode, SMK neutral mode ESCL	142
KIA\Select from vehicle\General area\Optima (TF)\2011-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Optima (TF)\2011-	Program remote,	197
KIA\Select from vehicle\General area\Optima (TF)\2011-	Program smart key, ECM neutral mode, ESCL neutral mode PDM	81
KIA\Select from vehicle\General area\Optima/Magentis	Program remote,	843
KIA\Select from vehicle\General area\Optima/Magentis	Program remote,	844
KIA\Select from vehicle\General area\Picanto (TA)\2012-	Program key, ECM neutral mode, Read key count,	147
KIA\Select from vehicle\General area\Picanto (TA)\2012-	Program remote,	197
KIA\Select from vehicle\General area\Picanto (TA)\2012-	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
KIA\Select from vehicle\General area\Pregio (EP)\2006\Im	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Quoris (KH)\2013-	Program smart key, ECM neutral mode, SMK neutral mode ESCL	142
KIA\Select from vehicle\General area\Rio (QBR)\2012-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Rio (QBR)\2012-	Program remote,	197

KIA\Select from vehicle\General area\Rio(OBR)\2012-	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
KIA\Select from vehicle\General area\Rio(UB)\2012-	Program key, ECM neutral mode, Read key count,	147
KIA\Select from vehicle\General area\Rio(UB)\2012-	Program remote,	197
KIA\Select from vehicle\General area\Rio(UB)\2012-	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
KIA\Select from vehicle\General area\Shuma/Spectra(SD)\	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Shuma/Spectra(SD)\	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\General area\Shuma/Spectra(SD)\	Program remote,	844
KIA\Select from vehicle\General area\Sorento(IMA)-	Program key, ECM neutral mode, Read key count,	147
KIA\Select from vehicle\General area\Sorento(IMA)-	Program remote,	253
KIA\Select from vehicle\General area\Sorento(IMA)-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
KIA\Select from vehicle\General area\Soul EV(PS	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
KIA\Select from vehicle\General area\Soul(AM)\2009-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\General area\Soul(AM)\2009-	Program remote,	197
KIA\Select from vehicle\General area\Soul(PS)\2013-	Program key, ECM neutral mode, Read key count,	147
KIA\Select from vehicle\General area\Soul(PS)\2013-	Program remote,	253
KIA\Select from vehicle\General area\Soul(PS)\2013-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
KIA\Select from vehicle\General area\Sportage(OL)\2016-	Program key, ECM neutral mode, Read key count,	147
KIA\Select from vehicle\General area\Sportage(OL)\2016-	Program remote,	253
KIA\Select from vehicle\General area\Sportage(OL)\2016-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
KIA\Select from vehicle\General area\Sportage(OLE)\2016-	Program key, ECM neutral mode, Read key count,	147
KIA\Select from vehicle\General area\Sportage(OLE)\2016-	Program remote,	253

KIA>Select from vehicle\General area\Sportage (OLF)\2016-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
KIA>Select from vehicle\General area\Sportage (SI)\2014-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA>Select from vehicle\General area\Sportage (SI)\2014-	Program remote,	197
KIA>Select from vehicle\General area\Sportage (SI)\2014-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
KIA>Select from vehicle\General area\Sportage (SI)\2011-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA>Select from vehicle\General area\Sportage (SI)\2011-	Program remote,	197
KIA>Select from vehicle\General area\Sportage (SI)\2011-	Program smart key, ECM neutral mode, ESCL neutral mode PDM	81
KIA>Select from vehicle\General area\Sportage (SIE)\2014-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA>Select from vehicle\General area\Sportage (SIE)\2014-	Program remote,	197
KIA>Select from vehicle\General area\Sportage (SIE)\2014-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
KIA>Select from vehicle\General area\Sportage (SIE)\2011-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA>Select from vehicle\General area\Sportage (SIE)\2011-	Program remote,	197
KIA>Select from vehicle\General area\Sportage (SIE)\2011-	Program smart key, ECM neutral mode, ESCL neutral mode PDM	81
KIA>Select from vehicle\General area\Venga (YN)\2013-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA>Select from vehicle\General area\Venga (YN)\2013-	Program remote,	197
KIA>Select from vehicle\General area\Venga (YN)\2013-	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
KIA>Select from vehicle\General area\Venga (YN)\2010-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA>Select from vehicle\General area\Venga (YN)\2010-	Program remote,	197
KIA>Select from vehicle\General area\Venga (YN)\2010-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
KIA>Select from vehicle\USA\AMANTI (GH)\2009\Immobilizer	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA>Select from vehicle\USA\AMANTI (GH)\2009\Smart key	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151

KIA>Select from vehicle\USA\Borrego (HM)\2009-2011\Immobilizer	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA>Select from vehicle\USA\Borrego (HM)\2009-2011\Remote	Program remote,	1043
KIA>Select from vehicle\USA\Borrego (HM)\2009-2011\Smart key	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
KIA>Select from vehicle\USA\Cadenza (VG)\2014-2016\Immobilizer	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA>Select from vehicle\USA\Cadenza (VG)\2014-2016\Remote	Program remote,	197
KIA>Select from vehicle\USA\Cadenza (VG)\2014-2016\Smart key	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
KIA>Select from vehicle\USA\Forte (YD)\2014-2016\Immobilizer	Program key, ECM neutral mode, Read key count,	147
KIA>Select from vehicle\USA\Forte (YD)\2014-2016\Remote	Program remote,	253
KIA>Select from vehicle\USA\Forte (YD)\2014-2016\Smart key	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
KIA>Select from vehicle\USA\K900 (KH)\2015-2017\Smart key	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
KIA>Select from vehicle\USA\Optima hybrid (TEHEV)\2014-	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
KIA>Select from vehicle\USA\Optima hybrid (TEHEV)\2013\Immo	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA>Select from vehicle\USA\Optima hybrid (TEHEV)\2013\Remo	Program remote,	197
KIA>Select from vehicle\USA\Optima hybrid (TEHEV)\2013\Smar	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
KIA>Select from vehicle\USA\Optima hybrid (TEHEV)\2011-	Program remote,	197
KIA>Select from vehicle\USA\Optima (JF)\2016\Immobilizer	Program key, ECM neutral mode, Read key count,	147
KIA>Select from vehicle\USA\Optima (JF)\2016\Remote	Program remote,	253
KIA>Select from vehicle\USA\Optima (JF)\2016\Smart key	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
KIA>Select from vehicle\USA\Optima (JFA)\2016\Immobilizer	Program key, ECM neutral mode, Read key count,	147
KIA>Select from vehicle\USA\Optima (JFA)\2016\Remote	Program remote,	253
KIA>Select from vehicle\USA\Optima (JFA)\2016\Smart key	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997



KIA\Select from vehicle\USA\Optima (MG)\2010\Immobilizer	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA\Select from vehicle\USA\Optima (MG)\2010\Smart key\With	Program smart key, ECM neutral mode, SMK neutral mode ESCL	151
KIA\Select from vehicle\USA\Optima (MG)\2010\Smart key\Without	Program smart key, ECM neutral mode, SMK neutral mode ESCL	1070
KIA\Select from vehicle\USA\Optima (MG)\2010\Remote	Program remote,	197
KIA\Select from vehicle\USA\Optima (MG)\2009\Immobilizer	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA\Select from vehicle\USA\Optima (MG)\2009\Remote	Program remote,	197
KIA\Select from vehicle\USA\Optima (MG)\2007-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA\Select from vehicle\USA\Optima (MG)\2007-	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\USA\Optima (MG)\2007-2008\Remote	Program remote,	197
KIA\Select from vehicle\USA\Optima (MG)\2006\Immobilizer	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\USA\Optima (MG)\2006\Remote	Program remote,	197
KIA\Select from vehicle\USA\OPTIMA (MS)\2003-2006\Remote	Program remote,	844
KIA\Select from vehicle\USA\OPTIMA (MS)\2001-2002\Remote	Program remote,	843
KIA\Select from vehicle\USA\Optima (TF/QE)\2014-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA\Select from vehicle\USA\Optima (TF/QE)\2014-2015\Remote	Program remote,	197
KIA\Select from vehicle\USA\Optima (TF/QE)\2014-2015\Smart key	Smart key, ECM neutral mode, SMK neutral mode ESCL neutral mode	997
KIA\Select from vehicle\USA\Optima (TF/QE)\2011-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA\Select from vehicle\USA\Optima (TF/QE)\2011-2013\Remote	Program remote,	197
KIA\Select from vehicle\USA\Optima (TF/QE)\2011-2013\Smart key	Program smart key, ECM neutral mode, ESCL neutral mode PDM	81
KIA\Select from vehicle\USA\RIO (BC)\2003-2005\Remote	Program remote,	844
KIA\Select from vehicle\USA\RIO (JB)\2006-2012\Remote	Program remote,	659

KIA\Select from vehicle\USA\Rio(UB)\2012-2017\Immobilizer	Program key, ECM neutral mode, Read key count,	147
KIA\Select from vehicle\USA\Rio(UB)\2012-2017\Remote	Program remote,	197
KIA\Select from vehicle\USA\Rio(UB)\2012-2017\Smart key	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
KIA\Select from vehicle\USA\Rondo(UN)\2007-2010\Immobilizer	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\USA\Rondo(UN)\2007-2010\Remote	Program remote,	197
KIA\Select from vehicle\USA\Sedona(VQ)\2007-2014\Immobilizer	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\USA\Sedona(VQ)\2006\Immobilizer	Program key, ECM neutral mode, Read key count,	146
KIA\Select from vehicle\USA\Sedona(YP)\2015-2016\Immobilizer	Program key, ECM neutral mode, Read key count,	147
KIA\Select from vehicle\USA\Sedona(YP)\2015-2016\Remote	Program remote,	253
KIA\Select from vehicle\USA\Sedona(YP)\2015-2016\Smart key	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
KIA\Select from vehicle\USA\Sorento(BL)\2007-2009\Immobilizer	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\USA\Sorento(BL)\2007-2009\Remote	Program remote,	197
KIA\Select from vehicle\USA\Sorento(BL)\2003-2006\Remote	Program remote,	844
KIA\Select from vehicle\USA\Sorento(IIMA)\2016-	Program key, ECM neutral mode, Read key count,	147
KIA\Select from vehicle\USA\Sorento(IIMA)\2016-2017\Remote	Program remote,	253
KIA\Select from vehicle\USA\Sorento(IIMA)\2016-2017\Smart	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
KIA\Select from vehicle\USA\Sorento(XM)\2014-2015\Immobilizer	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\USA\Sorento(XM)\2014-2015\Remote	Program remote,	197
KIA\Select from vehicle\USA\Sorento(XM)\2014-2015\Smart key	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
KIA\Select from vehicle\USA\Sorento(XM)\2011-2013\Immobilizer	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
KIA\Select from vehicle\USA\Sorento(XM)\2011-2013\Remote	Program remote,	197

KIA\Select from vehicle\USA\Sorento (XM) \2011-2013\Smart key	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
KIA\Select from vehicle\USA\Soul EV (PS EV)\2015-2016\Smart key	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
KIA\Select from vehicle\USA\Soul (AM) \2011-2013\Immobilizer	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA\Select from vehicle\USA\Soul (AM) \2011-2013\Remote	Program remote,	197
KIA\Select from vehicle\USA\Soul (AM) \2011-2013\Smart key	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
KIA\Select from vehicle\USA\Soul (AM) \2010\Immobilizer	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA\Select from vehicle\USA\Soul (AM) \2010\Remote	Program remote,	197
KIA\Select from vehicle\USA\Soul (PS) \2014-2016\Immobilizer	Program key, ECM neutral mode, Read key count,	147
KIA\Select from vehicle\USA\Soul (PS) \2014-2016\Remote	Program remote,	253
KIA\Select from vehicle\USA\Soul (PS) \2014-2016\Smart key	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
KIA\Select from vehicle\USA\Spectra (LD) \2007-2009\Immobilizer	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA\Select from vehicle\USA\Spectra (LD) \2007-2009\Remote	Program remote,	659
KIA\Select from vehicle\USA\Spectra (LD) \2004-2006\Remote	Program remote,	844
KIA\Select from vehicle\USA\Sportage (KM) \2007-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA\Select from vehicle\USA\Sportage (KM) \2007-2010\Remote	Program remote,	197
KIA\Select from vehicle\USA\Sportage (KM) \2005-2006\Remote	Program remote,	197
KIA\Select from vehicle\USA\Sportage (QI) \2017\Immobilizer	Program key, ECM neutral mode, Read key count,	147
KIA\Select from vehicle\USA\Sportage (QI) \2017\Remote	Program remote,	253
KIA\Select from vehicle\USA\Sportage (SI) \2014-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA\Select from vehicle\USA\Sportage (SI) \2014-2016\Remote	Program remote,	197
KIA\Select from vehicle\USA\Sportage (SI) \2014-2016\Smart	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997

KIA\Select from vehicle\USA\Sportage (SI)\2011-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
KIA\Select from vehicle\USA\Sportage (SI)\2011-2013\Remote	Program remote,	197
KIA\Select from vehicle\USA\Sportage (SI)\2011-2013\Smart	Program smart key, ECM neutral mode, ESCL neutral mode PDM	81
KIA\Select from type\Immobilizer\Type 7 (K)	Program key, ECM neutral mode, Read key count,	1046
KIA\Select from type\Immobilizer\Type 8 (CAN)	Program key, neutral mode,	1044
KIA\Select from type\Immobilizer\Type 9 (CAN)	Program key, neutral mode,	1045
KIA\Select from type\Smart key\General area\Type 1 (with slot	Program smart key, ECM neutral mode, SMK neutral mode ESCL	151
KIA\Select from type\Smart key\General area\Type 2 (with slot	Program smart key, ECM neutral mode, ESCL neutral mode PDM	81
KIA\Select from type\Smart key\General area\Type 3 (without	Program smart key, ECM neutral mode, SMK neutral mode ESCL	142
KIA\Select from type\Smart key\General area\Type 4 (without	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
KIA\Select from type\Smart key\USA\Type 1 (with slot K)	Program smart key, ECM neutral mode, SMK neutral mode ESCL	151
KIA\Select from type\Smart key\USA\Type 2 (with slot K)	Program smart key, ECM neutral mode, ESCL neutral mode PDM	81
KIA\Select from type\Smart key\USA\Type 3 (without slot CAN)	Smart key, ECM neutral mode, SMK neutral mode ESCL neutral mode	997
KIA\Select from type\Smart key\USA\Type 4 (without slot K)	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
KIA\Select from type\Remote\16 PIN\Type 6 (K)	Program remote,	1043
KIA\Select from vehicle\USA\Sportage (QI)\2017\Smart key	Smart key, ECM neutral mode, SMK neutral mode ESCL neutral mode	997
KIA\Select from vehicle\China\KX7 (QMC)\2017-\Smart key	Program smart key, ECM neutral mode, SMK neutral mode ESCL	142
CHRYSLER\Select from vehicle\Asia\Pacifica\2017\Smart key	Read PIN code, Add smart key, Delete smart key,	1882
CHRYSLER\Select from vehicle\Asia\Pacifica\2018\Smart key	Add smart key, Delete smart key, Key count,	1890
CHRYSLER\Select from vehicle\Asia\300C\2019-2020\Smart key	Add smart key, Delete smart key, Key count,	1880
CHRYSLER\Select from vehicle\Asia\300\2019-2020\Smart key	Add smart key, Delete smart key, Key count,	1880

CHRYSLER\Select from vehicle\Asia\300\2018\Smart key	Add smart key, Delete smart key, Key count,	1901
CHRYSLER\Select from vehicle\Asia\300C\2018\Smart key	Add smart key, Delete smart key, Key count,	1901
CHRYSLER\Select from vehicle\North America\300\2018\Smart key	Add smart key, Delete smart key, Key count,	1901
CHRYSLER\Select from vehicle\North America\300C\2018\Smart key	Add smart key, Delete smart key, Key count,	1901
CHRYSLER\Select from vehicle\North America\300\2019-	Add smart key, Delete smart key, Key count,	1880
CHRYSLER\Select from vehicle\North America\300C\2019-	Add smart key, Delete smart key, Key count,	1880
CHRYSLER\Select from vehicle\North America\Pacifica\2017\Smart key	Read PIN code, Add smart key, Delete smart key,	1882
CHRYSLER\Select from vehicle\North America\Pacifica\2018\Smart key	Add smart key, Delete smart key, Key count,	1890
CHRYSLER\Select from vehicle\North America\300C\2015-	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\North America\300\2015-	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\Asia\300C\2015-2017\PEPS\Type_1	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\Asia\300\2015-2017\PEPS\Type_1	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\Africa\300C\2015-2017\PEPS\Type_1	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\Africa\300\2015-2017\PEPS\Type_1	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\Australia\300C\2015-2017\PEPS\Type_1	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\Australia\300\2015-2017\PEPS\Type_1	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\Europe\300C\2015-2017\PEPS\Type_1	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\Europe\300\2015-2017\PEPS\Type_1	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\South America\300C\2015-	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\South America\300\2015-	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\Middle East\300C\2015-	Add smart key, Delete smart key, Read PIN code	268

CHRYSLER\Select from vehicle\Middle East\300\2015-	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\North America\300\2015-	Add smart key, Delete smart key,	1891
CHRYSLER\Select from vehicle\North America\300C\2015-	Add smart key, Delete smart key,	1891
CHRYSLER\Select from vehicle\Asia\300\2015-2017\PEPS\Type 2	Add smart key, Delete smart key,	1891
CHRYSLER\Select from vehicle\Asia\300C\2015-2017\PEPS\Type 2	Add smart key, Delete smart key,	1891
CHRYSLER\Select from vehicle\Europe\300\2015-2017\PEPS\Type 2	Add smart key, Delete smart key,	1891
CHRYSLER\Select from vehicle\Europe\300C\2015-2017\PEPS\Type 2	Add smart key, Delete smart key,	1891
CHRYSLER\Select from vehicle\South America\300\2015-	Add smart key, Delete smart key,	1891
CHRYSLER\Select from vehicle\South America\300C\2015-	Add smart key, Delete smart key,	1891
CHRYSLER\Select from vehicle\Middle East\300\2015-	Add smart key, Delete smart key,	1891
CHRYSLER\Select from vehicle\Middle East\300C\2015-	Add smart key, Delete smart key,	1891
CHRYSLER\Select from vehicle\Australia\300\2015-2017\PEPS\Type 2	Add smart key, Delete smart key,	1891
CHRYSLER\Select from vehicle\Australia\300C\2015-2017\PEPS\Type 2	Add smart key, Delete smart key,	1891
CHRYSLER\Select from vehicle\Africa\300\2015-2017\PEPS\Type 2	Add smart key, Delete smart key,	1891
CHRYSLER\Select from vehicle\Africa\300C\2015-2017\PEPS\Type 2	Add smart key, Delete smart key,	1891
CHRYSLER\Select from type\Immobilizer\Type 1(CAN)	Add new key, Add old key, Add remote, Detect key count Delete key	263
CHRYSLER\Select from type\Immobilizer\Type 2(CAN)	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from type\Immobilizer\Type 3(CAN)	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from type\Immobilizer\Type 4(CAN)	Read pin code, Add key, Delete key, Key count Modify VIN code	266
CHRYSLER\Select from type\Immobilizer\Type 5(CAN)	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from type\Smart key\Type 1(CAN)	Add smart key, Delete smart key, Read PIN code	268

CHRYSLER>Select from type\Remote\Type 4(CAN)	Add remote, Read pin code,	273
CHRYSLER>Select from type\Remote\Type 3(VPW)	Add remote,	272
CHRYSLER>Select from type\Remote\Type 2(VPW)	Add remote,	271
CHRYSLER>Select from type\Smart key\Type 2(CAN)	Read PIN code, Add smart key, Delete smart key, Key count	269
CHRYSLER>Select from type\Immobilizer\Type 6(VPW)	Add key, Delete key, Key count, Read PIN code(OBD) Read PIN	274
CHRYSLER>Select from type\IMMO-Fobik	Read PIN code, Sync smart key, Add key, Delete key, Modify	783
CHRYSLER>Select from vehicle\Asia\300\2011-2014\Smart key	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER>Select from vehicle\Asia\Fremont\2011-\Smart key	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER>Select from vehicle\Asia\300M\1998-2000\Remote	Add remote,	803
CHRYSLER>Select from vehicle\Asia\Concorde\1998-2000\Remote	Add remote,	803
CHRYSLER>Select from vehicle\Asia\LHS\1999-2001\Remote	Add remote,	803
CHRYSLER>Select from vehicle\Asia\PT Cruiser\2001-	Add remote,	270
CHRYSLER>Select from vehicle\Asia\Sebring\2001-2006\Remote	Add remote,	803
CHRYSLER>Select from vehicle\Asia\Town & Country\2001-	Add remote, Delete remote,	802
CHRYSLER>Select from type\Remote\Type 1(VPW)	Add remote,	270
CHRYSLER>Select from type\Remote\Type 5(VPW)	Add remote, Delete remote,	802
CHRYSLER>Select from type\Remote\Type 6(VPW)	Add remote,	803
CHRYSLER>Select from type\Remote\Type 7(VPW)	Add remote,	804
CHRYSLER>Select from type\Remote\Type 8(VPW)	Add remote,	805
CHRYSLER>Select from vehicle\Asia\200\2014-2017\Smart key	Read PIN code, Add smart key, Delete smart key,	990
CHRYSLER>Select from type\Immobilizer\Type 7(VPW)	Add key, Delete key,	1489

CHRYSLER\Select from type\Immobilizer\Type 8(CAN)	Add new key, Add old key, Add remote, Delete key, Key count, Read PIN	1483
CHRYSLER\Select from type\Smart key\Type 3(CAN)	Add smart key, Delete smart key, Read PIN code	1492
CHRYSLER\Select from type\Smart key\Type 4(CAN)	Sync smart function,	1493
CHRYSLER\Select from type\Smart key\Type 5(CAN)	Add smart key, Delete smart key, Read PIN code	1494
CHRYSLER\Select from vehicle\North America\200\2011-	Read PIN code, Add new key, Delete key, Key count, Add old key	264
CHRYSLER\Select from vehicle\North America\200\2014-	Read PIN code, Add smart key, Delete smart key,	990
CHRYSLER\Select from vehicle\North America\300\2005-	Add new key, Add old key, Add remote, Delete key, Key count, Read PIN	1483
CHRYSLER\Select from vehicle\North America\300\2006-	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from vehicle\North America\300\2008\EOBIK	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\North America\300\2009-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
CHRYSLER\Select from vehicle\North America\300\2011-	Read PIN code, Add new key, Delete key, Key count, Add old key	264
CHRYSLER\Select from vehicle\North America\300\2011-	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\North America\300C\2005-	Add new key, Add old key, Add remote, Delete key, Key count, Read PIN	1483
CHRYSLER\Select from vehicle\North America\300C\2006-	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from vehicle\North America\300C\2008\EOBIK	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\North America\300C\2009-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
CHRYSLER\Select from vehicle\North America\300C\2011-	Read PIN code, Add new key, Delete key, Key count, Add old key	264
CHRYSLER\Select from vehicle\North America\300C\2011-	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\North America\300M\1998-	Add key, Delete key, Key count, Read PIN code (OBD), Read PIN	274
CHRYSLER\Select from vehicle\North America\300M\1998-	Add remote,	803
CHRYSLER\Select from vehicle\North America\300M\2001-	Add key, Delete key, Key count, Read PIN code (OBD), Read PIN	274



CHRYSLER\Select from vehicle\North America\300M\2001-	Add remote,	803
CHRYSLER\Select from vehicle\North America\Aspen\2007-	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from vehicle\North America\Concorde\1998-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\North America\Concorde\1998-	Add remote,	803
CHRYSLER\Select from vehicle\North America\Concorde\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\North America\Concorde\2001-	Add remote,	803
CHRYSLER\Select from vehicle\North America\IHS\1999-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\North America\IHS\1999-	Add remote,	803
CHRYSLER\Select from vehicle\North America\Neon\2000\Immob	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\North America\Neon\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\North America\Neon\2001-	Add remote,	270
CHRYSLER\Select from vehicle\North America\Pacifica\2004-	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\North America\PT	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\North America\PT	Add remote,	270
CHRYSLER\Select from vehicle\North America\PT	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\North America\Sebring\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\North America\Sebring\2001-	Add remote,	803
CHRYSLER\Select from vehicle\North America\Sebring\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\North America\Town &	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\North America\Town &	Add remote,	272
CHRYSLER\Select from vehicle\North America\Town &	Add key, Delete key,	1489

CHRYSLER\Select from vehicle\North America\Town &	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\North America\Town &	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
CHRYSLER\Select from vehicle\North America\Town &	Sync smart function,	1493
CHRYSLER\Select from vehicle\North America\Town & Country	Read PIN code, Add new key, Delete key, Key count, Add old key	264
CHRYSLER\Select from vehicle\North America\Voyager\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\North America\Voyager\2004-	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\Asia\300\2005-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key, Key count, Read PIN	1483
CHRYSLER\Select from vehicle\Asia\300\2006-2007\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from vehicle\Asia\300\2008\FORIK	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\Asia\300\2009-2010\FORIK	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
CHRYSLER\Select from vehicle\Asia\300\2011-2014\Immobilizer	Read PIN code, Add new key, Delete key, Key count, Add old key	264
CHRYSLER\Select from vehicle\Asia\300C\2005-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key, Key count, Read PIN	1483
CHRYSLER\Select from vehicle\Asia\300C\2006-2007\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from vehicle\Asia\300C\2008\FORIK	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\Asia\300C\2009-2010\FORIK	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
CHRYSLER\Select from vehicle\Asia\300C\2011-2014\Immobilizer	Read PIN code, Add new key, Delete key, Key count, Add old key	264
CHRYSLER\Select from vehicle\Asia\300C\2011-2014\Smart key	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\Asia\300M\1998-2000\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Asia\300M\2001-2004\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Asia\300M\2001-2004\Remote	Add remote,	803
CHRYSLER\Select from vehicle\Asia\300M\2004-2007\Immobilizer	Add new key, Add old key, Add remote, Delete key, Key count, Read PIN	1483

CHRYSLER\Select from vehicle\Asia\Aspen\2007-2009\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from vehicle\Asia\Concorde\1998-2000\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Asia\Concorde\2001-2004\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Asia\Concorde\2001-2004\Remote	Add remote,	803
CHRYSLER\Select from vehicle\Asia\LHS\1999-2001\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Asia\Neon\2000\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Asia\Neon\2001-2005\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Asia\Neon\2001-2005\Remote	Add remote,	270
CHRYSLER\Select from vehicle\Asia\Pacifica\2004-2008\Immobilizer	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\Asia\PT Cruiser\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Asia\PT Cruiser\2006-	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\Asia\Sebring\2001-2006\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Asia\Sebring\2007-2010\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\Asia\Town & Country\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Asia\Town & Country\2004-	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\Asia\Town & Country\2008-	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\Asia\Town & Country\2011-2020\EOBIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
CHRYSLER\Select from vehicle\Asia\Town & Country\2011-	Sync smart function,	1493
CHRYSLER\Select from vehicle\Asia\Voyager\2001-2003\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Asia\Voyager\2004-2005\Immobilizer	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\Asia\Grand Voyager\2004-	Add key, Delete key,	1489

CHRYSLER\Select from vehicle\Asia\Grand Voyager\2004-	Add remote,	272
CHRYSLER\Select from vehicle\Asia\Grand Voyager\2008-\EORIK	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\Asia\Grand Voyager\2008-\Keyless-	Sync smart function,	1493
CHRYSLER\Select from vehicle\Europe\200\2011-2014\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\Europe\200\2014-2017\Smart key	Read PIN code, Add smart key, Delete smart key,	990
CHRYSLER\Select from vehicle\Europe\300\2005-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
CHRYSLER\Select from vehicle\Europe\300\2006-2007\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from vehicle\Europe\300\2008\EORIK	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\Europe\300\2009-2010\EORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
CHRYSLER\Select from vehicle\Europe\300\2011-2014\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\Europe\300\2011-2014\Smart key	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\Europe\300C\2005-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
CHRYSLER\Select from vehicle\Europe\300C\2006-2007\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from vehicle\Europe\300C\2008\EORIK	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\Europe\300C\2009-2010\EORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
CHRYSLER\Select from vehicle\Europe\300C\2011-2014\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\Europe\300C\2011-2014\Smart key	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\Europe\300M\1998-2000\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Europe\300M\1998-2000\Remote	Add remote,	803
CHRYSLER\Select from vehicle\Europe\300M\2001-2004\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Europe\300M\2001-2004\Remote	Add remote,	803

CHRYSLER\Select from vehicle\Europe\Aspen\2007-2009\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from vehicle\Europe\Concorde\1998-2000\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Europe\Concorde\1998-2000\Remote	Add remote,	803
CHRYSLER\Select from vehicle\Europe\Concorde\2001-2004\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Europe\Concorde\2001-2004\Remote	Add remote,	803
CHRYSLER\Select from vehicle\Europe\LHS\1999-2001\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Europe\LHS\1999-2001\Remote	Add remote,	803
CHRYSLER\Select from vehicle\Europe\Neon\2000\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Europe\Neon\2001-2005\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Europe\Neon\2001-2005\Remote	Add remote,	270
CHRYSLER\Select from vehicle\Europe\Pacifica\2004-2008\Immobilizer	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\Europe\PT Cruiser\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Europe\PT Cruiser\2001-	Add remote,	270
CHRYSLER\Select from vehicle\Europe\PT Cruiser\2006-	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\Europe\Sebring\2001-2006\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Europe\Sebring\2001-2006\Remote	Add remote,	803
CHRYSLER\Select from vehicle\Europe\Sebring\2007-2010\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\Europe\Town & Country\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Europe\Town & Country\2001-	Add remote,	272
CHRYSLER\Select from vehicle\Europe\Town & Country\2004-	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\Europe\Town & Country\2008-	Read pin code, Add key, Delete key, Key count	265

CHRYSLER\Select from vehicle\Europe\Town & Country\2011-2020\FORIK	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
CHRYSLER\Select from vehicle\Europe\Town & Country\2011-	Sync smart function,	1493
CHRYSLER\Select from vehicle\Europe\Voyager\2001-2003\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Europe\Voyager\2004-2007\Immobilizer	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\Europe\Grand Cherokee\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Europe\Grand Cherokee\2001-	Add remote,	271
CHRYSLER\Select from vehicle\Europe\Grand Voyager\2004-	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\Europe\Grand Voyager\2004-	Add remote,	272
CHRYSLER\Select from vehicle\Europe\Grand Voyager\2008-\FORIK	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\Europe\Grand Voyager\2008-\Keyless-	Sync smart function,	1493
CHRYSLER\Select from vehicle\Europe\300M\2004-2007\Immobilizer	Add new key, Add old key, Add remote, Delete key, Key count, Read PIN	1483
CHRYSLER\Select from vehicle\Europe\Voyager\2001-2003\Remote	Add remote,	272
CHRYSLER\Select from vehicle\South America\200\2011-	Read PIN code, Add new key, Delete key, Key count, Add old key	264
CHRYSLER\Select from vehicle\South America\200\2014-	Read PIN code, Add smart key, Delete smart key,	990
CHRYSLER\Select from vehicle\South America\300\2005-	Add new key, Add old key, Add remote, Delete key, Key count, Read PIN	1483
CHRYSLER\Select from vehicle\South America\300\2006-	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from vehicle\South America\300\2008\FORIK	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\South America\300\2009-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
CHRYSLER\Select from vehicle\South America\300\2011-	Read PIN code, Add new key, Delete key, Key count, Add old key	264
CHRYSLER\Select from vehicle\South America\300\2011-	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\South America\300C\2005-	Add new key, Add old key, Add remote, Delete key, Key count, Read PIN	1483

CHRYSLER

CHRYSLER\Select from vehicle\South America\300C\2006-	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from vehicle\South America\300C\2008\FORTK	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\South America\300C\2009-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
CHRYSLER\Select from vehicle\South America\300C\2011-	Read PIN code, Add new key, Delete key, Key count, Add old key	264
CHRYSLER\Select from vehicle\South America\300C\2011-	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\South America\300M\1998-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\South America\300M\1998-	Add remote,	803
CHRYSLER\Select from vehicle\South America\300M\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\South America\300M\2001-	Add remote,	803
CHRYSLER\Select from vehicle\South America\Aspen\2007-	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from vehicle\South America\Concorde\1998-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\South America\Concorde\1998-	Add remote,	803
CHRYSLER\Select from vehicle\South America\Concorde\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\South America\Concorde\2001-	Add remote,	803
CHRYSLER\Select from vehicle\South America\IHS\1999-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\South America\IHS\1999-	Add remote,	803
CHRYSLER\Select from vehicle\South America\Neon\2000\Immob	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\South America\Neon\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\South America\Neon\2001-	Add remote,	270
CHRYSLER\Select from vehicle\South America\Pacifica\2004-	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\South America\PT	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274

CHRYSLER\Select from vehicle\South America\PT	Add remote,	270
CHRYSLER\Select from vehicle\South America\PT	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\South America\Sebring\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\South America\Sebring\2001-	Add remote,	803
CHRYSLER\Select from vehicle\South America\Sebring\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\South America\Town &	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\South America\Town &	Add remote,	272
CHRYSLER\Select from vehicle\South America\Town &	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\South America\Town &	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\South America\Town &	Read pin code, Add key, Delete key, Key count Modify VIN code	266
CHRYSLER\Select from vehicle\South America\Town &	Sync smart function,	1493
CHRYSLER\Select from vehicle\South America\Voyager\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\South America\Voyager\2004-	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\South America\Grand	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\South America\Grand	Add remote,	272
CHRYSLER\Select from vehicle\South America\Grand	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\South America\Grand	Sync smart function,	1493
CHRYSLER\Select from vehicle\South America\300M\2004-	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
CHRYSLER\Select from vehicle\Middle East\200\2011-	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\Middle East\200\2014-	Read PIN code, Add smart key, Delete smart key,	990
CHRYSLER\Select from vehicle\Middle East\300\2005-	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483



CHRYSLER\Select from vehicle\Middle East\300\2006-	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from vehicle\Middle East\300\2008\FORTK	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\Middle East\300\2009-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
CHRYSLER\Select from vehicle\Middle East\300\2011-	Read PIN code, Add new key, Delete key, Key count, Add old key	264
CHRYSLER\Select from vehicle\Middle East\300\2011-	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\Middle East\300C\2005-	Add new key, Add old key, Add remote, Delete key, Key count, Read PIN	1483
CHRYSLER\Select from vehicle\Middle East\300C\2006-	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from vehicle\Middle East\300C\2008\FORTK	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\Middle East\300C\2009-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
CHRYSLER\Select from vehicle\Middle East\300C\2011-	Read PIN code, Add new key, Delete key, Key count, Add old key	264
CHRYSLER\Select from vehicle\Middle East\300C\2011-	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\Middle East\300M\1998-	Add key, Delete key, Key count, Read PIN code (OBD), Read PIN	274
CHRYSLER\Select from vehicle\Middle East\300M\1998-	Add remote,	803
CHRYSLER\Select from vehicle\Middle East\300M\2001-	Add key, Delete key, Key count, Read PIN code (OBD), Read PIN	274
CHRYSLER\Select from vehicle\Middle East\300M\2001-	Add remote,	803
CHRYSLER\Select from vehicle\Middle East\Aspen\2007-	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from vehicle\Middle East\Concorde\1998-	Add key, Delete key, Key count, Read PIN code (OBD), Read PIN	274
CHRYSLER\Select from vehicle\Middle East\Concorde\1998-	Add remote,	803
CHRYSLER\Select from vehicle\Middle East\Concorde\2001-	Add key, Delete key, Key count, Read PIN code (OBD), Read PIN	274
CHRYSLER\Select from vehicle\Middle East\Concorde\2001-	Add remote,	803
CHRYSLER\Select from vehicle\Middle East\LHS\1999-	Add key, Delete key, Key count, Read PIN code (OBD), Read PIN	274

CHRYSLER\Select from vehicle\Middle East\LHS\1999-	Add remote,	803
CHRYSLER\Select from vehicle\Middle East\Neon\2000\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Middle East\Neon\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Middle East\Neon\2001-	Add remote,	270
CHRYSLER\Select from vehicle\Middle East\Pacifica\2004-	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\Middle East\PT Cruiser\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Middle East\PT Cruiser\2001-	Add remote,	270
CHRYSLER\Select from vehicle\Middle East\PT Cruiser\2006-	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\Middle East\Sebring\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Middle East\Sebring\2001-	Add remote,	803
CHRYSLER\Select from vehicle\Middle East\Sebring\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\Middle East\Town & Country\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Middle East\Town & Country\2001-	Add remote,	272
CHRYSLER\Select from vehicle\Middle East\Town & Country\2001-	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\Middle East\Town & Country\2001-	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\Middle East\Town & Country\2001-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
CHRYSLER\Select from vehicle\Middle East\Town & Country\2001-	Sync smart function,	1493
CHRYSLER\Select from vehicle\Middle East\Voyager\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Middle East\Voyager\2004-	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\Middle East\Grand Cherokee\2001-	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\Middle East\Grand Cherokee\2001-	Add remote,	272

CHRYSLER\Select from vehicle\Middle East\Grand	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\Middle East\Grand	Sync smart function,	1493
CHRYSLER\Select from vehicle\Middle East\300M\2004-	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
CHRYSLER\Select from vehicle\Australia\200\2011-2014\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\Australia\200\2014-2017\Smart key	Read PIN code, Add smart key, Delete smart key,	990
CHRYSLER\Select from vehicle\Australia\300\2005-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
CHRYSLER\Select from vehicle\Australia\300\2006-2007\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from vehicle\Australia\300\2008\FORIK	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\Australia\300\2009-2010\FORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
CHRYSLER\Select from vehicle\Australia\300\2011-2014\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\Australia\300\2011-2014\Smart key	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\Australia\300C\2005-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
CHRYSLER\Select from vehicle\Australia\300C\2006-2007\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from vehicle\Australia\300C\2008\FORIK	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\Australia\300C\2009-2010\FORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
CHRYSLER\Select from vehicle\Australia\300C\2011-2014\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\Australia\300C\2011-2014\Smart key	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\Australia\300M\1998-2000\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Australia\300M\1998-2000\Remote	Add remote,	803
CHRYSLER\Select from vehicle\Australia\300M\2001-2004\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Australia\300M\2001-2004\Remote	Add remote,	803

CHRYSLER\Select from vehicle\Australia\Aspen\2007-2009\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from vehicle\Australia\Concorde\1998-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Australia\Concorde\1998-2000\Remote	Add remote,	803
CHRYSLER\Select from vehicle\Australia\Concorde\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Australia\Concorde\2001-2004\Remote	Add remote,	803
CHRYSLER\Select from vehicle\Australia\LHS\1999-2001\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Australia\LHS\1999-2001\Remote	Add remote,	803
CHRYSLER\Select from vehicle\Australia\Neon\2000\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Australia\Neon\2001-2005\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Australia\Neon\2001-2005\Remote	Add remote,	270
CHRYSLER\Select from vehicle\Australia\Pacific\2004-	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\Australia\PT Cruiser\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Australia\PT Cruiser\2001-	Add remote,	270
CHRYSLER\Select from vehicle\Australia\PT Cruiser\2006-	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\Australia\Sebring\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Australia\Sebring\2001-2006\Remote	Add remote,	803
CHRYSLER\Select from vehicle\Australia\Sebring\2007-	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\Australia\Town & Country\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Australia\Town & Country\2001-	Add remote,	272
CHRYSLER\Select from vehicle\Australia\Town & Country\2004-	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\Australia\Town & Country\2008-	Read pin code, Add key, Delete key, Key count	265

CHRYSLER\Select from vehicle\Australia\Town & Country\2011-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
CHRYSLER\Select from vehicle\Australia\Town & Country\2011-	Sync smart function,	1493
CHRYSLER\Select from vehicle\Australia\Voyager\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Australia\Voyager\2004-	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\Australia\Grand Voyager\2004-	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\Australia\Grand Voyager\2004-	Add remote,	272
CHRYSLER\Select from vehicle\Australia\Grand Voyager\2008-\EORIK	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\Australia\Grand Voyager\2008-\Keyless-	Sync smart function,	1493
CHRYSLER\Select from vehicle\Australia\300M\2004-2007\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
CHRYSLER\Select from vehicle\Africa\200\2011-2014\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\Africa\200\2014-2017\Smart key	Read PIN code, Add smart key, Delete smart key,	990
CHRYSLER\Select from vehicle\Africa\300\2005-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
CHRYSLER\Select from vehicle\Africa\300\2006-2007\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from vehicle\Africa\300\2008-\EORIK	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\Africa\300\2009-2010\EORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
CHRYSLER\Select from vehicle\Africa\300\2011-2014\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\Africa\300\2011-2014\Smart key	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\Africa\300C\2005-2006\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
CHRYSLER\Select from vehicle\Africa\300C\2006-2007\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from vehicle\Africa\300C\2008\EORIK	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\Africa\300C\2009-2010\EORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266

CHRYSLER\Select from vehicle\Africa\300C\2011-2014\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\Africa\300C\2011-2014\Smart key	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from vehicle\Africa\300M\1998-2000\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Africa\300M\1998-2000\Remote	Add remote,	803
CHRYSLER\Select from vehicle\Africa\300M\2001-2004\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Africa\300M\2001-2004\Remote	Add remote,	803
CHRYSLER\Select from vehicle\Africa\Aspen\2007-2009\Immobilizer	Add key, Delete key, Key count, Add remote, Read PIN code	267
CHRYSLER\Select from vehicle\Africa\Concorde\1998-2000\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Africa\Concorde\1998-2000\Remote	Add remote,	803
CHRYSLER\Select from vehicle\Africa\Concorde\2001-2004\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Africa\Concorde\2001-2004\Remote	Add remote,	803
CHRYSLER\Select from vehicle\Africa\LHS\1999-2001\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Africa\LHS\1999-2001\Remote	Add remote,	803
CHRYSLER\Select from vehicle\Africa\Neon\2000\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Africa\Neon\2001-2005\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Africa\Neon\2001-2005\Remote	Add remote,	270
CHRYSLER\Select from vehicle\Africa\Pacific\2004-2008\Immobilizer	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\Africa\PT Cruiser\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Africa\PT Cruiser\2001-	Add remote,	270
CHRYSLER\Select from vehicle\Africa\PT Cruiser\2006-	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\Africa\Sebring\2001-2006\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274

CHRYSLER\Select from vehicle\Africa\Sebring\2001-2006\Remote	Add remote,	803
CHRYSLER\Select from vehicle\Africa\Sebring\2007-2010\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from vehicle\Africa\Town & Country\2001-	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Africa\Town & Country\2001-	Add remote,	272
CHRYSLER\Select from vehicle\Africa\Town & Country\2004-	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\Africa\Town & Country\2008-	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\Africa\Town & Country\2011-2020\FORIK	Read pin code, Add key, Delete key, Key count Modify VIN code	266
CHRYSLER\Select from vehicle\Africa\Town & Country\2011-	Sync smart function,	1493
CHRYSLER\Select from vehicle\Africa\Voyager\2001-2003\Immobilizer	Add key, Delete key, Key count, Read PIN code (OBD) Read PIN	274
CHRYSLER\Select from vehicle\Africa\Voyager\2004-2005\Immobilizer	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\Africa\Grand Voyager\2004-	Add key, Delete key,	1489
CHRYSLER\Select from vehicle\Africa\Grand Voyager\2004-	Add remote,	272
CHRYSLER\Select from vehicle\Africa\Grand Voyager\2008-\EORIK	Read pin code, Add key, Delete key, Key count	265
CHRYSLER\Select from vehicle\Africa\Grand Voyager\2008-\KeyLess-	Sync smart function,	1493
CHRYSLER\Select from vehicle\Africa\300M\2004-2007\Immobilizer	Add new key, Add old key, Add remote, Delete key Key count Read PIN	1483
CHRYSLER\Select from vehicle\North America\Freemont\2011-	Add smart key, Delete smart key, Read PIN code	268
CHRYSLER\Select from type\Immobilizer\Type 9 (CAN)	Key count, Program key, Delete key, Program remote	1304
CHRYSLER\Select from vehicle\North America\Cirrus\2007-	Key count, Program key, Delete key, Program remote	1304
CHRYSLER\Select from vehicle\North America\Neon\2005-	Key count, Program key, Delete key, Program remote	1304
CHRYSLER\Select from vehicle\Asia\Cirrus\2007-\Immobilizer	Key count, Program key, Delete key, Program remote	1304
CHRYSLER\Select from vehicle\Asia\Neon\2005-\Immobilizer	Key count, Program key, Delete key, Program remote	1304

CHRYSLER\Select from vehicle\Europe\Cirrus\2007-\Immobilizer	Key count, Program key, Delete key, Program remote	1304
CHRYSLER\Select from vehicle\Europe\Neon\2005-\Immobilizer	Key count, Program key, Delete key, Program remote	1304
CHRYSLER\Select from vehicle\South America\Cirrus\2007-	Key count, Program key, Delete key, Program remote	1304
CHRYSLER\Select from vehicle\South America\Neon\2005-	Key count, Program key, Delete key, Program remote	1304
CHRYSLER\Select from vehicle\Australia\Cirrus\2007-\Immobilizer	Key count, Program key, Delete key, Program remote	1304
CHRYSLER\Select from vehicle\Australia\Neon\2005-\Immobilizer	Key count, Program key, Delete key, Program remote	1304
CHRYSLER\Select from vehicle\Middle East\Cirrus\2007-	Key count, Program key, Delete key, Program remote	1304
CHRYSLER\Select from vehicle\Middle East\Neon\2005-	Key count, Program key, Delete key, Program remote	1304
CHRYSLER\Select from vehicle\Africa\Cirrus\2007-\Immobilizer	Key count, Program key, Delete key, Program remote	1304
CHRYSLER\Select from vehicle\Africa\Neon\2005-\Immobilizer	Key count, Program key, Delete key, Program remote	1304
CHRYSLER\Select from vehicle\Asia\200\2011-2014\Immobilizer	Read PIN code, Add new key, Delete key, Key count Add old key	264
CHRYSLER\Select from type\Smart key\Type 6(CAN)	Read PIN code, Add key, Delete key,	788
CHRYSLER\Select from type\Smart key\Type 7(CAN)	Read PIN code, Add smart key, Delete smart key,	990
CHRYSLER\Select from type\Smart key\Type 8(CAN)\Keyless-go	Read pin code, Add key, Delete key,	396
CHRYSLER\Select from type\Smart key\Type 8(CAN)\Mechanical key	Read pin code, Add key, Delete key,	395
CHRYSLER\Select from type\Remote\Type 9(VPW)	Program remote,	1737
CHRYSLER\Select from vehicle\Asia\Town & Country\2008-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
CHRYSLER\Select from vehicle\North America\Town &	Read pin code, Add key, Delete key, Key count Modify VIN code	266
CHRYSLER\Select from vehicle\Europe\Town & Country\2008-	Read pin code, Add key, Delete key, Key count Modify VIN code	266
CHRYSLER\Select from vehicle\South America\Town &	Read pin code, Add key, Delete key, Key count Modify VIN code	266
CHRYSLER\Select from vehicle\Middle East\Town &	Read pin code, Add key, Delete key, Key count Modify VIN code	266



	CHRYSLER\Select from vehicle\Australia\Town & Country\2008-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
	CHRYSLER\Select from vehicle\Africa\Town & Country\2008-	Read pin code, Add key, Delete key, Key count, Modify VIN code	266
	HYUNDAI\Select from vehicle\China\Encino\2018\Smart key	Smart key, ECM neutral mode, SMK neutral mode, ESCL neutral mode	997
	HYUNDAI\Select from vehicle\China\Encino\2018\Immobilizer	Program key, ECM neutral mode, Read key count,	148
	HYUNDAI\Select from vehicle\China\Encino\2018\Remote	Program remote,	253
	HYUNDAI\Select from vehicle\China\IX35\2010-2013\Immobilizer	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
	HYUNDAI\Select from vehicle\China\Sonata (NF)\2004-	Program key, ECM neutral mode, Read key count,	146
	HYUNDAI\Select from vehicle\China\Tucson (TM)\2005-	Program key, ECM neutral mode, Read key count,	146
	HYUNDAI\Select from vehicle\China\Tucson (TM)\2005-	Program key, ECM neutral mode, Read key count,	146
	HYUNDAI\Select from vehicle\China\Tucson (TM)\2005-	Program key, ECM neutral mode, Read key count,	148
	HYUNDAI\Select from vehicle\China\Mistra (CE)\2014-\Immobilizer	Program key, ECM neutral mode, Read key count,	147
	HYUNDAI\Select from vehicle\China\Elantra (HDC)\2008-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
	HYUNDAI\Select from vehicle\China\Sonata (NF C)\2009-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
	HYUNDAI\Select from vehicle\China\I30 (FDC)\2009-2013\Immobilizer	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
	HYUNDAI\Select from vehicle\China\Verna (RBC/CB)\2014-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
	HYUNDAI\Select from vehicle\China\Elantra (MDC)\2012-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
	HYUNDAI\Select from vehicle\China\Elantra (MDC)\2012-\Smart	Program smart key, ECM neutral mode, ESCL neutral mode, PDM	81
	HYUNDAI\Select from vehicle\China\Sonata (NF C)\2009-2010\Smart key	Program smart key, ECM neutral mode, SMK neutral mode, ESCL	151
	HYUNDAI\Select from vehicle\China\IX35\2010-2013\Smart key	Program smart key, ECM neutral mode, SMK neutral mode, ESCL	151
	HYUNDAI\Select from vehicle\China\Elantra (HDC)\2011-2017\Smart key	Program smart key, ECM neutral mode, SMK neutral mode, PDM	152
	HYUNDAI\Select from vehicle\China\IX35\2014-2017\Smart key	Program smart key, ECM neutral mode, SMK neutral mode, PDM	152

HYUNDAI\Select from vehicle\China\Verna (RBC/CB)\2014-2016\Smart	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\China\IX25 (GC)\2014-\Smart key	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
HYUNDAI\Select from vehicle\China\Sonata 9\2015-\Smart key	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
HYUNDAI\Select from vehicle\China\New SantaFe (MDC)\2012-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
HYUNDAI\Select from vehicle\China\New Tucson\2015-2017\Smart	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
HYUNDAI\Select from vehicle\China\Mistra (CF)\2014-\Smart key	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
HYUNDAI\Select from vehicle\General area\AT07\1998-	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\General area\Getz (TB)\2005-	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\General area\Accent (IC)\2000-	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\General area\Matrix (EC)\2002-	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\General area\Elantra (XD)\2001-	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\General area\HD COUPE\2002-\Immobilizer	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\General area\Grandeur/Azera (TG)	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\General area\H-1\1998-	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\General area\TRAFET\1999-	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\General area\Veloster (ES)\2011-	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\General area\Elantra (AD)\2016-	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\General area\i40 (VE)\2012-	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\General area\Grandeur/Azera (HG)	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\General area\H-RUS (TO)\2008-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Veracruz\ix55 (EN)\	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79

HYUNDAI\Select from vehicle\General area\Genesis	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Genesis (BH)\2009-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Equus/Centennial (V	Program smart key, ECM neutral mode, SMK neutral mode ESCL	151
HYUNDAI\Select from vehicle\General area\Genesis	Program smart key, ECM neutral mode, SMK neutral mode ESCL	151
HYUNDAI\Select from vehicle\General area\i40 (VE)\2012-	Program smart key, ECM neutral mode, ESCL neutral mode PDM	81
HYUNDAI\Select from vehicle\General area\Veloster (ES)\2011-	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\General area\Genesis (BH)\2013-	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\General area\Equus/Centennial (V	Program smart key,	153
HYUNDAI\Select from vehicle\General area\Genesis (BH)\2009-	Program smart key,	153
HYUNDAI\Select from vehicle\General area\Genesis (BH)\2009-	Program smart key,	154
HYUNDAI\Select from vehicle\General area\Veracruz /ix55 (EN)\	Program smart key, ECM neutral mode, SMK neutral mode MSI	155
HYUNDAI\Select from vehicle\General area\Equus/Centennial (V	Program smart key, ECM neutral mode, SMK neutral mode ESCL	142
HYUNDAI\Select from vehicle\China\New Santafe (MDC)\2012-	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\General area\Santafe\2001-	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\General area\Santafe E/L\2009-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Santafe\2006-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Grand	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\General area\Grand	Program smart key, ECM neutral mode, SMK neutral mode ESCL	142
HYUNDAI\Select from vehicle\General area\Grandeur/Azera (HG)	Program smart key, ECM neutral mode, SMK neutral mode ESCL	144
HYUNDAI\Select from vehicle\China\Sonata 8 (YEC)\2011-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\China\Sonata 8 (YEC)\2011-2016\Smart	Program smart key, ECM neutral mode, SMK neutral mode ESCL	151

HYUNDAI\Select from vehicle\General area\Santafe F/I\2009-	Program smart key, ECM neutral mode, SMK neutral mode ESCL	151
HYUNDAI\Select from vehicle\General area\Accent (MC)\2006-	Program key, ECM neutral mode, Read key count,	172
HYUNDAI\Select from vehicle\General area\Santafe\2006-	Program key, ECM neutral mode, Read key count,	172
HYUNDAI\Select from vehicle\China\Elantra (HDC)\2011-2017\Remote	Program remote,	197
HYUNDAI\Select from vehicle\China\IX35\2010-2013\Remote	Program remote,	197
HYUNDAI\Select from vehicle\China\Verna (RBC/CB)\2014-2016\Remote	Program remote,	197
HYUNDAI\Select from vehicle\China\New Tucson\2015-	Program remote,	197
HYUNDAI\Select from vehicle\China\Sonata 8 (YEC)\2011-2016\Remote	Program remote,	197
HYUNDAI\Select from vehicle\General area\Genesis	Program remote,	197
HYUNDAI\Select from vehicle\China\I30 (FDC)\2009-2013\Remote	Program remote,	197
HYUNDAI\Select from vehicle\China\New Santafe (MDC)\2012-	Program remote,	197
HYUNDAI\Select from vehicle\General area\Grandeur/Azera (HG)	Program remote,	253
HYUNDAI\Select from vehicle\China\Elantra (AD)\2016-\Immobilizer	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\China\Elantra (AD)\2016-\Remote	Program remote,	253
HYUNDAI\Select from vehicle\China\Tucson (TM)\2005-2016\Remote	Program remote,	197
HYUNDAI\Select from type\Immobilizer\Type 1 (K)	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from type\Immobilizer\Type 2 (K)	Program key, ECM neutral mode, Read key count,	148
HYUNDAI\Select from type\Immobilizer\Type 3 (K)	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from type\Immobilizer\Type 4 (CAN)	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from type\Immobilizer\Type 5 (CAN)	Program key, ECM neutral mode, Read key count,	172
HYUNDAI\Select from type\Smart key\General area\Type1 (with key	Program smart key, ECM neutral mode, SMK neutral mode ESCL	151

HYUNDAI\Select from type\Smart key\General area\Ttype2(with key	Program smart key, ECM neutral mode, ESCL neutral mode PDM	81
HYUNDAI\Select from type\Smart key\General area\Ttype3(w/o key slot	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from type\Smart key\General area\Ttype4(with key	Program smart key,	153
HYUNDAI\Select from type\Smart key\General area\Ttype5(w/o key slot	Program smart key,	154
HYUNDAI\Select from type\Smart key\General area\Ttype6(with key	Program smart key, ECM neutral mode, SMK neutral mode MSI	155
HYUNDAI\Select from type\Smart key\General area\Ttype7(w/o key slot	Program smart key, ECM neutral mode, SMK neutral mode ESCL	142
HYUNDAI\Select from type\Smart key\General area\Ttype8(w/o key slot	Program smart key, ECM neutral mode, SMK neutral mode ESCL	144
HYUNDAI\Select from type\Remote\16 PIN\Type 1(K)	Program remote,	197
HYUNDAI\Select from type\Remote\16 PIN\Type 2(CAN)	Program remote,	253
HYUNDAI\Select from vehicle\China\Elantra (M DC)\2012-\Smart	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Read PIN code	Read PIN code (46 chip), 46 smart card Read PIN	427
HYUNDAI\Select from vehicle\China\Verna (RC) \Immobilizer	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from type\Remote\16 PIN\Type 3	Program remote,	659
HYUNDAI\Select from type\Remote\16 PIN\Type 4	Program remote,	660
HYUNDAI\Select from type\Remote\16 PIN\Type 5(K)	Program remote,	661
HYUNDAI\Select from vehicle\China\Elantra (A D)\2016-\Smart key	Program smart key, ECM neutral mode, SMK neutral mode ESCL	142
HYUNDAI\Select from vehicle\China\Verna (RBC /CB)\2017-\Immobilizer	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from type\Remote\10 PIN\Type 1	Program remote,	843
HYUNDAI\Select from vehicle\China\IX35\2017 -\Smart key	Smart key, ECM neutral mode, SMK neutral mode ESCL neutral mode	997
HYUNDAI\Select from type\Smart key\General area\Ttype9(w/o key slot	Smart key, ECM neutral mode, SMK neutral mode ESCL neutral mode	997
HYUNDAI\Select from vehicle\China\Accent (MC)\2005-\Immobilizer	Program key, ECM neutral mode, Read key count,	172

HYUNDAI\Select from vehicle\China\Accent (MC)\2005-\Remote	Program remote,	843
HYUNDAI\Select from vehicle\China\Elantra (MDC)\2012-	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\China\Elantra (MDC)\2012-\Remote	Program remote,	197
HYUNDAI\Select from vehicle\China\Elantra (HDC)\2008-2010\Remote	Program remote,	197
HYUNDAI\Select from vehicle\China\Elantra (HDC)\2011-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\China\Elantra (HDC-EV)\2017\Immobilizer	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\China\Elantra (HDC-EV)\2017\Remote	Program remote,	197
HYUNDAI\Select from vehicle\China\Elantra (HDC-EV)\2017\Smart key	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\China\New Celesta (ID)\2017\Immobi	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\China\New Celesta (ID)\2017\Remote	Program remote,	253
HYUNDAI\Select from vehicle\China\New Celesta (ID)\2017\Smart	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
HYUNDAI\Select from vehicle\China\Elantra\2004-2017\Remote	Program remote,	253
HYUNDAI\Select from vehicle\China\IX25 (GC)\2014-\Immobilizer	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\China\IX25 (GC)\2014-\Remote	Program remote,	197
HYUNDAI\Select from vehicle\China\IX35\2014-2017\Immobilizer	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\China\IX35\2014-2017\Remote	Program remote,	197
HYUNDAI\Select from vehicle\China\IX35\2017-\Immobilizer	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\China\Mistra (CE)\2014-\Remote	Program remote,	197
HYUNDAI\Select from vehicle\China\Sonata (LFC)\2015-	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\China\Sonata (LFC)\2015-2017\Remote	Program remote,	253
HYUNDAI\Select from vehicle\China\Sonata (LFC)\2015-2017\Smart key	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142

HYUNDAI\Select from vehicle\China\Sonata (NF C)\2009-2010\Remote	Program remote,	197
HYUNDAI\Select from vehicle\China\Sonata (NF)\2004-2008\Remote	Program remote,	197
HYUNDAI\Select from vehicle\China\New Tucson\2015-	Program remote,	253
HYUNDAI\Select from vehicle\China\New Tucson\2015-	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\China\Verna (RBC /CB)\2017-\Remote	Program remote,	253
HYUNDAI\Select from vehicle\China\Verna (RBC /CB)\2010-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\China\Verna (RBC /CB)\2010-2013\Remote	Program remote,	197
HYUNDAI\Select from vehicle\China\Verna\2016-2017\Immobilizer	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\China\Verna\2016-2017\Remote	Program remote,	253
HYUNDAI\Select from vehicle\General area\Getz (TB)\2005-	Program remote,	660
HYUNDAI\Select from vehicle\General area\Getz (TB)\2003-	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\General area\Getz (TB)\2003-	Program remote,	843
HYUNDAI\Select from vehicle\General area\Accent (LC)\2003-	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\General area\Accent (LC)\2003-	Program remote,	843
HYUNDAI\Select from vehicle\General area\Accent (MC)\2006-	Program remote,	660
HYUNDAI\Select from vehicle\General area\Accent (RR)\2011-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Accent (RR)\2011-	Program remote,	661
HYUNDAI\Select from vehicle\General area\Accent (RR)\2011-	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\General area\ccent	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\ccent	Program remote,	197
HYUNDAI\Select from vehicle\General area\ccent	Program smart key, ECM neutral mode, SMK neutral mode PDM	152

HYUNDAI\Select from vehicle\General area\Atos (MYT)-	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\General area\CRETA (GS)\2015-	Program remote,	253
HYUNDAI\Select from vehicle\General area\Elantra	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Elantra	Program remote,	197
HYUNDAI\Select from vehicle\General area\Elantra	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\General area\Elantra (AD)\2016-	Program remote,	253
HYUNDAI\Select from vehicle\General area\Elantra (AD)\2016-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
HYUNDAI\Select from vehicle\General area\Elantra (ADA)\2017\	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\General area\Elantra (ADA)\2017\	Program remote,	253
HYUNDAI\Select from vehicle\General area\Elantra (ADA)\2017\	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
HYUNDAI\Select from vehicle\General area\Elantra (HD)\2007-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Elantra (HD)\2007-	Program key, ECM neutral mode, Read key count,	172
HYUNDAI\Select from vehicle\General area\Elantra (HD)\2007-	Program remote,	197
HYUNDAI\Select from vehicle\General area\Elantra (MD)\2012-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Elantra (MD)\2012-	Program remote,	197
HYUNDAI\Select from vehicle\General area\Elantra (MD)\2012-	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\General area\Elantra (MDI)\2013-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Elantra (MDI)\2013-	Program remote,	197
HYUNDAI\Select from vehicle\General area\Elantra (MDI)\2013-	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\General area\Elantra (ID)\2014-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Elantra (ID)\2014-	Program remote,	197



HYUNDAI\Select from vehicle\General area\Elantra (ID)\2014-	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\General area\Elantra (XD)\2001-	Program remote,	843
HYUNDAI\Select from vehicle\General area\Elon (HA)\2012-	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\General area\Elon (HA)\2012-	Program remote,	197
HYUNDAI\Select from vehicle\General area\Genesis Coupe (BK)-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Genesis Coupe (BK)-	Program remote,	661
HYUNDAI\Select from vehicle\General area\Genesis (BH)\2009-	Program remote,	661
HYUNDAI\Select from vehicle\General area\Genesis (BH)\2013-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Genesis (BH)\2013-	Program remote,	661
HYUNDAI\Select from vehicle\General area\Genesis (BH)-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Genesis (BH)-	Program remote,	661
HYUNDAI\Select from vehicle\General area\Genesis (BH)-	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\General area\Genesis (DH)\2014-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
HYUNDAI\Select from vehicle\General area\Grand	Program remote,	197
HYUNDAI\Select from vehicle\General area\Grand	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Grand	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
HYUNDAI\Select from vehicle\General area\Grandeur/Azera (HG)	Program smart card, ECM neutral mode, SMK neutral mode ESCI	1041
HYUNDAI\Select from vehicle\General area\Grandeur/Azera (TG)	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Grandeur/Azera (TG)	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\General area\Grandeur/Azera (TG)	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Grandeur/Azera (TG)	Program remote,	661

HYUNDAI\Select from vehicle\General area\Grandeur/Azera(TG)	Program remote,	661
HYUNDAI\Select from vehicle\General area\H-RUS(TQ)\2008-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\H-RUS(TQ)\2008-	Program key, ECM neutral mode, Read key count,	148
HYUNDAI\Select from vehicle\General area\H-1/iMAX/iLOAD(TQ)\2008-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\H-1/iMAX/iLOAD(TQ)\2008-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\H-1/iMAX/iLOAD(TQ)\2008-	Program key, ECM neutral mode, Read key count,	148
HYUNDAI\Select from vehicle\General area\H-1/iMAX/iLOAD(TQ)\2008-	Program remote,	197
HYUNDAI\Select from vehicle\General area\H-100 Truck(HR)\2013-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\H-100 Truck(HR)\2013-	Program remote,	660
HYUNDAI\Select from vehicle\General area\H-100 Truck(HR)\2003-	Program remote,	660
HYUNDAI\Select from vehicle\General area\HR20(HR)\2013-	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\General area\HR20(HR)\2013-	Program remote,	197
HYUNDAI\Select from vehicle\General area\i10(TA)\2014-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\i10(TA)\2014-	Program remote,	253
HYUNDAI\Select from vehicle\General area\i10(TA)\2014-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
HYUNDAI\Select from vehicle\General area\i10(PA)\2008-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\i10(PA)\2008-	Program remote,	660
HYUNDAI\Select from vehicle\General area\i20(GB)\2015-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\i20(GB)\2015-	Program remote,	253
HYUNDAI\Select from vehicle\General area\i20(GB)\2015-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
HYUNDAI\Select from vehicle\General area\i20(TB)\2014-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79

HYUNDAI

HYUNDAI\Select from vehicle\General area\i20(TB)\2014-	Program remote,	253
HYUNDAI\Select from vehicle\General area\i20(TB)\2014-	Program smart key,ECM neutral mode,SMK neutral mode ESCI	142
HYUNDAI\Select from vehicle\General area\i20(PB)\2009-	Program key,Read key count,Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\i20(PB)\2009-	Program remote,	197
HYUNDAI\Select from vehicle\General area\i20(PB)\2013-	Program key,Read key count,Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\i20(PB)\2013-	Program remote,	197
HYUNDAI\Select from vehicle\General area\i20(PB)\2013-	Program smart key,ECM neutral mode,SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\General area\i20(PB)\2013-	Program smart key,ECM neutral mode,SMK neutral mode PDM	1042
HYUNDAI\Select from vehicle\General area\i30(EDe)\2009-	Program key,Read key count,Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\i30(EDe)\2009-	Program key,Read key count,Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\i30(EDe)\2009-	Program key,ECM neutral mode,Read key count,	172
HYUNDAI\Select from vehicle\General area\i30(EDe)\2009-	Program key,Read key count,Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\i30(EDe)\2009-	Program remote,	197
HYUNDAI\Select from vehicle\General area\i30(GD)\2013-	Program key,ECM neutral mode,Read key count,	147
HYUNDAI\Select from vehicle\General area\i30(GD)\2013-	Program remote,	197
HYUNDAI\Select from vehicle\General area\i30(GD)\2013-	Program smart key,ECM neutral mode,SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\General area\i30(GDe)\2013-	Program key,ECM neutral mode,Read key count,	147
HYUNDAI\Select from vehicle\General area\i30(GDe)\2013-	Program remote,	197
HYUNDAI\Select from vehicle\General area\i30(GDe)\2013-	Program smart key,ECM neutral mode,SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\General area\i30/Elantra	Program key,Read key count,Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\i30/Elantra	Program key,Read key count,Read PIN code(46 chip) ECM neutral	79

HYUNDAI\Select from vehicle\General area\i30/Elantra	Program key, ECM neutral mode, Read key count,	172
HYUNDAI\Select from vehicle\General area\i30/Elantra	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\i30/Elantra	Program remote,	197
HYUNDAI\Select from vehicle\General area\i40(VE)\2012-	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\General area\i40(VE)\2012-	Program remote,	197
HYUNDAI\Select from vehicle\General area\ix20(IC)\2011-	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\General area\ix20(IC)\2011-	Program remote,	197
HYUNDAI\Select from vehicle\General area\ix20(IC)\2011-	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\General area\ix35(FCEV)(M	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
HYUNDAI\Select from vehicle\General area\ix35(EI)\2014-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\ix35(EI)\2014-	Program remote,	197
HYUNDAI\Select from vehicle\General area\ix35(EI)\2014-	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\General area\ix35(EI)\2010-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\ix35(EI)\2010-	Program remote,	197
HYUNDAI\Select from vehicle\General area\ix35(EI)\2010-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
HYUNDAI\Select from vehicle\General area\Matrix(EC)\2002-	Program remote,	843
HYUNDAI\Select from vehicle\General area\Santafe	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\General area\Santafe	Program remote,	197
HYUNDAI\Select from vehicle\General area\Santafe	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
HYUNDAI\Select from vehicle\General area\New	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\New	Program remote,	197

HYUNDAI\Select from vehicle\General area\New	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
HYUNDAI\Select from vehicle\General area\New	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\New	Program remote,	197
HYUNDAI\Select from vehicle\General area\New	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\General area\New	Program remote,	197
HYUNDAI\Select from vehicle\General area\New	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
HYUNDAI\Select from vehicle\General area\New	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\General area\New	Program remote,	197
HYUNDAI\Select from vehicle\General area\New	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
HYUNDAI\Select from vehicle\General area\Sonata	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
HYUNDAI\Select from vehicle\General area\Santafa (SM)\2001-	Program remote,	843
HYUNDAI\Select from vehicle\General area\Sonata	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
HYUNDAI\Select from vehicle\General area\Sonata	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Sonata	Program remote,	197
HYUNDAI\Select from vehicle\General area\Sonata	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
HYUNDAI\Select from vehicle\General area\Sonata	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Sonata	Program remote,	197
HYUNDAI\Select from vehicle\General area\Sonata (EF)\2005-	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\General area\Sonata (LF)\2015-	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\General area\Sonata (LF)\2015-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Sonata (LF)\2015-	Program remote,	253

HYUNDAI\Select from vehicle\General area\Sonata(LE)\2015-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	142
HYUNDAI\Select from vehicle\General area\Sonata(LE)\2015-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Sonata(LE)\2015-	Program remote,	253
HYUNDAI\Select from vehicle\General area\Sonata(LE)\2015-	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
HYUNDAI\Select from vehicle\General area\Sonata(NE)\2007-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Sonata(NE)\2007-	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\General area\Sonata(NE)\2007-	Program key, ECM neutral mode, Read key count,	172
HYUNDAI\Select from vehicle\General area\Sonata(NE)\2007-	Program remote,	197
HYUNDAI\Select from vehicle\General area\Sonata(NE)\2005-	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\General area\Sonata(NE)\2005-	Program key, ECM neutral mode, Read key count,	172
HYUNDAI\Select from vehicle\General area\Sonata(NE)\2005-	Program remote,	197
HYUNDAI\Select from vehicle\General area\Sonata(YE)-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Sonata(YE)-	Program remote,	197
HYUNDAI\Select from vehicle\General area\Sonata(YE)-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
HYUNDAI\Select from vehicle\General area\Sonata(YET)\2012-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Sonata(YET)\2012-	Program remote,	197
HYUNDAI\Select from vehicle\General area\Sonata(YET)\2012-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
HYUNDAI\Select from vehicle\General area\Sonata/i45(YE)\201	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Sonata/i45(YE)\201	Program remote,	197
HYUNDAI\Select from vehicle\General area\Sonata/i45(YE)\201	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
HYUNDAI\Select from vehicle\General area\Terracan\2001-	Program key, ECM neutral mode, Read key count,	146

HYUNDAI\Select from vehicle\General area\TRAJET\1999-	Program remote,	843
HYUNDAI\Select from vehicle\General area\Tucson FEV(IM	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\General area\Tucson FEV(IM	Program key, ECM neutral mode, Read key count,	172
HYUNDAI\Select from vehicle\General area\Tucson FEV(IM	Program remote,	197
HYUNDAI\Select from vehicle\General area\Tucson(IM)\2005-	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\General area\Tucson(IM)\2005-	Program key, ECM neutral mode, Read key count,	148
HYUNDAI\Select from vehicle\General area\Tucson(IM)\2005-	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\General area\Tucson(IM)\2005-	Program remote,	197
HYUNDAI\Select from vehicle\General area\Tucson(TI)\2016\Im	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\General area\Tucson(TI)\2016\Re	Program remote,	253
HYUNDAI\Select from vehicle\General area\Tucson(TI)\2016\Sm	Program smart key, ECM neutral mode, SMK neutral mode ESCL	142
HYUNDAI\Select from vehicle\General area\Tucson(TIE)\2016\I	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\General area\Tucson(TIE)\2016\R	Program remote,	253
HYUNDAI\Select from vehicle\General area\Tucson(TIE)\2016\S	Program smart key, ECM neutral mode, SMK neutral mode ESCL	142
HYUNDAI\Select from vehicle\General area\Tucson/i35(IM)\201	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Tucson/i35(IM)\201	Program remote,	197
HYUNDAI\Select from vehicle\General area\Tucson/i35(IM)\201	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\General area\Tucson/i35(IM)\201	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Tucson/i35(IM)\201	Program remote,	197
HYUNDAI\Select from vehicle\General area\Tucson/i35(IM)\201	Program smart key, ECM neutral mode, SMK neutral mode ESCL	151
HYUNDAI\Select from vehicle\General area\Veloster(ES)\2011-	Program remote,	197

HYUNDAI\Select from vehicle\General area\Veracruz\ix55(EN)\	Program key, ECM neutral mode, Read key count,	172
HYUNDAI\Select from vehicle\General area\Veracruz\ix55(EN)\	Program remote,	197
HYUNDAI\Select from vehicle\General area\Verna(RRT)\2011-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\General area\Verna(RRT)\2011-	Program remote,	197
HYUNDAI\Select from vehicle\General area\Verna(RRT)\2011-	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\USA\Accent(LC)\2003-2005\Immobilizer	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\USA\Accent(LC)\2003-2005\Remote	Program remote,	843
HYUNDAI\Select from vehicle\USA\Accent(MC)\2006-2011\Immobilizer	Program key, ECM neutral mode, Read key count,	172
HYUNDAI\Select from vehicle\USA\Accent(MC)\2006-2011\Remote	Program remote,	843
HYUNDAI\Select from vehicle\USA\Accent(RB)\2012-2016\Immobilizer	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\USA\Accent(RB)\2012-2016\Remote	Program remote,	197
HYUNDAI\Select from vehicle\USA\Attitude(Mexico)\2006-	Program key, ECM neutral mode, Read key count,	172
HYUNDAI\Select from vehicle\USA\Azera(HG)\2012-2016\Immobilizer	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\USA\Azera(HG)\2012-2016\Remote	Program remote,	661
HYUNDAI\Select from vehicle\USA\Azera(HG)\2012-2016\Smart key	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\USA\Azera(TG)\2007-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\USA\Azera(TG)\2007-	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\USA\Azera(TG)\2007-2011\Remote	Program remote,	197
HYUNDAI\Select from vehicle\USA\Azera(TG)\2006\Immobilizer	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\USA\Azera(TG)\2006\Remote	Program remote,	197
HYUNDAI\Select from vehicle\USA\Elantra Coupe(IK)\2013-	Program key, Read key count, Read PIN code(46 chip) ECM neutral	79



HYUNDAI\Select from vehicle\USA\Elantra Coupe (TK)\2013-	Program remote,	197
HYUNDAI\Select from vehicle\USA\Elantra Coupe (TK)\2013-	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\USA\Elantra GT (GD)\2013-	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\USA\Elantra GT (GD)\2013-2016\Remote	Program remote,	197
HYUNDAI\Select from vehicle\USA\Elantra GT (GD)\2013-2016\Smart	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\USA\Elantra Touring (FD)\2009-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\USA\Elantra Touring (FD)\2009-	Program remote,	197
HYUNDAI\Select from vehicle\USA\Elantra (AD)\2017\Immobilizer	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\USA\Elantra (AD)\2017\Remote	Program remote,	253
HYUNDAI\Select from vehicle\USA\Elantra (AD)\2017\Smart key	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
HYUNDAI\Select from vehicle\USA\Elantra (ADA)\2017\Immobilizer	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\USA\Elantra (ADA)\2017\Remote	Program remote,	253
HYUNDAI\Select from vehicle\USA\Elantra (ADA)\2017\Smart key	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
HYUNDAI\Select from vehicle\USA\Elantra (HD)\2007-2010\Immobilizer	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\USA\Elantra (HD)\2007-2010\Remote	Program remote,	197
HYUNDAI\Select from vehicle\USA\Elantra (MD)\2011-2016\Immobilizer	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\USA\Elantra (MD)\2011-2016\Remote	Program remote,	197
HYUNDAI\Select from vehicle\USA\Elantra (MD)\2011-2016\Smart key	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\USA\Elantra (UD)\2011-2016\Immobilizer	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\USA\Elantra (UD)\2011-2016\Remote	Program remote,	197
HYUNDAI\Select from vehicle\USA\Elantra (UD)\2011-2016\Smart key	Program smart key, ECM neutral mode, SMK neutral mode PDM	152

HYUNDAI\Select from vehicle\USA\Elantra (XD)\2001-2006\Immobilizer	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\USA\Elantra (XD)\2001-2006\Remote	Program remote,	843
HYUNDAI\Select from vehicle\USA\Entourage (EP)\2007-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\USA\Entourage (EP)\2007-2010\Remote	Program remote,	1043
HYUNDAI\Select from vehicle\USA\Equus (VI)\2014-2016\Smart key	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
HYUNDAI\Select from vehicle\USA\Equus (VI)\2011-2013\Smart key	Program smart key,	153
HYUNDAI\Select from vehicle\USA\Genesis Coupe (BK)\2010-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\USA\Genesis Coupe (BK)\2010-	Program remote,	197
HYUNDAI\Select from vehicle\USA\Genesis Coupe (BK)\2010-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
HYUNDAI\Select from vehicle\USA\Genesis (BH)\2012-2014\Immobilizer	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\USA\Genesis (BH)\2012-2014\Remote	Program remote,	661
HYUNDAI\Select from vehicle\USA\Genesis (BH)\2012-2014\Smart key	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\USA\Genesis (BH)\2009-2011\Immobilizer	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\USA\Genesis (BH)\2009-2011\Remote	Program remote,	661
HYUNDAI\Select from vehicle\USA\Genesis (BH)\2009-2011\Smart key	Program smart key,	153
HYUNDAI\Select from vehicle\USA\Genesis (DH)\2015-2016\Smart key	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
HYUNDAI\Select from vehicle\USA\Santafe Sport (DMA)\2017\Immobilizer	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\USA\Santafe Sport (DMA)\2017\Smart key	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
HYUNDAI\Select from vehicle\USA\Santafe Sport (DMA)\2013-	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\USA\Santafe Sport (DMA)\2013-	Program remote,	197
HYUNDAI\Select from vehicle\USA\Santafe Sport (DMA)\2013-	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997

HYUNDAI\Select from vehicle\USA\New Santafe (CM)\2007-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\USA\New Santafe (CM)\2007-	Program remote,	197
HYUNDAI\Select from vehicle\USA\New Santafe (CM)\2012\Smart	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
HYUNDAI\Select from vehicle\USA\Santafe NC\2013-	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\USA\Santafe NC\2013-2017\Remote	Program remote,	197
HYUNDAI\Select from vehicle\USA\Santafe NC\2013-2017\Smart key	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
HYUNDAI\Select from vehicle\USA\Santafe (SM)\2006\Remote	Program remote,	843
HYUNDAI\Select from vehicle\USA\Santafe (SM)\2001-2005\Remote	Program remote,	843
HYUNDAI\Select from vehicle\USA\Sonata HEV (LF HEV)\2016\Smart	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
HYUNDAI\Select from vehicle\USA\Sonata Hybrid (YEHEV)\2011-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\USA\Sonata Hybrid (YEHEV)\2011-	Program remote,	197
HYUNDAI\Select from vehicle\USA\Sonata Hybrid (YEHEV)\2011-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
HYUNDAI\Select from vehicle\USA\Sonata PHEV (LF	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
HYUNDAI\Select from vehicle\USA\Sonata (LFA)\2015-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\USA\Sonata (LFA)\2015-	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\USA\Sonata (LFA)\2015-2016\Remote	Program remote,	253
HYUNDAI\Select from vehicle\USA\Sonata (LFA)\2015-2016\Smart key	Smart key, ECM neutral mode, SMK neutral mode ESCI neutral mode	997
HYUNDAI\Select from vehicle\USA\Sonata (NF)\2006-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\USA\Sonata (NF)\2006-	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\USA\Sonata (NF)\2006-2010\Remote	Program remote,	197
HYUNDAI\Select from vehicle\USA\Sonata (YF)\2011-2014\Immobilizer	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79

HYUNDAI\Select from vehicle\USA\Sonata (YF)\2011-2014\Remote	Program remote,	197
HYUNDAI\Select from vehicle\USA\Sonata (YF)\2011-2014\Smart key	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
HYUNDAI\Select from vehicle\USA\Tiburon (GK)\2003-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\USA\Tiburon (GK)\2003-	Program key, ECM neutral mode, Read key count,	146
HYUNDAI\Select from vehicle\USA\Tucson ECEV (LM ECEV)\2015-	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
HYUNDAI\Select from vehicle\USA\Tucson (LM)\2010-2015\Immobilizer	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\USA\Tucson (LM)\2010-2015\Remote	Program remote,	197
HYUNDAI\Select from vehicle\USA\Tucson (LM)\2010-2015\Smart key	Program smart key, ECM neutral mode, SMK neutral mode ESCI	151
HYUNDAI\Select from vehicle\USA\Tucson (JM)\2005-2009\Immobilizer\G	Program key, ECM neutral mode, Read key count,	148
HYUNDAI\Select from vehicle\USA\Tucson (JM)\2005-2009\Immobilizer\G	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\USA\Tucson (JM)\2005-2009\Remote	Program remote,	197
HYUNDAI\Select from vehicle\USA\Tiburon (TL)\2016\Remote	Program remote,	253
HYUNDAI\Select from vehicle\USA\Veloster (ES)\2012-	Program key, ECM neutral mode, Read key count,	147
HYUNDAI\Select from vehicle\USA\Veloster (ES)\2012-2016\Remote	Program remote,	197
HYUNDAI\Select from vehicle\USA\Veloster (ES)\2012-2016\Smart	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from vehicle\USA\Veracruz/ix55 (EN)\2007-	Program key, Read key count, Read PIN code (46 chip) ECM neutral	79
HYUNDAI\Select from vehicle\USA\Veracruz/ix55 (EN)\2007-2013\Remote	Program remote,	661
HYUNDAI\Select from vehicle\USA\Veracruz/ix55 (EN)\2007-2013\Smart	Program smart key, ECM neutral mode, SMK neutral mode MSI	155
HYUNDAI\Select from vehicle\USA\XG (XG)\2001-2005\Remote	Program remote,	843
HYUNDAI\Select from type\Remote\16 PIN\Type6 (K)	Program remote,	1043
HYUNDAI\Select from type\Immobilizer\Type6 (CAN)	Program key, neutral mode,	1044

HYUNDAI\Select from type\Immobilizer\Type7(CAN)	Program key, neutral mode,	1045
HYUNDAI\Select from type\Immobilizer\Type8(K)	Program key, ECM neutral mode, Read key count,	1046
HYUNDAI\Select from type\Smart key\China\Type1(with key)	Program smart key, ECM neutral mode, SMK neutral mode ESCL	151
HYUNDAI\Select from type\Smart key\China\Type2(with key)	Program smart key, ECM neutral mode, ESCL neutral mode PDM	81
HYUNDAI\Select from type\Smart key\China\Type3(w/o key)	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from type\Smart key\China\Type4(with key)	Program smart key,	153
HYUNDAI\Select from type\Smart key\China\Type5(with key)	Program smart key, ECM neutral mode, SMK neutral mode MSI	155
HYUNDAI\Select from type\Smart key\China\Type6(w/o key)	Program smart key, ECM neutral mode, SMK neutral mode ESCL	142
HYUNDAI\Select from type\Smart key\USA\Type1(with key)	Program smart key, ECM neutral mode, SMK neutral mode ESCL	151
HYUNDAI\Select from type\Smart key\USA\Type2(with key)	Program smart key, ECM neutral mode, ESCL neutral mode PDM	81
HYUNDAI\Select from type\Smart key\USA\Type3(w/o key)	Program smart key, ECM neutral mode, SMK neutral mode PDM	152
HYUNDAI\Select from type\Smart key\USA\Type4(with key)	Program smart key,	153
HYUNDAI\Select from type\Smart key\USA\Type5(with key)	Program smart key, ECM neutral mode, SMK neutral mode MSI	155
HYUNDAI\Select from type\Smart key\USA\Type6(w/o key)	Smart key, ECM neutral mode, SMK neutral mode ESCL neutral mode	997
HYUNDAI\Select from type\Smart key\General area\Type10(w/o key)	Program smart card, ECM neutral mode, SMK neutral mode ESCL	1041
HYUNDAI\Select from vehicle\China\Verna\2016-2017\Smart key	Program smart key, ECM neutral mode, SMK neutral mode ESCL	142
TOYOTA\Select from vehicle\China\86\2011-\With smart	Add smart key, Delete smart key, Generate LKE,	801
TOYOTA\Select from vehicle\China\86\2011-\Without smart	Key count, Add key, Delete key, Add remote Delete remote	710
TOYOTA\Select from vehicle\China\Camry\2000-2004\Mechanical	Add master key, Add valet key, Delete key Clear fault code	85
TOYOTA\Select from vehicle\China\Camry\2004-\Mechanical	Add master key, Add valet key, Delete key Clear fault code	85
TOYOTA\Select from vehicle\China\Reiz\Mechanical key(4D 67 68)	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735

TOYOTA\Select from vehicle\China\Crown\2009\Mechanical key(4D	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\Camry\2004\Mechanical key(with	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Prado\2010\Smart key	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Crown\2009\Mechanical key	Add master key,Add valet key,Delete key,	729
TOYOTA\Select from vehicle\China\Rav4\Smart key	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Reiz\Mechanical key(with G 72)	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Corolla\2012\Remote	Program remote,Delete remote,	741
TOYOTA\Select from vehicle\China\Camry\2004\Mechanical key(with	Add key,Delete key,Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Crown\2009\Mechanical	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Crown\2009\Mechanical	Add key,Delete key,Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Reiz\Mechanical key(with H 8A	Add key,Delete key,Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Camry\2004\Smart key	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Reiz\Smart key	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Camry\2004\Mechanical	Program remote,Delete remote,	741
TOYOTA\Select from vehicle\China\Vios\Mechanical key	Add master key,Add valet key,Delete key,	729
TOYOTA\Select from vehicle\China\Corolla\2012\Mechanical	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Camry\2004\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\China\Avanza\Mechanical key(with G 72)	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Vios\Mechanical key(4D 67 68)	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\Yaris\Smart key	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Levin\Mechanical key(with G 72)	Add key,Delete key,Program immo ECU Program engine	738

TOYOTA\Select from vehicle\China\Prado\2009-Mechanical key(4D 67	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from type\All smart key lost\All key lost	Backup EEPROM data,Generate SKE,Bind SKE Add smart	658
TOYOTA\Select from type\PEPS\Type 2(Crown XII)	Program remote,Add smart key,Reset immo ECU	725
TOYOTA\Select from type\PEPS\Type 3	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
TOYOTA\Select from type\IMMO\Type 4("8AE""H")	IMMO reset(8A all key lost), Add key,Delete key Program immo	727
TOYOTA\Select from type\IMMO\Type 5(Avanza)	Add key,	728
TOYOTA\Select from type\IMMO\Type 6	Add master key,Add valet key,Delete key,	729
TOYOTA\Select from vehicle\China\Corolla EX\Immobilizer\Mechanic	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from type\IMMO\Type 2("4D" 67or 68)	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from type\IMMO\Type 1("4C")	Add master key,Add valet key,Delete key Clear fault code	85
TOYOTA\Select from type\IMMO\Type 3("4D" 72 "C")	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from type\IMMO\Type 7(Toyota 86)	Read key count,Add key,Program remote Delete remote	739
TOYOTA\Select from type\Remote\Type 1	Program remote,Delete remote,	740
TOYOTA\Select from type\Remote\Type 2	Program remote,Delete remote,	741
TOYOTA\Select from type\PEPS\Type 1	Add smart key,Delete smart key,Reset smart key	743
TOYOTA\Select from type\Remote\Type 3	Program remote,	750
TOYOTA\Select from type\IMMO\Type 8(Avanza)	Reset G immo(All key lost),Reset DOT immo(All key lost)	858
TOYOTA\Select from vehicle\China\Avanza\All key lost	Reset G immo(All key lost),Reset DOT immo(All key lost)	858
TOYOTA\Select from vehicle\China\Corolla EX\Immobilizer\Mechanic	Add key,Delete key,Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Corolla EX\Smart key\Type 1	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Corolla EX\Smart key\Type 2	Program remote,Add smart key,Reset immo ECU	725

TOYOTA\Select from vehicle\USA\4Runner\1999-2002\Immobilizer	Add master key, Add valet key, Delete key Clear fault code	85
TOYOTA\Select from vehicle\USA\4Runner\2003-2009\Immobilizer	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\4Runner\2003-2009\Remote program	Remote program method,	976
TOYOTA\Select from vehicle\USA\4Runner\2009-2018\Mechanical	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\4Runner\2009-2018\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\4Runner\2009-2018\Mechanical	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\4Runner\2009-2018\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\4Runner\2009-2018\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\86\2016-2017\Smart key\Type 1	Add smart key, Delete smart key, Sync IMMO with steering	1497
TOYOTA\Select from vehicle\USA\86\2016-2017\Smart key\Type 2	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	1496
TOYOTA\Select from vehicle\USA\Allion\2006-2011(Smart key)	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Alphard\2006-2011(Smart key)	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Altis\2003-2006\Immobilizer(4C)	Add master key, Add valet key, Delete key Clear fault code	85
TOYOTA\Select from vehicle\USA\Altis\2011\Immobilizer(with G 72)	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Altis\2011\Immobilizer(with H 8A)	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Aurion\2006-2008\Immobilizer(4C)	Add master key, Add valet key, Delete key Clear fault code	85
TOYOTA\Select from vehicle\USA\Aurion\2006-2008\Immobilizer(4D 67)	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Aurion\2006-2008\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Aurion\2009\Immobilizer(4C)	Add master key, Add valet key, Delete key Clear fault code	85
TOYOTA\Select from vehicle\USA\Aurion\2009\Immobilizer(with G 72)	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Aurion\2009\Immobilizer(with H 8A)	Add key, Delete key, Program immo ECU Program engine	727



TOYOTA\Select from vehicle\USA\Aurion\2009-2011\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Aurion\2010-2011\Immobilizer	Add master key, Add valet key, Delete key, Clear fault code	85
TOYOTA\Select from vehicle\USA\Aurion\2010-2011\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Auris\2007-2008\Immobilizer	Add key, Delete key, All key lost, Reset immo ECU, Program engine ECU	735
TOYOTA\Select from vehicle\USA\Auris\2007-2008\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Auris\2009-2012\Immobilizer (4D 67	Add key, Delete key, All key lost, Reset immo ECU, Program engine ECU	735
TOYOTA\Select from vehicle\USA\Auris\2009-2012\Immobilizer (with G	Add key, Delete key, Program immo ECU, Program engine	738
TOYOTA\Select from vehicle\USA\Auris\2009-2012\Immobilizer (with H	Add key, Delete key, Program immo ECU, Program engine	727
TOYOTA\Select from vehicle\USA\Auris\2009-2012\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Avalon\1998-2004\Immobilizer (4C)	Add master key, Add valet key, Delete key, Clear fault code	85
TOYOTA\Select from vehicle\USA\Avalon\2005-2012\Mechanical	Add key, Delete key, All key lost, Reset immo ECU, Program engine ECU	735
TOYOTA\Select from vehicle\USA\Avalon\2005-2012\Mechanical	Add key, Delete key, Program immo ECU, Program engine	727
TOYOTA\Select from vehicle\USA\Avalon\2005-2012\Smart key	Add smart key, Delete smart key, Reset smart key	743
TOYOTA\Select from vehicle\USA\Avalon\2013-2018\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Avalon HV\2013-2017\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	1496
TOYOTA\Select from vehicle\USA\Avanza\2012-2015 (Mechanical key)	Add key, Delete key, All key lost, Reset immo ECU, Program engine ECU	735
TOYOTA\Select from vehicle\USA\Avensis\1997-2008\Immobilizer	Add key, Delete key, All key lost, Reset immo ECU, Program engine ECU	735
TOYOTA\Select from vehicle\USA\Avensis\2009-2011\Mechanical	Add key, Delete key, All key lost, Reset immo ECU, Program engine ECU	735
TOYOTA\Select from vehicle\USA\Avensis\2009-2011\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\USA\Avensis\2009-2011\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Avensis\2012-\Immobilizer (with G	Add key, Delete key, Program immo ECU, Program engine	738

TOYOTA\Select from vehicle\USA\Avenis\2012-\Immobilizer (with H	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Axio\2003\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Aygo\2005-2014\Immobilizer (4D 67	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Aygo\2005-2014\Immobilizer (with G	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Aygo\2005-2014\Immobilizer (with H	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Camry\1998-2003\Immobilizer	Add master key, Add valet key, Delete key Clear fault code	85
TOYOTA\Select from vehicle\USA\Camry\1998-2003\Remote program	Remote program method,	976
TOYOTA\Select from vehicle\USA\Camry\2004\Immobilizer (4C)	Add master key, Add valet key, Delete key Clear fault code	85
TOYOTA\Select from vehicle\USA\Camry\2004\Immobilizer (4D 67 68)	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Camry\2006-2011\Mechanical	Add master key, Add valet key, Delete key Clear fault code	85
TOYOTA\Select from vehicle\USA\Camry\2006-2011\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Camry\2006-2011\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\USA\Camry\2006-2011\Mechanical	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Camry\2006-2011\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Camry\2006-2011\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\USA\Camry\2006-2011\Mechanical	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Camry\2006-2011\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Camry\2006-2011\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\USA\Camry\2006-2011\Mechanical	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Camry\2006-2011\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Camry\2006-2011\Mechanical	Remote program method,	976

TOYOTA\Select from vehicle\USA\Camry\2006-2011\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Camry\2012-2018\Mechanical	Add key, Delete key, Program immo ECU, Program engine	738
TOYOTA\Select from vehicle\USA\Camry\2012-2018\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Camry\2012-2018\Mechanical	Add key, Delete key, Program immo ECU, Program engine	727
TOYOTA\Select from vehicle\USA\Camry\2012-2018\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Camry\2012-2018\Smart key\Type 1	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Camry\2012-2018\Smart key\Type 2	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	1496
TOYOTA\Select from vehicle\USA\Celsior\2000-2006 (Mechanical key)	Add key, Delete key, All key lost, Reset immo ECU, Program engine ECU	735
TOYOTA\Select from vehicle\USA\Corolla\2001-2006\Mechanical	Add master key, Add valet key, Delete key, Clear fault code	85
TOYOTA\Select from vehicle\USA\Corolla\2001-2006\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\USA\Corolla\2001-2006\Mechanical	Add key, Delete key, All key lost, Reset immo ECU, Program engine ECU	735
TOYOTA\Select from vehicle\USA\Corolla\2001-2006\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\USA\Corolla\2007-2008\Immobilizer	Add key, Delete key, All key lost, Reset immo ECU, Program engine ECU	735
TOYOTA\Select from vehicle\USA\Corolla\2009\Immobilizer (4D 67 68)	Add key, Delete key, All key lost, Reset immo ECU, Program engine ECU	735
TOYOTA\Select from vehicle\USA\Corolla\2009\Immobilizer (with G	Add key, Delete key, Program immo ECU, Program engine	738
TOYOTA\Select from vehicle\USA\Corolla\2009\Immobilizer (with H 8A	Add key, Delete key, Program immo ECU, Program engine	727
TOYOTA\Select from vehicle\USA\Corolla\2009\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Corolla\2010-2014\Mechanical	Add key, Delete key, All key lost, Reset immo ECU, Program engine ECU	735
TOYOTA\Select from vehicle\USA\Corolla\2010-2014\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Corolla\2010-2014\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\USA\Corolla\2010-2014\Mechanical	Add key, Delete key, Program immo ECU, Program engine	738

TOYOTA\Select from vehicle\USA\Corolla\2010-2014\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Corolla\2010-2014\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\USA\Corolla\2010-2014\Mechanical	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Corolla\2010-2014\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Corolla\2010-2014\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\USA\Corolla\2010-2014\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Corolla\2015-2018\Smart key\Type 1	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Corolla\2015-2018\Smart key\Type 2	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	1496
TOYOTA\Select from vehicle\USA\Crown\2003-\Mechanical	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Crown\2003-\Mechanical key\Remote	Program remote, Delete remote,	740
TOYOTA\Select from vehicle\USA\Crown\2003-\Smart key\Type 1	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Crown\2003-\Smart key\Type 2	Program remote, Add smart key, Reset immo ECU	725
TOYOTA\Select from vehicle\USA\Echo\2003-2005\Immobilizer (4C)	Add master key, Add valet key, Delete key Clear fault code	85
TOYOTA\Select from vehicle\USA\Estima\2006-2011 (Smart key)	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\FJ Cruiser\2008-	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\FJ Cruiser\2010-2014\Type	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\FJ Cruiser\2010-2014\Type	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\FJ Cruiser\2010-2014\Type	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\FJ Cruiser\2010-2014\Type	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\FJ Cruiser\2010-2014\Type	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Fieldler\2006-2011 (Smart key)	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726

TOYOTA\Select from vehicle\USA\Fortuner\2005-\Mechanical key(with	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Fortuner\2005-\Immobilizer(with H	Add key,Delete key,Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Hiace\2005\Remote program	Remote program method,	976
TOYOTA\Select from vehicle\USA\Hiace\2005-\Immobilizer(4D 67 68)	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Hiace\2005-\Mechanical key(with G	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Hiace\2005-\Immobilizer(with H 8A	Add key,Delete key,Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Highlander\2001-2003\Immobilizer	Add master key,Add valet key,Delete key Clear fault code	85
TOYOTA\Select from vehicle\USA\Highlander\2001-2003\Remote	Remote program method,	976
TOYOTA\Select from vehicle\USA\Highlander\2004-2007\Immobilizer	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Highlander\2004-2007\Remote	Program remote,Delete remote,	740
TOYOTA\Select from vehicle\USA\Highlander\2004-2007\Remote	Remote program method,	976
TOYOTA\Select from vehicle\USA\Highlander\2004-2007\Smart key	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Highlander\2008-	Add key,Delete key,Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Highlander\2008-2010\Smart key	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Highlander\2011-2018\Mechanical	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Highlander\2011-2018\Mechanical	Program remote,Delete remote,	741
TOYOTA\Select from vehicle\USA\Highlander\2011-2018\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\USA\Highlander\2011-2018\Mechanical	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Highlander HV\2008-2017(Smart	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Highlander HV\2008-2017(Smart	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	1496
TOYOTA\Select from vehicle\USA\Hilux\2004-2007\Immobilizer	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735

TOYOTA\Select from vehicle\USA\Hilux\2008-\Immobilizer(4D 67 68)	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Hilux\2008-\Mechanical key(with G	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Hilux\2008-\Immobilizer(with H 8A	Add key,Delete key,Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\IQ\2008-2011\Mechanical	Program remote,Delete remote,	741
TOYOTA\Select from vehicle\USA\IQ\2008-2011\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\USA\IQ\2008-2011\Mechanical	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\IQ\2008-2011\Mechanical	Program remote,Delete remote,	741
TOYOTA\Select from vehicle\USA\IQ\2008-2011\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\USA\IQ\2008-2011\Mechanical	Add key,Delete key,Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\IQ\2012-2014\Mechanical	Program remote,Delete remote,	741
TOYOTA\Select from vehicle\USA\IQ\2012-2014\Mechanical	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\IQ\2012-2014\Mechanical	Program remote,Delete remote,	741
TOYOTA\Select from vehicle\USA\IQ\2012-2014\Mechanical	Add key,Delete key,Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Innova\2003-2009\Immobilizer(with	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Innova\2010\Immobilizer(with G 72)	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Innova\2010\Immobilizer(with H 8A	Add key,Delete key,Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Kluger\2003-2005\Immobilizer	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Kluger\2006-2008\Immobilizer	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Kluger\2006-2008\Smart key	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Kluger\2009-2011\Mechanical	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Kluger\2009-2011\Mechanical	Add key,Delete key,Program immo ECU Program engine	727

TOYOTA\Select from vehicle\USA\Kluger\2009-2011\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Kluger\2012-\Immobilizer (with G	Add key, Delete key, Program immo ECU, Program engine	738
TOYOTA\Select from vehicle\USA\Kluger\2012-\Immobilizer (with H, 8A	Add key, Delete key, Program immo ECU, Program engine	727
TOYOTA\Select from vehicle\USA\Land Cruiser\1998-	Add master key, Add valet key, Delete key, Clear fault code	85
TOYOTA\Select from vehicle\USA\Land Cruiser\1998-	Remote program method,	976
TOYOTA\Select from vehicle\USA\Land Cruiser\2002-	Add key, Delete key, All key lost, Reset immo ECU, Program engine, ECU	735
TOYOTA\Select from vehicle\USA\Land Cruiser\2002-	Remote program method,	976
TOYOTA\Select from vehicle\USA\Land Cruiser\2002-2009\Smart	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Land Cruiser\2009-	Add key, Delete key, All key lost, Reset immo ECU, Program engine, ECU	735
TOYOTA\Select from vehicle\USA\Land Cruiser\2009-	Remote program method,	976
TOYOTA\Select from vehicle\USA\Land Cruiser\2009-	Add key, Delete key, Program immo ECU, Program engine	738
TOYOTA\Select from vehicle\USA\Land Cruiser\2009-	Remote program method,	976
TOYOTA\Select from vehicle\USA\Land Cruiser\2009-	Add key, Delete key, Program immo ECU, Program engine	727
TOYOTA\Select from vehicle\USA\Land Cruiser\2009-	Remote program method,	976
TOYOTA\Select from vehicle\USA\Land Cruiser\2009-\Smart	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Land Cruiser\2009-\Smart	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	1496
TOYOTA\Select from vehicle\USA\Land Cruiser_70\2002-	Add key, Delete key, Program immo ECU, Program engine	738
TOYOTA\Select from vehicle\USA\Land Cruiser_70\2002-	Remote program method,	976
TOYOTA\Select from vehicle\USA\Land Cruiser_70\2002-	Add key, Delete key, Program immo ECU, Program engine	727
TOYOTA\Select from vehicle\USA\Land Cruiser_70\2002-	Remote program method,	976
TOYOTA\Select from vehicle\USA\Land Cruiser_100\1999-	Add key, Delete key, All key lost, Reset immo ECU, Program engine, ECU	735

TOYOTA\Select from vehicle\USA\Land Cruiser_200\2002-(Smart	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Land Cruiser Prado\2004-	Add key, Delete key, All key lost, Reset immo ECU, Program engine ECU	735
TOYOTA\Select from vehicle\USA\Land Cruiser Prado\2009-	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
TOYOTA\Select from vehicle\USA\MR2 Snyder\2000-	Add master key, Add valet key, Delete key, Clear fault code	85
TOYOTA\Select from vehicle\USA\Mark x\2004\Remote program	Remote program method,	976
TOYOTA\Select from vehicle\USA\Mark x\2005-2006\Mechanical	Add key, Delete key, All key lost, Reset immo ECU, Program engine ECU	735
TOYOTA\Select from vehicle\USA\Mark x\2005-2006\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\USA\Mark x\2005-2006\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Mark x\2007-2010\Immobilizer	Add key, Delete key, All key lost, Reset immo ECU, Program engine ECU	735
TOYOTA\Select from vehicle\USA\Mark x\2007-2010\Remote	Remote program method,	976
TOYOTA\Select from vehicle\USA\Mark x\2010-2014\Mechanical	Add key, Delete key, Program immo ECU, Program engine	738
TOYOTA\Select from vehicle\USA\Mark x\2010-2014\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Mark x\2010-2014\Mechanical	Add key, Delete key, Program immo ECU, Program engine	727
TOYOTA\Select from vehicle\USA\Mark x\2010-2014\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Matrix\2005-2009\Immobilizer	Add key, Delete key, All key lost, Reset immo ECU, Program engine ECU	735
TOYOTA\Select from vehicle\USA\Matrix\2010-2014\Mechanical	Add key, Delete key, Program immo ECU, Program engine	738
TOYOTA\Select from vehicle\USA\Matrix\2010-2014\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Matrix\2010-2014\Mechanical	Add key, Delete key, Program immo ECU, Program engine	727
TOYOTA\Select from vehicle\USA\Matrix\2010-2014\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Matrix\2016-2017\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	1496
TOYOTA\Select from vehicle\USA\Mitri\2016(Smart key)	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726



TOYOTA\Select from vehicle\USA\Mr2\1999- (Mechanical key)	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\New Verso E7\2009-	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	1496
TOYOTA\Select from vehicle\USA\New Verso E7\2010-\Mechanical	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\New Verso E7\2010-\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\New Verso E7\2010-\Mechanical	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\New Verso E7\2010-\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Prado\2002-2008\Immobilizer	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Prado\2002-2008\Remote program	Remote program method,	977
TOYOTA\Select from vehicle\USA\Prado\2009\ Mechanical key (with G	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Prado\2009\ Mechanical key (with G	Remote program method,	977
TOYOTA\Select from vehicle\USA\Prado\2009\ Mechanical key (with H	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Prado\2009\ Mechanical key (with H	Remote program method,	977
TOYOTA\Select from vehicle\USA\Prado 150\2009 (Smart key)	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Premio\2006 \Mechanical key	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Premio\2006 \Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Premio\2007 -2011\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Previa\2001 -\Mechanical key	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Previa\2001 -\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Prius\2003\ Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Prius\2004-2009\Mechanical key (4D	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Prius\2004-2009\Mechanical key (4D	Program remote, Delete remote,	740

TOYOTA

TOYOTA\Select from vehicle\USA\Prius\2004-2009\Mechanical_key(4D	Remote program method,	976
TOYOTA\Select from vehicle\USA\Prius\2004-2009\Smart_key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Prius\2010-\Smart_key(type 1)	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Prius\2010-\Smart_key(type 2)	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	1496
TOYOTA\Select from vehicle\USA\Prius C\2012-2018\Mechanical	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Prius C\2012-2018\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Prius C\2012-2018\Mechanical	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Prius C\2012-2018\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Prius C\2012-2018\Smart_key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Prius PHV\2010-2017(Smart	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	1496
TOYOTA\Select from vehicle\USA\Prius Prime\2017(Smart_key)	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	1496
TOYOTA\Select from vehicle\USA\Prius V\2012-2017(Smart_key)	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	1496
TOYOTA\Select from vehicle\USA\Rav4\2001-2005\Mechanical_key(4C)	Add master key, Add valet key, Delete key Clear fault code	85
TOYOTA\Select from vehicle\USA\Rav4\2001-2005\Mechanical_key(4D	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Rav4\2006-2008\Mechanical	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Rav4\2006-2008\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Rav4\2006-2008\Smart_key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Rav4\2009-2017\Mechanical_key(4D	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Rav4\2009-2017\Mechanical_key(4D	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Rav4\2009-2017\Mechanical_key(4D	Remote program method,	976
TOYOTA\Select from vehicle\USA\Rav4\2009-2017\Mechanical	Add key, Delete key, Program immo ECU Program engine	738

TOYOTA\Select from vehicle\USA\Rav4\2009-2017\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\USA\Rav4\2009-2017\Mechanical	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Rav4\2009-2017\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\USA\Rav4\2009-2017\Smart_key\Type 1	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Rav4\2009-2017\Smart_key\Type 2	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	1496
TOYOTA\Select from vehicle\USA\Rav4 EV\2012-2014 (Smart key)	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	1496
TOYOTA\Select from vehicle\USA\Rav4 HV\2016-2017 (Smart key)	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	1496
TOYOTA\Select from vehicle\USA\Rumion\2006-2011 (Smart key)	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	1496
TOYOTA\Select from vehicle\USA\Sequoia\2000-2006\Mechanical	Add master key, Add valet key, Delete key Clear fault code	85
TOYOTA\Select from vehicle\USA\Sequoia\2000-2006\Mechanical	Remote program method,	1478
TOYOTA\Select from vehicle\USA\Sequoia\2007-2011\Mechanical	Add master key, Add valet key, Delete key Clear fault code	85
TOYOTA\Select from vehicle\USA\Sequoia\2007-2011\Mechanical	Remote program method,	1478
TOYOTA\Select from vehicle\USA\Sequoia\2007-2011\Mechanical	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Sequoia\2007-2011\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Sequoia\2007-2011\Mechanical	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Sequoia\2007-2011\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Sequoia\2007-2011\Mechanical	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Sequoia\2007-2011\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Sienna\2009\Mechanical	Add master key, Add valet key, Delete key Clear fault code	85
TOYOTA\Select from vehicle\USA\Sienna\2009\Mechanical key (4D	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Sienna\2009\Mechanical key (4D	Remote program method,	976

TOYOTA\Select from vehicle\USA\Sienna\2010-2011\Mechanical_key(4D	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Sienna\2010-2011\Mechanical	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Sienna\2010-2011\Mechanical	Program remote,Delete remote,	741
TOYOTA\Select from vehicle\USA\Sienna\2010-2011\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\USA\Sienna\2010-2011\Mechanical	Add key,Delete key,Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Sienna\2010-2011\Mechanical	Program remote,Delete remote,	741
TOYOTA\Select from vehicle\USA\Sienna\2010-2011\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\USA\Sienna\2010-2011\Smart_key	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Sienna\2012-\Mechanical_key(with G	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Sienna\2012-\Mechanical_key(with G	Program remote,Delete remote,	741
TOYOTA\Select from vehicle\USA\Sienna\2012-\Mechanical_key(with H	Add key,Delete key,Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Sienna\2012-\Mechanical_key(with H	Program remote,Delete remote,	741
TOYOTA\Select from vehicle\USA\Sienna\2012-\Smart_key	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Solara\1999-2003\Mechanical	Add master key,Add valet key,Delete key Clear fault code	85
TOYOTA\Select from vehicle\USA\Solara\1999-2003\Mechanical	Remote program method,	1480
TOYOTA\Select from vehicle\USA\Solara\1999-2003\Mechanical_key(4D	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Solara\1999-2003\Mechanical_key(4D	Remote program method,	1480
TOYOTA\Select from vehicle\USA\Solara\2004-2006\Mechanical_key(4D	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Tacoma\2004-2015\Mechanical_key(4D	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Tacoma\2004-2015\Mechanical_key(4D	Program remote,Delete remote,	741
TOYOTA\Select from vehicle\USA\Tacoma\2004-2015\Mechanical_key(4D	Remote program method,	976

TOYOTA\Select from vehicle\USA\Tacoma\2004-2015\Mechanical	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Tacoma\2004-2015\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Tacoma\2004-2015\Mechanical	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Tacoma\2004-2015\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Tacoma\2016-2017\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	1496
TOYOTA\Select from vehicle\USA\Tarago\2002-2008\Immobilizer	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Tarago\2009-\Mechanical key(with G	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Tarago\2009-\Mechanical key(with H	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Tundra\2000-2006\Remote	Program remote, Delete remote,	740
TOYOTA\Select from vehicle\USA\Tundra\2007-\Mechanical key(4D 67	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Tundra\2007-\Mechanical key(4D 67	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Tundra\2007-\Mechanical key(with G	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Tundra\2007-\Mechanical key(with G	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Tundra\2007-\Mechanical key(with H	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Tundra\2007-\Mechanical key(with H	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Urban Cruiser\2009(Smart key)	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Vanguard\2009(Smart key)	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Vela\2010(Mechanical key)	Remote program method,	976
TOYOTA\Select from vehicle\USA\Venza\2008-\Mechanical key(4D 67	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Venza\2008-\Mechanical key(4D 67	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Venza\2008-\Mechanical key(with G	Add key, Delete key, Program immo ECU Program engine	738

TOYOTA\Select from vehicle\USA\Venza\2008-\Mechanical key(with G	Program remote,Delete remote,	741
TOYOTA\Select from vehicle\USA\Venza\2008-\Mechanical key(with H	Add key,Delete key,Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Venza\2008-\Mechanical key(with H	Program remote,Delete remote,	741
TOYOTA\Select from vehicle\USA\Venza\2008-\Smart key	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Verso\2011(Mechanical key)	Remote program method,	976
TOYOTA\Select from vehicle\USA\Vigo\2005-2008\Immobilizer	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Vigo\2010\Mechanical key(with G	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Vigo\2010\Mechanical key(with H 8A	Add key,Delete key,Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Vios\2008(Mechanical key)	Remote program method,	1479
TOYOTA\Select from vehicle\USA\Vios\2008-(Mechanical key)	Remote program method,	976
TOYOTA\Select from vehicle\USA\Voxy\Smart key	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Yaris\2000	Remote program method,	976
TOYOTA\Select from vehicle\USA\Yaris\2001-2005\Mechanical	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Yaris\2001-2005\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\USA\Yaris\2001-2005\Mechanical key(4C)	Add master key,Add valet key,Delete key Clear fault code	85
TOYOTA\Select from vehicle\USA\Yaris\2006-2008\Mechanical	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Yaris\2006-2008\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\USA\Yaris\2006-2008\Smart key	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\USA\Yaris\2008-2011\Mechanical key(4D	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Yaris\2008-2011\Mechanical key(4D	Program remote,Delete remote,	741
TOYOTA\Select from vehicle\USA\Yaris\2008-2011\Mechanical key(4D	Remote program method,	976

TOYOTA\Select from vehicle\USA\Yaris\2008-2011\Mechanical	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Yaris\2008-2011\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Yaris\2008-2011\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\USA\Yaris\2008-2011\Mechanical	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Yaris\2008-2011\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Yaris\2008-2011\Mechanical	Remote program method,	976
TOYOTA\Select from vehicle\USA\Yaris\2012\Mechanical key(4D 67	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\USA\Yaris\2012\Mechanical key(4D 67	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Yaris\2012\Mechanical key(with G	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Yaris\2012\Mechanical key(with G	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Yaris\2012\Mechanical key(with H	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\USA\Yaris\2012\Mechanical key(with H	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\USA\Yaris\2014\Mechanical key(with G	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\USA\Yaris\2014\Mechanical key(with H	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\86\2016\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Alphard\2005\Mechanical key	Add master key, Add valet key, Delete key Clear fault code	85
TOYOTA\Select from vehicle\China\Alphard\2005\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Alphard\2005-\Mechanical key(4D	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\Alphard\2005-\Mechanical	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Alphard\2005-\Mechanical	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Alphard\2005-\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726

TOYOTA\Select from vehicle\China\Corolla\2012-\Mechanical key(4D	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\Corolla\2012-\Mechanical	Add key,Delete key,Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Corolla\2007-2011\Mechanical key	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\Corolla\2001-2006\Immobilizer	Add master key,Add valet key,Delete key Clear fault code	85
TOYOTA\Select from vehicle\China\Corolla\2001-2006\Remote program	Remote program method,	976
TOYOTA\Select from vehicle\China\EZ\2012\Smart key	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\EZ\2012-\Mechanical key(with G	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\EZ\2012-\Mechanical key(with H	Add key,Delete key,Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\FJ Cruiser)\2010\Smart key	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\FJ Cruiser)\-	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\FJ Cruiser)\-	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\FJ Cruiser)\-	Add key,Delete key,Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\FJ Cruiser)\2010-	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\FJ Cruiser)\2010-	Add key,Delete key,Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Fortuner\2005-\Mechanical	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Fortuner\2005-\Mechanical	Add key,Delete key,Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Fortuner/Hilux Sw4)\-	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\Fortuner/Hilux Sw4)\-	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Fortuner/Hilux Sw4)\2009\Smart	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Fortuner/Hilux Sw4)\2009-	Add key,Delete key,Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Fortuner/Hilux Sw4)\2009-	Add key,Delete key,Program immo ECU Program engine	727



TOYOTA\Select from vehicle\China\Fortuner/Hilux Sw4\2015-	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Fortuner/Hilux Sw4\2015-	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Fortuner/Hilux Sw4\2015-\Smart	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Hiace\2005\Remote program	Remote program method,	976
TOYOTA\Select from vehicle\China\Hiace\2006-2015\Mechanical	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\Hiace\2006-2015\Mechanical	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Hiace\2006-2015\Mechanical	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Hiace\2015-\Mechanical key(with	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Hiace\2015-\Mechanical key(with	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Hiace\2015-\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Highlander\2001-2003\Mechanical	Add master key, Add valet key, Delete key,	729
TOYOTA\Select from vehicle\China\Highlander\2004-\Mechanical	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\Highlander\2004-\Mechanical	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Highlander\2004-\Mechanical	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Highlander\2004-\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Hilux\Mechanical key(4D 67 68)	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\Hilux\Mechanical key(with G 72)	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Hilux\Mechanical key(with H 8A	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Land Cruiser\2002-	Add master key, Add valet key, Delete key Clear fault code	85
TOYOTA\Select from vehicle\China\Land Cruiser\2002-	Remote program method,	976
TOYOTA\Select from vehicle\China\Land Cruiser\2002-	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735

TOYOTA\Select from vehicle\China\Land Cruiser\2002-	Remote program method,	976
TOYOTA\Select from vehicle\China\Land Cruiser\2002-	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Land Cruiser\2002-	Remote program method,	976
TOYOTA\Select from vehicle\China\Land Cruiser\2002-	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Land Cruiser\2002-	Remote program method,	976
TOYOTA\Select from vehicle\China\Land Cruiser\2002-\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Land Cruiser 70\2002-	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Land Cruiser 70\2002-	Remote program method,	976
TOYOTA\Select from vehicle\China\Land Cruiser 70\2002-	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Land Cruiser 70\2002-	Remote program method,	976
TOYOTA\Select from vehicle\China\Land Cruiser 100\1999-	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\Land Cruiser 100\2002-	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\Land Cruiser 100\2002-	Remote program method,	976
TOYOTA\Select from vehicle\China\Land Cruiser 200\2002-(Smart	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Land Cruiser Prado\2004-	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\Land Cruiser Prado\2009-	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Levin\Mechanical key(with H 8A	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Levin\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Previa\2001-\Mechanical key	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\Previa\2001-\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Previa HV\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726

TOYOTA\Select from vehicle\China\Prius/Tarago\Mechanical key	Add master key, Add valet key, Delete key,	729
TOYOTA\Select from vehicle\China\Prius/Tarago\Mechanical key(4D	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\Prius/Tarago\Mechanical key(with	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Prius/Tarago\Mechanical key(with	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Prius/Tarago\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Prius\Mechanical key(4D 67 68)	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\Prius\Mechanical key(with G 72)	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Prius\Mechanical key(with H 8A	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Prius\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Prius+/Prius V\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Prius C\Mechanical key(with G	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Prius C\Mechanical key(with H	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Prius C\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Prius C2\2012-2013\Mechanical	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Prius C2\2012-2013\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\China\Prius C2\2012-2013\Mechanical	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Prius C2\2012-2013\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\China\Prius PHV\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Rav4\Mechanical key	Add master key, Add valet key, Delete key,	729
TOYOTA\Select from vehicle\China\Rav4\Mechanical key(4D 67 68)	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\Rav4\Mechanical key(with G 72)	Add key, Delete key, Program immo ECU Program engine	738

TOYOTA\Select from vehicle\China\Rav4\Mechanical key(with H 8A	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Rav4 HV\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Sequoia\2000-2007\Mechanical	Add master key, Add valet key, Delete key Clear fault code	85
TOYOTA\Select from vehicle\China\Sequoia\2000-2007\Mechanical	Remote program method,	1478
TOYOTA\Select from vehicle\China\Sequoia\2007-\Mechanical	Add master key, Add valet key, Delete key Clear fault code	85
TOYOTA\Select from vehicle\China\Sequoia\2007-\Mechanical	Remote program method,	1478
TOYOTA\Select from vehicle\China\Sequoia\2007-\Mechanical key(4D	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\Sequoia\2007-\Mechanical key(4D	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\China\Sequoia\2007-\Mechanical	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Sequoia\2007-\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\China\Sequoia\2007-\Mechanical	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Sequoia\2007-\Mechanical	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\China\Sienna\Mechanical key	Add master key, Add valet key, Delete key,	729
TOYOTA\Select from vehicle\China\Sienna\Mechanical key(4D 67	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\Sienna\Mechanical key(4D 67	Remote program method,	976
TOYOTA\Select from vehicle\China\Sienna\Mechanical key(with G	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Sienna\Mechanical key(with G	Remote program method,	976
TOYOTA\Select from vehicle\China\Sienna\Mechanical key(with H 8A	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Sienna\Mechanical key(with H 8A	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\China\Sienna\Mechanical key(with H 8A	Remote program method,	976
TOYOTA\Select from vehicle\China\Sienna\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726

TOYOTA\Select from vehicle\China\Tundra\2000-2006\Remote	Program remote, Delete remote,	740
TOYOTA\Select from vehicle\China\Tundra\2007-\Mechanical key(4D	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\Tundra\2007-\Mechanical key(4D	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\China\Tundra\2007-\Mechanical key(with	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Tundra\2007-\Mechanical key(with	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\China\Tundra\2007-\Mechanical key(with	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Tundra\2007-\Mechanical key(with	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\China\Venza\Mec	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\Venza\Mec	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\China\Venza\Mec	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Venza\Mec	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\China\Venza\Mec	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Venza\Mec	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\China\Venza\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Yaris\2008-\Mechanical key(4D 67	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
TOYOTA\Select from vehicle\China\Yaris\2008-\Mechanical key(4D 67	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\China\Yaris\2008-\Mechanical key(with	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Yaris\2008-\Mechanical key(with	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\China\Yaris\2008-\Mechanical key(with	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Yaris\2008-\Mechanical key(with	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\China\Yaris\2013-\Mechanical key(with	Add key, Delete key, Program immo ECU Program engine	738

TOYOTA\Select from vehicle\China\Yaris\2013-\Mechanical key(with	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\China\Yaris\2013-\Mechanical key(with	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Yaris\2013-\Mechanical key(with	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\China\Zelas\Mec hanical key(with G 72)	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Zelas\Mec hanical key(with H 8A	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Zelas\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Vios\Mech anical key(with G 72)	Add key, Delete key, Program immo ECU Program engine	738
TOYOTA\Select from vehicle\China\Vios\Mech anical key(with H 8A	Add key, Delete key, Program immo ECU Program engine	727
TOYOTA\Select from vehicle\China\Vios\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Camry\2004-\Mechanical key(with	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\China\Camry\2004-\Mechanical key(with	Remote program method,	976
TOYOTA\Select from vehicle\China\Camry\2004-\Mechanical key(with	Program remote, Delete remote,	741
TOYOTA\Select from vehicle\China\Camry\2004-\Mechanical key(with	Remote program method,	976
TOYOTA\Select from vehicle\China\Crown\2009\Smart key	Add smart key, Delete smart key, Reset smart key	743
TOYOTA\Select from vehicle\China\Crown\2009-\Smart key(type 1)	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
TOYOTA\Select from vehicle\China\Crown\2009-\Smart key(type 2)	Program remote, Add smart key, Reset immo ECU	725
TOYOTA\Select from vehicle\China\Crown\2009-\Remote	Program remote, Delete remote,	740
TOYOTA\Select from vehicle\China\86\Redeem LKE with SKE	Apply for a redemption, Progress query	1542
TOYOTA\Select from vehicle\China\Avalon\Smart key\Type 1	Add smart key, Delete smart key,	128
TOYOTA\Select from vehicle\USA\Frz\2013	Read key count, Add key, Program remote Delete remote	739
TOYOTA\Select from vehicle\USA\Corolla\2015-2018\Mechanical	Add key, Delete key, Program immo ECU Program engine	727

	TOYOTA\Select from vehicle\USA\Corolla\2015-2018\Mechanical	Program remote, Delete remote,	741
BMW	BMW\Select from type\CAS1/CAS2/CAS3	Program/delete key, Disable and enable, Sync, EIV, Sync	223
	BMW\Select from type\CAS4/CAS4+	Generate ignition key, Disable key, Enable key	794
	BMW\Select from type\FEM/BDC	Read key data, Preprocess FEM/BDC system, Make dealer	790
TRUMPCHI	TRUMPCHI\GS5\Immobilizer	Add key, Delete key, Read key count,	8
	TRUMPCHI\GS5\Smart key	All smart key lost,	7
	TRUMPCHI\GA5\Immobilizer	Add key, Delete key, Read key count,	8
	TRUMPCHI\GA5\Smart key	All smart key lost,	7
	TRUMPCHI\GA3 (GA3S)\Immobilizer	Add key, Read key count, All key lost,	314
	TRUMPCHI\GA8\Immobilizer	Add key, Read key count, All key lost,	314
	TRUMPCHI\GS4\Immobilizer	Add key, Read key count, All key lost,	314
	TRUMPCHI\GA6\Immobilizer	Add key, Read key count, All key lost,	314
	TRUMPCHI\Extended electric vehicles\Immobilizer	Add key, Delete key, Read key count,	8
	TRUMPCHI\GA3 (GA3S)\Smart key	All smart key lost,	7
	TRUMPCHI\GA6\Smart key	All smart key lost,	7
	TRUMPCHI\GA8\Smart key	All smart key lost,	7
	TRUMPCHI\GS4\Smart key	All smart key lost,	7
	TRUMPCHI\GS8\Smart key	All smart key lost,	7
	TRUMPCHI\GS8\Immobilizer	Add key, Delete key, Read key count,	8
	TRUMPCHI\GA4\Immobilizer	Add key, Read key count, All key lost,	314
TRUMPCHI\GA4\Smart key	All smart key lost,	7	

	TRUMPCHI\GS3\Immobilizer	Add key, Delete key, Read key count,	8
	TRUMPCHI\GS3\Smart key	All smart key lost,	7
	TRUMPCHI\GS7\Smart key	All smart key lost,	7
	TRUMPCHI\GE3\Smart key	All smart key lost,	7
	TRUMPCHI\GM8\Smart key	All smart key lost,	7
	TRUMPCHI\New energy vehicles\Immobilizer	Add key, Read key count, All key lost,	314
	TRUMPCHI\GA3S (PHEV)\Smart key	All smart key lost,	7
	TRUMPCHI\GS4 (PHEV)\Smart key	All smart key lost,	7
MASERATI	MASERATI\Flip key\Immobilizer	Program key, Backup immo data, Program remote Make dealer key	9
	MASERATI\Smart key(-2016)\Read PIN code	Read pin code,	40
	MASERATI\Smart key(-2016)\Smart key	Add smart key, Delete smart key,	41
	MASERATI\Smart key (2016-)\Smart key	Add smart key, Delete smart key, Backup immo data Backup immo	947
VOLVO	VOLVO\S60\2010-2018\Smart key[insert start]	Add key, All key lost, Read CEM security data Key recognition &	10
	VOLVO\S60\2010-2018\Keyless-go[button start]	Add smart key, Delete smart key, Read CEM security data Read KVM	35
	VOLVO\S80\2009-2016\Keyless-go[button start]	Add smart key, Delete smart key, Read CEM security data Read KVM	35
	VOLVO\XC60\2009-2018\Keyless-go[button start]	Add smart key, Delete smart key, Read CEM security data Read KVM	35
	VOLVO\S80\2009-2016\Smart key[insert start]	Add key, All key lost, Read CEM security data Key recognition &	10
	VOLVO\XC60\2009-2018\Smart key[insert start]	Add key, All key lost, Read CEM security data Key recognition &	10
	VOLVO\S40\2004-2012\Smart key	Add smart key, Delete smart key, Unlock key,	366
	VOLVO\S40\2004-2012\Immobilizer	Add key, Delete key, Identify key ID Unlock key	369
	VOLVO\S80\2007-2009\Smart key[insert start]	Add key, Delete key, Read CEM security data, Key recognition &	371



VOLVO

VOLVO\V40\2012-2018\Smart key[insert start]	Add key, Delete key, Read CEM security data, Key recognition &	372
VOLVO\C30\2007-2013\Immobilizer	Add key, Delete key, Identify key ID, Unlock key	369
VOLVO\C30\2007-2013\Smart key	Add smart key, Delete smart key, Unlock key,	366
VOLVO\V40\2012-2018\Keyless-go[button start]	Add smart key, Delete smart key, Read CEM security data, Read KVM	393
VOLVO\S80\2007-2009\Keyless-go[button start]	Add smart key, Delete smart key, Read CEM security data, Read KVM	394
VOLVO\V60\2011-2017\Smart key[insert start]	Add key, All key lost, Read CEM security data, Key recognition &	10
VOLVO\V60\2011-2017\Keyless-go[button start]	Add smart key, Delete smart key, Read CEM security data, Read KVM	35
VOLVO\XC60\2006-2009\Smart key[insert start]	Add key, Delete key, Read CEM security data, Key recognition &	371
VOLVO\XC60\2006-2009\Keyless-go[button start]	Add smart key, Delete smart key, Read CEM security data, Read KVM	394
VOLVO\XC90\2005-\Flip key	Add key, Delete key, Identify key ID, Key unlock	463
VOLVO\S80\2005-2007\Flip key	Add key, Delete key, Identify key ID, Key unlock	463
VOLVO\C70\2007-2013\Immobilizer	Add key, Delete key, Identify key ID, Unlock key	369
VOLVO\C70\2007-2013\Smart key	Add smart key, Delete smart key, Unlock key,	366
VOLVO\V70\2009-2016\Smart key[insert start]	Add key, All key lost, Read CEM security data, Key recognition &	10
VOLVO\V70\2009-2016\Keyless-go[button start]	Add smart key, Delete smart key, Read CEM security data, Read KVM	35
VOLVO\XC70\2010-2016\Smart key[insert start]	Add key, All key lost, Read CEM security data, Key recognition &	10
VOLVO\XC70\2010-2016\Keyless-go[button start]	Add smart key, Delete smart key, Read CEM security data, Read KVM	35
VOLVO\XC70\2007-2010\Smart key[insert start]	Add key, Delete key, Read CEM security data, Key recognition &	371
VOLVO\XC70\2007-2010\Keyless-go[button start]	Add smart key, Delete smart key, Read CEM security data, Read KVM	394
VOLVO\XC70\2006\Flip key	Add key, Delete key, Identify key ID, Key unlock	463
VOLVO\V70\2006-2008\Flip key	Add key, Delete key, Identify key ID, Key unlock	463

CITROEN\Select from vehicle\C4\Immobilizer\ Type 1	Program key,	24
CITROEN\Select from vehicle\Triomphe\Immobilizer	Program key,	24
CITROEN\Select from vehicle\C5(China)\Immobilizer	Program key,	24
CITROEN\Select from vehicle\Quatre\Immobilizer	Program key,	24
CITROEN\Select from vehicle\C4L\Immobilizer	Program key,	27
CITROEN\Select from vehicle\C4L\Smart key	All smart key lost,	288
CITROEN\Select from vehicle\C3-XR\Smart key	All smart key lost,	288
CITROEN\Read PIN code	Type 1, Type 2, Type 3, Type 4 (K line),	289
CITROEN\Select from type\Immobilizer\Type 1	Program key,	287
CITROEN\Select from type\Smart key\Type 1	All smart key lost,	288
CITROEN\Select from type\Immobilizer\Type 3	Program key,	27
CITROEN\Select from type\Immobilizer\Type 2	Program key,	24
CITROEN\Select from vehicle\Berlingo\Immobilizer\Type 2	Program key,	287
CITROEN\Select from vehicle\C1\Immobilizer	Program key,	287
CITROEN\Select from vehicle\C2\Immobilizer\ Type 1(K)	Program key,	287
CITROEN\Select from vehicle\C3\Immobilizer\ Type 1(K)	Program key,	287
CITROEN\Select from vehicle\C5\Immobilizer\ Type 2	Program key,	287
CITROEN\Select from vehicle\C8\Immobilizer\ Type 1(K)	Program key,	287
CITROEN\Select from vehicle\Dispatch\Immobilizer\Type 2	Program key,	287
CITROEN\Select from vehicle\Jumpy\Immobilizer\Type 2	Program key,	287
CITROEN\Select from vehicle\Nemo\Immobilizer\Type 1(K)	Program key,	287

CITROEN

CITROEN\Select from vehicle\Picasso\Immobilizer	Program key,	287
CITROEN\Select from vehicle\Relay\Immobilizer	Program key,	287
CITROEN\Select from vehicle\Relay2\Immobilizer	Program key,	287
CITROEN\Select from vehicle\Synergie\Immobilizer\Type 2	Program key,	287
CITROEN\Select from vehicle\XSARA (China)\Immobilizer	Program key,	287
CITROEN\Select from vehicle\Xsara\Immobilizer\Type 2	Program key,	287
CITROEN\Select from vehicle\Xantia\Immobilizer\Type 2	Program key,	287
CITROEN\Select from vehicle\Berlingo\Immobilizer\Type 3	Program key,	24
CITROEN\Select from vehicle\C2\Immobilizer\Type 2(CAN)	Program key,	24
CITROEN\Select from vehicle\C3\Immobilizer\Type 2(CAN)	Program key,	24
CITROEN\Select from vehicle\C5\Immobilizer\Type 3	Program key,	24
CITROEN\Select from vehicle\C6\Immobilizer	Program key,	24
CITROEN\Select from vehicle\C8\Immobilizer\Type 2(CAN)	Program key,	24
CITROEN\Select from vehicle\Dispatch\Immobilizer\Type 3	Program key,	24
CITROEN\Select from vehicle\Evasion\Immobilizer\Type 3	Program key,	24
CITROEN\Select from vehicle\Jumpy\Immobilizer\Type 3	Program key,	24
CITROEN\Select from vehicle\Nemo\Immobilizer\Type 2(CAN)	Program key,	24
CITROEN\Select from vehicle\Relay3\Immobilizer	Program key,	24
CITROEN\Select from vehicle\Synergie\Immobilizer\Type 3	Program key,	24
CITROEN\Select from vehicle\Xsara\Immobilizer\Type 3	Program key,	24
CITROEN\Select from vehicle\Xantia\Immobilizer\Type 3	Program key,	24

CITROEN\Select from vehicle\C3- XR\Immobilizer	Program key,	27
CITROEN\Select from vehicle\C6 (China)\2016- \Immobilizer	Program key,	27
CITROEN\Select from vehicle\Elysee\2012- \Immobilizer	Program key,	27
CITROEN\Select from vehicle\C4\Smart key	All smart key lost,	288
CITROEN\Select from vehicle\C6 (China)\2016- \Smart key	All smart key lost,	288
CITROEN\Select from vehicle\C- Crossover\Petrol\Smart	All smart key lost,	288
CITROEN\Select from type\Immobilizer\Type 4	Read key/remote count, Program immo key Program remote key	717
CITROEN\Select from vehicle\C- Crossover\Petrol\Immobilizer	Read key/remote count, Program immo key Program remote key	717
CITROEN\Select from vehicle\C- Crossover\Diesel\Immobilizer	Read key/remote count, Program immo key Program remote key	717
CITROEN\Select from vehicle\C4\Immobilizer\ Type 2	Program key,	27
CITROEN\Select from type\Replace engine ECU\M745	Replace engine ECU,	1137
PORSCHE\Cayenne\Cayenne 2010-\Smart key	Program smart key, Make dealer key,	19
PORSCHE\Macan\Macan\Smart key	Program smart key, Make dealer key,	19
PORSCHE\Macan\Macan S\Smart key	Program smart key, Make dealer key,	19
PORSCHE\Macan\Macan Turbo\Smart key	Program smart key, Make dealer key,	19
PORSCHE\Cayenne\Cayenne GTS 2010-\Smart key	Program smart key, Make dealer key,	19
PORSCHE\New 911\Carrera S\Smart key	Program smart key, Make dealer key,	19
PORSCHE\New 911\Carrera Targa 4\Smart key	Program smart key, Make dealer key,	19
PORSCHE\New 911\Turbo\Smart key	Program smart key, Make dealer key,	19
PORSCHE\New 718\Cayman\Smart key	Program smart key, Make dealer key,	19
PORSCHE\New 718\Boxster\Smart key	Program smart key, Make dealer key,	19

PORSCHE

PORSCHE\New 718\Boxster S\Smart key	Program smart key, Make dealer key,	19
PORSCHE\Panamera\Panamera\Smart key	Program smart key, Make dealer key,	19
PORSCHE\Panamera\Panamera 4\Smart key	Program smart key, Make dealer key,	19
PORSCHE\Panamera\Panamera S\Smart key	Program smart key, Make dealer key,	19
PORSCHE\Cayenne\2010\Immobilizer	Program key,	199
PORSCHE\Cayenne\2010\Read PIN code	Engine,	196
PORSCHE\Cayman\2005-2011\Immobilizer	Program key, Program key (without PIN),	853
PORSCHE\Boxter\2005-2011\Immobilizer	Program key, Program key (without PIN),	853
PORSCHE\997\2005-2010\Immobilizer	Program key, Program key (without PIN),	853
PORSCHE\911\2005-2010\Immobilizer	Program key, Program key (without PIN),	853
PEUGEOT>Select from vehicle\308\Immobilizer\Type 1	Program key,	24
PEUGEOT>Select from vehicle\3008\Immobilizer	Program key,	24
PEUGEOT>Select from vehicle\307\Immobilizer\Type 2 (CAN)	Program key,	24
PEUGEOT>Select from vehicle\308S\Immobilizer	Program key,	27
PEUGEOT\Read PIN code	Type 1, Type 2, Type 3, Type 4 (K line),	289
PEUGEOT>Select from vehicle\4007\Petrol\Smart key	All smart key lost,	288
PEUGEOT>Select from type\Immobilizer\Type 1	Program key,	287
PEUGEOT>Select from vehicle\207\Immobilizer\Type 1 (K)	Program key,	287
PEUGEOT>Select from vehicle\307\Immobilizer\Type 1 (K)	Program key,	287
PEUGEOT>Select from vehicle\508\Smart key	All smart key lost,	288
PEUGEOT>Select from vehicle\508\Immobilizer	Program key,	27

PEUGEOT

PEUGEOT\Select from vehicle\408\408(T73)\Immobilizer	Program key,	24
PEUGEOT\Select from vehicle\408\408(T93)\Immobilizer	Program key,	27
PEUGEOT\Select from type\Smart key\Type 1	All smart key lost,	288
PEUGEOT\Select from type\Immobilizer\Type 3	Program key,	27
PEUGEOT\Select from type\Immobilizer\Type 2	Program key,	24
PEUGEOT\Select from vehicle\1007\Immobilizer\Type 1(K)	Program key,	287
PEUGEOT\Select from vehicle\206\Immobilizer	Program key,	287
PEUGEOT\Select from vehicle\406(VF38)\Immobilizer	Program key,	287
PEUGEOT\Select from vehicle\607\Immobilizer\Type 1(K)	Program key,	287
PEUGEOT\Select from vehicle\807\Immobilizer\Type 1(K)	Program key,	287
PEUGEOT\Select from vehicle\Partner\Immobilizer\Type 1(K)	Program key,	287
PEUGEOT\Select from vehicle\1007\Immobilizer\Type 2(CAN)	Program key,	24
PEUGEOT\Select from vehicle\207\Immobilizer\Type 2(CAN)	Program key,	24
PEUGEOT\Select from vehicle\207CC\Immobilizer	Program key,	24
PEUGEOT\Select from vehicle\407\Immobilizer	Program key,	24
PEUGEOT\Select from vehicle\5008\Immobilizer	Program key,	24
PEUGEOT\Select from vehicle\607\Immobilizer\Type 2(CAN)	Program key,	24
PEUGEOT\Select from vehicle\807\Immobilizer\Type 2(CAN)	Program key,	24
PEUGEOT\Select from vehicle\Expert\2007-\Immobilizer	Program key,	24
PEUGEOT\Select from vehicle\Partner\Immobilizer\Type 2(CAN)	Program key,	24
PEUGEOT\Select from vehicle\Rcz\Immobilizer	Program key,	24

PEUGEOT>Select from vehicle\208\Immobilizer	Program key,	27
PEUGEOT>Select from vehicle\2008\Immobilizer	Program key,	27
PEUGEOT>Select from vehicle\301\Immobilizer	Program key,	27
PEUGEOT>Select from type\Immobilizer\Type 4	Read key/remote count,Program immo key,Program remote key	717
PEUGEOT>Select from vehicle\4007\Petrol\Immobilizer	Read key/remote count,Program immo key,Program remote key	717
PEUGEOT>Select from vehicle\4007\Diesel\Immobilizer	Read key/remote count,Program immo key,Program remote key	717
PEUGEOT>Select from vehicle\3008\Smart key	All smart key lost,	288
PEUGEOT>Select from vehicle\4008\Smart key	All smart key lost,	288
PEUGEOT>Select from vehicle\5008\Smart key	All smart key lost,	288
PEUGEOT>Select from vehicle\4008\Immobilizer\Type 1	Program key,	27
PEUGEOT>Select from vehicle\1007\Immobilizer\Type 3	Add key,Delete key,Reset Immo ECU,Program engine ECU	994
PEUGEOT>Select from vehicle\4008 (China)\Smart key	All smart key lost,	288
PEUGEOT>Select from vehicle\4008 (China)\Immobilizer	Program key,	27
PEUGEOT>Select from vehicle\308\Immobilizer\Type 2	Program key,	27
PEUGEOT>Select from type\Replace engine ECU\M745	Replace engine ECU,	1137
LINCOLN\MKC\Smart key\2017	Add smart key,All smart key lost,	812
LINCOLN\MKZ\Smart key\2013-2017	Add smart key,All smart key lost,	812
LINCOLN\Navigator\Immobilizer\2010-2014	Add key,All key lost,	277
LINCOLN\MKS\Smart key	Erase smart key,Add smart key,Read smart key count	278
LINCOLN\MKT\Smart key	Erase smart key,Add smart key,Read smart key count	278
LINCOLN\MKX\Smart key\2011-2015	Erase smart key,Add smart key,Read smart key count	278

LINCOLN

LINCOLN\Town Car\2005-2010\Immobilizer	Program key,	405
LINCOLN\MKX\Smart key\2016-2017	Add smart key, All smart key lost,	812
LINCOLN\Continental\Smart key\2017	Add smart key, All smart key lost,	812
LINCOLN\Navigator\Remote	Program remote, Delete remote,	991
LINCOLN\Aviator\2003-2005\Immobilizer	Program key, All key lost, Key count,	1314
LINCOLN\Blackwood\2002\Immobilizer	Program key, All key lost, Key count,	1315
LINCOLN\Continental\Immobilizer\1998-2002	Program key, All key lost, Key count,	1315
LINCOLN\LS\2000-2006\Immobilizer	Program key, All key lost, Key count,	1315
LINCOLN\Mark LT\2005-2007\Immobilizer	Program remote, All key lost, Key count,	1318
LINCOLN\Mark LT\2008-\Immobilizer	Program key, All key lost, Key count,	1319
LINCOLN\Mark VIII\1997-1998\Immobilizer	Delete key, Key count,	1326
LINCOLN\MKS\Immobilizer	Program key, All key lost, Key count,	1320
LINCOLN\MKX\Immobilizer\Petrol\2007-2010	Program key, All key lost, Key count,	1319
LINCOLN\MKX\Immobilizer\Petrol\2010-2012	Program key, All key lost, Key count,	1320
LINCOLN\MKX\Immobilizer\Hybrid	Program key, All key lost, Key count,	1320
LINCOLN\MKZ\Immobilizer\2007-2010	Program key, All key lost, Key count,	1319
LINCOLN\MKZ\Immobilizer\2010-2013	Program key, All key lost, Key count,	1320
LINCOLN\MKZ\Immobilizer\2013-	Add key, All key lost, Read key count,	83
LINCOLN\MKZ\Smart key\2011-	Erase smart key, Add smart key, Read smart key count,	278
LINCOLN\Navigator\Immobilizer\1997-1998	All key lost, Key count,	1316
LINCOLN\Navigator\Immobilizer\1999-2002	Program key, All key lost, Key count,	1315



	LINCOLN\Navigator\Immobilizer\2003-2004	Program key, All key lost, Key count,	1314
	LINCOLN\Navigator\Immobilizer\2005-2006	Program remote, All key lost, Key count,	1318
	LINCOLN\Navigator\Immobilizer\2007-2009	Program key, All key lost, Key count,	1319
	LINCOLN\Navigator\Smart key\2015	Erase smart key, Add smart key, Read smart key count,	278
	LINCOLN\Town Car\1998-2002\Immobilizer	Program key, All key lost, Key count,	1315
	LINCOLN\Town Car\2003-2004\Immobilizer	Program key, All key lost, Key count,	1314
	LINCOLN\Zephyr\2006\Immobilizer	Program key, All key lost, Key count,	1319
	LINCOLN\PCM IMMO\Immobilizer	All key lost, Read key count,	218
	LINCOLN\Navigator\Smart key\2018-2019	Add smart key, All smart key lost,	811
	LINCOLN\Nautilus\Smart key\2018-2019	Add smart key, All smart key lost,	811
	LINCOLN\MKC\Smart key\2017-	Add smart key, All smart key lost,	811
	LINCOLN\MKZ\Smart key\2017-	Add smart key, All smart key lost,	811
	LINCOLN\MKX\Smart key\2017-	Add smart key, All smart key lost,	811
	LINCOLN\Continental\Smart key\2017-	Add smart key, All smart key lost,	811
LAMBORGHINI	LAMBORGHINI\LP560\Remote	Program remote, Delete remote,	72
	LAMBORGHINI\LP570\Remote	Program remote, Delete remote,	72
	LAMBORGHINI\LP580\Key (smart key) programming	Backup immo data, Make dealer key, Learn key Clear airbag fault	48
	LAMBORGHINI\LP610\Key (smart key) programming	Backup immo data, Make dealer key, Learn key Clear airbag fault	48
	LAMBORGHINI\LP700\Key (smart key) programming	Backup immo data, Make dealer key, Learn key Clear airbag fault	48
LEXUS	LEXUS>Select from vehicle\ES240\Smart key	Add smart key, Delete smart key,	121
	LEXUS>Select from vehicle\CT200H\2012-\Smart key	Add smart key, Delete smart key,	121

LEXUS\Select from vehicle\ES250\2012-\Smart key	Add smart key, Delete smart key,	121
LEXUS\Select from vehicle\ES350\Smart key	Add smart key, Delete smart key,	121
LEXUS\Select from vehicle\RX270\Smart key	Add smart key, Delete smart key,	121
LEXUS\Select from vehicle\IS300\Smart key	Smart key registration, Delete smart key Reset	135
LEXUS\Select from vehicle\GS300\2006-2007\Smart key\Type 1	Smart key registration, Delete smart key Reset	135
LEXUS\Select from vehicle\ES200\Smart key	Add smart key, Delete smart key,	121
LEXUS\All smart key lost\All key lost	Backup EEPROM data, Generate SKE, Bind SKE Add smart	658
LEXUS\Select from vehicle\CT200H\2010\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
LEXUS\Select from vehicle\ES300\2002-2003\Mechanical key	Add master key, Add valet key, Delete key Clear fault code	85
LEXUS\Select from vehicle\ES300\2002-2003\Remote programming	Remote program method,	976
LEXUS\Select from vehicle\ES300H\2012-2015\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
LEXUS\Select from vehicle\ES330\2003-2006\Mechanical key	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
LEXUS\Select from vehicle\GS300\1998-2001\Remote	Program remote, Delete remote,	740
LEXUS\Select from vehicle\GS300\2002-2005\Mechanical	Add master key, Add valet key, Delete key Clear fault code	85
LEXUS\Select from vehicle\GS300\2002-2005\Mechanical	Program remote, Delete remote,	740
LEXUS\Select from vehicle\GS300\2006-2007\Smart key\Type 2	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
LEXUS\Select from vehicle\GS350\2006-2008\Smart key\Type 1	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
LEXUS\Select from vehicle\GS350\2006-2008\Smart key\Type 2	Smart key registration, Delete smart key Reset	135
LEXUS\Select from vehicle\GS350\2009-\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
LEXUS\Select from vehicle\GS430\2001-2005\Mechanical	Add master key, Add valet key, Delete key Clear fault code	85
LEXUS\Select from vehicle\GS430\2001-2005\Mechanical	Program remote, Delete remote,	740

LEXUS\Select from vehicle\GS430\2005-2006\Smart key	Smart key registration, Delete smart key, Reset	135
LEXUS\Select from vehicle\GS430\2006-2010\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
LEXUS\Select from vehicle\GS450H\2007-2011\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
LEXUS\Select from vehicle\GS450H\2008-2011\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
LEXUS\Select from vehicle\GS460\2008-2011\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
LEXUS\Select from vehicle\GX460\2003-2009\Mechanical key	Add key, Delete key, All key lost, Reset immo ECU, Program engine ECU	735
LEXUS\Select from vehicle\GX460\2010-2013\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
LEXUS\Select from vehicle\GX470\2003-2009\Mechanical key	Add key, Delete key, All key lost, Reset immo ECU, Program engine ECU	735
LEXUS\Select from vehicle\GX470\2003-2009\Remote	Program remote, Delete remote,	740
LEXUS\Select from vehicle\GX470\2003-2009\Remote programming	Remote program method,	978
LEXUS\Select from vehicle\HS250H\2008-2012\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
LEXUS\Select from vehicle\IS200\Mechanical key\Remote	Remote program method,	977
LEXUS\Select from vehicle\IS250\2006-2010\Smart key	Smart key registration, Delete smart key, Reset	135
LEXUS\Select from vehicle\IS250\2011\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
LEXUS\Select from vehicle\IS250\2012-2013\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
LEXUS\Select from vehicle\IS250\2014-\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
LEXUS\Select from vehicle\IS250C\2009-2015\Smart key (CAN)	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726
LEXUS\Select from vehicle\IS300\Mechanical key\2000-2005\IMMO	Add master key, Add valet key, Delete key, Clear fault code	85
LEXUS\Select from vehicle\IS300\Mechanical key\2000-2005\Remote	Program remote, Delete remote,	740
LEXUS\Select from vehicle\IS350\2006-2013\Smart key	Smart key registration, Delete smart key, Reset	135
LEXUS\Select from vehicle\IS250\2014-2015\Smart key	Add smart key, Delete smart key, Reset PEPS, Reset PEPS &	726

LEXUS

LEXUS\Select from vehicle\LS400\1998-2000\Mechanical	Program remote, Delete remote,	740
LEXUS\Select from vehicle\LS430\2001-2006\Type 1\Mechanical	Add master key, Add valet key, Delete key Clear fault code	85
LEXUS\Select from vehicle\LS430\2001-2006\Type 1\Mechanical	Program remote, Delete remote,	740
LEXUS\Select from vehicle\LS430\2001-2006\Type 1\Mechanical	Remote program method,	978
LEXUS\Select from vehicle\LS430\2001-2006\Type 2\Mechanical	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
LEXUS\Select from vehicle\LS430\2001-2006\Type 2\Mechanical	Program remote, Delete remote,	740
LEXUS\Select from vehicle\LS430\2001-2006\Type 2\Mechanical	Remote program method,	978
LEXUS\Select from vehicle\LS430\2001-2006\Type 2\Smart key	Smart key registration, Delete smart key Reset	135
LEXUS\Select from vehicle\LS460\2007-2012\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
LEXUS\Select from vehicle\LS460\2013-\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
LEXUS\Select from vehicle\LS460H\2007-2008\Mechanical	Remote program method,	976
LEXUS\Select from vehicle\LS460H\2007-2008\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
LEXUS\Select from vehicle\LS460H\2008-\Mechanical key\Remote	Remote program method,	976
LEXUS\Select from vehicle\LX470\2001-2002\Mechanical key	Add master key, Add valet key, Delete key Clear fault code	85
LEXUS\Select from vehicle\LX470\2003-2007\Mechanical	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
LEXUS\Select from vehicle\LX470\2003-2007\Mechanical	Program remote, Delete remote,	740
LEXUS\Select from vehicle\LX470\2003-2007\Mechanical	Remote program method,	976
LEXUS\Select from vehicle\LX570\2008-2010\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
LEXUS\Select from vehicle\RX300\1999-2003\Mechanical	Program remote, Delete remote,	740
LEXUS\Select from vehicle\RX300\2003-2005\Mechanical	Add key, Delete key, All key lost, Reset immo ECU Program engine ECU	735
LEXUS\Select from vehicle\RX300\2003-2005\Mechanical	Program remote, Delete remote,	740

LEXUS\Select from vehicle\RX300\2003-2005\Mechanical	Remote program method,	976
LEXUS\Select from vehicle\RX330\2004-2006\Mechanical	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
LEXUS\Select from vehicle\RX330\2004-2006\Mechanical	Program remote,Delete remote,	740
LEXUS\Select from vehicle\RX330\2004-2006\Mechanical	Remote program method,	976
LEXUS\Select from vehicle\RX350\2007-2009\Mechanical	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
LEXUS\Select from vehicle\RX350\2007-2009\Mechanical	Program remote,Delete remote,	740
LEXUS\Select from vehicle\RX350\2007-2009\Mechanical	Remote program method,	976
LEXUS\Select from vehicle\RX350\2010-2013\Smart key	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
LEXUS\Select from vehicle\RX400H\2005-2009\Mechanical	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
LEXUS\Select from vehicle\RX400H\2005-2009\Mechanical	Program remote,Delete remote,	740
LEXUS\Select from vehicle\RX400H\2005-2009\Mechanical	Remote program method,	976
LEXUS\Select from vehicle\RX450H\2010-2011\Smart key	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
LEXUS\Select from vehicle\RX450H\2012\Smart key	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
LEXUS\Select from vehicle\SC430\2002-2010\Mechanical	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
LEXUS\Select from vehicle\SC430\2002-2010\Mechanical	Program remote,Delete remote,	740
LEXUS\Select from vehicle\SC430\2002-2010\Mechanical	Remote program method,	976
LEXUS\Select from type\IMMO\Type 1	Add master key,Add valet key,Delete key Clear fault code	85
LEXUS\Select from type\IMMO\Type 2	Add key,Delete key,All key lost,Reset immo ECU Program engine ECU	735
LEXUS\Select from type\Remote	Program remote,Delete remote,	740
LEXUS\Select from type\PEPS\Type 1	Add smart key,Delete smart key,Reset PEPS Reset PEPS &	726
LEXUS\Select from type\PEPS\Type 2	Smart key registration,Delete smart key Reset	135

	LEXUS\Select from vehicle\IS250C\2009-2015\Smart key(KWP)	Add smart key, Delete smart key, Reset smart key	743
	LEXUS\Select from vehicle\RX300\1999-2003\Mechanical	Add master key, Add valet key, Delete key Clear fault code	85
	LEXUS\Select from vehicle\RX300\2016-\Smart key	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
	LEXUS\Select from type\PEPS\Type 3	Add smart key, Delete smart key, Reset PEPS Reset PEPS &	726
DS	DS\Select from vehicle\DS4\Smart key	All smart key lost,	288
	DS\Read PIN code	Type 1, Type 2, Type 3, Type 4 (K line),	289
	DS\Select from type\Immobilizer\Type 1	Program key,	287
	DS\Select from type\Smart key\Type 1	All smart key lost,	288
	DS\Select from type\Immobilizer\Type 3	Program key,	27
	DS\Select from type\Immobilizer\Type 2	Program key,	24
	DS\Select from vehicle\DS5\Immobilizer\Type 2	Program key,	287
	DS\Select from vehicle\DS5\Immobilizer\Type 3	Program key,	24
	DS\Select from vehicle\DS3\Immobilizer	Program key,	27
	DS\Select from vehicle\DS4\Immobilizer	Program key,	27
	DS\Select from vehicle\DS5\Immobilizer\Type 1	Program key,	27
	DS\Select from vehicle\DS6\Immobilizer	Program key,	27
	DS\Select from vehicle\DS5\Smart key	All smart key lost,	288
	DS\Select from vehicle\DS6\Smart key	All smart key lost,	288
	DS\Select from type\Immobilizer\Type 4	Read key/remote count, Program immo key Program remote key	717
	DS\Select from type\Replace engine ECU\M745	Replace engine ECU,	1137
DENTLE EV	BENTLEY\Flying Spur\2012 \Immobilizer	Learn key, Read PIN code,	225

DEWILLE	BENTLEY\Mulsanne\6.8 liter\Immobilizer\Smart key	Backup immo data, Make dealer key, Learn key Clear airbag fault	48
FERRARI	FERRARI\458\Immobilizer	Program key, Backup immo data, Program remote Make dealer key	9
	FERRARI\F12\Immobilizer	Program key, Backup immo data, Program remote Make dealer key	9
	FERRARI\F149\Immobilizer	Program key, Backup immo data, Program remote Make dealer key	9
LUXGEN	LUXGEN\Select from vehicle\Big 7 SUV\Smart key	Program smart key, PIN initialization, Program ICU Program ECM Detect	249
	LUXGEN\Select from vehicle\5 SEDAN\Smart key	Program smart key, PIN initialization, Program ICU Program ECM Detect	249
	LUXGEN\Select from vehicle\Big 7 MPV\Smart key	Program smart key, PIN initialization, Program ICU Program ECM Detect	249
	LUXGEN\Select from vehicle\MASTER CEO\Smart key	Program smart key, PIN initialization, Program ICU Program ECM Detect	249
	LUXGEN\Select from vehicle\U6 SUV\Smart key	Program smart key, PIN initialization, Program ICU Program ECM Detect	249
	LUXGEN\Select from vehicle\Big 7 MPV(new)\Smart key	Program smart key, PIN initialization, Program ICU Program ECM Detect	249
	LUXGEN\Select from vehicle\Big 7 SUV(new)\Smart key	Program smart key, PIN initialization, Program ICU Program ECM Detect	249
	LUXGEN\Select from vehicle\5 SEDAN(new)\Smart key	Program smart key, PIN initialization, Program ICU Program ECM Detect	249
BAIC	BAIC\Immobilizer\D50	Detect key count, Add key, Delete key,	301
	BAIC\Immobilizer\X25	Program key, Delete key,	302
	BAIC\Immobilizer\X35	Program key, Delete key,	302
	BAIC\Immobilizer\X55	Program key, Delete key,	302
	BAIC\Immobilizer\X65	Program key, Delete key,	302
	BAIC\Immobilizer\E series	Program key, Delete key, Check key status Check immo lock	303
	BAIC\Immobilizer\D20	Program key, Delete key, Check key status Check immo lock	303
	BAIC\Immobilizer\BJ40	Program key,	304
	BAIC\Immobilizer\BJ80	Program key,	304

BAIC

BAIC\Immobilizer\S3	Program key, Delete key, Reset PIN code Reset immo(all key	305
BAIC\Smart key\BJ80	Program smart key,	306
BAIC\Smart key\CC (C60F)	Program smart key,	306
BAIC\Smart key\D280	Program smart key,	306
BAIC\Smart key\D50 (C50E)	Program smart key,	306
BAIC\Smart key\D60	Program smart key,	306
BAIC\Smart key\D61	Program smart key,	306
BAIC\Smart key\D70 (C70G)	Program smart key,	306
BAIC\Smart key\D80 (C80G)	Program smart key,	306
BAIC\Smart key\X55	Program smart key,	306
BAIC\Smart key\X65	Program smart key,	306
BAIC\Immobilizer\S50	Program key, Delete key,	302
BAIC\Immobilizer\S3L	Program key, Delete key, Reset PIN code Reset immo(all key	305
BAIC\Immobilizer\S2	Program key, Delete key, Reset PIN code Reset immo(all key	305
BAIC\Immobilizer\H2	Program key, Delete key, Reset PIN code Reset immo(all key	305
BAIC\Immobilizer\H6	Program key, Delete key, Reset PIN code Reset immo(all key	305
BAIC\Smart key\BJ40	Program smart key,	306
BAIC\Smart key\H3	Program smart key, Program ESCL,	662
BAIC\Smart key\H3F	Program smart key, Program ESCL,	662
BAIC\Smart key\S3L	Program smart key,	663
BAIC\Smart key\S6	Program smart key,	664



BAIC\Smart key\H2	Program smart key,	665
BAIC\Remote\BJ40L	Program remote,	666
BAIC\Remote\S6	Program remote,	667
BAIC\Immobilizer\BJ40L\ Type 1	Read key count, Program key, Delete key,	668
BAIC\Immobilizer\EX200	Program key, Delete key,	669
BAIC\Immobilizer\EX260	Program key, Delete key,	669
BAIC\Immobilizer\EU220	Add key, Delete key,	670
BAIC\Immobilizer\EU260	Add key, Delete key,	670
BAIC\Immobilizer\EV150	Program key, Delete key,	671
BAIC\Immobilizer\EV150	Program key, Delete key,	671
BAIC\Immobilizer\EV160	Program key, Delete key,	671
BAIC\Immobilizer\EV200	Program key, Delete key,	671
BAIC\Smart key\S50	Program smart key,	306
BAIC\Smart key\S5	Program smart key, Program ESCL,	662
BAIC\Smart key\D230	Program smart key,	306
BAIC\Immobilizer\BJ20	Program key,	304
BAIC\Smart key\BJ20	Program smart key,	306
BAOJUN\BAOJUN\Immobiliz er\560	Check key count, Program key, Delete key, Reset engine ECM Program	312
BAOJUN\BAOJUN\Immobiliz er\330	Check key count, Program key, Delete key,	311
BAOJUN\BAOJUN\Smart key\560	Add key, All key lost, Key count,	309
BAOJUN\BAOJUN\Immobiliz er\310	Check key count, Program key, Delete key, Reset engine ECM Program	308

BAOJUN	BAOJUN\BAOJUN\Immobilizer\730	Check key count, Program key, Delete key, Reset engine ECM Program	308
	BAOJUN\BAOJUN\Immobilizer\630	Read key count, Program key, Delete key, Program remote	417
	BAOJUN\BAOJUN\Immobilizer\610	Read key count, Program key, Delete key, Program remote	417
	BAOJUN\BAOJUN\Immobilizer\510	Check key count, Program key, Delete key, Reset engine ECM Program	308
	BAOJUN\BAOJUN\Smart key\730	Add key, All key lost, Key count,	309
	BAOJUN\BAOJUN\Smart key\510	Add key, All key lost,	684
	BAOJUN\BAOJUN\Smart key\310 Wagon	Add key, All key lost,	684
	BAOJUN\BAOJUN\Immobilizer\530	Check key count, Program key, Delete key, Reset engine ECM Program	312
YEMA AUTO	YEMA AUTO\T70\IMMO	Add key, Delete key, Replace ECM, Replace IMMO Replace IMMO &	317
	YEMA AUTO\T70\PEPS	Program smart key, Program EMS (Delphi) Program	708
	YEMA AUTO\T70\BCM	Program remote, Read remote count,	707
QOROS	QOROS\Smart key	Program 1 smart key, Program 2 smart keys	323
	BYD\Smart key\Surui	Read key data, Clear & program working key Program smart	368
	BYD\Smart key\Sirui	Read key data, Clear & program working key Program smart	368
	BYD\Smart key\Qin	Read key data, Clear & program working key Program smart	368
	BYD\Smart key\Tang	Read key data, Clear & program working key Program smart	368
	BYD\Smart key\S7	Read key data, Clear & program working key Program smart	368
	BYD\Smart key\G5	Read key data, Clear & program working key Program smart	368
	BYD\Smart key\G6	Read key data, Clear & program working key Program smart	368
	BYD\Smart key\L3	Read key data, Clear & program working key Program smart	368
	BYD\Smart key\F3	Read key data, Clear & program working key Program smart	368

BYD

BYD\Smart key\S6	Read key data,Clear & program working key Program smart	368
BYD\Smart key\VA	Read key data,Clear & program working key Program smart	368
BYD\Smart key\E6A	Read key data,Clear & program working key Program smart	368
BYD\Smart key\E6B	Read key data,Clear & program working key Program smart	368
BYD\Smart key\E6Y	Read key data,Clear & program working key Program smart	368
BYD\Smart key\F0	Read key data,Clear & program working key Program smart	368
BYD\Smart key\G3	Read key data,Clear & program working key Program smart	368
BYD\Smart key\M6	Read key data,Clear & program working key Program smart	368
BYD\Smart key\F3R	Read key data,Clear & program working key Program smart	368
BYD\Smart key\Song	Read key data,Clear & program working key Program smart	368
BYD\Smart key\Qin EV	Read key data,Clear & program working key Program smart	368
BYD\Smart key\New F3	Read key data,Clear & program working key Program smart	368
BYD\Smart key\Yuan	Read key data,Clear & program working key Program smart	368
BYD\Smart key\E5	Read key data,Clear & program working key Program smart	368
BYD\Smart key\F3CK	Read key data,Clear & program working key Program smart	368
BYD\Smart key\F6	Read key data,Clear & program working key Program smart	368
BYD\Smart key\G3R	Read key data,Clear & program working key Program smart	368
BYD\Smart key\K9A	Read key data,Clear & program working key Program smart	368
BYD\Smart key\K9B	Read key data,Clear & program working key Program smart	368
BYD\Smart key\S8	Read key data,Clear & program working key Program smart	368
JAC\IMMO\Refine S3\Delphi IMMO	Clear fault code,Reset PIN code,Program key Delete key Reset	340

JAC\IMMO\Benjoy\Delphi IMMO	Clear fault code, Reset PIN code, Program key Delete key Reset	340
JAC\IMMO\Tongyue\Delphi IMMO	Clear fault code, Reset PIN code, Program key Delete key Reset	340
JAC\IMMO\Heyue RS\Delphi IMMO	Clear fault code, Reset PIN code, Program key Delete key Reset	340
JAC\IMMO\Heyue sedan\Delphi IMMO	Clear fault code, Reset PIN code, Program key Delete key Reset	340
JAC\IMMO\Yueyue\Delphi IMMO	Clear fault code, Reset PIN code, Program key Delete key Reset	340
JAC\IMMO\Sunray\Delphi IMMO	Clear fault code, Reset PIN code, Program key Delete key Reset	340
JAC\IMMO\Refine S3\UAES IMMO	Clear fault code, Read key count, Add key Detect key Program	341
JAC\IMMO\Tongyue\UAES IMMO	Clear fault code, Read key count, Add key Detect key Program	341
JAC\IMMO\Heyue RS\UAES IMMO	Clear fault code, Read key count, Add key Detect key Program	341
JAC\IMMO\Heyue sedan\UAES IMMO	Clear fault code, Read key count, Add key Detect key Program	341
JAC\IMMO\Yueyue\UAES IMMO	Clear fault code, Read key count, Add key Detect key Program	341
JAC\IMMO\Heyue A30\MT\UAES IMMO	Clear fault code, Read key count, Add key Detect key Program	341
JAC\IMMO\Sunray\UAES IMMO	Clear fault code, Read key count, Add key Detect key Program	341
JAC\IMMO\Refine S5\IMMO	Read key count, Add old key, Add new key, Delete key Reset immo	342
JAC\IMMO\Heyue A30\CVT\Smart PEPS	Read key count, ESCL learning, Add key Program engine ECU	343
JAC\Remote\16 PIN\RS\Type 1	Program remote,	344
JAC\Remote\16 PIN\Tongyue	Program remote,	344
JAC\Remote\16 PIN\Benjoy	Program remote,	344
JAC\Remote\16 PIN\Sunray	Program remote,	344
JAC\Remote\16 PIN\Three-ring remote	Program remote,	345
JAC\Remote\16 PIN\Refine M5	Program remote, Delete remote, Remote count,	346

JAC

JAC\Remote\16 PIN\Refine S2	Program remote, Delete remote, Remote count,	346
JAC\Remote\16 PIN\Refine S3	Program remote, Delete remote, Remote count,	346
JAC\Remote\16 PIN\Refine S5	Program remote, Delete remote, Remote count,	346
JAC\Remote\16 PIN\Refine M5	Program remote, Delete remote, Remote count,	346
JAC\Remote\16 PIN\RS A30 (CVT)	Program remote, Delete remote, Remote count,	347
JAC\IMMO\Refine S5\PEPS	Program ESCL, Add old key, Add new key, Delete key Reset immo	642
JAC\Remote\16 PIN\Refine M3	Program remote,	344
JAC\Remote\16 PIN\IEV5 (EV)	Program remote,	344
JAC\IMMO\Refine S2\Delphi IMMO	Clear fault code, Reset PIN code, Program key Delete key Reset	340
JAC\IMMO\Refine S2\UAES IMMO	Clear fault code, Read key count, Add key Detect key Program	341
JAC\IMMO\Heyue M3\UAES IMMO	Clear fault code, Read key count, Add key Detect key Program	341
JAC\IMMO\Heyue A30\CVT\UAES IMMO	Clear fault code, Read key count, Add key Detect key Program	341
JAC\Remote\10 PIN\Type 1	Program remote,	845
JAC\Remote\10 PIN\Type 2	Program remote,	846
JAC\IMMO\Refine S3\IMMO	Read key count, Add old key, Add new key, Delete key Reset immo	342
JAC\IMMO\Refine A60\PEPS	Program ESCL, Add old key, Add new key, Delete key Reset immo	642
JAC\IMMO\Refine S2\PEPS	Program ESCL, Add old key, Add new key, Delete key Reset immo	642
JAC\IMMO\Refine S2 mini\IMMO	Read key count, Add old key, Add new key, Delete key Reset immo	342
JAC\IMMO\Refine S3\PEPS	Program ESCL, Add old key, Add new key, Delete key Reset immo	642
JAC\IMMO\Refine S5\Delphi IMMO	Clear fault code, Reset PIN code, Program key Delete key Reset	340
JAC\IMMO\Refine S5\UAES IMMO	Clear fault code, Read key count, Add key Detect key Program	341

JAC\IMMO\Refine S7\IMMO	Read key count, Add old key, Add new key, Delete key, Reset immo	342
JAC\IMMO\Refine S7\PEPS	Program ESCL, Add old key, Add new key, Delete key, Reset immo	642
JAC\IMMO\Refine M4\IMMO	Read key count, Add old key, Add new key, Delete key, Reset immo	342
JAC\IMMO\Refine M5\PEPS	Program ESCL, Add old key, Add new key, Delete key, Reset immo	642
JAC\IMMO\Sunray\IMMO	Read key count, Add old key, Add new key, Delete key, Reset immo	342
JAC\Remote\16 PIN\Refine M4	Program remote, Delete remote, Remote count,	346
JAC\Remote\16 PIN\Refine S2 mini	Program remote, Delete remote, Remote count,	346
JAC\Remote\16 PIN\Refine S7	Program remote, Delete remote, Remote count,	346
JAC\Remote\16 PIN\6S EV	Program remote, Delete remote, Remote count,	346
JAC\Remote\16 PIN\RS\Type 2	Program remote,	1270
ZOTYE\A1\IMMO\Shanghai Industrial Traffic IMMO	Clear fault code, Reset PIN code, Program key, Reset	398
ZOTYE\Z100\IMMO\Shanghai Industrial Traffic IMMO	Clear fault code, Reset PIN code, Program key, Reset	398
ZOTYE\Z300\IMMO\Shanghai Industrial Traffic IMMO	Clear fault code, Reset PIN code, Program key, Reset	398
ZOTYE\Langyue\IMMO\Shanghai Industrial Traffic IMMO	Clear fault code, Reset PIN code, Program key, Reset	398
ZOTYE\Langjun\IMMO\Shanghai Industrial Traffic IMMO	Clear fault code, Reset PIN code, Program key, Reset	398
ZOTYE\Z300\IMMO\Lianchuan IMMO	Clear fault code, Read key count, Add key, Delete key, Detect	399
ZOTYE\Domy X5\Remote	Remote count, Program remote, Delete remote,	400
ZOTYE\SR7\Remote	Remote count, Program remote, Delete remote,	400
ZOTYE\T600\Remote	Remote count, Program remote, Delete remote,	400
ZOTYE\Z500\Remote	Remote count, Program remote, Delete remote,	400
ZOTYE\Z700\Remote	Remote count, Program remote, Delete remote,	400

ZOTYE

ZOTYE\Z100\Remote	Delete remote, Program remote,	401
ZOTYE\Langyue\Remote	Delete remote, Program remote,	401
ZOTYE\Langjun\Remote	Delete remote, Program remote,	401
ZOTYE\Domy X5\PEPS	Program full system, Program full system(w/o	402
ZOTYE\T600\PEPS\Naen (Magotan-type key)	Program full system, Program full system(w/o	402
ZOTYE\SR7\PEPS	Program full system, Program full system(w/o	402
ZOTYE\Z500\PEPS	Program full system, Program full system(w/o	402
ZOTYE\Z700\PEPS	Program full system, Program full system(w/o	402
ZOTYE\5008\PEPS	Program remote A, Program remote B Program smart key	403
ZOTYE\T200\PEPS	Program remote A, Program remote B Program smart key	403
ZOTYE\Langlang\PEPS	Program remote A, Program remote B Program smart key	403
ZOTYE\Z200\PEPS	Program remote A, Program remote B Program smart key	403
ZOTYE\T600\PEPS\Huofu (Huundai-type key)	Program new key, Program old key, Program PEPS Program	404
ZOTYE\Z300\Remote\Type 1	Program remote, Delete remote,	602
ZOTYE\Z300\Remote\Type 2	Remote count, Program remote, Delete remote,	400
ZOTYE\2008\PEPS	Program remote A, Program remote B Program smart key	403
ZOTYE\T600\IMMO	Program key, Delete key, Program immobiliser Program	689
ZOTYE\SR9\PEPS	Program full system, Program full system(w/o	402
ZOTYE\E30\Remote	Remote count, Program remote, Delete remote,	1090
ZOTYE\X7\Remote	Remote count, Program remote, Delete remote,	400
ZOTYE\X7\PEPS	Program full system, Program full system(w/o	402

ZOTYE\SR9\Remote	Remote count, Program remote, Delete remote,	400	
ZOTYE\T300\Atech BCM	Remote count, Program remote, Delete remote,	1090	
ZOTYE\T300\PEPS	Program full system, Program full system(w/o	402	
ZOTYE\T300\BCM	Remote count, Program remote, Delete remote,	902	
ZOTYE\T700\PEPS	Program whole system, Replace BCM Replace engine	903	
ZOTYE\E200\PEPS	Program smart key, Delete smart key Setup PSN Setup	905	
ZOTYE\Z360\IMMO\Shanghai Industrial Traffic IMMO	Clear fault code, Reset PIN code, Program key Reset	398	
ZOTYE\Z360\IMMO\Lianchuan IMMO	Clear fault code, Read key count, Add key Delete key Detect	399	
ZOTYE\Z360\Remote\Type 1	Program remote, Delete remote,	602	
ZOTYE\Z360\Remote\Type 2	Remote count, Program remote, Delete remote,	400	
ZOTYE\Z360\PEPS	Program full system, Program full system(w/o	402	
ZOTYE\Z560\Remote	Remote count, Program remote, Delete remote,	400	
ZOTYE\Z560\PEPS	Program full system, Program full system(w/o	402	
ZOTYE\Z300\PEPS	Program full system, Program full system(w/o	402	
ZOTYE\T500\Remote	Remote count, Program remote, Delete remote,	400	
ZOTYE\T500\PEPS	Program full system, Program full system(w/o	402	
FAW RED FLAG	FAW RED FLAG>Select from type\PEPS\Type 1	Smart key registration, Program remote Reset	411
	FAW RED FLAG>Select from vehicle\HQ300\Type 1	Smart key registration, Program remote Reset	411
	FAW RED FLAG>Select from type\PEPS\Type 2	Delete smart key, Add smart key,	412
	FAW RED FLAG>Select from vehicle\H7\Type 2	Delete smart key, Add smart key,	412
	FAW RED FLAG>Select from type\IMMO \VW IMMO	Program key,	413



	FAW RED FLAG\Select from vehicle\Ming Shi\VW IMMO	Program key,	413
JMC	JMC\S350\PEPS	Program key,	416
	JMC\S330\PEPS	Program key,	675
ZHENGZHOU MAZDA	ZHENGZHOU MAZDA\IMMO\Lianchuang IMMO	Write immo VIN code, Write engine VIN code Engine ECU	418
ISUZU	ISUZU\D-Max\Key\Type 1(46 chip)	Program key, Delete key, Clear fault code Reset IMMO Reset	415
	ISUZU\MU-7\Immobilizer\46 chip	Program key, Delete key, Clear fault code Reset IMMO Reset	415
	ISUZU\D-Max\Key\Type 2	Program access control and start system, Reset steering lock ECU Reset	444
	ISUZU\MU-X\Smart key\Type 1	Program access control and start system, Reset steering lock ECU Reset	444
	ISUZU\D-Max\Smart key\Type 1	Add smart key, Delete smart key,	825
	ISUZU\MU-X\Smart key\Type 2	Add smart key, Delete smart key,	825
	ISUZU\D-Max\Remote	Program remote, Delete remote,	826
	ISUZU\TF\IMMO 2008-2012	Add key, Delete key, Clear fault code,	896
	ISUZU\D-Max\Immobilizer\Type 3(48 chip)	Program key, Delete key, Read key data, Clear fault code	1087
	ISUZU\MU-7\Immobilizer\48 chip	Program key, Delete key, Read key data, Clear fault code	1087
	ISUZU\MU-X\Remote	Program remote, Delete remote,	826
	ISUZU\Rodeo\Immobilizer\46 chip	Program key, Delete key, Clear fault code Reset IMMO Reset	415
	ISUZU\Rodeo\Immobilizer\48 chip	Program key, Delete key, Read key data, Clear fault code	1087
	ISUZU\D-Max\Smart key\Type 2(2017-2019)	Program access control and start system, Reset steering lock ECU Reset	444
WULING MOTORS\S1\Immobilizer	WULING MOTORS\S1\Immobilizer	Check key count, Program key, Delete key, Reset engine ECM Program	308
	WULING MOTORS\S3\Immobilizer	Check key count, Program key, Delete key, Reset engine ECM Program	308
	WULING MOTORS\S3\Smart key	Query key count, Add key, All key lost,	1565

WULING MOTORS	WULING MOTORS\Journey\Smart key	Query key count, Add key, All key lost,	1565
	WULING MOTORS\Journey\Immobilizer	Check key count, Program key, Delete key, Reset engine ECM Program	308
	WULING MOTORS\Journey\Remote	Program remote,	1622
	WULING MOTORS\S1 (sports)\Immobilizer	Check key count, Program key, Delete key, Reset engine ECM Program	308
SOUEAST MOTORS	SOUEAST MOTORS\DX7\PEPS	Program key, Read pin code,	426
	SOUEAST MOTORS\DX3\PEPS	Read pin code, Program key,	673
	SOUEAST MOTORS\V6\PEPS	All key lost, Learning status, Clear PEPS, Clear EMS Delete	1128
	SOUEAST MOTORS\V3\Industrial traffic IMMO	Program immobiliser, Program engine Reset	1165
	SOUEAST MOTORS\GALANT\Mitsubishi-IMMO	Clear fault code, Read key count, Program key Reset immo ECU	1117
	SOUEAST MOTORS\SOVERAN\Mitsubishi-IMMO	Clear fault code, Read key count, Program key Reset immo ECU	1117
	SOUEAST MOTORS\DX3\Mechanical key\IMMO(CAN)	Program key, Read PIN code,	1133
	SOUEAST MOTORS\DX3\Mechanical key\Remote(CAN)	Program remote,	1134
TIANJIN FAW	TIANJIN FAW\IMMO\Vela (MT34 Delphi) key\Reset	Reset immobox (4C chip),	555
	TIANJIN FAW\IMMO\Xenia S80	Add key,	556
	TIANJIN FAW\IMMO\N5	Add key,	556
	TIANJIN FAW\IMMO\New N5	Add key,	556
	TIANJIN FAW\IMMO\N7	Add key,	556
	TIANJIN FAW\IMMO\D60	Add key,	556
	TIANJIN FAW\IMMO\Vizhi V5\ECU IMMO initialization	Type 1, Type 2, Type 3,	557
	TIANJIN FAW\PEPS\D60	Program ESCL, Program PEPS, Delete smart key Read key	558
	TIANJIN FAW\Remote\D60	Program remote, Read remote count, Delete remote	559

	TIANJIN FAW\IMMO\Vizhi V5\IMMO	Add key,	556
	TIANJIN FAW\IMMO\Vizhi (MT34 Delphi) key	Reset immobox(4C chip),	555
	TIANJIN FAW\IMMO\Vizhi V5\Replace ignition coil and program key	Replace immo coil to program key,	1036
	TIANJIN FAW\IMMO\Vela (MT34 Delphi) key\Sync engine	Sync engine and IMMO (CAN),	1122
	TIANJIN FAW\IMMO\Vizhi V2\Sync engine and immo (CAN)	Sync engine and IMMO (CAN),	1123
	TIANJIN FAW\IMMO\A70	All key lost,	548
FAW JIABAO	FAW JIABAO\V80/V80L/T80\Integrated IMMO	Program engine ECU, Program key, Delete key Immo ECU reset	443
	AEOLUS\S30\Lianchuang IMMO	Write immo VIN, Write engine VIN, Check engine ECU Read VIN code Reset	445
	AEOLUS\H30\Lianchuang IMMO	Write immo VIN, Write engine VIN, Check engine ECU Read VIN code Reset	445
	AEOLUS\H30 Cross\Lianchuang IMMO	Write immo VIN, Write engine VIN, Check engine ECU Read VIN code Reset	445
	AEOLUS\A60\A60-HR16, MR20\BCM	Activate steering wheel lock,	446
	AEOLUS\A60\A60-HR16, MR20\IMMO\Type 1	Add key, Activate steering wheel lock(all key lost)	447
	AEOLUS\A60\A60-HR16, MR20\IMMO\Type 2	Add key, Activate steering wheel lock(all key lost)	448
	AEOLUS\A60\A60-HR16, MR20\PEPS\Type 1	Program smart key,	449
	AEOLUS\A60\A60-HR16, MR20\PEPS\Type 2	Program smart key,	450
	AEOLUS\H30\IMMO	Key program status, Reprogram faulty parts Replace immo host	452
	AEOLUS\H30 Cross\IMMO	Key program status, Reprogram faulty parts Replace immo host	452
	AEOLUS\S30\IMMO	Key program status, Reprogram faulty parts Replace immo host	452
	AEOLUS\A30\IMMO	Key program status, Reprogram faulty parts Replace immo host	452
	AEOLUS\AX3\AX3 (DFM A15 MT22.1) [key start]\IMMO	Key program status, Reprogram faulty parts Replace immo host	452
AEOLUS	AEOLUS\AX3\AX3 (DFM A14T MT62.1) [key start]\IMMO	Key program status, Reprogram faulty parts Replace immo host	452

AEOLUS\A60\A60-A16\BCM	Program key,	453
AEOLUS\A60\A60-A14T\BCM	Program key,	453
AEOLUS\AX7\BCM	Program key,	453
AEOLUS\A60\A60-A16\PEPS	Program key,	454
AEOLUS\AX3\AX3 (DFM A14T MT62.1) [button start]\PEPS	Program key,	454
AEOLUS\AX7\PEPS	Program key,	454
AEOLUS\A30\BCM	Replace OBC & program remote, Program remote,	455
AEOLUS\L60\IMMO	Program key,	457
AEOLUS\AX3\AX3 (DFM A15 MT22.1) [key start]\BCM	Program remote key,	456
AEOLUS\AX3\AX3 (DFM A14T MT62.1) [key start]\BCM	Program remote key,	456
AEOLUS\MX5\BCM	Program key,	453
AEOLUS\EV\A60EV\BCM	Program key,	453
DONGFENG FENGXING\Joyear\B11\Lianchuang IMMO	Write immo VIN code, Write engine VIN code Engine ECU	1175
DONGFENG FENGXING\Joyear\B12\Lianchuang IMMO	Write immo VIN code, Write engine VIN code Engine ECU	1175
DONGFENG FENGXING\Joyear\BH5/BH5 LV/BH5A\Lianchuang IMMO	Write immo VIN code, Write engine VIN code Engine ECU	1175
DONGFENG FENGXING\Joyear\BX5/BX5 A\Lianchuang IMMO	Write immo VIN code, Write engine VIN code Engine ECU	1175
DONGFENG FENGXING\Joyear\BX3\Lianchuang IMMO	Write immo VIN code, Write engine VIN code Engine ECU	1175
DONGFENG FENGXING\Joyear\XV\Lianchuang IMMO	Write immo VIN code, Write engine VIN code Engine ECU	1175
DONGFENG FENGXING\Joyear\S50\Lianchuang IMMO	Write immo VIN code, Write engine VIN code Engine ECU	1175
DONGFENG FENGXING\Joyear\SX5/X5\Lianchuang IMMO	Write immo VIN code, Write engine VIN code Engine ECU	1175
DONGFENG FENGXING\Joyear\SX6\Lianchuang IMMO	Write immo VIN code, Write engine VIN code Engine ECU	1175

DONGFENG FENGXING

DONGFENG FENGXING\Lingzhi\CM7/CV 7/CM7A\Lianchuang IMMO	Write immo VIN code,Write engine VIN code Engine ECU	1175
DONGFENG FENGXING\Fengxing series\CM7\Lianchuang	Write immo VIN code,Write engine VIN code Engine ECU	1175
DONGFENG FENGXING\Fengxing series\S500\Lianchuang	Write immo VIN code,Write engine VIN code Engine ECU	1175
DONGFENG FENGXING\F600/L series\Lianchuang IMMO	Write immo VIN code,Write engine VIN code Engine ECU	1175
DONGFENG FENGXING\Joyear\BX5/BX5 A\PEPS	Program whole system,Program engine ECU Program key Clear	1177
DONGFENG FENGXING\Joyear\S50\PEP S	Program whole system,Program engine ECU Program key Clear	1177
DONGFENG FENGXING\Joyear\XV\PEPS	Program whole system,Program engine ECU Program key Clear	1177
DONGFENG FENGXING\Joyear\SX5/X5\ PEPS	Program whole system,Program engine ECU Program key Clear	1177
DONGFENG FENGXING\Joyear\SX6\PEP S	Program whole system,Program engine ECU Program key Clear	1177
DONGFENG FENGXING\Lingzhi\CM7/CV 7/CM7A\PEPS	Program whole system,Program engine ECU Program key Clear	1177
DONGFENG FENGXING\Fengxing series\CM7\PEPS	Program whole system,Program engine ECU Program key Clear	1177
DONGFENG FENGXING\Fengxing series\S500\PEPS	Program whole system,Program engine ECU Program key Clear	1177
DONGFENG FENGXING\F600/L series\PEPS	Program whole system,Program engine ECU Program key Clear	1177
DONGFENG FENGXING\Joyear\BX5/BX5 A\BCM IMMO	Key count, Program key, Delete key, Program whole system Replace	461
DONGFENG FENGXING\Joyear\S50\BCM IMMO	Key count, Program key, Delete key, Program whole system Replace	461
DONGFENG FENGXING\Joyear\XV\BCM IMMO	Key count, Program key, Delete key, Program whole system Replace	461
DONGFENG FENGXING\Joyear\SX5/X5\ BCM IMMO	Key count, Program key, Delete key, Program whole system Replace	461
DONGFENG FENGXING\Joyear\SX6\BCM IMMO	Key count, Program key, Delete key, Program whole system Replace	461
DONGFENG FENGXING\Fengxing series\CM7\BCM IMMO	Key count, Program key, Delete key, Program whole system Replace	461
DONGFENG FENGXING\Fengxing series\S500\BCM IMMO	Key count, Program key, Delete key, Program whole system Replace	461
DONGFENG FENGXING\F600/L series\BCM IMMO	Key count, Program key, Delete key, Program whole system Replace	461

DONGFENG FENGXING\Joyear\BX5/BX5 A\IAES_BCM	Delete remote, Program remote,	1176
DONGFENG FENGXING\Joyear\S50\UAE S_BCM	Delete remote, Program remote,	1176
DONGFENG FENGXING\Joyear\XV\UAE BCM	Delete remote, Program remote,	1176
DONGFENG FENGXING\Joyear\SX5/X5\ IAES_BCM	Delete remote, Program remote,	1176
DONGFENG FENGXING\Joyear\SX6\UAE S_BCM	Delete remote, Program remote,	1176
DONGFENG FENGXING\Fengxing series\CM7\IAES_BCM	Delete remote, Program remote,	1176
DONGFENG FENGXING\Fengxing series\S500\IAES_BCM	Delete remote, Program remote,	1176
DONGFENG FENGXING\F600/L series\IAES_BCM	Delete remote, Program remote,	1176
DONGFENG FENGXING\Joyear\B11\1.8 T Lianchuang IMMO(K4)	Write immo VIN code, Write engine VIN code Engine ECU	635
DONGFENG FENGXING\Joyear\B12\1.8 T Lianchuang IMMO(K4)	Write immo VIN code, Write engine VIN code Engine ECU	635