

**MITSUBISHI**

China

Select from vehicle

V73

- Fault codes
- Erase DTC
- Live data
- Program keys
- Reset immobiliser

V97

- Fault codes
- Erase DTC
- Live data
- Program keys
- Reset immobiliser

Galant

- Fault codes
- Erase DTC
- Live data
- Program keys
- Reset immobiliser

Grandis

- Fault codes
- Erase DTC
- Live data
- Program keys
- Reset immobiliser

Lancer

With smart

- ECU identification
- Live data
- Change security code
- All smart keys lost
- Program engine key code
- Program engine key code&VIN write

Without smart

- ECU identification
- Live data
- Change security code
- All keys lost
- Program remotes
- Program engine key code
- Program engine key code&VIN write

Outlander

-2013

- ECU identification
- Live data
- Change security code
- All smart keys lost
- Program engine key code
- Program engine key code&VIN write

2014-

- Program smart keys

ASX

With smart

- Program smart keys

Without smart

- Program keys

- Add remote

L200 TRITON

-2010

Type 1

- Program keys

- Program remotes

Type 2

- Change security code

- All keys lost

- Program remote

- Program engine key code&VIN write

Type 3

- All keys lost

- Add remote

2011-

Type 1

- Program keys

- Program remotes

Type 2

- Change security code

- All keys lost

- Program remote

- Program engine key code&VIN write

Type 3

- All keys lost

- Add remote

Pajero

-2010

- Fault codes

- Erase DTC

**2016.05.15**

---

- Live data
- Program keys
- Reset immobiliser
- 2010-
  - Program keys
  - Program remotes
- Pajero V93
  - 2011-
    - Fault codes
    - Erase DTC
    - Live data
    - Program keys
    - Reset immobiliser
- Select from type
  - Type 1
    - Fault codes
    - Erase DTC
    - Live data
    - Program keys
    - Reset immobiliser
  - Type 2(CAN With smart)
    - ECU identification
    - Live data
    - Change security code
    - All smart keys lost
    - Program engine key code
    - Program engine key code&VIN write
  - Type 3(CAN Without smart)
    - ECU identification
    - Live data
    - Change security code
    - All keys lost
    - Program remotes
    - Program engine key code
    - Program engine key code&VIN write
  - Type 4(CAN With smart)
    - Program smart keys
  - Type 5(CAN Without smart)
    - Program keys
    - Program remotes
  - Type 6(CAN Without smart)
    - Change security code
    - All keys lost
    - Program remote

Program engine key code&VIN write

Type 7(CAN Without smart)

Program keys

Add remote

Japan

Carisma

96-04

Fault codes

Erase DTC

Live data

Program keys

Reset immobiliser

Colt

96-00

Fault codes

Erase DTC

Live data

Program keys

Reset immobiliser

Eclipse

96-03

Fault codes

Erase DTC

Live data

Program keys

Reset immobiliser

Galant[PIN1]

96-03

Fault codes

Erase DTC

Live data

Program keys

Reset immobiliser

Galant[PIN2]

96-03

Fault codes

Erase DTC

Live data

Program keys

Reset immobiliser

Lancer

96-03

Fault codes

Erase DTC

---

Live data  
Program keys  
Reset immobiliser

03-06  
Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Lancer SW  
96-03  
Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

L200  
99-06  
Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Montero  
99-00  
Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

01-06  
Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Montero IO  
99-  
Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Montero Sport

99-04

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Nativa

01-02

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Pajero

96-00

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

00-05

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Pajero IO

99-

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Pajero PININ

99-

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Pajero Sport

99-03

Fault codes  
Erase DTC

---

Live data  
Program keys  
Reset immobiliser

Shogun

96-00

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

00-05

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Shogun PININ

99-

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Shogun Sport

99-03

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Space Gear

96-

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Space Runner

98-99

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

99-02

- Fault codes
- Erase DTC
- Live data
- Program keys
- Reset immobiliser

Space Start[PIN1]

99-

- Fault codes
- Erase DTC
- Live data
- Program keys
- Reset immobiliser

Space Start[PIN2]

99-

- Fault codes
- Erase DTC
- Live data
- Program keys
- Reset immobiliser

Space Wagon

98-99

- Fault codes
- Erase DTC
- Live data
- Program keys
- Reset immobiliser

99-02

- Fault codes
- Erase DTC
- Live data
- Program keys
- Reset immobiliser

3000 GT

96-01

- Fault codes
- Erase DTC
- Live data
- Program keys
- Reset immobiliser

Australia

Challenger

99-03

- Fault codes



---

Erase DTC  
Live data  
Program keys  
Reset immobiliser

Express

96-

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Lancer

96-03

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

03-06

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Lancer SW

96-03

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Magna

96-05

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Mirage

96-02

Fault codes  
Erase DTC  
Live data  
Program keys

Reset immobiliser

Nimbus

98-99

Fault codes

Erase DTC

Live data

Program keys

Reset immobiliser

99-02

Fault codes

Erase DTC

Live data

Program keys

Reset immobiliser

Pajero

96-00

Fault codes

Erase DTC

Live data

Program keys

Reset immobiliser

00-05

Fault codes

Erase DTC

Live data

Program keys

Reset immobiliser

Pajero IO

99-

Fault codes

Erase DTC

Live data

Program keys

Reset immobiliser

Triton[PIN1]

99-

Fault codes

Erase DTC

Live data

Program keys

Reset immobiliser

Triton[PIN2]

99-

Fault codes

Erase DTC  
Live data  
Program keys  
Reset immobiliser

Verada

96-02  
Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Greek

Carisma

96-04  
Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Colt

96-00  
Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Colt New

02-  
Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Galant

96-03  
Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Lancer

96-03  
Fault codes  
Erase DTC

---

Live data  
Program keys  
Reset immobiliser

Lancer SW

96-03

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

L200

99-06

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Pajero

96-00

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Pajero New

00-03

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Pajero PININ

99-

Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser

Pajero Sport

99-03

Fault codes  
Erase DTC  
Live data  
Program keys

---

Reset immobiliser

Space Gear

96-

Fault codes

Erase DTC

Live data

Program keys

Reset immobiliser

Space Runner

98-99

Fault codes

Erase DTC

Live data

Program keys

Reset immobiliser

99-02

Fault codes

Erase DTC

Live data

Program keys

Reset immobiliser

Space Start

99-

Fault codes

Erase DTC

Live data

Program keys

Reset immobiliser

3000 GT

96-

Fault codes

Erase DTC

Live data

Program keys

Reset immobiliser

USA

Diamante

00-06

Fault codes

Erase DTC

Live data

Program keys

Reset immobiliser

Eclipse

96-05  
    Fault codes  
    Erase DTC  
    Live data  
    Program keys  
    Reset immobiliser  
Eclipse[CAN]  
    06-09  
        All keys lost  
        Key N0  
Endeavor[CAN]  
    06-09  
        All keys lost  
        Key N0  
Galant  
    04-05  
        Fault codes  
        Erase DTC  
        Live data  
        Program keys  
        Reset immobiliser  
Galant[CAN]  
    06-09  
        All keys lost  
        Key N0  
Galant[PIN1]  
    96-00  
        Fault codes  
        Erase DTC  
        Live data  
        Program keys  
        Reset immobiliser  
    00-03  
        Fault codes  
        Erase DTC  
        Live data  
        Program keys  
        Reset immobiliser  
Galant[PIN2]  
    96-00  
        Fault codes  
        Erase DTC  
        Live data  
        Program keys

---

Reset immobiliser  
00-03  
Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser  
Lancer  
96-03  
Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser  
Lancer EVO  
03-06  
Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser  
Lancer SW  
96-03  
Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser  
Lancer[CAN]  
08-09  
All keys lost  
Key N0  
Montero  
99-00  
Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser  
01-06  
Fault codes  
Erase DTC  
Live data  
Program keys

---

Reset immobiliser  
Montero Sport  
99-04  
Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser  
Outlander  
00-03  
Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser  
04-06  
Fault codes  
Erase DTC  
Live data  
Program keys  
Reset immobiliser  
Outlander[CAN]  
07-09  
All keys lost  
Key N0