



深圳市朗仁科技有限公司
Shenzhen Xtooltech Co., Ltd

NISSAN Function List V27.07

System	Options 1	Options 2	Options 3	Options 4	Options 5	Functions
Pin Calculator	Type 1(4 pincode)	-	-	-	-	
Pin Calculator	Type 2(4 pincode)	-	-	-	-	Made in Mexico Made in Germany Made in Europe
Pin Calculator	Type 3(20 pincode)	-	-	-	-	
Pin Calculator	Help	-	-	-	-	
Read bcm code and Release steering lock(4 pincode)	-	-	-	-	-	Read BCM code Release steering lock
Program keys	Select from type	Immobiliser system	4 pincode	Type 1 (KWP)	-	Fault codes Erase DTC Program keys
Program keys	Select from type	Immobiliser system	4 pincode	Type 2 (CAN)	-	Erase DTC Program keys Release steering lock
Program keys	Select from type	Immobiliser system	12 pincode	Type 1 (KWP)	-	Number of keys Program keys
Program keys	Select from type	Immobiliser system	12 pincode	Type 2 (CAN)	-	Read number of keys Program keys
Program keys	Select from type	Immobiliser system	20 pincode	Type_1	-	Program key
Program keys	Select from type	Immobiliser system	20 pincode	Type_2	-	Program key
Program keys	Select from type	Smart key system	4 pincode	Type 1 (With slot and Push-button)	-	Fault codes Erase DTC Program keys
Program keys	Select from type	Smart key system	4 pincode	Type 2 (With slot and Push-button)	-	Erase DTC Program keys Release steering lock
Program keys	Select from type	Smart key system	4 pincode	Type 3 (Without slot and knob)	-	Program smart keys Erase all smart keys Program steering lock
Program keys	Select from type	Smart key system	4 pincode	Type 4 (Without slot and knob)	-	Program smart keys Erase all smart keys
Program keys	Select from type	Smart key system	4 pincode	Type 5 (Without slot and Push-button)	-	Read BCM code Release steering lock Program smart keys
Program keys	Select from type	Smart key system	4 pincode	Type 6 (07-11 Altima Hybrid)	-	Release steering lock Program smart keys
Program keys	Select from type	Smart key system	12 pincode	-	-	Read number of keys Program keys Program remote Erase remotes
Program keys	Select from type	Smart key system	20 pincode	Type 1	-	Program smart keys Replace engine ECU
Program keys	Select from type	Smart key system	20 pincode	Type 2	-	Program smart keys
Program keys	Select from type	Smart key system	20 pincode	Typr_3	-	Program key
Program keys	Select from vehicle	China	Teana	-12	Body System (BCM)	Read BCM code Release steering lock
Program keys	Select from vehicle	China	Teana	-12	Smart key system (KWP)	Erase DTC Program keys Release steering lock

Program keys	Select from vehicle	China	Teana	-12	Smart key system(CAN)	-	Fault codes Erase DTC Program keys
Program keys	Select from vehicle	China	Teana	13-18(20 pin code)	Smart key system	-	Program smart keys Replace engine ECU
Program keys	Select from vehicle	China	ALTIMA	2019-(20 pin code)	Smart key system	-	Program smart keys
Program keys	Select from vehicle	China	New March	Smart key system	-	-	Read BCM code Release steering lock Program smart keys
Program keys	Select from vehicle	China	New Sunny	Smart key system	-	-	Read BCM code Release steering lock Program smart keys
Program keys	Select from vehicle	China	New Tiida	Smart key system	-	-	Read BCM code Release steering lock Program smart keys
Program keys	Select from vehicle	China	Altima Hybrid(07-11)	Smart key system	-	-	Release steering lock Program smart keys
Program keys	Select from vehicle	China	LANNIA(2015-)	Smart key system	-	-	Read BCM code Release steering lock Program smart keys
Program keys	Select from vehicle	China	New X-Trail	-2016	With Smart key system(20 pincode)	-	Program smart keys
Program keys	Select from vehicle	China	New X-Trail	-2016	Without smart key system(20 pincode)	-	Program key
Program keys	Select from vehicle	China	New X-Trail	2017	With Smart key system(20 pincode)	-	Program smart keys
Program keys	Select from vehicle	China	New Sylphy	Without smart key system	-	-	Erase DTC Program keys Release steering lock
Program keys	Select from vehicle	China	New Sylphy	With Smart key system	-	-	Read BCM code Release steering lock Program smart keys
Program keys	Select from vehicle	China	Murano	Smart key system(20 pincode)	-	-	Program smart keys Replace engine ECU
Program keys	Select from vehicle	China	Qashqai	With Smart key system(20 pincode)	-	-	Program smart keys
Program keys	Select from vehicle	China	Qashqai	Without smart key system(20 pincode)	-	-	Program key
Program keys	Select from vehicle	China	Cima	Smart key system(20 pincode)	-	-	Program smart keys Replace engine ECU
Program keys	Select from vehicle	China	KICKS	Immobiliser system	-	-	Program key
Program keys	Select from vehicle	China	KICKS	Smart key system	-	-	Program key
Program keys	Select from vehicle	Europe	350Z	Program remote	2005-2007	-	Fault codes Erase DTC Program keys
Program keys	Select from vehicle	Europe	350Z	Program remote	2008-	-	Erase DTC Program keys Release steering lock
Program keys	Select from vehicle	Europe	370Z	Smart key system	2009-	-	Erase DTC Program keys Release steering lock
Program keys	Select from vehicle	Europe	ALMERA	Program remote	-	-	Fault codes Erase DTC Program keys

Program keys	Select from vehicle	Europe	ALMERA TINO	Program remote	-	-	Fault codes Erase DTC Program keys
Program keys	Select from vehicle	Europe	ALTIMA	Program remote	2000-2001	-	Fault codes Erase DTC Program keys
Program keys	Select from vehicle	Europe	ARMADA	Program remote	2004-2007	-	Fault codes Erase DTC Program keys
Program keys	Select from vehicle	Europe	CABSTAR	Program remote	2006-	-	Fault codes Erase DTC Program keys
Program keys	Select from vehicle	Europe	CUBE	Program remote	-	-	Erase DTC Program keys Release steering lock
Program keys	Select from vehicle	Europe	CUBE	Smart key system	2009-	-	Read BCM code Release steering lock Program smart keys
Program keys	Select from vehicle	Europe	ELGRAND (IMPORT)	Smart key system	2002-2010	-	Program smart keys Erase all smart keys Program steering lock
Program keys	Select from vehicle	Europe	ELGRAND (IMPORT)	Mechanical Key	2002-2010	-	Fault codes Erase DTC Program keys
Program keys	Select from vehicle	Europe	FRONTIER	Program remote	2006-2008	-	Fault codes Erase DTC Program keys
Program keys	Select from vehicle	Europe	INTERSTAR	Immobiliser system	2006-	-	Program keys
Program keys	Select from vehicle	Europe	JUKE	Program remote	2010-	-	Erase DTC Program keys Release steering lock
Program keys	Select from vehicle	Europe	JUKE	Smart key system	2010-	-	Read BCM code Release steering lock Program smart keys
Program keys	Select from vehicle	Europe	KUBISTAR	Immobiliser system	-2007	-	Program keys
Program keys	Select from vehicle	Europe	LEAF	Smart key system	2011-	-	Read BCM code Release steering lock Program smart keys
Program keys	Select from vehicle	Europe	MARCH	Smart key system	2011-	-	Read BCM code Release steering lock Program smart keys
Program keys	Select from vehicle	Europe	MAXIMA	Program remote	2004-2006	-	Fault codes Erase DTC Program keys
Program keys	Select from vehicle	Europe	MAXIMA	Smart key system	2007-2008	-	Erase DTC Program keys Release steering lock
Program keys	Select from vehicle	Europe	MICAR	Immobiliser system	2002-2010	Type1	Read number of keys Program keys
Program keys	Select from vehicle	Europe	MICAR	Immobiliser system	2002-2010	Type2	Read number of keys Program keys Program remote Erase remotes
Program keys	Select from vehicle	Europe	MICAR	Program remote	2000-2003	-	Fault codes Erase DTC Program keys
Program keys	Select from vehicle	Europe	MICAR	Program remote	2011-	-	Erase DTC Program keys Release steering lock

Program keys	Select from vehicle	Europe	MICAR	Smart key system	2011-	-	Read BCM code Release steering lock Program smart keys
Program keys	Select from vehicle	Europe	MURANO	Program remote	2004-2008	-	Fault codes Erase DTC Program keys
Program keys	Select from vehicle	Europe	NAVARA	Program remote	2004-2014	-	Fault codes Erase DTC Program keys
Program keys	Select from vehicle	Europe	NAVARA	Smart key system	2008-2014	-	Program smart keys Erase all smart keys Program steering lock
Program keys	Select from vehicle	Europe	NAVARA	Smart key system	2014-2017	-	Read BCM code Release steering lock Program smart keys
Program keys	Select from vehicle	Europe	NAVARA	Mechanical Key	2008-2014	-	Erase DTC Program keys Release steering lock
Program keys	Select from vehicle	Europe	NOTE	Immobiliser system	2003-2013	-	Read number of keys Program keys
Program keys	Select from vehicle	Europe	NOTE	Program remote	2013-	-	Erase DTC Program keys Release steering lock
Program keys	Select from vehicle	Europe	NOTE	Smart key system	2003-	-	Read number of keys Program keys Program remote Erase remotes
Program keys	Select from vehicle	Europe	NOTE	Smart key system	2013-	-	Read BCM code Release steering lock Program smart keys
Program keys	Select from vehicle	Europe	NV200	Immobiliser system	2009-2015	-	Read number of keys Program keys
Program keys	Select from vehicle	Europe	NV400	Immobiliser system	2010-2014	-	Read number of keys Program keys
Program keys	Select from vehicle	Europe	PATHINDER	Program remote	2005-	-	Erase DTC Program keys Release steering lock
Program keys	Select from vehicle	Europe	PATHINDER	Smart key system	2006-2014	-	Program smart keys Erase all smart keys Program steering lock
Program keys	Select from vehicle	Europe	PATHINDER	Mechanical Key	-	-	Erase DTC Program keys Release steering lock
Program keys	Select from vehicle	Europe	PATROL	Smart key system	2010-	-	Fault codes Erase DTC Program keys
Program keys	Select from vehicle	Europe	PIXO	Immobiliser system	2009-2013	-	Read Trouble Code Clear Trouble Code ECU identification All keys lost
Program keys	Select from vehicle	Europe	PRIMASTAR	Immobiliser system	2003-2008	-	Program keys
Program keys	Select from vehicle	Europe	PRIMERA	Pin Calculator	-	-	Made in Mexico Made in Germany Made in Europe
Program keys	Select from vehicle	Europe	PRIMERA	Program remote	2002-2008	-	Fault codes Erase DTC Program keys
Program keys	Select from vehicle	Europe	PULSAR	Immobiliser system	2014-	-	Program smart keys
Program keys	Select from vehicle	Europe	QASHQAI	2007-2009 Program remote	-	-	Fault codes Erase DTC Program keys

Program keys	Select from vehicle	Europe	QASHQAI	2009-2013	Program remote	-	Erase DTC Program keys Release steering lock
Program keys	Select from vehicle	Europe	QASHQAI	2009-2013	Mechanical Key	-	Erase DTC Program keys Release steering lock
Program keys	Select from vehicle	Europe	QASHQAI	2009-2013	Smart key system	-	Program smart keys Erase all smart keys Program steering lock
Program keys	Select from vehicle	Europe	QASHQAI	2014-	Immobiliser system	Type1	Program smart keys
Program keys	Select from vehicle	Europe	QASHQAI	2014-	Immobiliser system	Type2	Program key
Program keys	Select from vehicle	Europe	QUEST	Program remote	2004-2007	-	Fault codes Erase DTC Program keys
Program keys	Select from vehicle	Europe	SENTRA	Program remote	2000-2006	-	Fault codes Erase DTC Program keys
Program keys	Select from vehicle	Europe	SENTRA	Program remote	2012	-	Erase DTC Program keys Release steering lock
Program keys	Select from vehicle	Europe	SKYLINE (Import)	Smart key system	2011	-	Erase DTC Program keys Release steering lock
Program keys	Select from vehicle	Europe	SKYLINE GTR-35	Smart key system	2009-	-	Fault codes Erase DTC Program keys
Program keys	Select from vehicle	Europe	TERRANO 2	Program remote	2002-2006	-	Fault codes Erase DTC Program keys
Program keys	Select from vehicle	Europe	TIIDA	Immobiliser system	2004-2012	-	Read number of keys Program keys
Program keys	Select from vehicle	Europe	TIIDA	Smart key system	-	-	Read number of keys Program keys Program remote Erase remotes
Program keys	Select from vehicle	Europe	TITAN	Program remote	2004-2007	-	Fault codes Erase DTC Program keys
Program keys	Select from vehicle	Europe	XTERRA	Program remote	2002-2007	-	Fault codes Erase DTC Program keys
Program keys	Select from vehicle	Europe	X-TRAIL	Program remote	2001-2007	-	Fault codes Erase DTC Program keys
Program keys	Select from vehicle	Europe	X-TRAIL	Program remote	2008-2013	-	Erase DTC Program keys Release steering lock
Program keys	Select from vehicle	Europe	X-TRAIL	Smart key system	-	-	Program smart keys
Program keys	Select from vehicle	Europe	X-TRAIL PROX-TWIST	Mechanical Key	-	-	Erase DTC Program keys Release steering lock
Program keys	Select from vehicle	Europe	X-TRAIL PROX-TWIST	Smart key system	-	-	Program smart keys Erase all smart keys Program steering lock
Program remote	Type 1	-	-	-	-	-	Program remote Erase remotes
Program remote	Type 2	-	-	-	-	-	Program remote Erase remotes