

Immobilizer		
Car Brand	Model	Functions
BMW	BMW\Select from type\CAS1/CAS2/CAS3	Program/delete key,Disable and
	BMW\Select from type\CAS4/CAS4+	Generate ignition key,Disable key,Enable
	BMW\Select from type\FEM/BDC	Read key data,Preprocess FEM/BDC system,Make
TRUMPCHI	TRUMPCHI\GS5\Immobilizer	Add key,Delete key,Read key count,
	TRUMPCHI\GS5\Smart key	All smart key lost,
	TRUMPCHI\GA5\Immobilizer	Add key,Delete key,Read key count,
	TRUMPCHI\GA5\Smart key	All smart key lost,
	TRUMPCHI\GA3(GA3S)\Immobilizer	Add key,Read key count,All key lost,
	TRUMPCHI\GA8\Immobilizer	Add key,Read key count,All key lost,
	TRUMPCHI\GS4\Immobilizer	Add key,Read key count,All key lost,
	TRUMPCHI\GA6\Immobilizer	Add key,Read key count,All key lost,
	TRUMPCHI\Extended electric	Add key,Delete key,Read key count,
	TRUMPCHI\GA3(GA3S)\Smart key	All smart key lost,
	TRUMPCHI\GA6\Smart key	All smart key lost,
	TRUMPCHI\GA8\Smart key	All smart key lost,
	TRUMPCHI\GS4\Smart key	All smart key lost,
	TRUMPCHI\GS8\Smart key	All smart key lost,
TRUMPCHI\GS8\Immobilizer	Add key,Delete key,Read key count,	

	TRUMPCHI\GA4\Immobilizer	Add key,Read key count,All key lost,
	TRUMPCHI\GA4\Smart key	All smart key lost,
	TRUMPCHI\GS3\Immobilizer	Add key,Delete key,Read key count,
	TRUMPCHI\GS3\Smart key	All smart key lost,
	TRUMPCHI\GS7\Smart key	All smart key lost,
	TRUMPCHI\GE3\Smart key	All smart key lost,
	TRUMPCHI\GM8\Smart key	All smart key lost,
	TRUMPCHI\New energy vehicles\Immobilizer	Add key,Read key count,All key lost,
	TRUMPCHI\GA3S(PHEV)\Smart key	All smart key lost,
	TRUMPCHI\GS4(PHEV)\Smart key	All smart key lost,
MASERATI	MASERATI\Flip key\Immobilizer	Program key,Backup immo data,Program
	MASERATI\Smart key(-2016)\Read PIN code	Read pin code,
	MASERATI\Smart key(-2016)\Smart key	Add smart key,Delete smart key,
	MASERATI\Smart key(2016-)\Smart key	Add smart key,Delete smart key,Backup immo
	VOLVO\S60\2010-2018\Smart key[insert	Add key,All key lost,Read CEM security data,Key
	VOLVO\S60\2010-2018\Keyless-go[button	Add smart key,Delete smart key,Read CEM
	VOLVO\S80\2009-2016\Keyless-go[button	Add smart key,Delete smart key,Read CEM
	VOLVO\XC60\2009-2018\Keyless-go[button	Add smart key,Delete smart key,Read CEM
	VOLVO\S80\2009-2016\Smart key[insert	Add key,All key lost,Read CEM security data,Key
	VOLVO\XC60\2009-2018\Smart key[insert	Add key,All key lost,Read CEM security data,Key

## VOLVO

VOLVO\S40\2004-2012\Smart key	Add smart key,Delete smart key,Unlock key,
VOLVO\S40\2004-2012\Immobilizer	Add key,Delete key,Identify key ID,Unlock key,
VOLVO\S80\2007-2009\Smart key[insert	Add key,Delete key,Read CEM security data,Key
VOLVO\V40\2012-2018\Smart key[insert	Add key,Delete key,Read CEM security data,Key
VOLVO\C30\2007-2013\Immobilizer	Add key,Delete key,Identify key ID,Unlock key,
VOLVO\C30\2007-2013\Smart key	Add smart key,Delete smart key,Unlock key,
VOLVO\V40\2012-2018\Keyless-go[button	Add smart key,Delete smart key,Read CEM
VOLVO\S80\2007-2009\Keyless-go[button	Add smart key,Delete smart key,Read CEM
VOLVO\V60\2011-2017\Smart key[insert	Add key,All key lost,Read CEM security data,Key
VOLVO\V60\2011-2017\Keyless-go[button	Add smart key,Delete smart key,Read CEM
VOLVO\XC60\2006-2009\Smart key[insert	Add key,Delete key,Read CEM security data,Key
VOLVO\XC60\2006-2009\Keyless-go[button	Add smart key,Delete smart key,Read CEM
VOLVO\XC90\2005-\Flip key	Add key,Delete key,Identify key ID,Key unlock,
VOLVO\S80\2005-2007\Flip key	Add key,Delete key,Identify key ID,Key unlock,
VOLVO\C70\2007-2013\Immobilizer	Add key,Delete key,Identify key ID,Unlock key,
VOLVO\C70\2007-2013\Smart key	Add smart key,Delete smart key,Unlock key,
VOLVO\V70\2009-2016\Smart key[insert	Add key,All key lost,Read CEM security data,Key
VOLVO\V70\2009-2016\Keyless-go[button	Add smart key,Delete smart key,Read CEM
VOLVO\XC70\2010-2016\Smart key[insert	Add key,All key lost,Read CEM security data,Key
VOLVO\XC70\2010-2016\Keyless-go[button	Add smart key,Delete smart key,Read CEM

	VOLVO\XC70\2007-2010\Smart key\insert	Add key,Delete key,Read CEM security data,Key
	VOLVO\XC70\2007-2010\Keyless-go\button	Add smart key,Delete smart key,Read CEM
	VOLVO\XC70\2006\Flip key	Add key,Delete key,Identify key ID,Key unlock,
	VOLVO\V70\2006-2008\Flip key	Add key,Delete key,Identify key ID,Key unlock,
	SSANG YONG\Select from type\Immobilizer\Type 1	Program key,
	SSANG YONG\Select from type\Remote\Type 1	Program remote,
	SSANG YONG\Select from type\Immobilizer\Type 2	Program key,
	SSANG YONG\Select from type\Immobilizer\Type 3	Program key,
	SSANG YONG\Select from vehicle\Actyon\Petrol	Program key,
	SSANG YONG\Select from vehicle\Actyon\Diesel	Program key,
	SSANG YONG\Select from vehicle\Actyon\XDi system	Program key,
	SSANG YONG\Select from vehicle\Chairman\Petrol\Im	Program key,
	SSANG YONG\Select from vehicle\Chairman\Diesel	Program key,
	SSANG YONG\Select from vehicle\Chairman\XDi	Program key,
	SSANG YONG\Select from vehicle\Korando\Petrol	Program key,
	SSANG YONG\Select from vehicle\Korando\Diesel	Program key,
	SSANG YONG\Select from vehicle\Korando\XDi	Program key,
	SSANG YONG\Select from vehicle\Kyron\Petrol	Program key,
	SSANG YONG\Select from vehicle\Kyron\Diesel	Program key,
SSANG YONG\Select from vehicle\Kyron\XDi system	Program key,	

SSANG YONG\Select from vehicle\Musso\Petrol	Program key,
SSANG YONG\Select from vehicle\Musso\Diesel	Program key,
SSANG YONG\Select from vehicle\Musso\XDi system	Program key,
SSANG YONG\Select from vehicle\Rexton\Petrol	Program key,
SSANG YONG\Select from vehicle\Rexton\Diesel	Program key,
SSANG YONG\Select from vehicle\Rexton\XDi system	Program key,
SSANG YONG\Select from vehicle\Stavic	Program key,
SSANG YONG\Select from vehicle\Stavic	Program key,
SSANG YONG\Select from vehicle\Stavic Rodius\XDi	Program key,
SSANG YONG\Select from vehicle\Rodius\Petrol	Program key,
SSANG YONG\Select from vehicle\Rodius\Diesel\Type	Program key,
SSANG YONG\Select from vehicle\Rodius\XDi system	Program key,
SSANG YONG\Select from vehicle\RextonII\Petrol	Program key,
SSANG YONG\Select from vehicle\RextonII\Diesel	Program key,
SSANG YONG\Select from vehicle\RextonII\XDi	Program key,
SSANG YONG\Select from vehicle\New Rexton\Petrol	Program key,
SSANG YONG\Select from vehicle\New Rexton\Diesel	Program key,
SSANG YONG\Select from vehicle\New Rexton\XDi	Program key,
SSANG YONG\Select from type\Remote\Type 2	Program remote,
SSANG YONG\Select from vehicle\New	Program smart key,

SSANG YONG

SSANG YONG\Select from vehicle\ChairmanH\Petrol\	Program smart key,
SSANG YONG\Select from vehicle\Rodius-Stavic	Program smart key,
SSANG YONG\Select from vehicle\Actyon	Program smart key,
SSANG YONG\Select from vehicle\XLV\Petrol\Smart	Program smart key,
SSANG YONG\Select from vehicle\XLV\Petrol\Remote	Program remote,
SSANG YONG\Select from vehicle\Musso(Rexton	Program remote,
SSANG YONG\Select from vehicle\Rexton(G4)\Petrol\	Program remote,
SSANG YONG\Select from vehicle\New	Program remote,
SSANG YONG\Select from vehicle\Tivolan\Remote	Program remote,
SSANG YONG\Select from vehicle\XLV\Petrol\Immobil	Program key,
SSANG YONG\Select from vehicle\Musso(Rexton	Program key,
SSANG YONG\Select from vehicle\Rexton(G4)\Petrol\I	Program key,
SSANG YONG\Select from vehicle\New	Program key,
SSANG YONG\Select from vehicle\Tivolan\Immobilizer	Program key,
SSANG YONG\Select from vehicle\Rexton(G4)\Petrol\	Program smart key,
SSANG YONG\Select from vehicle\Musso(Rexton	Program smart key,
SSANG YONG\Select from type\Smart key\Type 1	Program smart key,
SSANG YONG\Select from type\Smart key\Type 2	Program smart key,
SSANG YONG\Select from type\Immobilizer\Type 4	Program key,
SSANG YONG\Select from type\Remote\Type 3	Program remote,

	SSANG YONG\Select from vehicle\New	Program key,
	SSANG YONG\Select from vehicle\New	Program remote,
	SSANG YONG\Select from vehicle\New	Program smart key,
	SSANG YONG\Select from vehicle\Rexton	Program smart key,
	SSANG YONG\Select from vehicle\Rexton	Program key,
	SSANG YONG\Select from vehicle\Rodius\Diesel\Type	Program key,
	SSANG YONG\Select from vehicle\Rodius-Stavic	Program key,
	SSANG YONG\Select from vehicle\Rodius-Stavic	Program smart key,
	SSANG YONG\Select from vehicle\Actyon	Program key,
	SSANG YONG\Select from vehicle\Actyon	Program smart key,
	SSANG YONG\Select from vehicle\XLV\Diesel\Immobil	Program key,
	SSANG YONG\Select from vehicle\XLV\Diesel\Remote	Program remote,
	SSANG YONG\Select from vehicle\XLV\Diesel\Smart	Program smart key,
	SSANG YONG\Select from vehicle\Rexton(G4)\Diesel\	Program key,
	SSANG YONG\Select from vehicle\Rexton(G4)\Diesel\	Program remote,
	SSANG YONG\Select from vehicle\Rexton(G4)\Diesel\	Program smart key,
	SSANG YONG\Select from vehicle\Tivolan\Smart key	Program smart key,
	CITROEN\Select from vehicle\C4\Immobilizer\Typ	Program key,
	CITROEN\Select from vehicle\Triomphe\Immobiliz	Program key,
	CITROEN\Select from vehicle\C5(China)\Immobili	Program key,

CITROEN\Select from vehicle\Quatre\Immobilizer	Program key,
CITROEN\Select from vehicle\C4L\Immobilizer	Program key,
CITROEN\Select from vehicle\C4L\Smart key	All smart key lost,
CITROEN\Select from vehicle\C3-XR\Smart key	All smart key lost,
CITROEN\Read PIN code	Type 1,Type 2,Type 3,Type 4 (K line),
CITROEN\Select from type\Immobilizer\Type 1	Program key,
CITROEN\Select from type\Smart key\Type 1	All smart key lost,
CITROEN\Select from type\Immobilizer\Type 3	Program key,
CITROEN\Select from type\Immobilizer\Type 2	Program key,
CITROEN\Select from vehicle\Berlingo\Immobilize	Program key,
CITROEN\Select from vehicle\C1\Immobilizer	Program key,
CITROEN\Select from vehicle\C2\Immobilizer\Typ	Program key,
CITROEN\Select from vehicle\C3\Immobilizer\Typ	Program key,
CITROEN\Select from vehicle\C5\Immobilizer\Typ	Program key,
CITROEN\Select from vehicle\C8\Immobilizer\Typ	Program key,
CITROEN\Select from vehicle\Dispatch\Immobiliz	Program key,
CITROEN\Select from vehicle\Jumpy\Immobilizer\	Program key,
CITROEN\Select from vehicle\Nemo\Immobilizer\	Program key,
CITROEN\Select from vehicle\Picasso\Immobilize	Program key,
CITROEN\Select from vehicle\Relay\Immobilizer	Program key,



CITROEN

CITROEN>Select from vehicle\Relay2\Immobilizer	Program key,
CITROEN>Select from vehicle\Synergie\Immobiliz	Program key,
CITROEN>Select from vehicle\XSARA(China)\Im	Program key,
CITROEN>Select from vehicle\Xsara\Immobilizer\	Program key,
CITROEN>Select from vehicle\Xantia\Immobilizer\	Program key,
CITROEN>Select from vehicle\Berlingo\Immobilize	Program key,
CITROEN>Select from vehicle\C2\Immobilizer\Typ	Program key,
CITROEN>Select from vehicle\C3\Immobilizer\Typ	Program key,
CITROEN>Select from vehicle\C5\Immobilizer\Typ	Program key,
CITROEN>Select from vehicle\C6\Immobilizer	Program key,
CITROEN>Select from vehicle\C8\Immobilizer\Typ	Program key,
CITROEN>Select from vehicle\Dispatch\Immobiliz	Program key,
CITROEN>Select from vehicle\Evasion\Immobilize	Program key,
CITROEN>Select from vehicle\Jumpy\Immobilizer\	Program key,
CITROEN>Select from vehicle\Nemo\Immobilizer\	Program key,
CITROEN>Select from vehicle\Relay3\Immobilizer	Program key,
CITROEN>Select from vehicle\Synergie\Immobiliz	Program key,
CITROEN>Select from vehicle\Xsara\Immobilizer\	Program key,
CITROEN>Select from vehicle\Xantia\Immobilizer\	Program key,
CITROEN>Select from vehicle\C3-XR\Immobilizer	Program key,

	CITROEN>Select from vehicle\C6(China)\2016-	Program key,
	CITROEN>Select from vehicle\Elysee\2012-	Program key,
	CITROEN>Select from vehicle\C4\Smart key	All smart key lost,
	CITROEN>Select from vehicle\C6(China)\2016-	All smart key lost,
	CITROEN>Select from vehicle\C-	All smart key lost,
	CITROEN>Select from type\Immobilizer\Type 4	Read key/remote count,Program immo
	CITROEN>Select from vehicle\C-	Read key/remote count,Program immo
	CITROEN>Select from vehicle\C-	Read key/remote count,Program immo
	CITROEN>Select from vehicle\C4\Immobilizer\Typ	Program key,
	CITROEN>Select from type\Replace engine	Replace engine ECU,
PORSCH	PORSCH\Cayenne\Cayenne 2010-\Smart key	Program smart key,Make dealer key,
	PORSCH\Macan\Macan\Smart key	Program smart key,Make dealer key,
	PORSCH\Macan\Macan S\Smart key	Program smart key,Make dealer key,
	PORSCH\Macan\Macan Turbo\Smart key	Program smart key,Make dealer key,
	PORSCH\Cayenne\Cayenne GTS 2010-\Smart key	Program smart key,Make dealer key,
	PORSCH\New 911\Carrera S\Smart key	Program smart key,Make dealer key,
	PORSCH\New 911\Carrera Targa 4\Smart	Program smart key,Make dealer key,
	PORSCH\New 911\Turbo\Smart key	Program smart key,Make dealer key,
	PORSCH\New 718\Cayman\Smart key	Program smart key,Make dealer key,
	PORSCH\New 718\Boxster\Smart key	Program smart key,Make dealer key,

PORSCHE

PORSCHE\New 718\Boxster S\Smart key	Program smart key,Make dealer key,
PORSCHE\Panamera\Panamera\Smart key	Program smart key,Make dealer key,
PORSCHE\Panamera\Panamera 4\Smart key	Program smart key,Make dealer key,
PORSCHE\Panamera\Panamera S\Smart key	Program smart key,Make dealer key,
PORSCHE\Cayenne\2010\Immobilizer	Program key,
PORSCHE\Cayenne\2010\Read PIN code	Engine,
PORSCHE\Cayman\2005-2011\Immobilizer	Program key,Program key(without PIN),
PORSCHE\Boxter\2005-2011\Immobilizer	Program key,Program key(without PIN),
PORSCHE\997\2005-2010\Immobilizer	Program key,Program key(without PIN),
PORSCHE\911\2005-2010\Immobilizer	Program key,Program key(without PIN),
FORD\China\New Mondeo\2017\Immobilizer	Add key,All key lost,Read key count,
FORD\China\New Mondeo\2017\Smart key	Add smart key,All smart key lost,
FORD\China\Escort\2017\Immobilizer	Add key,All key lost,Read key count,
FORD\China\Edge\2015-2017\Smart key	Add smart key,All smart key lost,
FORD\China\Mustang\Smart key\2017	Add smart key,All smart key lost,
FORD\China\Escape\2005-2007\Immobilizer	All key lost,Add key,Read key count,
FORD\China\Raptor F350\Immobilizer	Delete key,Add key,Read key count,
FORD\China\Transit\2000-2013\Immobilizer	Add key,Delete key,All key lost,
FORD\China\Mondeo CHIA-X\PEPS\Smart key	Smart key all lost,Add smart key,
FORD\China\Mondeo CHIA-X\IMMO\Type	Add key,Delete key,All key lost,

FORD\China\Mondeo CHIA-X\IMMO\Type	Add key,Delete key,All key lost,
FORD\China\Focus\Classi c Focus\Type	Add key,All key lost,
FORD\China\Focus\New Focus\2011-	Add key,Delete key,All key lost,
FORD\China\Kuga\ 2015\Immobilizer	Add key,Delete key,All key lost,
FORD\China\Ecosport\Im mobilizer	Add key,Delete key,All key lost,
FORD\China\Fiesta\IMMO\ -2013\Immobilizer	Add key,Delete key,
FORD\China\Focus\Classi c Focus\Type	Add key,Delete key,All key lost,
FORD\China\Mondeo\Imm obilizer	All key lost,Read key count,
FORD\China\Ecosport\Sm art key	All smart key lost,Add smart key,
FORD\China\Fiesta\PEPS\ Smart key	All smart key lost,Add smart key,
FORD\China\Focus\New Focus\2014-\Immobilizer	Add key,Delete key,All key lost,
FORD\China\Explorer\201 1-\Immobilizer	Delete key,Add key,Read key count,
FORD\China\Classic Focus\Type 2\Immobilizer	Add key,Delete key,All key lost,
FORD\China\Kuga\ 2015\Smart key	Add key,Delete key,All key lost,Add smart key,Delete
FORD\China\Kuga\2016- \Smart key	Add smart key,All smart key lost,
FORD\China\Edge\ 2015\Smart key	Erase smart key,Add smart key,Read smart key count,
FORD\China\Raptor F150\2011-	Delete key,Add key,Read key count,
FORD\China\Raptor F150\2009-	Add key,Delete key,Read key count,Sync PCM-
FORD\China\Raptor F250\2009-	Add key,Delete key,Read key count,Sync PCM-
FORD\China\Everest\Smar t key\2017	Add smart key,All smart key lost,

FORD\China\Classic Focus\Type 1\Immobilizer	Add key,All key lost,
FORD\China\Explorer\2015-\Smart key	Add smart key,All smart key lost,
FORD\China\Taurus\2015-2016\Smart key	Add smart key,All smart key lost,
FORD\China\Everest\Immobilizer-2017	Add key,All key lost,Read key count,
FORD\China\S-MAX\IMMO\Type	Add key,Delete key,All key lost,
FORD\China\S-MAX\IMMO\Type	Add key,Delete key,All key lost,
FORD\China\Focus\New Focus\2011-2013\Smart	Add key,Delete key,All key lost,Add smart key,Delete
FORD\China\Fiesta\IMMO\2013-\Immobilizer	Add key,Delete key,All key lost,
FORD\China\New Mondeo\2017-\Smart key	Add smart key,All smart key lost,
FORD\China\Taurus\2017-\Smart key	Add smart key,All smart key lost,
FORD\China\Ranger\2007-2010\Immobilizer	Read key numbers,Add key,All key lost,
FORD\China\Ranger\2015\Immobilizer	Add key,Delete key,All key lost,Read key
FORD\China\Ranger\2017\Immobilizer	Read key count,Add key,All key lost,
FORD\China\Escape\2008-2009\Immobilizer	Read key numbers,Add key,All key lost,
FORD\China\Raptor F150\2015-\Smart key	Add smart key,All smart key lost,
FORD\China\Raptor F250\2015-\Smart key	Add smart key,All smart key lost,
FORD\China\C-MAX\Smart key	Add key,Delete key,All key lost,Add smart key,Delete
FORD\China\Focus\New Focus\2014-\Smart key	Add smart key,All smart key lost,
FORD\China\Remote\Type 1	Remote,Delete remote,
FORD\China\Edge-\2015\Immobilizer	Delete key,Add key,Read key count,

FORD\China\Edge\2017-\Smart key	Add smart key,All smart key lost,
FORD\China\Escort\2017-\Immobilizer	Add key,Delete key,Read key count,
FORD\China\Raptor F150\2015-\Immobilizer	Add key,All key lost,Read key count,
FORD\China\Transit\2013-\Immobilizer\Type 1	Add key,Delete key,All key lost,
FORD\China\Fusion\2006-2009\Immobilizer	Program key,Delete key,Key count,
FORD\China\Mustang\Immobilizer\2011-2014	Program key,All key lost,Key count,
FORD\USA\C-MAX\Smart key	Add key,Delete key,All key lost,Add smart key,Delete
FORD\USA\Contour\1997-1998\Immobilizer	All key lost,Key count,
FORD\USA\Contour\1999-2000\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Cougar\1999-2002\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Crown Victoria\1998-	Program key,All key lost,Key count,
FORD\USA\Crown Victoria\2003-	Program key,All key lost,Key count,
FORD\USA\Crown Victoria\2005-	Program remote,All key lost,Key count,
FORD\USA\E-Series Van\2008-	Program key,All key lost,Key count,
FORD\USA\E-250 Van\Immobilizer	Program key,All key lost,Key count,
FORD\USA\E-350 Van\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Econoline\2008-\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Edge\Immobilizer\2007-2010	Program key,All key lost,Key count,
FORD\USA\Escape\Immobilizer\2001-2004	Program key,All key lost,Key count,
FORD\USA\Escape\Immobilizer\2005-2007	Program remote,All key lost,Key count,

FORD\USA\Escape\Immobilizer\2008-2012\Type 1	Program key,All key lost,Key count,
FORD\USA\Escape\Immobilizer\2008-2012\Type 2	Program key,All key lost,Key count,
FORD\USA\Escape\Smart key	Add key,Delete key,All key lost,Add smart key,Delete
FORD\USA\Escape Titanium\Smart key	Add smart key,All smart key lost,
FORD\USA\Excursion\2000-2005\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Expedition\1997-1998\Immobilizer	All key lost,Key count,
FORD\USA\Expedition\1999-2002\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Expedition\2003-2004\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Expedition\2005-2006\Immobilizer	Program remote,All key lost,Key count,
FORD\USA\Expedition\2007-2008\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Expedition\2009-2013\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Explorer\1998-2001\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Explorer\2001-2003\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Explorer\2004-2005\Immobilizer	Program remote,All key lost,Key count,
FORD\USA\Explorer\2006-2010\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Explorer\2010\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Explorer Sport Trac\2001\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Explorer Sport Trac\2001-	Program key,All key lost,Key count,
FORD\USA\Explorer Sport Trac\2006-	Program key,All key lost,Key count,
FORD\USA\Explorer Sport Trac\2010\Immobilizer	Program key,All key lost,Key count,

FORD\USA\Fiesta\2014-2019\Smart key	All smart key lost,Add smart key,
FORD\USA\Five Hundred\2005-	Program remote,All key lost,Key count,
FORD\USA\Flex\2009-2012\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Focus\Immobilizer\2000-2004	Program key,All key lost,Key count,
FORD\USA\Focus\Immobilizer\2005-2007	Program remote,All key lost,Key count,
FORD\USA\Focus\Immobilizer\2008-2011	Add key,Delete key,Read key count,Sync PCM-
FORD\USA\Focus\Smart key	Add key,Delete key,All key lost,Add smart key,Delete
FORD\USA\Ford GT\2005-2006\Immobilizer	Program key,All key lost,Key count,
FORD\USA\FreeStar\2004-2005\Immobilizer	Program key,All key lost,Key count,
FORD\USA\FreeStar\2006-2007\Immobilizer	Program remote,All key lost,Key count,
FORD\USA\Freestyle\2005-2006\Immobilizer	Program remote,All key lost,Key count,
FORD\USA\Freestyle\2007-\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Focus ST\Smart key	Add smart key,All smart key lost,
FORD\USA\Focus Titanium\Smart key	Add smart key,All smart key lost,
FORD\USA\Fusion\2006-2009\Immobilizer	Program key,All key lost,Key count,
FORD\USA\F-150\1999-2003\Immobilizer	Program key,All key lost,Key count,
FORD\USA\F-150\2004-2008\Immobilizer	Program remote,All key lost,Key count,
FORD\USA\F-150\2009-2010\Immobilizer\Type 1	Program key,All key lost,Key count,
FORD\USA\F-150\2009-2010\Immobilizer\Type 2	Add key,Delete key,Read key count,Sync PCM-
FORD\USA\F-250\2008-2010\Immobilizer\Type 1	Program key,All key lost,Key count,



FORD\USA\F-250\2008-2010\Immobilizer\Type 2	Program key,All key lost,Key count,
FORD\USA\F-350\2008-2009\Immobilizer	Program key,All key lost,Key count,
FORD\USA\F-350\2010\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Mustang\1996-1997\Immobilizer	All key lost,Key count,
FORD\USA\Mustang\1998\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Mustang\1999-2004\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Mustang\2005-2009\Immobilizer	Program remote,All key lost,Key count,
FORD\USA\Mustang\2009-2014\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Ranger\1999-2000\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Ranger\2001-2006\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Ranger\2007-2012\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Taurus\Immobilizer\1996-1997	All key lost,Key count,
FORD\USA\Taurus\Immobilizer\1998-1999	Program key,All key lost,Key count,
FORD\USA\Taurus\Immobilizer\2000-2003	Program key,All key lost,Key count,
FORD\USA\Taurus\Immobilizer\2004-2007	Program remote,All key lost,Key count,
FORD\USA\Taurus\Immobilizer\2008-2009	Program key,All key lost,Key count,
FORD\USA\Thunderbird\2002-2005\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Transit\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Windstar\1999-2000\Immobilizer	Program key,All key lost,Key count,
FORD\USA\Windstar\2001-2004\Immobilizer	Program key,All key lost,Key count,

FORD\Europe\Transit Custom\2014-\Immobilizer	Key count,Delete key,Add key,
FORD\Europe\Transit Courier\2014\Immobilizer	Key count,Delete key,Add key,
FORD\Europe\Transit\2014-\Immobilizer	Key count,Delete key,Add key,
FORD\Europe\Tourneo Custom\2014-\Immobilizer	Key count,Delete key,Add key,
FORD\Europe\Tourneo Connect\2013-	Key count,Delete key,Add key,
FORD\Europe\C-Max\2010-2015\Smart	Add smart key,Delete smart key,
FORD\Europe\Focus\2011-2014\Smart key\Prox-	Add smart key,Delete smart key,
FORD\Europe\Kuga\2013-2015\Smart key\Prox-Rem	Add smart key,Delete smart key,
FORD\Europe\Focus\2005-2011\Smart key	Add smart key,Delete smart key,Read smart key
FORD\Europe\Kuga\2009-2013\Smart key	Add smart key,Delete smart key,Read smart key
FORD\Europe\Kuga\2007-2009\Immobilizer	Add key,Delete key,Read key count,
FORD\Europe\Windstar\1997-1998\Immobilizer	Delete key,Add key,Key count,
FORD\Europe\Transit\2000-2007\Immobilizer\Dura-	Delete key,Add key,Key count,
FORD\Europe\Transit\1998-2000\Immobilizer\Petrol	Delete key,Add key,Key count,
FORD\Europe\Transit\1997-1998\Immobilizer\Petrol	Delete key,Add key,Key count,
FORD\Europe\Scorpio\1997\Immobilizer\Petrol-	Delete key,Add key,Key count,
FORD\Europe\Granada\1997-\Immobilizer\Petrol-	Delete key,Add key,Key count,
FORD\Europe\Galaxy\2000-2006\Immobilizer\Petrol-	Delete key,Add key,Key count,
FORD\Europe\Explorer\1997-2001\Immobilizer\Type	Delete key,Add key,Key count,
FORD\Europe\Explorer\1997-2001\Immobilizer\Type	Delete key,Add key,Key count,

FORD\Europe\Galaxy\1997-2000\Immobilizer\Petrol-	Delete key,Key count,
FORD\Europe\Windstar\1998-\Immobilizer	All key lost,Add key,Key count,
FORD\Europe\Courier\2001-	Program remote,All key lost,Key count,
FORD\Europe\Courier\2001-	Program remote,All key lost,Key count,
FORD\Europe\Courier\2001-2007\Immobilizer\Diesel	Program remote,All key lost,Key count,
FORD\Europe\Fiesta\2001-	Program remote,All key lost,Key count,
FORD\Europe\Fiesta\2001-	Program remote,All key lost,Key count,
FORD\Europe\Fiesta\2001-2007\Immobilizer\Diesel	Program remote,All key lost,Key count,
FORD\Europe\Fusion\2002-2011\Immobilizer	Program remote,All key lost,Key count,
FORD\Europe\KA\2002-2008\Immobilizer	Program remote,All key lost,Key count,
FORD\Europe\C-Max\2010\Immobilizer\Type 1	Program key,All key lost,Key count,
FORD\Europe\C-Max\2010\Immobilizer\Type 2	Program key,All key lost,Key count,
FORD\Europe\Focus\2005-2011\Immobilizer	Program key,All key lost,Key count,
FORD\Europe\Tourneo\2007-2010\Immobilizer	Program key,All key lost,Key count,
FORD\Europe\Transit Connect\2007-	Program key,All key lost,Key count,
FORD\Europe\Ranger\2012-2014\Immobilizer	Add key,Delete key,All key lost,Read key
FORD\Europe\Cougar\Immobilizer	Program key,All key lost,Key count,
FORD\Europe\Courier\1999-2001\Immobilizer	Program key,All key lost,Key count,
FORD\Europe\Escape\Immobilizer	Program key,All key lost,Key count,
FORD\Europe\Fiesta\1999-2001\Immobilizer	Program key,All key lost,Key count,

FORD\Europe\Focus\1995-1998\Immobilizer\Diesel	Program key,All key lost,Key count,
FORD\Europe\Focus\1998-2004\Immobilizer	Program key,All key lost,Key count,
FORD\Europe\Galaxy\2000-2006\Immobilizer\Petrol-	Program key,All key lost,Key count,
FORD\Europe\KA\1998-2001\Immobilizer	Program key,All key lost,Key count,
FORD\Europe\Mondeo\1997-	Program key,All key lost,Key count,
FORD\Europe\Mondeo\1998-2007\Immobilizer	Program key,All key lost,Key count,
FORD\Europe\Puma\1996-2001\Immobilizer\Petrol -	Program key,All key lost,Key count,
FORD\Europe\Transit\1998-2000\Immobilizer\Diesel	Program key,All key lost,Key count,
FORD\Europe\Transit\1998-2000\Immobilizer\EPIC -	Program key,All key lost,Key count,
FORD\Europe\Transit\2000-2007\Immobilizer\Petrol	Program key,All key lost,Key count,
FORD\Europe\Transit\2000-2007\Immobilizer\Diesel	Program key,All key lost,Key count,
FORD\Europe\Transit\2000-2007\Immobilizer\Dura-	Program key,All key lost,Key count,
FORD\Europe\Transit Connect\2006\Immobilizer	Program key,All key lost,Key count,
FORD\Europe\Ranger\2012\Immobilizer	Program key,All key lost,Key count,
FORD\Europe\Ranger\2012\Manual PIN	Program key,All key lost,Key count,
FORD\Europe\Explorer\1997-2001\Immobilizer\Type	Program key,All key lost,Key count,
FORD\Europe\B-Max\2012-\Smart key	Smart key all lost,Add smart key,
FORD\Europe\Courier\2008-2013\Smart key	Smart key all lost,Add smart key,
FORD\Europe\Courier\2013-\Smart key	Smart key all lost,Add smart key,
FORD\Europe\Fiesta\2008-2013\Smart key	Smart key all lost,Add smart key,

FORD

FORD\Europe\Fiesta\2013- -Smart key	Smart key all lost,Add smart key,
FORD\Europe\Galaxy\2007- 2010\Smart key	Smart key all lost,Add smart key,
FORD\Europe\Galaxy\2010- 2015\Smart key	Smart key all lost,Add smart key,
FORD\Europe\Mondeo\2007- 2010\Smart key	Smart key all lost,Add smart key,
FORD\Europe\Mondeo\2010- 2014\Smart key	Smart key all lost,Add smart key,
FORD\Europe\S- Max\2007-2010\Smart key	Smart key all lost,Add smart key,
FORD\Europe\S- Max\2010-2015\Smart key	Smart key all lost,Add smart key,
FORD\Europe\Courier\2013- \Immobilizer	Add key,Delete key,All key lost,
FORD\Europe\Ecosport\2013\ Immobilizer	Add key,Delete key,All key lost,
FORD\Europe\Edge\2011- 2013\Immobilizer	Delete key,Add key,Read key count,
FORD\Europe\Explorer\2011- 2015\Immobilizer	Delete key,Add key,Read key count,
FORD\Europe\Courier\2008- 2013\Immobilizer	Add key,Delete key,
FORD\Europe\Fiesta\2008- 2013\Immobilizer	Add key,Delete key,
FORD\Europe\Transit\2007- 2013\Immobilizer	Add key,Delete key,All key lost,
FORD\Europe\S- Max\2010-	Add key,Delete key,Key count,
FORD\Europe\Mondeo\2010- 2014\Immobilizer	Add key,Delete key,Key count,
FORD\Europe\Galaxy\2010- 2015\Immobilizer	Add key,Delete key,Key count,
FORD\Europe\Transit Connect\2013-\Immobilizer	Add key,Delete key,All key lost,
FORD\Europe\Kuga\2013- 2015\Immobilizer	Add key,Delete key,All key lost,
FORD\Europe\Focus\2015- 2016\Immobilizer	Add key,Delete key,All key lost,

FORD\Europe\Focus\2011-2014\Immobilizer	Add key,Delete key,All key lost,
FORD\Europe\C-Max\2015-	Add key,Delete key,All key lost,
FORD\Europe\C-Max\2010-	Add key,Delete key,All key lost,
FORD\Europe\Vignale\2015-\Smart key	Read key count,Add key,All key lost,
FORD\Europe\Transit Custom\2017-\Immobilizer	Read key count,Add key,All key lost,
FORD\Europe\S-Max\2015-\Smart key	Read key count,Add key,All key lost,
FORD\Europe\Mustang\2015-\Smart key	Read key count,Add key,All key lost,
FORD\Europe\Mondeo\2015-\Immobilizer	Read key count,Add key,All key lost,
FORD\Europe\Mondeo\2015-\Smart key	Read key count,Add key,All key lost,
FORD\Europe\Galaxy\2015\Smart key	Read key count,Add key,All key lost,
FORD\Europe\Edge\2013-\Smart key	Read key count,Add key,All key lost,
FORD\Europe\S-Max\2007-	Add key,Delete key,All key lost,
FORD\Europe\Mondeo\2007-2010\Immobilizer	Add key,Delete key,All key lost,
FORD\Europe\Galaxy\2007-2010\Immobilizer	Add key,Delete key,All key lost,
FORD\Europe\Transit\1998-2000\Immobilizer\EPIC -	Key count,Add key,Delete key,
FORD\Europe\Scorpio\1997\Immobilizer\Petrol -	Key count,Add key,Delete key,
FORD\Europe\Puma\1996-2001\Immobilizer\Petrol -	Key count,Add key,Delete key,
FORD\Europe\Mondeo\1997-1998\Immobilizer\Petrol	Key count,Add key,Delete key,
FORD\Europe\KA\1997-1998\Immobilizer\PATS 3	Key count,Add key,Delete key,
FORD\Europe\Granada\1997-\Immobilizer\Petrol -	Key count,Add key,Delete key,

FORD\Europe\Galaxy\2000-2006\Immobilizer\Petrol -	Key count,Add key,Delete key,
FORD\Europe\Fiesta\1997-	Key count,Add key,Delete key,
FORD\Europe\Courier\1997-	Key count,Add key,Delete key,
FORD\Europe\Transit\1997-	Add key,Delete key,Key count,
FORD\Europe\Scorpio\1997\Immobilizer\Diesel(PATS	Add key,Delete key,Key count,
FORD\Europe\Mondeo\1997-	Add key,Delete key,Key count,
FORD\Europe\Granada\1997-	Add key,Delete key,Key count,
FORD\Europe\Fiesta\1997-	Add key,Delete key,Key count,
FORD\Europe\Fiesta\1996-	Add key,Delete key,Key count,
FORD\Europe\Courier\1997-	Add key,Delete key,Key count,
FORD\Europe\Courier\1996-	Add key,Delete key,Key count,
FORD\Europe\Kuga\2013-2015\Smart key\Immo chip	Add key,Delete key,All key lost,
FORD\Europe\Focus\2011-2014\Smart key\Immo	Add key,Delete key,All key lost,
FORD\Europe\C-Max\2010-2015\Smart	Add key,Delete key,All key lost,
FORD\Europe\Galaxy\2000-2006\Immobilizer\Diesel	Add key,Delete key,Key count,
FORD\Europe\Galaxy\2000-2006\Immobilizer\Petrol -	Add key,Delete key,Key count,
FORD\Australia\C-Max\Immobilizer\Type 1	Program key,All key lost,Key count,
FORD\Australia\C-Max\Immobilizer\Type 2	Program key,All key lost,Key count,
FORD\Australia\Cougar\Immobilizer	Program key,All key lost,Key count,
FORD\Australia\Courier\Petrol\1997-1998	Key count,Add key,Delete key,

FORD\Australia\Courier\Pe tro\1998-2000	Program key,All key lost,Key count,
FORD\Australia\Courier\Pe tro\2001-2008\Type 1	Program remote,All key lost,Key count,
FORD\Australia\Courier\Pe tro\2001-2008\Type 2	Program remote,All key lost,Key count,
FORD\Australia\Courier\Pe tro\2008-\Immobilizer	Add key,Delete key,
FORD\Australia\Courier\Pe tro\2008-\Smart key	Smart key all lost,Add smart key,
FORD\Australia\Courier\Di esel\2008-\Smart key	Smart key all lost,Add smart key,
FORD\Australia\Courier\Di esel\2008-\Immobilizer	Add key,Delete key,
FORD\Australia\Courier\Di esel\2001-	Program remote,All key lost,Key count,
FORD\Australia\Courier\Di esel\1999-2001	Program key,All key lost,Key count,
FORD\Australia\Courier\Di esel\1997-	Add key,Delete key,Key count,
FORD\Australia\Escape ZD	Program remote,All key lost,Key count,
FORD\Australia\Escape	Program key,All key lost,Key count,
FORD\Australia\Explorer\1 997-\Type 3	Program key,All key lost,Key count,
FORD\Australia\Explorer\1 997-\Type 2	Delete key,Add key,Key count,
FORD\Australia\Explorer\1 997-\Type 1	Delete key,Add key,Key count,
FORD\Australia\Fiesta\Die sel\2008-2012\Smart key	Smart key all lost,Add smart key,
FORD\Australia\Fiesta\Die sel\2008-2012\Immobilizer	Add key,Delete key,
FORD\Australia\Fiesta\Die sel\2001-2008\Immobilizer	Program remote,All key lost,Key count,
FORD\Australia\Fiesta\Die sel\1999-2001	Program key,All key lost,Key count,
FORD\Australia\Fiesta\Die sel\1997-	Add key,Delete key,Key count,



FORD\Australia\Fiesta\Petro\2008-2012\Smart key	Smart key all lost,Add smart key,
FORD\Australia\Fiesta\Petro\2008-2012\Immobilizer	Add key,Delete key,
FORD\Australia\Fiesta\Petro\2001-2008\Type 2	Program remote,All key lost,Key count,
FORD\Australia\Fiesta\Petro\2001-2008\Type 1	Program remote,All key lost,Key count,
FORD\Australia\Fiesta\Petro\1998-2000	Program key,All key lost,Key count,
FORD\Australia\Fiesta\Petro\1997-1998	Key count,Add key,Delete key,
FORD\Australia\Focus\Diesel\2011-\Immobilizer	Add key,Delete key,All key lost,
FORD\Australia\Focus\Diesel\2005-2011\Smart key	Add smart key,Delete smart key,Read smart key
FORD\Australia\Focus\Diesel\2005-2011\Immobilizer	Delete key,Add key,Read key count,
FORD\Australia\Focus\Diesel\1998-2004	Program key,All key lost,Key count,
FORD\Australia\Focus\Diesel\1995-1998	Program key,All key lost,Key count,
FORD\Australia\Focus\Petrol\2011-\Immobilizer	Add key,Delete key,All key lost,
FORD\Australia\Focus\Petrol\2005-2011\Smart key	Add smart key,Delete smart key,Read smart key
FORD\Australia\Focus\Petrol\2005-2011\Immobilizer	Delete key,Add key,Read key count,
FORD\Australia\Focus\Petrol\1998-2004	Program key,All key lost,Key count,
FORD\Australia\Fusion	Program remote,All key lost,Key count,
FORD\Australia\Galaxy\Diesel\2000-\Type 1\PATS	Add key,Delete key,Key count,
FORD\Australia\Galaxy\Petrol\2000-V6	Add key,Delete key,Key count,
FORD\Australia\Galaxy\Petrol\2000-\NOT V6\Type	Delete key,Add key,Key count,
FORD\Australia\Galaxy\Petrol\1997-2000\NOT	Delete key,Key count,

FORD\Australia\Galaxy\Petrol\1997\NOT V6\PATS 2	Delete key,Add key,Key count,
FORD\Australia\Granada Scorpio\Diesel\1997-	Add key,Delete key,Key count,
FORD\Australia\Granada Scorpio\Petrol\Automatic\1	Delete key,Add key,Key count,
FORD\Australia\Granada Scorpio\Petrol\Manual\199	Key count,Add key,Delete key,
FORD\Australia\KA\Petrol\2002-2008	Program remote,All key lost,Key count,
FORD\Australia\KA\Petrol\1998-2000	Program key,All key lost,Key count,
FORD\Australia\KA\Petrol\1997-1998	Key count,Add key,Delete key,
FORD\Australia\Maverick\2001-	Program key,All key lost,Key count,
FORD\Australia\Mondeo\Diesel\2007-\Smart key	Smart key all lost,Add smart key,
FORD\Australia\Mondeo\Diesel\2007-\Immobilizer	Add key,Delete key,All key lost,
FORD\Australia\Mondeo\Diesel\1998-\Type 1\PATS	Program key,All key lost,Key count,
FORD\Australia\Mondeo\Diesel\1997-1998\Type	Add key,Delete key,Key count,
FORD\Australia\Mondeo\Petrol\Automatic\2007-	Smart key all lost,Add smart key,
FORD\Australia\Mondeo\Petrol\Automatic\2007-	Add key,Delete key,All key lost,
FORD\Australia\Mondeo\Petrol\Automatic\1997-	Program key,All key lost,Key count,
FORD\Australia\Mondeo\Petrol\Manual\2007-\Smart	Smart key all lost,Add smart key,
FORD\Australia\Mondeo\Petrol\Manual\2007-	Add key,Delete key,All key lost,
FORD\Australia\Mondeo\Petrol\Manual\1998-\PATS	Program key,All key lost,Key count,
FORD\Australia\Mondeo\Petrol\Manual\1997-	Key count,Add key,Delete key,
FORD\Australia\Puma\Petrol\14 Zetec\1997-\PATS 3	Key count,Add key,Delete key,

FORD\Australia\Puma\Petro\14 Zetec\1996-	Program key,All key lost,Key count,
FORD\Australia\Ranger\2012-	Add key,Delete key,All key lost,Read key
FORD\Australia\Ranger\2012	Program key,All key lost,Key count,
FORD\Australia\Transit Connect\2007-\Type 2	Add key,Delete key,All key lost,
FORD\Australia\Transit Connect\2007-\Type 1	Program key,All key lost,Key count,
FORD\Australia\Transit Connect\2007	Program key,All key lost,Key count,
FORD\Australia\Transit\Epic\1998-\Type 2	Program key,All key lost,Key count,
FORD\Australia\Transit\Epic\1998-\Type 1	Key count,Add key,Delete key,
FORD\Australia\Transit\Dura Torque\Type 2	Program key,All key lost,Key count,
FORD\Australia\Transit\Dura Torque\Type 1	Delete key,Add key,Key count,
FORD\Australia\Transit\Diesel\2007-	Add key,Delete key,All key lost,
FORD\Australia\Transit\Diesel\1998-	Program key,All key lost,Key count,
FORD\Australia\Transit\Diesel\1997-1998	Add key,Delete key,Key count,
FORD\Australia\Transit\Petrol\2007-	Add key,Delete key,All key lost,
FORD\Australia\Transit\Petrol\2000-	Program key,All key lost,Key count,
FORD\Australia\Transit\Petrol\1997-2000	Delete key,Add key,Key count,
FORD\Australia\Windstar\1998-	All key lost,Add key,Key count,
FORD\Australia\Windstar\1997-1998	Delete key,Add key,Key count,
FORD\Africa\Transit\2014-	Key count,Delete key,Add key,
FORD\Africa\Mondeo\1997-1998	Program key,All key lost,Key count,

FORD\Africa\Icon\2002-2008	Program remote,All key lost,Key count,
FORD\Africa\Figo\2007-	Program remote,All key lost,Key count,
FORD\Africa\Fiesta\2012-2014	Add key,Delete key,All key lost,
FORD\Africa\Fiesta\2002-2008	Program remote,All key lost,Key count,
FORD\Africa\Bantam\2007-	Program remote,All key lost,Key count,
FORD\China\Explorer\2017-\Smart key	Add smart key,All smart key lost,
FORD\South America\F350\-	Key count,Delete key,
FORD\South America\F250\Diesel(Cum	Key count,Delete key,
FORD\India\Ecosport\2012-\Immobilizer	Add key,Delete key,All key lost,
FORD\India\Fiesta\2008-\Smart key	Smart key all lost,Add smart key,
FORD\India\Fiesta\2008-\Immobilizer	Add key,Delete key,
FORD\India\Fiesta\2004-	Program key,All key lost,Key count,
FORD\India\Figo\2008-\Smart key	Smart key all lost,Add smart key,
FORD\India\Figo\2008-\Immobilizer	Add key,Delete key,
FORD\India\Figo\2004-	Program key,All key lost,Key count,
FORD\India\Fusion\1318	Program remote,All key lost,Key count,
FORD\India\Mondeo\Diesel\2007-\Smart key	Smart key all lost,Add smart key,
FORD\India\Mondeo\Diesel\2007-\Immobilizer	Add key,Delete key,All key lost,
FORD\India\Mondeo\Diesel\1998-2007	Program key,All key lost,Key count,
FORD\India\Mondeo\Diesel\1997-1998	Add key,Delete key,Key count,

FORD\India\Mondeo\Petrol \Automatic\2007-	Add key,Delete key,All key lost,
FORD\India\Mondeo\Petrol \Automatic\1997-2006	Program key,All key lost,Key count,
FORD\India\Mondeo\Petrol \Manual\2007-Smart key	Smart key all lost,Add smart key,
FORD\India\Mondeo\Petrol \Manual\2007-Immobilizer	Add key,Delete key,All key lost,
FORD\India\Mondeo\Petrol \Manual\1998-2006	Program key,All key lost,Key count,
FORD\India\Mondeo\Petrol \Manual\1997-1998	Key count,Add key,Delete key,
FORD\South America\Ecosport\2011-	Smart key all lost,Add smart key,
FORD\South America\Ecosport\2011-	Add key,Delete key,All key lost,
FORD\South America\Ecosport\2010-	Program remote,All key lost,Key count,
FORD\South America\Ecosport\2009-	Program remote,All key lost,Key count,
FORD\South America\Ecosport\2003-	Program remote,All key lost,Key count,
FORD\South America\Edge\2007-	Program key,All key lost,Key count,
FORD\South America\F250\Petrol	Program key,All key lost,Key count,
FORD\South America\Ranger\2012-	Add key,Delete key,All key lost,Read key
FORD\South America\Fusion\2010-	Program key,All key lost,Key count,
FORD\South America\Focus\2005-	Program key,All key lost,Key count,
FORD\Israel\Edge\2011- \Smart key	Delete key,Add key,Read count of smart key,
FORD\Israel\Edge\2011- \Immobilizer	Delete key,Add key,Read key count,
FORD\Israel\Explorer\2011 -Smart key	Delete key,Add key,Read count of smart key,
FORD\Israel\Explorer\2011 -Immobilizer	Delete key,Add key,Read key count,

FORD\Israel\Focus\2011-2014\Immobilizer	Add key,Delete key,All key lost,
FORD\China\HEC\Immobilizer	All key lost,Key count,Reset system,
FORD\China\PCM\Immobilizer	All key lost,Read key count,
FORD\USA\HEC\Immobilizer	All key lost,Key count,Reset system,
FORD\USA\PCM\Immobilizer	All key lost,Read key count,
FORD\Europe\Tourneo Courier\2014-\Immobilizer	Add key,Delete key,All key lost,
FORD\China\Transit\2013-\Immobilizer\Type 2	Key count,Delete key,Add key,
FORD\China\Remote\Type 2(Transit 2014-)	Program remote,
FORD\China\Tourneo\2014-\Immobilizer	Key count,Delete key,Add key,
FORD\India\Ecosport\2012-\Smart key	All smart key lost,Add smart key,
PEUGEOT>Select from vehicle\308\Immobilizer\Ty	Program key,
PEUGEOT>Select from vehicle\3008\Immobilizer	Program key,
PEUGEOT>Select from vehicle\307\Immobilizer\Ty	Program key,
PEUGEOT>Select from vehicle\308S\Immobilizer	Program key,
PEUGEOT\Read PIN code	Type 1,Type 2,Type 3,Type 4 (K line),
PEUGEOT>Select from vehicle\4007\Petrol\Smart	All smart key lost,
PEUGEOT>Select from type\Immobilizer\Type 1	Program key,
PEUGEOT>Select from vehicle\207\Immobilizer\Ty	Program key,
PEUGEOT>Select from vehicle\307\Immobilizer\Ty	Program key,
PEUGEOT>Select from vehicle\508\Smart key	All smart key lost,

PEUGEOT

PEUGEOT\Select from vehicle\508\Immobilizer	Program key,
PEUGEOT\Select from vehicle\408\408(T73)\Imm	Program key,
PEUGEOT\Select from vehicle\408\408(T93)\Imm	Program key,
PEUGEOT\Select from type\Smart key\Type 1	All smart key lost,
PEUGEOT\Select from type\Immobilizer\Type 3	Program key,
PEUGEOT\Select from type\Immobilizer\Type 2	Program key,
PEUGEOT\Select from vehicle\1007\Immobilizer\T	Program key,
PEUGEOT\Select from vehicle\206\Immobilizer	Program key,
PEUGEOT\Select from vehicle\406(VF38)\Immobilizer	Program key,
PEUGEOT\Select from vehicle\607\Immobilizer\Ty	Program key,
PEUGEOT\Select from vehicle\807\Immobilizer\Ty	Program key,
PEUGEOT\Select from vehicle\Partner\Immobilizer	Program key,
PEUGEOT\Select from vehicle\1007\Immobilizer\T	Program key,
PEUGEOT\Select from vehicle\207\Immobilizer\Ty	Program key,
PEUGEOT\Select from vehicle\207CC\Immobilizer	Program key,
PEUGEOT\Select from vehicle\407\Immobilizer	Program key,
PEUGEOT\Select from vehicle\5008\Immobilizer	Program key,
PEUGEOT\Select from vehicle\607\Immobilizer\Ty	Program key,
PEUGEOT\Select from vehicle\807\Immobilizer\Ty	Program key,
PEUGEOT\Select from vehicle\Expert\2007-	Program key,

	PEUGEOT\Select from vehicle\Partner\Immobilizer	Program key,
	PEUGEOT\Select from vehicle\Rcz\Immobilizer	Program key,
	PEUGEOT\Select from vehicle\208\Immobilizer	Program key,
	PEUGEOT\Select from vehicle\2008\Immobilizer	Program key,
	PEUGEOT\Select from vehicle\301\Immobilizer	Program key,
	PEUGEOT\Select from type\Immobilizer\Type 4	Read key/remote count,Program immo
	PEUGEOT\Select from vehicle\4007\Petro\Immobi	Read key/remote count,Program immo
	PEUGEOT\Select from vehicle\4007\Diesel\Immobi	Read key/remote count,Program immo
	PEUGEOT\Select from vehicle\3008\Smart key	All smart key lost,
	PEUGEOT\Select from vehicle\4008\Smart key	All smart key lost,
	PEUGEOT\Select from vehicle\5008\Smart key	All smart key lost,
	PEUGEOT\Select from vehicle\4008\Immobilizer	Program key,
	PEUGEOT\Select from vehicle\1007\Immobilizer\T	Add key,Delete key,Reset Immo ECU,Program
	PEUGEOT\Select from vehicle\4008(China)\Smart	All smart key lost,
	PEUGEOT\Select from vehicle\4008(China)\Immo	Program key,
	PEUGEOT\Select from vehicle\308\Immobilizer\Ty	Program key,
	PEUGEOT\Select from type\Replace engine	Replace engine ECU,
	JAGUAR\Select from vehicle\XF\2013-\Smart	Add smart key,All smart key lost,
	JAGUAR\Select from vehicle\XF\2012\Smart key	Add smart key,All smart key lost,
	JAGUAR\Select from vehicle\XJ\Smart key	Add smart key,All smart key lost,



JAGUAR

JAGUAR\Select from vehicle\F-type\Smart key	Add smart key,All smart key lost,
JAGUAR\Select from vehicle\S-Type\Immobilizer	All key lost,
JAGUAR\Select from vehicle\XF\2012\Smart	Delete smart key,Add smart key,
JAGUAR\Select from vehicle\S-Type\Remote	Program remote>Delete remote,
JAGUAR\Select from vehicle\X-	All key lost,
JAGUAR\Select from vehicle\SOVERIGN\Immob	All key lost,
JAGUAR\Select from vehicle\XJ6\2003-	All key lost,
JAGUAR\Select from vehicle\XJ8\2003-	All key lost,
JAGUAR\Select from vehicle\XJR\2004-	All key lost,
JAGUAR\Select from vehicle\XK\2006-	Program remote,Remote count,
JAGUAR\Select from vehicle\XKR\2006-	Program remote,Remote count,
JAGUAR\Select from type\Immobilizer\Type 1	All key lost,
JAGUAR\Select from type\Smart key\Type 1	Delete smart key,Add smart key,
JAGUAR\Select from type\Smart key\Type 2	Add smart key,All smart key lost,
JAGUAR\Select from type\Smart key\Type 3	Add smart key,All smart key lost,
JAGUAR\Select from type\Smart key\Type 4	Add smart key,All smart key lost,
JAGUAR\Select from type\Remote\Type 1	Program remote,Remote count,
JAGUAR\Select from type\Remote\Type 2	Program remote>Delete remote,
JAGUAR\Select from vehicle\New Jaguar(2015-	Add smart key,
JAGUAR\Select from vehicle\New Jaguar(2015-	Add smart key,

	JAGUAR\Select from vehicle\New Jaguar(2015-	Write a workable key,Read key ID,
LAND ROVER	LAND ROVER\Select from vehicle\Range	Add smart key,All smart key lost,
	LAND ROVER\Select from vehicle\Discovery	Generate LKE,Program key,Read VIN code,
	LAND ROVER\Select from vehicle\Freelander 2\Smart	Program old smart key,Read VIN
	LAND ROVER\Select from vehicle\Freelander\Remote	Program remote,
	LAND ROVER\Select from vehicle\Discovery4\Smart	Add smart key,All smart key lost,
	LAND ROVER\Select from vehicle\Evoque\Smart key	Add smart key,All smart key lost,
	LAND ROVER\Select from vehicle\Freelander 2\Smart	Add smart key,All smart key lost,
	LAND ROVER\Select from vehicle\Evoque\Immobilize	Generate LKE,Program key,Read VIN code,
	LAND ROVER\Select from vehicle\Evoque\Immobilize	Program key,
	LAND ROVER\Select from vehicle\Freelander	Add old key,Add new key,Reset engine ECU,
	LAND ROVER\Select from vehicle\Freelander\Smart	Program old smart key,Read VIN
	LAND ROVER\Select from vehicle\Freelander\Remote	Program remote,
	LAND ROVER\Select from vehicle\Defender\Remote\2	Program remote,
	LAND ROVER\Select from type\Immobilizer\Type 1	Add old key,Add new key,Reset engine ECU,
	LAND ROVER\Select from type\Immobilizer\Type 2	Generate LKE,Program key,Read VIN code,
	LAND ROVER\Select from type\Immobilizer\Type 3	Program key,
	LAND ROVER\Select from type\Smart key\Type 1	Program old smart key,Read VIN
	LAND ROVER\Select from type\Smart key\Type 2	Add smart key,All smart key lost,
	LAND ROVER\Select from type\Remote\Type 1	Program remote,

	LAND ROVER>Select from vehicle\New	Add smart key,
	LAND ROVER>Select from vehicle\New	Add smart key,
	LAND ROVER>Select from vehicle\New	Write a workable key,Read key ID,
	MAZDA\China\Axela\2016\Smart key	Add smark key,All smart key lost,Switch ignition on,
	MAZDA\China\Atenza\2013-2016\Smart key	Add smark key,All smart key lost,Switch ignition on,
	MAZDA\China\CX-5\2016\Smart key	Add smark key,All smart key lost,Switch ignition on,
	MAZDA\China\M6\Immobilizer	Add key,All key lost,Valid backup key setting,Invalid
	MAZDA\China\M6\Smart key	Add smart key,Delete smart key,
	MAZDA\China\M3\Immobilizer\Type 1	Add key,Read key count,All key lost,
	MAZDA\China\M2\2008-2014\Immobilizer	Add key,All key lost,
	MAZDA\China\Mazda6\Immobilizer	All key lost,
	MAZDA\China\Mazda6\Smart key	Delete & program smart key,All key/smart key
	MAZDA\China\M3\Immobilizer\Type 2	Add key,All key lost,
	MAZDA\China\M5\Immobilizer\Type 2	Add key,All key lost,
	MAZDA\China\M8\Smart key	Add key,All key lost,Add smart key,Lost all smart
	MAZDA\China\M5\Immobilizer\Type 1	Add key,All key lost,Read key count,
	MAZDA\China\M3\Smart key\Type 1	Add smark key,All smart key lost,Switch ignition on,
	MAZDA\China\Axela\2017-2018\Smart key	Add smart key,All smart key lost,Switch ignition on,
	MAZDA\China\M8\Immobilizer	Add key,All key lost,Setup spare key valid,Setup
	MAZDA\China\CX-7\With smart\2016	Add key,All key lost,Add smart key,Lost all smart

MAZDA

MAZDA\China\CX-3-2017\Smart key	Add smark key,All smart key lost,Switch ignition on,
MAZDA\China\CX-4-2016\Smart key	Add smark key,All smart key lost,Switch ignition on,
MAZDA\China\CX-4\2017\Smart key	Add smart key,All smart key lost,Switch ignition on,
MAZDA\China\M2\2014-2016\Smart key	Add smark key,All smart key lost,Switch ignition on,
MAZDA\China\B series\2007-\Immobilizer	Key count,Add key,All key lost,
MAZDA\China\CX-9\Without smart\2004-2009	Add key,Read key count,All key lost,
MAZDA\China\CX-9\Without smart\2009-	Add key,All key lost,
MAZDA\China\MX-5\2004-2009\Immobilizer	Add key,Read key count,All key lost,
MAZDA\China\MX-5\2009-2016\Immobilizer	Keys count,Add key,All key lost,
MAZDA\China\BT50\2012-\Immobilizer	Add key,Erase key,All key lost,
MAZDA\China\CX-7\With smart\2016	All smart key lost,Add smart key,Switch ignition
MAZDA\China\CX-9\With smart\2016	All smart key lost,Add smart key,Switch ignition
MAZDA\China\CX-5\2017\Smart key	Add smart key,All smart key lost,Switch ignition on,
MAZDA\China\M121\Immo bilizer	Key count,Delete key,Add key,
MAZDA\China\M2\2008-2014\PEPS\Type 1	Add key,Clear key,Add remote,Delete remote,Key
MAZDA\China\Atenza\2017\Smart key	Add smart key,All smart key lost,Switch ignition on,
MAZDA\China\Demio\2001\Immobilizer	Key number,Delete key,Add key,
MAZDA\China\Demio\2002-2007\Immobilizer	Key number,Delete key,Add key,
MAZDA\China\Demio\2008-2013\Smart key	Add key,Clear key,Add remote,Delete remote,Key
MAZDA\China\Demio\2008-2013\Immobilizer	Key number,Delete key,Add key,

MAZDA\China\Demio\2014 \Smart key	Add smark key,All smart key lost,Switch ignition on,
MAZDA\China\MX-5\2017- \Smart key	Add smart key,All smart key lost,Switch ignition on,
MAZDA\China\MX-5 Miata\2005-	Key number,Delete key,Add key,
MAZDA\China\Premacy\20 05\Smart key	Key number,Delete key,Add key,
MAZDA\China\RX-8\2004- 2009\Immobilizer	Key count,Delete key,Add key,
MAZDA\China\RX- 8\2009\Smart key	Add key,Clear key,Add remote,Delete remote,Key
MAZDA\China\RX- 8\2009\Immobilizer	Key number,Delete key,Add key,
MAZDA\China\Tribute\Imm obilizer\2001-2004	Key number,Delete key,Add key,
MAZDA\China\Tribute\Imm obilizer\2005-2008	Key number,Delete key,Add key,
MAZDA\China\Tribute\Imm obilizer\2009-2011	Key count,Delete key,Add key,
MAZDA\China\M2\2017- \Smart key	Add smart key,All smart key lost,Switch ignition on,
MAZDA\China\M3\Smart key\Type 2(2017-)	Add smart key,All smart key lost,Switch ignition on,
MAZDA\China\CX-3\2017- \Smart key	Add smart key,All smart key lost,Switch ignition on,
MAZDA\China\M2\2002- 2008\Mechanical key	Add key,All key lost,Valid backup key setting,Invalid
MAZDA\China\M2\2008- 2014\PEPS\Type 2	All key lost,Add key,All smart key lost,Add smart
MAZDA\China\Axela\2018- \Smart key	All smart key lost,Turn ignition ON,Add smart key,
MAZDA\China\CX-5\2018- \Smart key	All smart key lost,Turn ignition ON,Add smart key,
MAZDA\China\CX-4\2018- \Smart key	All smart key lost,Turn ignition ON,Add smart key,
MAZDA\China\M2\2018- \Smart key	All smart key lost,Turn ignition ON,Add smart key,
MAZDA\China\CX-9\With smart\2018-	All smart key lost,Turn ignition ON,Add smart key,

	MAZDA\China\CX-7\With smart\2018-	All smart key lost,Turn ignition ON,Add smart key,
	MAZDA\China\CX-7\With smart\2017-2018	Add smart key,All smart key lost,Switch ignition on,
	MAZDA\China\CX-9\With smart\2017-2018	Add smart key,All smart key lost,Switch ignition on,
	MAZDA\China\Atenza\2018-\Smart key	All smart key lost,Turn ignition ON,Add smart key,
	MAZDA\China\MX-5\2018-\Smart key	All smart key lost,Turn ignition ON,Add smart key,
	MAZDA\China\CX-8\2018-\Smart key	All smart key lost,Turn ignition ON,Add smart key,
	MAZDA\China\CX-7\Without smart\2009-	Add key,All key lost,
	MAZDA\China\CX-7\Without smart\2004-2009	Add key,Read key count,All key lost,
	LINCOLN\MKC\Smart key\2017	Add smart key,All smart key lost,
	LINCOLN\MKZ\Smart key\2013-2017	Add smart key,All smart key lost,
	LINCOLN\Navigator\Immobilizer\2010-2014	Add key,All key lost,
	LINCOLN\MKS\Smart key	Erase smart key,Add smart key,Read smart key count,
	LINCOLN\MKT\Smart key	Erase smart key,Add smart key,Read smart key count,
	LINCOLN\MKX\Smart key\2011-2015	Erase smart key,Add smart key,Read smart key count,
	LINCOLN\Town Car\2005-2010\Immobilizer	Program key,
	LINCOLN\MKX\Smart key\2016-2017	Add smart key,All smart key lost,
	LINCOLN\Continental\Smart key\2017	Add smart key,All smart key lost,
	LINCOLN\Navigator\Remote	Program remote,Delete remote,
	LINCOLN\Aviator\2003-2005\Immobilizer	Program key,All key lost,Key count,
	LINCOLN\Blackwood\2002\Immobilizer	Program key,All key lost,Key count,

LINCOLN	LINCOLN\Continental\Immobilizer\1998-2002	Program key,All key lost,Key count,
	LINCOLN\LS\2000-2006\Immobilizer	Program key,All key lost,Key count,
	LINCOLN\Mark LT\2005-2007\Immobilizer	Program remote,All key lost,Key count,
	LINCOLN\Mark LT\2008-\Immobilizer	Program key,All key lost,Key count,
	LINCOLN\Mark VIII\1997-1998\Immobilizer	Delete key,Key count,
	LINCOLN\MKS\Immobilizer	Program key,All key lost,Key count,
	LINCOLN\MKX\Immobilizer\Petrol\2007-2010	Program key,All key lost,Key count,
	LINCOLN\MKX\Immobilizer\Hybrid	Program key,All key lost,Key count,
	LINCOLN\MKZ\Immobilizer\2007-2010	Program key,All key lost,Key count,
	LINCOLN\Navigator\Immobilizer\1997-1998	All key lost,Key count,
	LINCOLN\Navigator\Immobilizer\1999-2002	Program key,All key lost,Key count,
	LINCOLN\Navigator\Immobilizer\2003-2004	Program key,All key lost,Key count,
	LINCOLN\Navigator\Immobilizer\2005-2006	Program remote,All key lost,Key count,
	LINCOLN\Navigator\Immobilizer\2007-2009	Program key,All key lost,Key count,
	LINCOLN\Town Car\1998-2002\Immobilizer	Program key,All key lost,Key count,
	LINCOLN\Town Car\2003-2004\Immobilizer	Program key,All key lost,Key count,
	LINCOLN\Zephyr\2006\Immobilizer	Program key,All key lost,Key count,
	LINCOLN\PCM IMMO\Immobilizer	All key lost,Read key count,
	AUDI\A6L\2009-\Immobilizer	Backup immo data,Make dealer key,Learn
	AUDI\A6L\2009-\Immobilizer	Backup immo data,Make dealer key,Learn

AUDI	AUDI\IMMO5\Immobilizer/ Smart key	Backup immo data,Make dealer key,Learn key,Clear
	AUDI\Q7\2009 \Immobilizer	Backup immo data,Make dealer key,Learn
	AUDI\Q7\2009- \Immobilizer	Backup immo data,Make dealer key,Learn
	AUDI\A3\TT\R8- CDC32XX+24C32\Immobilizer	Backup EEPROM,Recover EEPROM,Backup immo
	AUDI\Q3\ 2013\Immobilizer	Backup EEPROM,Recover EEPROM,Make dealer
	AUDI\A1\Immobilizer	Backup EEPROM,Recover EEPROM,Make dealer
	AUDI\A4L\Immobilizer/Sm art key	Backup immo data,Make dealer key,Learn key,Clear
	AUDI\Q3\2014- \Immobilizer	Make dealer key,Learn key(OBD),Backup
	AUDI\Remote\Central locking(1281)	Add remote>Delete remote,
	AUDI\Remote\Central module(1281)	Add remote>Delete remote,
	AUDI\Remote\Remote	Add remote>Delete remote,
	AUDI\A3\2016\Immobilizer	Backup EEPROM,Recover EEPROM,Backup immo
	AUDI\A6L\2012- \Immobilizer/Smart key	Backup immo data,Make dealer key,Learn key,Clear
	AUDI\Q5\Immobilizer/Sm art key	Backup immo data,Make dealer key,Learn key,Clear
	NISSAN\Select from type\Immobilizer\Electronic	Add key,Activate steering wheel lock,Add key(fixed
	NISSAN\Select from type\Immobilizer\Electronic	Program key,
	NISSAN\Select from type\Immobilizer\Electronic	Add key,Add key(fixed code),
	NISSAN\Select from type\Immobilizer\Auto	Add key,
	NISSAN\Select from type\Remote\Type 1	Add remote>Delete remote,
	NISSAN\Select from type\Smart key\4-digit PIN	Program smart key>Delete smart key,Program



NISSAN>Select from type\Smart key\New 20-	Program smart key,
NISSAN>Select from type\Smart key\New 20-	Program smart key,
NISSAN>Select from type\Smart key\New 20-	Program smart key,
NISSAN>Select from type\Smart key\New 20-	Program smart key,
NISSAN>Select from type\Smart key\New 20-	Program smart key,
NISSAN>Select from type\Smart key\New 20-	Program smart key,
NISSAN>Select from type\Smart key\New 20-	Program smart key,
NISSAN>Select from type\Smart key\New 20-	Program smart key,
NISSAN>Select from type\Smart key\New 20-	Program smart key,
NISSAN>Select from type\Smart key\4-digit PIN	Program smart key,Delete smart key,
NISSAN>Select from type\Smart key\4-digit PIN	Program smart key,
NISSAN>Select from type\Smart key\4-digit PIN	Program smart key,Clear fault code,
NISSAN>Select from type\Smart key\4-digit PIN	Program smart key,
NISSAN>Select from type\Immobilizer\New 20-	Add key,
NISSAN>Select from type\Immobilizer\Activate	Activate steering wheel lock,
NISSAN>Select from type\Smart key\4-digit PIN	Activate steering wheel lock,
NISSAN>Select from type\Smart key\12-digit	Smart key,Key count,
NISSAN>Select from type\Immobilizer\12-digit	Smart key,Key count,
NISSAN>Select from type\Immobilizer\12-digit	Program key,Key count,
NISSAN\Read BCM code and release directional	Release steering lock,Read BCM inner
NISSAN>Select from type\Smart key\4-digit PIN	Read BCM inner code,Release steering

NISSAN\Select from vehicle\Asia\Sunny\Smart	Read BCM inner code,Release steering
NISSAN\Select from vehicle\Asia\350Z\2003-	Add key,Add key(fixed code),
NISSAN\Select from vehicle\Asia\X-	Program smart key,
NISSAN\Select from vehicle\North	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Asia\Almera\N16\Di	Program key,Clear fault code,
NISSAN\Select from vehicle\Asia\350Z\Z33	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Asia\Almera\N16\P	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Asia\Almera	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Asia\Cabstar\Petrol	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Asia\Fairlady	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Asia\Maxima\A34	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Asia\Micra\K11\200	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Asia\Patrol\Y61\Pet	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Asia\Primera\P12\P	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Asia\Pulsar\N16	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Asia\Skyline\V35	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Asia\Terrano	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Asia\X-	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\North	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\North	Program key,Clear fault code,Read BCM inner

NISSAN\Select from vehicle\North	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\North	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\North	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\North America\X-	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\South	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\South	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\South	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\South	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\South	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\South	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\South	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\South	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\South	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\South	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\South	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\South America\X-	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Asia\Almera	Program key,Clear fault code,
NISSAN\Select from vehicle\Asia\Cabstar\Diease	Program key,Clear fault code,
NISSAN\Select from vehicle\Asia\Navara\D40(S	Program key,Clear fault code,
NISSAN\Select from vehicle\Asia\Primera\P12\	Program key,Clear fault code,

NISSAN\Select from vehicle\Asia\Tiida\Diesel\2	Program key,Clear fault code,
NISSAN\Select from vehicle\Asia\X-	Program key,Clear fault code,
NISSAN\Select from vehicle\South	Program key,Clear fault code,
NISSAN\Select from vehicle\South	Program key,Clear fault code,
NISSAN\Select from vehicle\South	Program key,Clear fault code,
NISSAN\Select from vehicle\South	Program key,Clear fault code,
NISSAN\Select from vehicle\South	Program key,Clear fault code,
NISSAN\Select from vehicle\South	Program key,Clear fault code,
NISSAN\Select from vehicle\South America\X-	Program key,Clear fault code,
NISSAN\Select from vehicle\Asia\Micra\K13\Bar	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Asia\Pathfinder\R5	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Asia\Fairlady	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Asia\Atlas\F24	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Asia\Cube\Bar type	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Asia\Juke\Bar type	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Asia\Latio\2003-	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Asia\March\2011\4-	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Asia\Navara\D40(C	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Asia\X-	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\North	Read BCM inner code,Program key,Delete



NISSAN\Select from vehicle\South	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Asia\Navara\D40(S	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Asia\Qashqai\J10\	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\South	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\South	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\North	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\North	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\North	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\North	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\North	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\North	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\North	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\North	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\North	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Asia\Qashqai\J10\	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Asia\Navara\D40(S	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\South	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\South	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\North	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Asia\Navara\D40(C	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Asia\Latio\2003-	Read BCM inner code,Program key,Delete







NISSAN\Select from vehicle\North	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Asia\Cube\Proximit	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Asia\Juke\Proximity	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Asia\Micra\K13\Pro	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\South	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\South	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\North	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Asia\InterStar\X70	Program key,Clear fault code,
NISSAN\Select from vehicle\Asia\Terrano	Program key,Clear fault code,
NISSAN\Select from vehicle\Asia\Micra\K12\Bar	Program key,Clear fault code,
NISSAN\Select from vehicle\Asia>Note\E11\Bar	Program key,Clear fault code,
NISSAN\Select from vehicle\Asia\NV200\Bar	Program key,Clear fault code,
NISSAN\Select from vehicle\Asia\Tiida\Petrol	Program key,Clear fault code,
NISSAN\Select from vehicle\South	Program key,Clear fault code,
NISSAN\Select from vehicle\South	Program key,Clear fault code,
NISSAN\Select from vehicle\South	Program key,Clear fault code,
NISSAN\Select from vehicle\South	Program key,Clear fault code,
NISSAN\Select from vehicle\Asia\Micra\K12\Sm	Read key count,Program smart key,Add
NISSAN\Select from vehicle\Asia\Note\E11\Sma	Read key count,Program smart key,Add
NISSAN\Select from vehicle\South	Read key count,Program smart key,Add

NISSAN\Select from vehicle\South	Read key count,Program smart key,Add
NISSAN\Select from vehicle\Asia\Qashqai\J11\	Program key,
NISSAN\Select from vehicle\North	Program key,
NISSAN\Select from vehicle\South	Program key,
NISSAN\Select from vehicle\Asia\Qashqai\J11\	Program smart key,
NISSAN\Select from vehicle\North	Program smart key,
NISSAN\Select from vehicle\Asia\Teana\2013-	Program smart key,
NISSAN\Select from vehicle\North	Program smart key,
NISSAN\Select from vehicle\North	Program smart key,
NISSAN\Select from vehicle\North	Program smart key,
NISSAN\Select from vehicle\North	Program smart key,
NISSAN\Select from vehicle\North	Program smart key,
NISSAN\Select from vehicle\North	Program smart key,
NISSAN\PIN calculator	Type 1,Type 2,Type 3 (20-bit rolling code/PIN),
NISSAN\Select from vehicle\North	Read BCM inner code,Program key,
NISSAN\Select from vehicle\Africa\350Z\Z33	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Africa\Almera\N16\	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Africa\Almera\N16\	Program key,Clear fault code,
NISSAN\Select from vehicle\Africa\Almera	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Africa\Almera	Program key,Clear fault code,
NISSAN\Select from vehicle\Africa\Bluebird\Sylp	Read BCM inner code,Program key,Delete

NISSAN

NISSAN\Select from vehicle\Africa\Cabstar\Petr	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Africa\Cabstar\Dies	Program key,Clear fault code,
NISSAN\Select from vehicle\Africa\Cube\Bar	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Africa\Cube\Proxim	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Africa\InterStar\X70	Program key,Clear fault code,
NISSAN\Select from vehicle\Africa\Juke\Bar	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Africa\Juke\2011-	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Africa\Leaf	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Africa\Livina\2006-	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Africa\Maxima\A34	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Africa\March\K12\B	Program key,Clear fault code,
NISSAN\Select from vehicle\Africa\Micra\K11\20	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Africa\Micra\K12\B	Program key,Clear fault code,
NISSAN\Select from vehicle\Africa\Micra\K12\S	Read key count,Program smart key,Add
NISSAN\Select from vehicle\Africa\Micra\K13\B	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Africa\Micra\K13\Pr	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Africa\Navara\D40(	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Africa\Navara\D40(	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Africa\Navara\D40(	Program key,Clear fault code,
NISSAN\Select from vehicle\Africa\Navara\D40(	Read BCM inner code,Program key,Delete

NISSAN\Select from vehicle\Africa\Navara\D40\	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Africa\NV200\Bar	Program key,Clear fault code,
NISSAN\Select from vehicle\Africa\Note\E11\Ba	Program key,Clear fault code,
NISSAN\Select from vehicle\Africa\Note\E11\S	Read key count,Program smart key,Add
NISSAN\Select from vehicle\Africa\NP30\Diesel	Program key,Clear fault code,
NISSAN\Select from vehicle\Africa\Pathfinder\R	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Africa\Pathfinder\R	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Africa\Petrol\Y61\P	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Africa\Primera\P12\	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Africa\Primera\P12\	Program key,Clear fault code,
NISSAN\Select from vehicle\Africa\Pulsar\N16	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Africa\Qashqai\J10\	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Africa\Qashqai\J10\	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Africa\Qashqai\J10\	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Africa\Qashqai\J10\	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Africa\Qashqai\J11\	Program key,
NISSAN\Select from vehicle\Africa\Qashqai\J11\	Program smart key,
NISSAN\Select from vehicle\Africa\Rogue\2008-	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Africa\Skyline\V35	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Africa\Terrano	Program key,Clear fault code,Read BCM inner

NISSAN\Select from vehicle\Africa\Tiida\Petrol	Program key,Clear fault code,
NISSAN\Select from vehicle\Africa\Tiida\Diesel\	Program key,Clear fault code,
NISSAN\Select from vehicle\Africa\X-Trail\Petrol	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Africa\X-	Program key,Clear fault code,
NISSAN\Select from vehicle\Australia\350Z\Z33	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Australia\370Z\200	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Australia\Almera\N	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Australia\Almera\N	Program key,Clear fault code,
NISSAN\Select from vehicle\Australia\Almera	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Australia\Almera	Program key,Clear fault code,
NISSAN\Select from vehicle\Australia\Cabstar\P	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Australia\Cabstar\D	Program key,Clear fault code,
NISSAN\Select from vehicle\Australia\Cube\Bar	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\Cube\Pro	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Australia\Dualis\20	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\Dualis\20	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\Dualis\20	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\InterStar\	Program key,Clear fault code,
NISSAN\Select from vehicle\Australia\Juke\Bar	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\Juke\201	Read BCM inner code,Program smart key,

NISSAN\Select from vehicle\Australia\Leaf	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Australia\Maxima\A	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Australia\March\K1	Program key,Clear fault code,
NISSAN\Select from vehicle\Australia\Micra\K11	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Australia\Micra\K12	Program key,Clear fault code,
NISSAN\Select from vehicle\Australia\Micra\K12	Read key count,Program smart key,Add
NISSAN\Select from vehicle\Australia\Micra\K13	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\Micra\K13	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Australia\Murano\2	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Australia\Navara\D	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\Navara\D	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\Navara\D	Program key,Clear fault code,
NISSAN\Select from vehicle\Australia\Navara\D	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\Navara\D	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\NV200\Ba	Program key,Clear fault code,
NISSAN\Select from vehicle\Australia>Note\E11\	Program key,Clear fault code,
NISSAN\Select from vehicle\Australia\NP30\Die	Program key,Clear fault code,
NISSAN\Select from vehicle\Australia\Pathfinder	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\Pathfinder	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\Patrol\Y6	Program key,Clear fault code,Read BCM inner

NISSAN\Select from vehicle\Australia\Patrol\Y6	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\Patrol\Y6	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\Primera\P	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Australia\Primera\P	Program key,Clear fault code,
NISSAN\Select from vehicle\Australia\Pulsar\N1	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Australia\Pulsar\B1	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\Pulsar\C1	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Australia\Qashqai\J	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\Qashqai\J	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\Qashqai\J	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\Qashqai\J	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\Qashqai\J	Program key,
NISSAN\Select from vehicle\Australia\Qashqai\J	Program smart key,
NISSAN\Select from vehicle\Australia\Skyline\V	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Australia\Terrano	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Australia\Tiida\-	Program key,Clear fault code,
NISSAN\Select from vehicle\Australia\Tiida\200	Program key,Clear fault code,
NISSAN\Select from vehicle\Australia\Tiida\200	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\X-	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Australia\X-	Program key,Clear fault code,

NISSAN\Select from vehicle\Australia\X-	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\X-	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Australia\X-	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Australia\Tiida\200	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Europe\350Z\Z33	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Europe\370Z\Z34\S	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Europe\Almera\N1	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Europe\Almera\N1	Program key,Clear fault code,
NISSAN\Select from vehicle\Europe\Almera	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Europe\Almera	Program key,Clear fault code,
NISSAN\Select from vehicle\Europe\Armada\20	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Europe\Cabstar\Pe	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Europe\Cabstar\Di	Program key,Clear fault code,
NISSAN\Select from vehicle\Europe\Cube\Bar	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Europe\Cube\Proxi	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Europe\Juke\Bar	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Europe\Juke\Proxi	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Europe\March\K13\	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Europe\Leaf	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Europe\Leaf\A34	Program key,Clear fault code,Read BCM inner



NISSAN\Select from vehicle\Europe\Micra\K11\	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Europe\Micra\K12\	Program key,Clear fault code,
NISSAN\Select from vehicle\Europe\Micra\K12\	Read key count,Program smart key,Add
NISSAN\Select from vehicle\Europe\Micra\K13\	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Europe\Micra\K13\	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Europe\Navara\D4	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Europe\Navara\D4	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Europe\Navara\D4	Program key,Clear fault code,
NISSAN\Select from vehicle\Europe\Navara\D4	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Europe\Navara\D4	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Europe\NV200\Bar	Program key,Clear fault code,
NISSAN\Select from vehicle\Europe\Note\E11\B	Program key,Clear fault code,
NISSAN\Select from vehicle\Europe\Note\E11\S	Read key count,Program smart key,Add
NISSAN\Select from vehicle\Europe\Note\E2\Ba	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Europe\Pathfinder\	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Europe\Pathfinder\	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Europe\Petrol\Y61\	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Europe\Primera\P1	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Europe\Primera\P1	Program key,Clear fault code,
NISSAN\Select from vehicle\Europe\Pulsar\N16	Program key,Clear fault code,Read BCM inner

NISSAN\Select from vehicle\Europe\Qashqai\J1	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Europe\Qashqai\J1	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Europe\Qashqai\J1	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Europe\Qashqai\J1	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Europe\Qashqai\J1	Program key,
NISSAN\Select from vehicle\Europe\Qashqai\J1	Program smart key,
NISSAN\Select from vehicle\Europe\Quest\V28	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Europe\Sentra\B16	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Europe\Skyline\V3	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Europe\Skyline\IP	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Europe\Terrano	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Europe\Tiida\Petrol	Program key,Clear fault code,
NISSAN\Select from vehicle\Europe\Tiida\Diesel	Program key,Clear fault code,
NISSAN\Select from vehicle\Europe\Xterra\WD2	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Europe\Xterra\N50	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Europe\X-	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Europe\X-	Program key,Clear fault code,
NISSAN\Select from vehicle\Europe\X-	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Europe\X-	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Europe\X-	Program key,

NISSAN\Select from vehicle\Europe\X-	Program smart key,
NISSAN\Select from vehicle\Middle	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Middle	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Middle	Program key,Clear fault code,
NISSAN\Select from vehicle\Middle East\Almera	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Middle East\Almera	Program key,Clear fault code,
NISSAN\Select from vehicle\Middle	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Middle	Program key,Clear fault code,
NISSAN\Select from vehicle\Middle	Read BCM inner code,Program key>Delete
NISSAN\Select from vehicle\Middle	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Middle	Read BCM inner code,Program key>Delete
NISSAN\Select from vehicle\Middle	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Middle East\Leaf	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Middle	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Middle	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Middle	Program key,Clear fault code,
NISSAN\Select from vehicle\Middle	Read key count,Program smart key,Add
NISSAN\Select from vehicle\Middle	Read BCM inner code,Program key>Delete
NISSAN\Select from vehicle\Middle	Read BCM inner code,Program smart key,
NISSAN\Select from vehicle\Middle	Read BCM inner code,Program key>Delete

NISSAN\Select from vehicle\Middle	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Middle	Program key,Clear fault code,
NISSAN\Select from vehicle\Middle	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Middle	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Middle	Program key,Clear fault code,
NISSAN\Select from vehicle\Middle	Program key,Clear fault code,
NISSAN\Select from vehicle\Middle	Read key count,Program smart key,Add
NISSAN\Select from vehicle\Middle	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Middle	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Middle	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Middle	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Middle	Program key,Clear fault code,
NISSAN\Select from vehicle\Middle	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Middle	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Middle	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Middle	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Middle	Read BCM inner code,Program key,Delete
NISSAN\Select from vehicle\Middle	Program key,
NISSAN\Select from vehicle\Middle	Program smart key,
NISSAN\Select from vehicle\Middle	Program key,Clear fault code,Read BCM inner

NISSAN\Select from vehicle\Middle	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Middle	Program key,Clear fault code,
NISSAN\Select from vehicle\Middle	Program key,Clear fault code,
NISSAN\Select from vehicle\Middle East\X-	Program key,Clear fault code,Read BCM inner
NISSAN\Select from vehicle\Middle East\X-	Program key,Clear fault code,
NISSAN\Select from vehicle\Asia\Kicks\2017-	Program key,Read key count,
NISSAN\Select from vehicle\Asia\X-	Replace BCM,Configure data in read and write
NISSAN\Select from vehicle\Asia\X-	Program smart key,
NISSAN\Select from type\Remote\Type 2	Delete remote,Add remote,
NISSAN\Select from vehicle\Asia\Kicks\2017-	Program smart key,
NISSAN\Select from vehicle\North	Program key,
NISSAN\Select from vehicle\North	Read BCM inner code,Program key,Add
NISSAN\Select from vehicle\North	Read BCM inner code,Program key>Delete
NISSAN\Select from vehicle\Asia\Teana\2019-	Program smart key,
RENAULT\Select from type\Smart key\IMMO2	Program smart key,Collision recovery,
RENAULT\Select from type\Smart key\IMMO1	Program smart key,Collision recovery,
RENAULT\Select from vehicle\Fluence\2008 -	Program key,
RENAULT\Select from vehicle\Clio\1997-1999	Set IMMO unit,Initialize new immobilizer,
RENAULT\Select from vehicle\Clio\2000-2008 VIN	Program key,
RENAULT\Select from vehicle\Clio\2006-2012 VIN	Program smart key,

RENAULT>Select from vehicle\Clio\2006-2012 VIN	Program key,
RENAULT>Select from vehicle\Espace\2002- VIN	Program smart key,
RENAULT>Select from vehicle\Espace\2002- VIN	Program smart key,
RENAULT>Select from vehicle\Kangoo\1999-	Set IMMO unit,
RENAULT>Select from vehicle\Kangoo\1999-	Set IMMO unit,Initialize new immobilizer,
RENAULT>Select from vehicle\Kangoo\2003-2008	Program key,
RENAULT>Select from vehicle\Koleos\2008-2010	Program smart key,
RENAULT>Select from vehicle\Laguna\-	Program smart key,
RENAULT>Select from vehicle\Laguna\-	Program smart key,
RENAULT>Select from vehicle\Laguna\2007-2011	Program smart key,
RENAULT>Select from vehicle\Master\ -2003	Set IMMO unit,Initialize new immobilizer,
RENAULT>Select from vehicle\Master\2003-2010	Program key,
RENAULT>Select from vehicle\Maxity	Read BCM,Program remote,Delete remote,
RENAULT>Select from vehicle\Megane\2002-2008	Program smart key,
RENAULT>Select from vehicle\Megane\02-	Program smart key,
RENAULT>Select from vehicle\Megane\2008 -	Program key,
RENAULT>Select from vehicle\Scenic\2002-2006,	Program smart key,
RENAULT>Select from vehicle\Scenic\2006-2009,	Program smart key,
RENAULT>Select from vehicle\Scenic\2008-2011	Program key,
RENAULT>Select from vehicle\Modus\2004-2012	Program key,

RENAULT\Select from vehicle\Modus\2004-2012	Program smart key,Program
RENAULT\Select from vehicle\Safrane\2008- VIN	Program smart key,
RENAULT\Select from vehicle\Scala\2011-	Read BCM,Program key,Program
RENAULT\Select from vehicle\Trafic\2002- VIN	Program key,
RENAULT\Select from vehicle\Trafic\2002	Set IMMO unit,Initialize new immobilizer,
RENAULT\Select from vehicle\Twingo\2007 VIN	Set IMMO unit,
RENAULT\Select from vehicle\Twingo\2007 VIN	Set IMMO unit,Initialize new immobilizer,
RENAULT\Select from vehicle\Twingo\2007- VIN	Program key,
RENAULT\Select from vehicle\Velsatis\2002-2010	Program smart key,
RENAULT\Select from vehicle\Velsatis\2002-2010	Program smart key,
RENAULT\Select from vehicle\Wind\2010- VIN	Program key,
RENAULT\Select from vehicle\Safrane\KNMG4	Read BCM,Program key,Program
RENAULT\Select from vehicle\Koleos\2010-2016	Program smart key,Collision recovery,
RENAULT\Select from vehicle\Latitude	Program key,
RENAULT\Select from vehicle\Scenic\1999-2002	Read PIN code,Program key,
RENAULT\Select from vehicle\Scenic\2008	Program key,
RENAULT\Select from vehicle\Twingo\Twingo I	Add key,
RENAULT\Select from vehicle\Symbol\Symbol.\Ty	Add key,
RENAULT\Select from vehicle\Thalia\Thalia.\Type	Add key,
RENAULT\Select from vehicle\Trafic\Trafic II Ph2.	Add key,

RENAULT

RENAULT>Select from vehicle\Master\Master.	Add key,
RENAULT>Select from vehicle\Primastar\Primasta	Add key,
RENAULT>Select from vehicle\Clio\Clio II Ph2.	Add key,
RENAULT>Select from vehicle\Kangoo\Kangoo I.	Add key,
RENAULT>Select from vehicle\Symbol\Symbol.\Ty	Program key,
RENAULT>Select from vehicle\Thalia\Thalia.\Type	Program key,
RENAULT>Select from vehicle\Dacia\Duster\2010-	Program key,
RENAULT>Select from vehicle\Laguna\Laguna II.	Add key,
RENAULT>Select from vehicle\Espace\Espace IV.	Add key,
RENAULT>Select from vehicle\Velsatis\2005.	Add key,
RENAULT>Select from vehicle\Laguna\Laguna II	Add key,
RENAULT>Select from vehicle\Espace\Espace IV	Add key,
RENAULT>Select from vehicle\Velsatis\2005-.	Add key,
RENAULT>Select from vehicle\Clio\CLIO	Add key,
RENAULT>Select from vehicle\Modus\Modus.\Wit	Add key,
RENAULT>Select from vehicle\Clio\CLIO III.\With	Add key,
RENAULT>Select from vehicle\Trafic\Trafic II	Add key,Revise VIN code,Clear fault code,
RENAULT>Select from vehicle\Master\Master	Add key,Revise VIN code,Clear fault code,
RENAULT>Select from vehicle\Kangoo\Kangoo	Add key,
RENAULT>Select from vehicle\Twingo\Twingo	Add key,



RENAULT>Select from vehicle\Wind\2010-2013.	Add key,
RENAULT>Select from vehicle\Laguna\Laguna	Add key,
RENAULT>Select from vehicle\Megane\Megane	Add key,
RENAULT>Select from vehicle\Fluence\2009-	Add key,
RENAULT>Select from vehicle\Koleos\2008 -.	Add key,
RENAULT>Select from type\All\Type 0	Add key,
RENAULT>Select from type\All\Type 1	Add key,
RENAULT>Select from type\All\Type 2	Program key,
RENAULT>Select from type\All\Type 3	Add key,
RENAULT>Select from type\All\Type 4	Add key,
RENAULT>Select from type\All\Type 5	Add key,
RENAULT>Select from type\All\Type 6	Add key,
RENAULT>Select from type\All\Type 7	Add key,Revise VIN code,Clear fault code,
RENAULT>Select from type\All\Type 8	Add key,
RENAULT>Select from type\All\Type 9	Program key,
RENAULT>Select from type\All\Type A	Add key,
RENAULT>Select from vehicle\Scenic\Scenic III	Add key,
RENAULT>Select from type\All\Type B	Read PIN code,Program key,Recover backup data,
RENAULT>Select from vehicle\Trafic\Trafic III	Read PIN code,Program key,Recover backup data,
RENAULT>Select from vehicle\Clio\Clio IV.\2012-	Add key,Recover data,All key lost,Make dealer key,

RENAULT>Select from vehicle\Captur	Add key,Recover data,All key lost,Make dealer key,
RENAULT>Select from vehicle\Symbol\2013-2018	Program key,Read PIN code,Read key count,
RENAULT>Select from vehicle\Avantime\2001-	Add key,
RENAULT>Select from vehicle\Dacia\Logan\2013-	Program key,Read PIN code,Read key count,
RENAULT>Select from vehicle\Trafic\Trafic III	Program key,
RENAULT>Select from vehicle\Twingo\Twingo III.	Read PIN code,Recover backup data,Program key,
RENAULT>Select from vehicle\Kangoo\Kangoo	Add key,Revise VIN code,Clear fault code,
RENAULT>Select from vehicle\Espace\2015-	Program smart key,Make dealer key,
RENAULT>Select from vehicle\Megane\Megane	Program key,
RENAULT>Select from vehicle\Espace\2015-	Program key,Make dealer key,
RENAULT>Select from vehicle\Megane\Megane	Program smart key,Make dealer key,
RENAULT>Select from vehicle\Megane\Megane	Program key,Make dealer key,
RENAULT>Select from vehicle\Scenic\Scenic	Program key,Make dealer key,
RENAULT>Select from vehicle\Scenic\Scenic	Program smart key,Make dealer key,
RENAULT>Select from vehicle\Dacia\Dokker\2012	Program key,Read PIN code,Read key count,
RENAULT>Select from vehicle\Dacia\Duster\2013-	Program key,Read PIN code,Read key count,
RENAULT>Select from vehicle\Dacia\Solenza	Add key,
RENAULT>Select from vehicle\Dacia\Lodgy\2013-	Program key,Read PIN code,Read key count,
RENAULT>Select from vehicle\Dacia\Sandero	Add key,
RENAULT>Select from vehicle\Dacia\Sandero\200	Add key,

RENAULT>Select from vehicle\Dacia\LOGAN\200	Add key,
RENAULT>Select from vehicle\Dacia\Sandero\201	Program key,Read PIN code,Read key count,
RENAULT>Select from vehicle\Dacia\LOGAN(MA1	Add key,
RENAULT>Select from vehicle\Fluence\2008 -	Program key,
RENAULT>Select from vehicle\Trafic\Trafic III	Read PIN code,Recover backup data,Program key,
RENAULT>Select from vehicle\Koleos\2016-	Read DFLASH,Add key,Make dealer key,All
RENAULT>Select from vehicle\Koleos\2016-	Read DFLASH,Add smart key,All smart key
RENAULT>Select from vehicle\Kadjar\2016-	Read DFLASH,Add key,Make dealer key,All
RENAULT>Select from vehicle\Kadjar\2016-\Smart	Read DFLASH,Add smart key,All smart key
SUZUKI\China\Swift\2005-	All key lost,
SUZUKI\China\Vitara\Immobilizer\Type 1	All key lost,
SUZUKI\China\Vitara\Immobilizer\Type 2	Program key,Obtain immoID,
SUZUKI\China\Alto\Immobilizer	Program key,Obtain immoID,
SUZUKI\China\SX4\Immobilizer	Program key,Obtain immoID,
SUZUKI\China\Vitara\Immobilizer\Type 3	Program key,Read immoID,Program key
SUZUKI\China\Vitara\Smart key\Type 1	Program smart key (PIN required),Program smart
SUZUKI\China\Alivio\Smart key	Program smart key (PIN required),Program smart
SUZUKI\China\Alivio\Immobilizer	Program key,Read immoID,Program key
SUZUKI\China\Liana\Immobilizer>Type 1	All key lost,
SUZUKI\China\S-Cross\Smart key	Program smart key (PIN required),Program smart

SUZUKI	SUZUKI\China\Jimny\Immobilizer\Type 1	Program key,Delete key,Register immobiliser,
	SUZUKI\Japan\Ignis\Immobilizer	Program key,Delete key,Register immobiliser,
	SUZUKI\China\Liana\Immobilizer\Type 2	Program key,Delete key,Register immobiliser,
	SUZUKI\China\Jimny\Immobilizer\Type 2	All key lost,
	SUZUKI\China\Swift\2012-	Program smart key (PIN required),Program smart
	SUZUKI\USA\XL7(USA)\2007-2009\Immobilizer	All key lost,
	SUZUKI\China\Swift\2015-\Type 1	Program key,Read immoID,Program key
	SUZUKI\Japan\Baleno\Immobilizer\1996-2001	Program key,Delete ey,
	SUZUKI\China\Kizashi\Smart key	Program smart key (PIN required),Program smart
	SUZUKI\Japan\Wagon R\Immobilizer\1998-	Program key,Delete key,Register immobiliser,
	SUZUKI\China\Swift\2015-\Type 2	All key lost,
	SUZUKI\Japan\Swift\Immobilizer\1996-2004	Program key,Delete ey,
	SUZUKI\Japan\Alto\Immobilizer\1996-2002	Program key,Delete ey,
	SUZUKI\Japan\Grand Vitara\Immobilizer\1996-	Program key,Delete ey,
	SUZUKI\Japan\Grand Vitara\Immobilizer\2002-	Program key,Delete ey,
	SUZUKI\Japan\Vitara\Immobilizer\1996-2002	Program key,Delete ey,
	SUZUKI\Japan\Vitara\Immobilizer\2002-	Program key,Delete ey,
	SUZUKI\Japan\Jimny\Immobilizer	Program key,Delete ey,
	SUZUKI\China\New Alto	Program key,Obtain immoID,
	LAMBORGHINI\LP560\Remote	Program remote,Delete remote,

LAMBORGHINI	LAMBORGHINI\LP570\Remote	Program remote,Delete remote,
	LAMBORGHINI\LP580\Key(smart key) programming	Backup immo data,Make dealer key,Learn key,Clear
	LAMBORGHINI\LP610\Key(smart key) programming	Backup immo data,Make dealer key,Learn key,Clear
	LAMBORGHINI\LP700\Key(smart key) programming	Backup immo data,Make dealer key,Learn key,Clear
	HYUNDAI>Select from vehicle\China\IX35\2010-	Program key,Read key count,Read PIN code(46
	HYUNDAI>Select from vehicle\China\Sonata(NF)\	Program key,ECM neutral mode,Read key count,
	HYUNDAI>Select from vehicle\China\Tucson(JM)\	Program key,ECM neutral mode,Read key count,
	HYUNDAI>Select from vehicle\China\Tucson(JM)\	Program key,ECM neutral mode,Read key count,
	HYUNDAI>Select from vehicle\China\Tucson(JM)\	Program key,ECM neutral mode,Read key count,
	HYUNDAI>Select from vehicle\China\Mistra(CF)\2	Program key,ECM neutral mode,Read key count,
	HYUNDAI>Select from vehicle\China\Elantra(HDC	Program key,Read key count,Read PIN code(46
	HYUNDAI>Select from vehicle\China\Sonata(NFC	Program key,Read key count,Read PIN code(46
	HYUNDAI>Select from vehicle\China\I30(FDC)\20	Program key,Read key count,Read PIN code(46
	HYUNDAI>Select from vehicle\China\Verna(RBC/	Program key,Read key count,Read PIN code(46
	HYUNDAI>Select from vehicle\China\Elantra(MDC	Program key,Read key count,Read PIN code(46
	HYUNDAI>Select from vehicle\China\Elantra(MDC	Program smart key,ECM neutral mode,ESCL neutral
	HYUNDAI>Select from vehicle\China\Sonata(NFC	Program smart key,ECM neutral mode,SMK neutral
	HYUNDAI>Select from vehicle\China\IX35\2010-	Program smart key,ECM neutral mode,SMK neutral
	HYUNDAI>Select from vehicle\China\Elantra(HDC	Program smart key,ECM neutral mode,SMK neutral
	HYUNDAI>Select from vehicle\China\IX35\2014-	Program smart key,ECM neutral mode,SMK neutral

HYUNDAI\Select from vehicle\China\Verna(RBC/	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\China\IX25(GC)\20	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\China\Sonata	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\China\New	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\China\New	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\China\Mistra(CF)\2	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General area\HD	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General area\H-	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General area\H-	Program key,Read key count,Read PIN code(46

HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,ESCL neutral
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program smart key,
HYUNDAI\Select from vehicle\General	Program smart key,
HYUNDAI\Select from vehicle\General	Program smart key,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\China\New	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral

HYUNDAI\Select from vehicle\China\Sonata	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\China\Sonata	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\China\Elantra(HDC	Program remote,
HYUNDAI\Select from vehicle\China\IX35\2010-	Program remote,
HYUNDAI\Select from vehicle\China\Verna(RBC/	Program remote,
HYUNDAI\Select from vehicle\China\New	Program remote,
HYUNDAI\Select from vehicle\China\Sonata	Program remote,
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\China\I30(FDC)\20	Program remote,
HYUNDAI\Select from vehicle\China\New	Program remote,
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\China\Elantra(AD)\	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\China\Elantra(AD)\	Program remote,
HYUNDAI\Select from vehicle\China\Tucson(JM)\	Program remote,
HYUNDAI\Select from type\Immobilizer\Type 1(K)	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from type\Immobilizer\Type 2(K)	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from type\Immobilizer\Type 3(K)	Program key,ECM neutral mode,Read key count,



HYUNDAI>Select from type\Immobilizer\Type	Program key,Read key count,Read PIN code(46
HYUNDAI>Select from type\Immobilizer\Type	Program key,ECM neutral mode,Read key count,
HYUNDAI>Select from type\Smart key\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from type\Smart key\General	Program smart key,ECM neutral mode,ESCL neutral
HYUNDAI>Select from type\Smart key\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from type\Smart key\General	Program smart key,
HYUNDAI>Select from type\Smart key\General	Program smart key,
HYUNDAI>Select from type\Smart key\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from type\Smart key\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from type\Smart key\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from type\Remote\16 PIN\Type	Program remote,
HYUNDAI>Select from type\Remote\16 PIN\Type	Program remote,
HYUNDAI>Select from vehicle\China\Elantra(MDC	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Read PIN code	Read PIN code(46 chip),46 smart card,Read PIN
HYUNDAI>Select from vehicle\China\Verna(RC)\I	Program key,Read key count,Read PIN code(46
HYUNDAI>Select from type\Remote\16 PIN\Type	Program remote,
HYUNDAI>Select from type\Remote\16 PIN\Type	Program remote,
HYUNDAI>Select from type\Remote\16 PIN\Type	Program remote,
HYUNDAI>Select from vehicle\China\Elantra(AD)\	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from vehicle\China\Verna(RBC/	Program key,ECM neutral mode,Read key count,

HYUNDAI>Select from type\Remote\10 PIN\Type	Program remote,
HYUNDAI>Select from vehicle\China\IX35\2017-	Smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from type\Smart key\General	Smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from vehicle\China\Accent(MC)\	Program key,ECM neutral mode,Read key count,
HYUNDAI>Select from vehicle\China\Accent(MC)\	Program remote,
HYUNDAI>Select from vehicle\China\Elantra(MDC	Program key,ECM neutral mode,Read key count,
HYUNDAI>Select from vehicle\China\Elantra(MDC	Program remote,
HYUNDAI>Select from vehicle\China\Elantra(HDC	Program remote,
HYUNDAI>Select from vehicle\China\Elantra(HDC	Program key,Read key count,Read PIN code(46
HYUNDAI>Select from vehicle\China\Elantra(HDC	Program key,ECM neutral mode,Read key count,
HYUNDAI>Select from vehicle\China\Elantra(HDC	Program remote,
HYUNDAI>Select from vehicle\China\Elantra(HDC	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from vehicle\China\New	Program key,ECM neutral mode,Read key count,
HYUNDAI>Select from vehicle\China\New	Program remote,
HYUNDAI>Select from vehicle\China\New	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from vehicle\China\Elantra\2004	Program remote,
HYUNDAI>Select from vehicle\China\IX25(GC)\20	Program key,ECM neutral mode,Read key count,
HYUNDAI>Select from vehicle\China\IX25(GC)\20	Program remote,
HYUNDAI>Select from vehicle\China\IX35\2014-	Program key,Read key count,Read PIN code(46
HYUNDAI>Select from vehicle\China\IX35\2014-	Program remote,

HYUNDAI\Select from vehicle\China\IX35\2017-	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\China\Mistra(CF)\2	Program remote,
HYUNDAI\Select from vehicle\China\Sonata(LFC)	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\China\Sonata(LFC)	Program remote,
HYUNDAI\Select from vehicle\China\Sonata(LFC)	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\China\Sonata(NFC)	Program remote,
HYUNDAI\Select from vehicle\China\Sonata(NF)\	Program remote,
HYUNDAI\Select from vehicle\China\New	Program remote,
HYUNDAI\Select from vehicle\China\New	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\China\Verna(RBC/	Program remote,
HYUNDAI\Select from vehicle\China\Verna(RBC/	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\China\Verna(RBC/	Program remote,
HYUNDAI\Select from vehicle\China\Verna\2016-	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\China\Verna\2016-	Program remote,
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program remote,

HYUNDAI>Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI>Select from vehicle\General	Program remote,
HYUNDAI>Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from vehicle\General area\ccent	Program key,Read key count,Read PIN code(46
HYUNDAI>Select from vehicle\General area\ccent	Program remote,
HYUNDAI>Select from vehicle\General area\ccent	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI>Select from vehicle\General	Program remote,
HYUNDAI>Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI>Select from vehicle\General	Program remote,
HYUNDAI>Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from vehicle\General	Program remote,
HYUNDAI>Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI>Select from vehicle\General	Program remote,
HYUNDAI>Select from vehicle\General	Smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI>Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI>Select from vehicle\General	Program remote,
HYUNDAI>Select from vehicle\General	Program key,Read key count,Read PIN code(46

HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral

HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program smart card,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General area\H-	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General area\H-	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General area\H-	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General area\H-	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General area\H-	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General area\H-	Program remote,
HYUNDAI\Select from vehicle\General area\H-	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General area\H-	Program remote,
HYUNDAI\Select from vehicle\General area\H-	Program remote,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program remote,

HYUNDAI

HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,

HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General area\ix35	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46



HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General area\New	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General area\New	Program remote,
HYUNDAI\Select from vehicle\General area\New	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General area\New	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General area\New	Program remote,
HYUNDAI\Select from vehicle\General area\New	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General area\New	Program remote,
HYUNDAI\Select from vehicle\General area\New	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General area\New	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General area\New	Program remote,
HYUNDAI\Select from vehicle\General area\New	Program smart key,ECM neutral mode,SMK neutral

HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program remote,

HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,

HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\General	Program remote,
HYUNDAI\Select from vehicle\General	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\Accent(LC)\20	Program key,ECM neutral mode,Read key count,

HYUNDAI\Select from vehicle\USA\Accent(LC)\20	Program remote,
HYUNDAI\Select from vehicle\USA\Accent(MC)\2	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\USA\Accent(MC)\2	Program remote,
HYUNDAI\Select from vehicle\USA\Accent(RB)\2	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\USA\Accent(RB)\2	Program remote,
HYUNDAI\Select from vehicle\USA\Attitude(Mexic	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\USA\Azera(HG)\20	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\USA\Azera(HG)\20	Program remote,
HYUNDAI\Select from vehicle\USA\Azera(HG)\20	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\Azera(TG)\20	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\USA\Azera(TG)\20	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\USA\Azera(TG)\20	Program remote,
HYUNDAI\Select from vehicle\USA\Azera(TG)\20	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\USA\Azera(TG)\20	Program remote,
HYUNDAI\Select from vehicle\USA\Elantra	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\USA\Elantra	Program remote,
HYUNDAI\Select from vehicle\USA\Elantra	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\Elantra	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\USA\Elantra	Program remote,
HYUNDAI\Select from vehicle\USA\Elantra	Program smart key,ECM neutral mode,SMK neutral

HYUNDAI\Select from vehicle\USA\Elantra	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\USA\Elantra	Program remote,
HYUNDAI\Select from vehicle\USA\Elantra(AD)\2	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\USA\Elantra(AD)\2	Program remote,
HYUNDAI\Select from vehicle\USA\Elantra(AD)\2	Smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\Elantra(ADA)\	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\USA\Elantra(ADA)\	Program remote,
HYUNDAI\Select from vehicle\USA\Elantra(ADA)\	Smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\Elantra(HD)\2	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\USA\Elantra(HD)\2	Program remote,
HYUNDAI\Select from vehicle\USA\Elantra(MD)\2	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\USA\Elantra(MD)\2	Program remote,
HYUNDAI\Select from vehicle\USA\Elantra(MD)\2	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\Elantra(UD)\2	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\USA\Elantra(UD)\2	Program remote,
HYUNDAI\Select from vehicle\USA\Elantra(UD)\2	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\Elantra(XD)\2	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\USA\Elantra(XD)\2	Program remote,
HYUNDAI\Select from vehicle\USA\Entourage(EP	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\USA\Entourage(EP	Program remote,

HYUNDAI\Select from vehicle\USA\Equus(VI)\201	Smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\Equus(VI)\201	Program smart key,
HYUNDAI\Select from vehicle\USA\Genesis	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\USA\Genesis	Program remote,
HYUNDAI\Select from vehicle\USA\Genesis	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\Genesis(BH)\	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\USA\Genesis(BH)\	Program remote,
HYUNDAI\Select from vehicle\USA\Genesis(BH)\	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\Genesis(BH)\	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\USA\Genesis(BH)\	Program remote,
HYUNDAI\Select from vehicle\USA\Genesis(BH)\	Program smart key,
HYUNDAI\Select from vehicle\USA\Genesis(DH)\	Smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\Santafe	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\USA\Santafe	Smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\Santafe	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\USA\Santafe	Program remote,
HYUNDAI\Select from vehicle\USA\Santafe	Smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\New	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\USA\New	Program remote,
HYUNDAI\Select from vehicle\USA\New	Program smart key,ECM neutral mode,SMK neutral

HYUNDAI\Select from vehicle\USA\Santafe	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\USA\Santafe	Program remote,
HYUNDAI\Select from vehicle\USA\Santafe	Smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\Santafe(SM)\	Program remote,
HYUNDAI\Select from vehicle\USA\Santafe(SM)\	Program remote,
HYUNDAI\Select from vehicle\USA\Sonata	Smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\Sonata	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\USA\Sonata	Program remote,
HYUNDAI\Select from vehicle\USA\Sonata	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\Sonata	Smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\Sonata(LFA)\	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\USA\Sonata(LFA)\	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\USA\Sonata(LFA)\	Program remote,
HYUNDAI\Select from vehicle\USA\Sonata(LFA)\	Smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\Sonata(NF)\2	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\USA\Sonata(NF)\2	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\USA\Sonata(NF)\2	Program remote,
HYUNDAI\Select from vehicle\USA\Sonata(YF)\2	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\USA\Sonata(YF)\2	Program remote,
HYUNDAI\Select from vehicle\USA\Sonata(YF)\2	Program smart key,ECM neutral mode,SMK neutral



HYUNDAI\Select from vehicle\USA\Tiburon(GK)\2	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\USA\Tiburon(GK)\2	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\USA\Tucson	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\Tucson(LM)\2	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\USA\Tucson(LM)\2	Program remote,
HYUNDAI\Select from vehicle\USA\Tucson(LM)\2	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\Tucson(JM)\2	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\USA\Tucson(JM)\2	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\USA\Tucson(JM)\2	Program remote,
HYUNDAI\Select from vehicle\USA\Tiburon(TL)\2	Program remote,
HYUNDAI\Select from vehicle\USA\Veloster(FS)\	Program key,ECM neutral mode,Read key count,
HYUNDAI\Select from vehicle\USA\Veloster(FS)\	Program remote,
HYUNDAI\Select from vehicle\USA\Veloster(FS)\	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\Veracruz/ix55	Program key,Read key count,Read PIN code(46
HYUNDAI\Select from vehicle\USA\Veracruz/ix55	Program remote,
HYUNDAI\Select from vehicle\USA\Veracruz/ix55	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI\Select from vehicle\USA\XG(XG)\2001-	Program remote,
HYUNDAI\Select from type\Remote\16	Program remote,
HYUNDAI\Select from type\Immobilizer\Type6(CA	Program key,neutral mode,
HYUNDAI\Select from type\Immobilizer\Type7(CA	Program key,neutral mode,

HYUNDAI>Select from type\Immobilizer\Type8( K)	Program key,ECM neutral mode,Read key count,
HYUNDAI>Select from type\Smart	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from type\Smart	Program smart key,ECM neutral mode,ESCL neutral
HYUNDAI>Select from type\Smart	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from type\Smart	Program smart key,
HYUNDAI>Select from type\Smart	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from type\Smart	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from type\Smart	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from type\Smart	Program smart key,ECM neutral mode,ESCL neutral
HYUNDAI>Select from type\Smart	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from type\Smart	Program smart key,
HYUNDAI>Select from type\Smart	Program smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from type\Smart	Smart key,ECM neutral mode,SMK neutral
HYUNDAI>Select from type\Smart key\General	Program smart card,ECM neutral mode,SMK neutral
HYUNDAI>Select from vehicle\China\Verna\2016-	Program smart key,ECM neutral mode,SMK neutral
TOYOTA\Select from vehicle\China\Camry\2000-	Add master key,Add valet key,Delete key,Clear fault
TOYOTA\Select from vehicle\China\Camry\2004-	Add master key,Add valet key,Delete key,Clear fault
TOYOTA\Select from vehicle\China\Reiz\Mechan	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from vehicle\China\Crown\-	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from vehicle\China\Camry\2004-	Add key,Delete key,Program immo

TOYOTA\Select from vehicle\China\Prado\2010-	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Crown\2009-	Add master key,Add valet key,Delete key,
TOYOTA\Select from vehicle\China\Rav4\Smart	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Reiz\Mechan	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Corolla\2012	Program remote,Delete remote,
TOYOTA\Select from vehicle\China\Camry\2004-	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Crown\-	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Crown\-	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Reiz\Mechan	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Camry\2004-	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Reiz\Smart	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Camry\2004-	Program remote,Delete remote,
TOYOTA\Select from vehicle\China\Vios\Mechan	Add master key,Add valet key,Delete key,
TOYOTA\Select from vehicle\China\Corolla\2012	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Camry\2004-	Remote program method,
TOYOTA\Select from vehicle\China\Avanza\Mec	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Vios\Mechan	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from vehicle\China\Yaris\Smart	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Levin\Mecha	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Prado\2009-	Add key,Delete key,All key lost,Reset immo

TOYOTA\Select from type\All smart key lost\All	Backup EEPROM data,Generate SKE,Bind
TOYOTA\Select from type\PEPS\Type 2(Crown	Program remote,Add smart key,Reset immo ECU,
TOYOTA\Select from type\PEPS\Type 3	Add smart key,Delete smart key,Reset
TOYOTA\Select from type\IMMO\Type	IMMO reset(8A all key lost),Add key,Delete
TOYOTA\Select from type\IMMO\Type	Add key,
TOYOTA\Select from type\IMMO\Type 6	Add master key,Add valet key,Delete key,
TOYOTA\Select from vehicle\China\Corolla	Add key,Delete key,Program immo
TOYOTA\Select from type\IMMO\Type 2("4D"	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from type\IMMO\Type 1("4C")	Add master key,Add valet key,Delete key,Clear fault
TOYOTA\Select from type\IMMO\Type 3("4D"72"	Add key,Delete key,Program immo
TOYOTA\Select from type\IMMO\Type 7(Toyota	Read key count,Add key,Program
TOYOTA\Select from type\Remote\Type 1	Program remote,Delete remote,
TOYOTA\Select from type\Remote\Type 2	Program remote,Delete remote,
TOYOTA\Select from type\PEPS\Type 1	Add smart key,Delete smart key,Reset smart
TOYOTA\Select from type\Remote\Type 3	Program remote,
TOYOTA\Select from type\IMMO\Type	Reset G immo(All key lost),Reset DOT immo(All
TOYOTA\Select from vehicle\China\Avanza\All	Reset G immo(All key lost),Reset DOT immo(All
TOYOTA\Select from vehicle\China\Corolla	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Corolla	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Corolla	Program remote,Add smart key,Reset immo ECU,

TOYOTA\Select from vehicle\China\86\2016\Sm	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Alphard\-	Add master key,Add valet key,Delete key,Clear fault
TOYOTA\Select from vehicle\China\Alphard\-	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Alphard\200	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from vehicle\China\Alphard\200	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Alphard\200	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Alphard\200	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Corolla\2012	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from vehicle\China\Corolla\2012	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Corolla\2007	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from vehicle\China\Corolla\2001	Add master key,Add valet key,Delete key,Clear fault
TOYOTA\Select from vehicle\China\Corolla\2001	Remote program method,
TOYOTA\Select from vehicle\China\EZ\-	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\EZ\2012-	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\EZ\2012-	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\FJ Cruiser\-	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\FJ Cruiser\-	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from vehicle\China\FJ Cruiser\-	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\FJ Cruiser\-	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\FJ	Add key,Delete key,Program immo

TOYOTA\Select from vehicle\China\FJ	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Fortuner\200	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Fortuner\200	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Fortuner/Hilu	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from vehicle\China\Fortuner/Hilu	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Fortuner/Hilu	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Fortuner/Hilu	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Fortuner/Hilu	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Fortuner/Hilu	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Fortuner/Hilu	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Fortuner/Hilu	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Fortuner/Hilu	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Hiace\-	Remote program method,
TOYOTA\Select from vehicle\China\Hiace\2006-	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from vehicle\China\Hiace\2006-	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Hiace\2006-	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Hiace\2015-	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Hiace\2015-	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Hiace\2015-	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Highlander\2	Add master key,Add valet key,Delete key,
TOYOTA\Select from vehicle\China\Highlander\2	Add key,Delete key,All key lost,Reset immo

TOYOTA

TOYOTA\Select from vehicle\China\Highlander\2	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Highlander\2	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Highlander\2	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Hilux\Mecha	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from vehicle\China\Hilux\Mecha	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Hilux\Mecha	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Land	Add master key,Add valet key,Delete key,Clear fault
TOYOTA\Select from vehicle\China\Land	Remote program method,
TOYOTA\Select from vehicle\China\Land	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from vehicle\China\Land	Remote program method,
TOYOTA\Select from vehicle\China\Land	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Land	Remote program method,
TOYOTA\Select from vehicle\China\Land	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Land	Remote program method,
TOYOTA\Select from vehicle\China\Land	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Land Cruiser	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Land Cruiser	Remote program method,
TOYOTA\Select from vehicle\China\Land Cruiser	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Land Cruiser	Remote program method,
TOYOTA\Select from vehicle\China\Land Cruiser	Add key,Delete key,All key lost,Reset immo

TOYOTA\Select from vehicle\China\Land Cruiser	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from vehicle\China\Land Cruiser	Remote program method,
TOYOTA\Select from vehicle\China\Land Cruiser	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Land Cruiser	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from vehicle\China\Land Cruiser	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Levin\Mecha	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Levin\Smart	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Previa\2001-	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from vehicle\China\Previa\2001-	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Previa	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Prius/Tarago	Add master key,Add valet key,Delete key,
TOYOTA\Select from vehicle\China\Prius/Tarago	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from vehicle\China\Prius/Tarago	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Prius/Tarago	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Prius/Tarago	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Prius\Mecha	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from vehicle\China\Prius\Mecha	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Prius\Mecha	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Prius\Smart	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Prius+/Prius	Add smart key,Delete smart key,Reset



TOYOTA\Select from vehicle\China\Prius	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Prius	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Prius	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Prius	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Prius	Program remote,Delete remote,
TOYOTA\Select from vehicle\China\Prius	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Prius	Program remote,Delete remote,
TOYOTA\Select from vehicle\China\Prius	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Rav4\Mecha	Add master key,Add valet key,Delete key,
TOYOTA\Select from vehicle\China\Rav4\Mecha	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from vehicle\China\Rav4\Mecha	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Rav4\Mecha	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Rav4	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Sequoia\200	Add master key,Add valet key,Delete key,Clear fault
TOYOTA\Select from vehicle\China\Sequoia\200	Remote program method,
TOYOTA\Select from vehicle\China\Sequoia\200	Add master key,Add valet key,Delete key,Clear fault
TOYOTA\Select from vehicle\China\Sequoia\200	Remote program method,
TOYOTA\Select from vehicle\China\Sequoia\200	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from vehicle\China\Sequoia\200	Program remote,Delete remote,
TOYOTA\Select from vehicle\China\Sequoia\200	Add key,Delete key,Program immo

TOYOTA\Select from vehicle\China\Sequoia\200	Program remote,Delete remote,
TOYOTA\Select from vehicle\China\Sequoia\200	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Sequoia\200	Program remote,Delete remote,
TOYOTA\Select from vehicle\China\Sienna\Mech	Add master key,Add valet key,Delete key,
TOYOTA\Select from vehicle\China\Sienna\Mech	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from vehicle\China\Sienna\Mech	Remote program method,
TOYOTA\Select from vehicle\China\Sienna\Mech	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Sienna\Mech	Remote program method,
TOYOTA\Select from vehicle\China\Sienna\Mech	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Sienna\Mech	Program remote,Delete remote,
TOYOTA\Select from vehicle\China\Sienna\Mech	Remote program method,
TOYOTA\Select from vehicle\China\Sienna\Smar	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Tundra\2000	Program remote,Delete remote,
TOYOTA\Select from vehicle\China\Tundra\2007	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from vehicle\China\Tundra\2007	Program remote,Delete remote,
TOYOTA\Select from vehicle\China\Tundra\2007	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Tundra\2007	Program remote,Delete remote,
TOYOTA\Select from vehicle\China\Tundra\2007	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Tundra\2007	Program remote,Delete remote,
TOYOTA\Select from vehicle\China\Tundra\2007	Add key,Delete key,All key lost,Reset immo

TOYOTA\Select from vehicle\China\Venza\Mech	Program remote,Delete remote,
TOYOTA\Select from vehicle\China\Venza\Mech	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Venza\Mech	Program remote,Delete remote,
TOYOTA\Select from vehicle\China\Venza\Mech	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Venza\Mech	Program remote,Delete remote,
TOYOTA\Select from vehicle\China\Venza\Smart	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Yaris\2008-	Add key,Delete key,All key lost,Reset immo
TOYOTA\Select from vehicle\China\Yaris\2008-	Program remote,Delete remote,
TOYOTA\Select from vehicle\China\Yaris\2008-	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Yaris\2008-	Program remote,Delete remote,
TOYOTA\Select from vehicle\China\Yaris\2008-	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Yaris\2008-	Program remote,Delete remote,
TOYOTA\Select from vehicle\China\Yaris\2013-	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Yaris\2013-	Program remote,Delete remote,
TOYOTA\Select from vehicle\China\Yaris\2013-	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Yaris\2013-	Program remote,Delete remote,
TOYOTA\Select from vehicle\China\Zelas\Mecha	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Zelas\Mecha	Add key,Delete key,Program immo
TOYOTA\Select from vehicle\China\Zelas\Smart	Add smart key,Delete smart key,Reset
TOYOTA\Select from vehicle\China\Vios\Mechan	Add key,Delete key,Program immo

	TOYOTA\Select from vehicle\China\Vios\Mechan	Add key,Delete key,Program immo
	TOYOTA\Select from vehicle\China\Vios\Smart	Add smart key,Delete smart key,Reset
	TOYOTA\Select from vehicle\China\Camry\2004-	Program remote,Delete remote,
	TOYOTA\Select from vehicle\China\Camry\2004-	Remote program method,
	TOYOTA\Select from vehicle\China\Camry\2004-	Program remote,Delete remote,
	TOYOTA\Select from vehicle\China\Camry\2004-	Remote program method,
	TOYOTA\Select from vehicle\China\Crown\-	Add smart key,Delete smart key,Reset smart
	TOYOTA\Select from vehicle\China\Crown\2009-	Add smart key,Delete smart key,Reset
	TOYOTA\Select from vehicle\China\Crown\2009-	Program remote,Add smart key,Reset immo ECU,
	TOYOTA\Select from vehicle\China\Crown\2009-	Program remote,Delete remote,
	TOYOTA\Select from vehicle\China\86\Redeem	Apply for a redemption,Progress
	TOYOTA\Select from vehicle\China\Avalon\Smar	Add smart key,Delete smart key,
	MITSUBISHI\Select from type\Immobilizer\Type 1	All key lost,Register key ID,
	MITSUBISHI\Select from type\Remote\Type 1	Program remote,
	MITSUBISHI\Select from type\Smart key\Type 1	Program smart key,
	MITSUBISHI\Select from type\Immobilizer\Type 2	Program key,
	MITSUBISHI\Select from type\Remote\Type 2	Program remote,
	MITSUBISHI\Select from type\Smart key\Type 2	Program smart key,
	MITSUBISHI\Select from type\Immobilizer\Type 3	Program key,
	MITSUBISHI\Select from type\Remote\Type 3	Program remote,

MITSUBISHI\Select from type\Remote\Type 4	Program remote,
MITSUBISHI\Select from type\Immobilizer\Type 4	Program key,
MITSUBISHI\Select from vehicle\China\Lancer-	Program smart key,
MITSUBISHI\Select from vehicle\China\Lancer-	All key lost,Register key ID,
MITSUBISHI\Select from vehicle\China\Lancer-	Program remote,
MITSUBISHI\Select from vehicle\China\Outlander\	Program smart key,
MITSUBISHI\Select from vehicle\China\ASX\Smart	Program smart key,
MITSUBISHI\Select from vehicle\China\ASX\Immobil	Program key,
MITSUBISHI\Select from vehicle\China\ASX\Remote	Program remote,
MITSUBISHI\Select from vehicle\China\TRITON\	Program key,
MITSUBISHI\Select from vehicle\China\TRITON\	Program key,
MITSUBISHI\Select from vehicle\China\TRITON\	Program remote,
MITSUBISHI\Select from vehicle\China\TRITON\	Program remote,
MITSUBISHI\Select from vehicle\China\TRITON\201	Program key,
MITSUBISHI\Select from vehicle\China\TRITON\201	Program key,
MITSUBISHI\Select from vehicle\China\TRITON\201	Program remote,
MITSUBISHI\Select from vehicle\China\TRITON\201	Program remote,
MITSUBISHI\Select from vehicle\China\Pajero	Program key,
MITSUBISHI\Select from vehicle\China\Pajero	Program remote,
MITSUBISHI\Select from type\Immobilizer\Type 5	Add key,

MITSUBISHI\Select from vehicle\China\V73\Immobilizer	Add key,
MITSUBISHI\Select from vehicle\China\V97\Immobilizer	Add key,
MITSUBISHI\Select from vehicle\China\Galant\Immobilizer	Add key,
MITSUBISHI\Select from vehicle\China\Grandis\Immobilizer	Add key,
MITSUBISHI\Select from vehicle\China\Pajero	Add key,
MITSUBISHI\Select from vehicle\China\Pajero	Program key,
MITSUBISHI\Select from vehicle\China\Pajero	Program remote,
MITSUBISHI\Select from vehicle\China\Pajero	Add key,
MITSUBISHI\Select from vehicle\China\Outlander\2004	Program smart key,
MITSUBISHI\Select from type\Immobilizer\Type 6	Program key,
MITSUBISHI\Select from type\Immobilizer\Type 7	All key lost,
MITSUBISHI\Select from type\Immobilizer\Type 8	Add key,
MITSUBISHI\Select from type\Immobilizer\Type 9	All key lost,Key count,
MITSUBISHI\Select from type\Immobilizer\Type 10	All key lost,Key count,
MITSUBISHI\Select from type\Smart key\Type 3	Program smart key,
MITSUBISHI\Select from type\Smart key\Type 4	Add smart key,Key count,
MITSUBISHI\Select from type\Remote\Type 5	Program remote,
MITSUBISHI\Select from type\Remote\Type 6	Program remote,
MITSUBISHI\Select from type\Remote\Type 7	Program remote,
MITSUBISHI\Select from type\Remote\Type 8	Program remote,

MITSUBISHI\Select from type\Immobilizer\Type 1	Program key,
MITSUBISHI\Select from vehicle\China\Mirage\With	Add smart key,Key count,
MITSUBISHI\Select from vehicle\China\Mirage\With	Add key,Program remote,
MITSUBISHI\Select from type\Immobilizer\Type 12	Program key,
MITSUBISHI\Select from type\Immobilizer\Type 13	Program key,
MITSUBISHI\Select from vehicle\China\Lancer\Immo	Program key,
MITSUBISHI\Select from vehicle\China\Lancer\Rem	Program remote,
MITSUBISHI\Select from vehicle\China\Outlander\-	Program key,
MITSUBISHI\Select from vehicle\China\Outlander\-	Program remote,
MITSUBISHI\Select from vehicle\Australia\3000gt	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Australia\Airtrek	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Australia\ASX\With	Program smart key,
MITSUBISHI\Select from vehicle\Australia\ASX\With	Program key,
MITSUBISHI\Select from vehicle\Australia\Colt	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Australia\Challenge	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\Australia\Express\1	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\Australia\Express	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Australia\EVO\Typ	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Australia\EVO\Typ	Program key,
MITSUBISHI\Select from vehicle\Australia\Galant	Add key,Reset immo ECU,

MITSUBISHI\Select from vehicle\Australia\Lancer\19	Add key,Reset immobiliser,
MITSUBISHI\Select from vehicle\Australia\Lancer\20	Add key,Reset immobiliser,
MITSUBISHI\Select from vehicle\Australia\Lancer(C	Program key,
MITSUBISHI\Select from vehicle\Australia\Lancer	Add key,Reset immobiliser,
MITSUBISHI\Select from vehicle\Australia\Lancer(sp	Program key,
MITSUBISHI\Select from vehicle\Australia\Lancer	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Australia\Lancer	Program key,
MITSUBISHI\Select from vehicle\Australia\Mirage\19	Add key,Reset immobiliser,
MITSUBISHI\Select from vehicle\Australia\Mirage\19	Add key,Reset immobiliser,
MITSUBISHI\Select from vehicle\Australia\Mirage\-	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Australia\Mirage\20	Program smart key,
MITSUBISHI\Select from vehicle\Australia\Nimbus\1	Add key,Reset immobiliser,
MITSUBISHI\Select from vehicle\Australia\Nimbus\1	Add key,Reset immobiliser,
MITSUBISHI\Select from vehicle\Australia\CJ	Program key,
MITSUBISHI\Select from vehicle\Australia\CJ	Program key,
MITSUBISHI\Select from vehicle\Australia\CJ	Program key,
MITSUBISHI\Select from vehicle\Australia\CJ	Program key,
MITSUBISHI\Select from vehicle\Australia\CJ	Program key,
MITSUBISHI\Select from vehicle\Australia\Outlander	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Australia\Outlander	All key lost,Program remote,



MITSUBISHI\Select from vehicle\Australia\Outlander	Program smart key,
MITSUBISHI\Select from vehicle\Australia\Pajero\19	Add key,Reset immobiliser,
MITSUBISHI\Select from vehicle\Australia\Pajero\20	Add key,Reset immobiliser,
MITSUBISHI\Select from vehicle\Australia\Pajero	Add key,Reset immobiliser,
MITSUBISHI\Select from vehicle\Australia\Star	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Australia\Trion	Add key,Reset immobiliser,
MITSUBISHI\Select from vehicle\Australia\Trion	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Australia\Trion	Program key,
MITSUBISHI\Select from vehicle\Australia\Verada\1	Add key,Reset immobiliser,
MITSUBISHI\Select from vehicle\Africa\Lancer\2006-	Program key,
MITSUBISHI\Select from vehicle\Africa\L200	Add key,Reset immobiliser,
MITSUBISHI\Select from vehicle\Africa\Outlander\20	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Africa\Pajero\1999-	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Africa\Shogun\200	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\America\USA\Diam	Add key,Reset immobiliser,
MITSUBISHI\Select from vehicle\America\USA\Eclip	Add key,Reset immobiliser,
MITSUBISHI\Select from vehicle\America\USA\Eclip	All key lost,Key count,
MITSUBISHI\Select from vehicle\America\USA\Ende	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\America\USA\Ende	All key lost,Key count,
MITSUBISHI\Select from vehicle\America\USA\EVO	Add key,Reset immo ECU,

MITSUBISHI\Select from vehicle\America\USA\Gala	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\America\USA\Gala	All key lost,Key count,
MITSUBISHI\Select from vehicle\America\USA\Gala	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\America\USA\Gala	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\America\USA\Gala	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\America\USA\Gala	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\America\USA\Lanc	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\America\USA\Lanc	Program key,
MITSUBISHI\Select from vehicle\America\USA\Mira	Program smart key,
MITSUBISHI\Select from vehicle\America\USA\Mont	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\America\USA\Mont	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\America\USA\Mont	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\America\USA\Outla	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\America\USA\Outla	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\America\USA\Outla	All key lost,Key count,
MITSUBISHI\Select from vehicle\America\USA\Outla	Program smart key,
MITSUBISHI\Select from vehicle\America\USA\Outla	Program smart key,
MITSUBISHI\Select from vehicle\America\USA\Outla	Program key,
MITSUBISHI\Select from vehicle\America\USA\RVR\	Program key,
MITSUBISHI\Select from vehicle\America\USA\RVR\	Program key,

MITSUBISHI\Select from vehicle\America\South	Program key,
MITSUBISHI\Select from vehicle\America\South	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\America\South	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\America\South	All key lost,Key count,
MITSUBISHI\Select from vehicle\America\South	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\America\South	All key lost,Key count,
MITSUBISHI\Select from vehicle\America\South	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\America\South	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\America\South	All key lost,Key count,
MITSUBISHI\Select from vehicle\America\South	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\America\South	Program key,
MITSUBISHI\Select from vehicle\America\South	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\America\South	Program key,
MITSUBISHI\Select from vehicle\America\South	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\America\South	Program key,
MITSUBISHI\Select from vehicle\America\South	Program smart key,
MITSUBISHI\Select from vehicle\America\South	Program key,
MITSUBISHI\Select from vehicle\America\South	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Europe\3000gt	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Europe\ASX\With	Program smart key,

mitsubishi

MITSUBISHI\Select from vehicle\Europe\ASX\Witho	Program key,
MITSUBISHI\Select from vehicle\Europe\Carisma	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Europe\Colt Lander	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Europe\Eclipse	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Europe\EVO\Type	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Europe\EVO\Type	Program key,
MITSUBISHI\Select from vehicle\Europe\Galant	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Europe\Galant\199	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Europe\Grandis	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Europe\I-miev	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Europe\L200	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Europe\L200\CAN\	Program key,
MITSUBISHI\Select from vehicle\Europe\L400	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Europe\Lancer	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Europe\Lancer	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Europe\Lancer	Program key,
MITSUBISHI\Select from vehicle\Europe\Lancer[CA	Program key,
MITSUBISHI\Select from vehicle\Europe\Lancer	Program key,
MITSUBISHI\Select from vehicle\Europe\Mirage\201	Program smart key,
MITSUBISHI\Select from vehicle\Europe\Magnum	Add key,Reset immo ECU,

MITSUBISHI\Select from vehicle\Europe\Outlander\	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Europe\Outlander\	Program smart key,
MITSUBISHI\Select from vehicle\Europe\Outlander[	Program key,
MITSUBISHI\Select from vehicle\Europe\Pajero\199	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Europe\Pajero	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Europe\Shogun	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Europe\Sigma	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Europe\Space	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Japan\Carism	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\Asia\Japan\Colt\19	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\Asia\Japan\Eclipse\	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\Asia\Japan\Galant[	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\Asia\Japan\Galant[	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\Asia\Japan\Lancer\	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\Asia\Japan\Lancer\	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\Asia\Japan\Lancer	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\Asia\Japan\L200\1	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\Asia\Japan\Monter	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\Asia\Japan\Monter	Add key,Reset immobilser,
MITSUBISHI\Select from vehicle\Asia\Japan\Monter	Add key,Reset immobilser,

MITSUBISHI\Select from vehicle\Asia\Japan\Monter	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Asia\Japan\Nativa\	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Asia\Japan\Pajero\	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Asia\Japan\Pajero\	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Asia\Japan\Pajero	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Asia\Japan\Pajero	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Asia\Japan\Pajero	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Asia\Japan\Shogun	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Asia\Japan\Shogun	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Asia\Japan\Shogun	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Asia\Japan\Shogun	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Asia\Japan\Space	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Asia\Japan\Space	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Asia\Japan\Space	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Asia\Japan\Space	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Asia\Japan\Space	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Asia\Japan\Space	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Asia\Japan\Space	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Asia\Japan\Space	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Asia\Japan\3000	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Asia\Israel\Carisma	Add key,Reset immo ECU,

MITSUBISHI\Select from vehicle\Asia\Israel\Eclipse	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Israel\Eclipse	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Israel\Endeav	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Israel\Galant\1	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Israel\Grandis	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Israel\GT3000	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Israel\L200\20	Program key,
MITSUBISHI\Select from vehicle\Asia\Israel\L400	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Israel\Lancer\	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Israel\Lancer\	Program key,
MITSUBISHI\Select from vehicle\Asia\Israel\Mirage	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Israel\Magun	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Israel\Nativa	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Israel\Outland	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Israel\Outland	Program smart key,
MITSUBISHI\Select from vehicle\Asia\Israel\Pajero	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Israel\Sigma	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Israel\Spacew	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Israel\Spacew	Program smart key,
MITSUBISHI\Select from vehicle\Asia\Israel\Space\S	Add key,Reset immo ECU,

MITSUBISHI\Select from vehicle\Asia\Israel\Strada	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Other\Delica\2	Program key,
MITSUBISHI\Select from vehicle\Asia\Other\EVO 8	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Other\EVO 9	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Other\EVO10\	Program key,
MITSUBISHI\Select from vehicle\Asia\Other\EVO10\	Program key,
MITSUBISHI\Select from vehicle\Asia\Other\Grandis	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Other\Lancer\	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Other\Lancer\	Program key,
MITSUBISHI\Select from vehicle\Asia\Other\L200	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Asia\Other\L200	Program key,
MITSUBISHI\Select from vehicle\Asia\Other\L200	Program key,
MITSUBISHI\Select from vehicle\Asia\Other\L200	All key lost,
MITSUBISHI\Select from vehicle\Asia\Other\Outland	Program key,
MITSUBISHI\Select from vehicle\Asia\Other\Pajero\	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Greece\Carisma\19	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Greece\Colt\1996-	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Greece\Colt	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Greece\Galant\199	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Greece\Lancer\199	Add key,Reset immobillser,



MITSUBISHI\Select from vehicle\Greece\Lancer	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Greece\L200\1999-	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Greece\Pajero\199	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Greece\Pajero	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Greece\Pajero	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Greece\Pajero	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Greece\Space	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Greece\Space	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Greece\Space	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Greece\Space	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Greece\3000gt\199	Add key,Reset immobillser,
MITSUBISHI\Select from vehicle\Middle East\Eclipse	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Middle East\Eclipse	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Middle	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Middle	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Middle	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Middle	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Middle	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Middle	Program key,
MITSUBISHI\Select from vehicle\Middle East\L200\	Add key,Reset immo ECU,

MITSUBISHI\Select from vehicle\Middle East\Magna	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Middle East\Nativa	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Middle	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Middle	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Middle East\Strada	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Middle	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\Middle East\Sigma	Add key,Reset immo ECU,
MITSUBISHI\Select from vehicle\China\Pajero	Program smart key,Turn ignition on forcibly,Turn
MITSUBISHI\Select from vehicle\China\TRITON\201	Program smart key,Turn ignition on forcibly,Turn
MITSUBISHI\Select from vehicle\China\Attraga\2015	Program smart key,
MITSUBISHI\Select from vehicle\Australia\Outlander	Program remote,Add key,
MITSUBISHI\Select from vehicle\Australia\Outlander	Program smart key,
MITSUBISHI\Select from vehicle\Australia\Outlander	Program smart key,
MITSUBISHI\Select from vehicle\America\USA\Gala	Add key,Reset immobiliser,
MITSUBISHI\Select from vehicle\America\USA\Gala	All key lost,Key count,
MITSUBISHI\Select from vehicle\China\Attraga\-	All key lost,
MITSUBISHI\Select from vehicle\China\Attraga\-	Program remote,
MITSUBISHI\Select from vehicle\China\Phantom\Wit	All key lost,
MITSUBISHI\Select from vehicle\China\Phantom\Wit	Program remote,
MITSUBISHI\Select from vehicle\China\Phantom\Wit	Program smart key,

MITSUBISHI\Select from vehicle\China\Phantom\Wit	Program smart key,
MITSUBISHI\Select from vehicle\China\Phantom\Wit	Program remote,
MITSUBISHI\Select from vehicle\China\Outlander\20	Add key,
MITSUBISHI\Select from vehicle\China\Outlander\20	Program remote,
MITSUBISHI\Select from vehicle\China\Outlander\20	Add key,
MITSUBISHI\Select from vehicle\China\Outlander\20	Program remote,
MITSUBISHI\Select from vehicle\China\Mirage\With	Program smart key,
MITSUBISHI\Generate LKE for all key lost	Generate LKE for all key lost,
MITSUBISHI\Register key ID and VIN to engine	Register key ID to engine,Register VIN to
MITSUBISHI\Select from vehicle\China\Xpander\201	Program smart key,Turn ignition on forcibly,Turn
MITSUBISHI\Help (Mitsubishi's PIN)	Help (Mitsubishi's PIN),
MITSUBISHI\Select from vehicle\China\Attraga\-	Program smart key,
HONDA\Select from type\Immobilizer\16-Pin	Add one key,All key lost,Reset key,
HONDA\Select from type\Immobilizer\16-Pin	Add one key,All key lost,Reset key,
HONDA\Select from type\Smart key\Knob type	Add one key,All key lost,Detect smart key,
HONDA\Select from type\Smart key\Button type	Add one key,All key lost,
HONDA\Select from type\Remote\IMMO9	Add remote,Delete remote,
HONDA\Select from type\Immobilizer\16-Pin	Add key,All key lost,Reset immobiliser,
HONDA\Select from type\Immobilizer\16-Pin	Reset immobox,Reset ECM,
HONDA\Select from type\Immobilizer\16-Pin	Immo type,

HONDA\Select from type\Smart key\Button type	Add 1 key,All key lost,
HONDA\Select from type\Smart key\Button type	Add 1 key,All key lost,
HONDA\Select from type\Immobilizer\3-Pin	Search IMMO type,
HONDA\Select from type\Immobilizer\3-Pin	Add 1 key,All key lost,Reset key,
HONDA\Select from type\Immobilizer\3-Pin	Add one key,All key lost,Reset key,
HONDA\Select from type\Immobilizer\3-Pin	Add key,All key lost,Odometer adjustment,
HONDA\Select from type\Immobilizer\3-Pin	Reset immobox,Reset ECM,
HONDA\Select from vehicle\Europe\S2000\200	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Europe\S2000\200	Read key count,All key lost,
HONDA\Select from vehicle\Europe\Legend\20	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Europe\Legend\19	Reset immobox,Reset ECM,
HONDA\Select from vehicle\Europe\Jazz\2008-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Europe\Jazz\2008-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Europe\Insight\201	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Europe\Insight\199	Read key count,All key lost,
HONDA\Select from vehicle\Europe\Hrv\2000-	Read key count,All key lost,
HONDA\Select from vehicle\Europe\Hrv\2000-	Add key,All key lost,Reset immobiliser,
HONDA\Select from vehicle\Europe\Frv	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Europe\Element\20	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Europe\Crz\2010-	Add one key,All key lost,Reset key,

HONDA\Select from vehicle\Europe\Crv\2013-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Europe\Crv\2007-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Europe\Crv\2002-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Europe\Crv\2001	Read key count,All key lost,
HONDA\Select from vehicle\Europe\Crv\2001	Add key,All key lost,Reset immobiliser,
HONDA\Select from vehicle\Europe\Civic\2006-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Europe\Civic\2001-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Europe\City\2008-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Europe\Accord\200	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Europe\Accord\200	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Europe\Accord\-	Add key,All key lost,Reset immobiliser,
HONDA\Select from vehicle\Middle	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Middle	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\India\Mobilo	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\India\Jazz	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\India\Crv\2007-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\India\Crv\2006	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\India\Civic	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\India\City	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\India\Brio	Add one key,All key lost,Reset key,

HONDA\Select from vehicle\India\Accord\2008-	Add key,All key lost,Reset immobiliser,
HONDA\Select from vehicle\India\Accord\2003-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\India\Accord\1997-	Read key count,All key lost,
HONDA\Select from vehicle\India\Amaze	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\S2000	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Prelude\1	Reset immobox,Reset ECM,
HONDA\Select from vehicle\Australia\Odyssey\	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Odyssey\	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Odyssey\	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Odyssey\	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Odyssey\	Reset immobox,Reset ECM,
HONDA\Select from vehicle\Australia\Odyssey\	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Odyssey\	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\NSX\Type	Reset immobox,Reset ECM,
HONDA\Select from vehicle\Australia\NSX\Type	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\MDX\200	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Legend\2	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Legend\2	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Legend\1	Reset immobox,Reset ECM,
HONDA\Select from vehicle\Australia\Legend\1	Add one key,All key lost,Reset key,

HONDA

HONDA\Select from vehicle\Australia\Jazz\2008	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Jazz\2002	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Integra\20	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Integra\19	Reset immobox,Reset ECM,
HONDA\Select from vehicle\Australia\Insight\20	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Insight\20	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Hrv\1999-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Crv\2007-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Crv\2002-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Crv\1999-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Crv\1999-	Add key,All key lost,Reset immobiliser,
HONDA\Select from vehicle\Australia\Crv\1997-	Reset immobox,Reset ECM,
HONDA\Select from vehicle\Australia\Crv\1997-	Add key,All key lost,Reset immobiliser,
HONDA\Select from vehicle\Australia\Civic type	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Civic\200	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Civic\199	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Civic\199	Reset immobox,Reset ECM,
HONDA\Select from vehicle\Australia\City\2009-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Accord\20	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Australia\Accord\20	Add one key,All key lost,Reset key,

HONDA\Select from vehicle\Australia\Accord\20	Add key,All key lost,Reset immobiliser,
HONDA\Select from vehicle\Australia\Accord\19	Reset immobox,Reset ECM,
HONDA\Select from vehicle\Australia\Accord\19	Add key,All key lost,Reset immobiliser,
HONDA\Select from vehicle\Asia\Stepwagon\-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\Stream\Remot	Add remote,Delete remote,
HONDA\Select from vehicle\Asia\Stream\Mecha	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\Stream\Mecha	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\S2000\2007-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\Odyssey\2008	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\Odyssey\1999	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\Integra\2002	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\Jazz\Mechani	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\Jazz\Mechani	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\Hrv\2014-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\Fit\2007-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\Fit\2007-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\Elysion\2005-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia>Edit\2006-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\Crv\2006-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\Crv\2002-	Add one key,All key lost,Reset key,



HONDA\Select from vehicle\Asia\Civic type	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\Civic type	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\Civic\2006-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\Civic\2005	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\City\Mechanic	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\City\Mechanic	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\Airwave\2006-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\Accord\2008-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Asia\Accord\1998-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Africa\Jazz\2009-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Africa\Jazz\2006-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\Africa\Brio	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\South	Reset immobox,Reset ECM,
HONDA\Select from vehicle\South	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\South	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\South	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\South	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\South	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\South	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\South	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Accord\1998-	Read key count,All key lost,
HONDA\Select from vehicle\USA\Accord\2003-	Add one key,All key lost,Reset key,

HONDA\Select from vehicle\USA\Accord\2008-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Accord\2008-	Add remote>Delete remote,
HONDA\Select from vehicle\USA\Accord\2013-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Accord\2014-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Accord\2016\	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Crv\2002-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Crv\2007-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Crv\2007-	Add remote>Delete remote,
HONDA\Select from vehicle\USA\Crv\2015-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Crv\2015-	Add remote>Delete remote,
HONDA\Select from vehicle\USA\Crz\2013	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Civic\2001-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Civic\2006-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Civic\2006-	Add remote>Delete remote,
HONDA\Select from vehicle\USA\Civic\2014-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Civic\2014-	Add remote>Delete remote,
HONDA\Select from vehicle\USA\Crosstour\201	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Crosstour\201	Add remote>Delete remote,
HONDA\Select from vehicle\USA\Element\2003	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Fit\2007-2008	Add one key,All key lost,Reset key,

HONDA\Select from vehicle\USA\Fit\2009-2013	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Fit\2014-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Fit\2014-	Add remote>Delete remote,
HONDA\Select from vehicle\USA\Hrv\2016\Mec	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Hrv\2016\Re	Add remote>Delete remote,
HONDA\Select from vehicle\USA\Insight\2000-	Read key count,All key lost,
HONDA\Select from vehicle\USA\Insight\2010-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Odyssey\199	Read key count,All key lost,
HONDA\Select from vehicle\USA\Odyssey\200	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Odyssey\201	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Odyssey\201	Add remote>Delete remote,
HONDA\Select from vehicle\USA\Pilot\2005-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Pilot\2009-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Pilot\2009-	Add remote>Delete remote,
HONDA\Select from vehicle\USA\Prelude	Read key count,All key lost,
HONDA\Select from vehicle\USA\Ridgeline\200	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\S2000\2000-	Read key count,All key lost,
HONDA\Select from vehicle\USA\S2000\2006-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Xrv\2010-	Add one key,All key lost,Reset key,
HONDA\Select from vehicle\USA\Xrv\2010-	Add remote>Delete remote,

	HONDA\Select from vehicle\USA\Veze\2010-	Add one key,All key lost,Reset key,
	HONDA\Select from vehicle\USA\Veze\2010-	Add remote,Delete remote,
	HONDA\Select from type\Immobilizer\16-Pin	Read key count,All key lost,
	LEXUS\Select from vehicle\ES240\Smart key	Add smart key,Delete smart key,
	LEXUS\Select from vehicle\CT200H\2012-	Add smart key,Delete smart key,
	LEXUS\Select from vehicle\ES250\2012-	Add smart key,Delete smart key,
	LEXUS\Select from vehicle\ES350\Smart key	Add smart key,Delete smart key,
	LEXUS\Select from vehicle\RX270\Smart key	Add smart key,Delete smart key,
	LEXUS\Select from vehicle\IS300\Smart key	Smart key registration,Delete smart
	LEXUS\Select from vehicle\GS300\2006-	Smart key registration,Delete smart
	LEXUS\Select from vehicle\ES200\Smart key	Add smart key,Delete smart key,
	LEXUS\All smart key lost\All key lost	Backup EEPROM data,Generate SKE,Bind
	LEXUS\Select from vehicle\CT200H\2010\Sma	Add smart key,Delete smart key,Reset
	LEXUS\Select from vehicle\ES300\2002-	Add master key,Add valet key,Delete key,Clear fault
	LEXUS\Select from vehicle\ES300\2002-	Remote program method,
	LEXUS\Select from vehicle\ES300H\2012-	Add smart key,Delete smart key,Reset
	LEXUS\Select from vehicle\ES330\2003-	Add key,Delete key,All key lost,Reset immo
	LEXUS\Select from vehicle\GS300\1998-	Program remote,Delete remote,
	LEXUS\Select from vehicle\GS300\2002-	Add master key,Add valet key,Delete key,Clear fault
	LEXUS\Select from vehicle\GS300\2002-	Program remote,Delete remote,

LEXUS\Select from vehicle\GS300\2006-	Add smart key,Delete smart key,Reset
LEXUS\Select from vehicle\GS350\2006-	Add smart key,Delete smart key,Reset
LEXUS\Select from vehicle\GS350\2006-	Smart key registration,Delete smart
LEXUS\Select from vehicle\GS350\2009-	Add smart key,Delete smart key,Reset
LEXUS\Select from vehicle\GS430\2001-	Add master key,Add valet key,Delete key,Clear fault
LEXUS\Select from vehicle\GS430\2001-	Program remote,Delete remote,
LEXUS\Select from vehicle\GS430\2005-	Smart key registration,Delete smart
LEXUS\Select from vehicle\GS430\2006-	Add smart key,Delete smart key,Reset
LEXUS\Select from vehicle\GS450H\2007-	Add smart key,Delete smart key,Reset
LEXUS\Select from vehicle\GS450H\2008-	Add smart key,Delete smart key,Reset
LEXUS\Select from vehicle\GS460\2008-	Add smart key,Delete smart key,Reset
LEXUS\Select from vehicle\GX460\2003-	Add key,Delete key,All key lost,Reset immo
LEXUS\Select from vehicle\GX460\2010-	Add smart key,Delete smart key,Reset
LEXUS\Select from vehicle\GX470\2003-	Add key,Delete key,All key lost,Reset immo
LEXUS\Select from vehicle\GX470\2003-	Program remote,Delete remote,
LEXUS\Select from vehicle\GX470\2003-	Remote program method,
LEXUS\Select from vehicle\HS250H\2008-	Add smart key,Delete smart key,Reset
LEXUS\Select from vehicle\IS200\Mechanical	Remote program method,
LEXUS\Select from vehicle\IS250\2006-	Smart key registration,Delete smart
LEXUS\Select from vehicle\IS250\2011\Smart	Add smart key,Delete smart key,Reset

## LEXUS

LEXUS\Select from vehicle\IS250\2012-	Add smart key,Delete smart key,Reset
LEXUS\Select from vehicle\IS250\2014-\Smart	Add smart key,Delete smart key,Reset
LEXUS\Select from vehicle\IS250C\2009-	Add smart key,Delete smart key,Reset
LEXUS\Select from vehicle\IS300\Mechanical	Add master key,Add valet key,Delete key,Clear fault
LEXUS\Select from vehicle\IS300\Mechanical	Program remote,Delete remote,
LEXUS\Select from vehicle\IS350\2006-	Smart key registration,Delete smart
LEXUS\Select from vehicle\IS250\2014-	Add smart key,Delete smart key,Reset
LEXUS\Select from vehicle\LS400\1998-	Program remote,Delete remote,
LEXUS\Select from vehicle\LS430\2001-	Add master key,Add valet key,Delete key,Clear fault
LEXUS\Select from vehicle\LS430\2001-	Program remote,Delete remote,
LEXUS\Select from vehicle\LS430\2001-	Remote program method,
LEXUS\Select from vehicle\LS430\2001-	Add key,Delete key,All key lost,Reset immo
LEXUS\Select from vehicle\LS430\2001-	Program remote,Delete remote,
LEXUS\Select from vehicle\LS430\2001-	Remote program method,
LEXUS\Select from vehicle\LS430\2001-	Smart key registration,Delete smart
LEXUS\Select from vehicle\LS460\2007-	Add smart key,Delete smart key,Reset
LEXUS\Select from vehicle\LS460\2013-\Smart	Add smart key,Delete smart key,Reset
LEXUS\Select from vehicle\LS460H\2007-	Remote program method,
LEXUS\Select from vehicle\LS460H\2007-	Add smart key,Delete smart key,Reset
LEXUS\Select from vehicle\LS460H\2008-	Remote program method,

LEXUS>Select from vehicle\LX470\2001-	Add master key,Add valet key,Delete key,Clear fault
LEXUS>Select from vehicle\LX470\2003-	Add key,Delete key,All key lost,Reset immo
LEXUS>Select from vehicle\LX470\2003-	Program remote,Delete remote,
LEXUS>Select from vehicle\LX470\2003-	Remote program method,
LEXUS>Select from vehicle\LX570\2008-	Add smart key,Delete smart key,Reset
LEXUS>Select from vehicle\RX300\1999-	Program remote,Delete remote,
LEXUS>Select from vehicle\RX300\2003-	Add key,Delete key,All key lost,Reset immo
LEXUS>Select from vehicle\RX300\2003-	Program remote,Delete remote,
LEXUS>Select from vehicle\RX300\2003-	Remote program method,
LEXUS>Select from vehicle\RX330\2004-	Add key,Delete key,All key lost,Reset immo
LEXUS>Select from vehicle\RX330\2004-	Program remote,Delete remote,
LEXUS>Select from vehicle\RX330\2004-	Remote program method,
LEXUS>Select from vehicle\RX350\2007-	Add key,Delete key,All key lost,Reset immo
LEXUS>Select from vehicle\RX350\2007-	Program remote,Delete remote,
LEXUS>Select from vehicle\RX350\2007-	Remote program method,
LEXUS>Select from vehicle\RX350\2010-	Add smart key,Delete smart key,Reset
LEXUS>Select from vehicle\RX400H\2005-	Add key,Delete key,All key lost,Reset immo
LEXUS>Select from vehicle\RX400H\2005-	Program remote,Delete remote,
LEXUS>Select from vehicle\RX400H\2005-	Remote program method,
LEXUS>Select from vehicle\RX450H\2010-	Add smart key,Delete smart key,Reset

	LEXUS\Select from vehicle\RX450H\2012\Sma	Add smart key,Delete smart key,Reset
	LEXUS\Select from vehicle\SC430\2002-	Add key,Delete key,All key lost,Reset immo
	LEXUS\Select from vehicle\SC430\2002-	Program remote,Delete remote,
	LEXUS\Select from vehicle\SC430\2002-	Remote program method,
	LEXUS\Select from type\IMMO\Type 1	Add master key,Add valet key,Delete key,Clear fault
	LEXUS\Select from type\IMMO\Type 2	Add key,Delete key,All key lost,Reset immo
	LEXUS\Select from type\Remote	Program remote,Delete remote,
	LEXUS\Select from type\PEPS\Type 1	Add smart key,Delete smart key,Reset
	LEXUS\Select from type\PEPS\Type 2	Smart key registration,Delete smart
	LEXUS\Select from vehicle\IS250C\2009-	Add smart key,Delete smart key,Reset smart
	LEXUS\Select from vehicle\RX300\1999-	Add master key,Add valet key,Delete key,Clear fault
DS	DS\Select from vehicle\DS4\Smart key	All smart key lost,
	DS\Read PIN code	Type 1,Type 2,Type 3,Type 4 (K line),
	DS\Select from type\Immobilizer\Type 1	Program key,
	DS\Select from type\Smart key\Type 1	All smart key lost,
	DS\Select from type\Immobilizer\Type 3	Program key,
	DS\Select from type\Immobilizer\Type 2	Program key,
	DS\Select from vehicle\DS5\Immobilizer\Ty	Program key,
	DS\Select from vehicle\DS5\Immobilizer\Ty	Program key,
	DS\Select from vehicle\DS3\Immobilizer	Program key,



	DS>Select from vehicle\DS4\Immobilizer	Program key,
	DS>Select from vehicle\DS5\Immobilizer\Ty	Program key,
	DS>Select from vehicle\DS6\Immobilizer	Program key,
	DS>Select from vehicle\DS5\Smart key	All smart key lost,
	DS>Select from vehicle\DS6\Smart key	All smart key lost,
	DS>Select from type\Immobilizer\Type 4	Read key/remote count,Program immo
	DS>Select from type\Replace engine	Replace engine ECU,
	SUBARU>Select from type\Immobilizer\Type 1	All key lost,
	SUBARU>Select from type\Smart key\Type C	Add smart key,Delete smart key,Register smart
	SUBARU>Select from type\Smart key\Type	Reset PEPS,Add smart key,Delete smart
	SUBARU>Select from type\Immobilizer\Type	Add key,Delete key,Detect key count,Register
	SUBARU>Select from type\Remote\Type 1	Add remote,Clear remote,
	SUBARU>Select from type\Immobilizer\Type 3	Add key,Read PIN code,
	SUBARU>Select from type\Immobilizer\Type 4	Key count,Add key,
	SUBARU>Select from type\Immobilizer\Type 5	Key count,Add key,Delete key,Add remote,Delete
	SUBARU>Select from type\Smart key\Type 3	Key count,Add key,Delete key,Add remote,Delete
	SUBARU>Select from type\Smart key\Type 4	Key count,Add key,
	SUBARU>Select from type\Remote\Type 2	Add remote,
	SUBARU>Select from type\Remote\Type 3	Add remote,
	SUBARU>Select from type\Immobilizer\Type	Check key count,Add key,All key lost,Delete

## SUBARU

SUBARU>Select from type\Smart key\Type 5	Add smart key,Delete smart key,Generate LKE,
SUBARU>Select from vehicle\B4\2009-	Add smart key,Delete smart key,Key count,Read
SUBARU>Select from vehicle\Baja\2005-2007	All key lost,
SUBARU>Select from vehicle\Brz\2013-Without	Key count,Add key,Delete key,Add remote,Delete
SUBARU>Select from vehicle\Brz\2013-With	Add smart key,Delete smart key,Generate LKE,
SUBARU>Select from vehicle\Crosstrek\2014-	Check key count,Add key,All key lost,Delete
SUBARU>Select from vehicle\Crosstrek\2014-	Add smart key,Delete smart key,Detect key
SUBARU>Select from vehicle\Forester\2013 -	Check key count,Add key,All key lost,Delete
SUBARU>Select from vehicle\Forester\2013 -	Add smart key,Delete smart key,Detect key
SUBARU>Select from vehicle\Impreza\Without	All key lost,
SUBARU>Select from vehicle\Impreza\Without	Check key count,Add key,All key lost,Delete
SUBARU>Select from vehicle\Impreza\With	Add smart key,Delete smart key,Key count,Read
SUBARU>Select from vehicle\Impreza\With	Add smart key,Delete smart key,Detect key
SUBARU>Select from vehicle\Legacy\Without	All key lost,
SUBARU>Select from vehicle\Legacy\With smart	Add smart key,Delete smart key,Key count,Read
SUBARU>Select from vehicle\Levorg\2015-Without	Add smart key,Delete smart key,Detect key
SUBARU>Select from vehicle\Outback\Without	All key lost,
SUBARU>Select from vehicle\Outback\Without	Add key,Read PIN code,
SUBARU>Select from vehicle\Sti	All key lost,
SUBARU>Select from vehicle\Tribeca\Without	All key lost,

	SUBARU>Select from vehicle\Tribeca\Without	Key count,Add key,Delete key,Add remote,Delete
	SUBARU>Select from vehicle\Tribeca\With	Add smart key,Delete smart key,Generate LKE,
	SUBARU>Select from vehicle\XV\2013-Without	Check key count,Add key,All key lost,Delete
	SUBARU>Select from vehicle\XV\2013-With	Add smart key,Delete smart key,Detect key
	SUBARU>Select from vehicle\XV	Check key count,Add key,All key lost,Delete
	SUBARU>Select from vehicle\XV	Add smart key,Delete smart key,Detect key
	SUBARU>Select from vehicle\WRX\-	All key lost,
	SUBARU>Select from vehicle\WRX\2014-	Check key count,Add key,All key lost,Delete
	SUBARU>Select from vehicle\WRX\2014-With	Add smart key,Delete smart key,Detect key
	SUBARU>Select from vehicle\Liberty\2009-	Add smart key,Delete smart key,Key count,Read
	SUBARU>Select from vehicle\Liberty\2014-With	Add smart key,Delete smart key,Key count,Read
	SUBARU>Select from vehicle\Liberty\2014-	All key lost,
	SUBARU>Select from vehicle\Forester\2017-	Add smart key,Delete smart key,Detect key
	SUBARU>Select from vehicle\Outback\With	Add smart key,Delete smart key,Detect key
BENTLEY	BENTLEY\Flying Spur\2012 \Immobilizer	Learn key,Read PIN code,
	BENTLEY\Mulsanne\6.8 liter\Immobilizer/Smart key	Backup immo data,Make dealer key,Learn key,Clear
SMART	SMART\BR451\Immobilizer	Program key,
	SMART\BR450\2002\Immobilizer	Program key,
	SMART\BR453\Immobilizer	Read PIN code,Program key,Recover configured
	SMART\BR452\2003-2006\Immobilizer	Program key,Read key count,

	SMART\BR454\2004-2006\Immobilizer	Program key,
	SMART\BR450\2002-\Immobilizer	Program key,Read key count,
	CHRYSLER\Select from type\Immobilizer\Type	Add new key,Add old key,Add remote,Detect key
	CHRYSLER\Select from type\Immobilizer\Type	Read PIN code,Add new key,Delete key,Key
	CHRYSLER\Select from type\Immobilizer\Type	Read pin code,Add key,Delete key,Key count,
	CHRYSLER\Select from type\Immobilizer\Type	Read pin code,Add key,Delete key,Key
	CHRYSLER\Select from type\Immobilizer\Type	Add key,Delete key,Key count,Add remote,Read
	CHRYSLER\Select from type\Smart key\Type	Add smart key,Delete smart key,Read PIN code,
	CHRYSLER\Select from type\Remote\Type 4(CAN)	Add remote,Read pin code,
	CHRYSLER\Select from type\Remote\Type 3(VPW)	Add remote,
	CHRYSLER\Select from type\Remote\Type 2(VPW)	Add remote,
	CHRYSLER\Select from type\Smart key\Type	Read PIN code,Add smart key,Delete smart key,Key
	CHRYSLER\Select from type\Immobilizer\Type	Add key,Delete key,Key count,Read PIN
	CHRYSLER\Select from type\IMMO-Fobik	Read PIN code,Sync smart key,Add key,Delete
	CHRYSLER\Select from vehicle\Asia\300\2011-	Add smart key,Delete smart key,Read PIN code,
	CHRYSLER\Select from vehicle\Asia\Fremont\201	Add smart key,Delete smart key,Read PIN code,
	CHRYSLER\Select from vehicle\Asia\300M\1998-	Add remote,
	CHRYSLER\Select from vehicle\Asia\Concorde\199	Add remote,
	CHRYSLER\Select from vehicle\Asia\LHS\1999-	Add remote,
	CHRYSLER\Select from vehicle\Asia\PT	Add remote,

CHRYSLER\Select from vehicle\Asia\Sebring\2001-	Add remote,
CHRYSLER\Select from vehicle\Asia\Town &	Add remote,Delete remote,
CHRYSLER\Select from type\Remote\Type 1(VPW)	Add remote,
CHRYSLER\Select from type\Remote\Type 5(VPW)	Add remote,Delete remote,
CHRYSLER\Select from type\Remote\Type 6(VPW)	Add remote,
CHRYSLER\Select from type\Remote\Type 7(VPW)	Add remote,
CHRYSLER\Select from type\Remote\Type 8(VPW)	Add remote,
CHRYSLER\Select from vehicle\Asia\200\2014-	Read PIN code,Add smart key,Delete smart key,
CHRYSLER\Select from type\Immobilizer\Type	Add key,Delete key,
CHRYSLER\Select from type\Immobilizer\Type	Add new key,Add old key,Add remote,Delete
CHRYSLER\Select from type\Smart key\Type	Add smart key,Delete smart key,Read PIN code,
CHRYSLER\Select from type\Smart key\Type	Sync smart function,
CHRYSLER\Select from type\Smart key\Type	Add smart key,Delete smart key,Read PIN code,
CHRYSLER\Select from vehicle\North	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\North	Read PIN code,Add smart key,Delete smart key,
CHRYSLER\Select from vehicle\North	Add new key,Add old key,Add remote,Delete
CHRYSLER\Select from vehicle\North	Add key,Delete key,Key count,Add remote,Read
CHRYSLER\Select from vehicle\North	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\North	Read pin code,Add key,Delete key,Key
CHRYSLER\Select from vehicle\North	Read PIN code,Add new key,Delete key,Key

CHRYSLER\Select from vehicle\North	Add smart key,Delete smart key,Read PIN code,
CHRYSLER\Select from vehicle\North	Add new key,Add old key,Add remote,Delete
CHRYSLER\Select from vehicle\North	Add key,Delete key,Key count,Add remote,Read
CHRYSLER\Select from vehicle\North	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\North	Read pin code,Add key,Delete key,Key
CHRYSLER\Select from vehicle\North	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\North	Add smart key,Delete smart key,Read PIN code,
CHRYSLER\Select from vehicle\North	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\North	Add remote,
CHRYSLER\Select from vehicle\North	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\North	Add remote,
CHRYSLER\Select from vehicle\North	Add key,Delete key,Key count,Add remote,Read
CHRYSLER\Select from vehicle\North	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\North	Add remote,
CHRYSLER\Select from vehicle\North	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\North	Add remote,
CHRYSLER\Select from vehicle\North	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\North	Add remote,
CHRYSLER\Select from vehicle\North	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\North	Add key,Delete key,Key count,Read PIN

CHRYSLER\Select from vehicle\North	Add remote,
CHRYSLER\Select from vehicle\North	Add key,Delete key,
CHRYSLER\Select from vehicle\North America\PT	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\North America\PT	Add remote,
CHRYSLER\Select from vehicle\North America\PT	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\North	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\North	Add remote,
CHRYSLER\Select from vehicle\North	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\North	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\North	Add remote,
CHRYSLER\Select from vehicle\North	Add key,Delete key,
CHRYSLER\Select from vehicle\North	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\North	Read pin code,Add key,Delete key,Key
CHRYSLER\Select from vehicle\North	Sync smart function,
CHRYSLER\Select from vehicle\North	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\North	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\North	Add key,Delete key,
CHRYSLER\Select from vehicle\Asia\300\2005-	Add new key,Add old key,Add remote,Delete
CHRYSLER\Select from vehicle\Asia\300\2006-	Add key,Delete key,Key count,Add remote,Read
CHRYSLER\Select from vehicle\Asia\300\2008\FOB	Read pin code,Add key,Delete key,Key count,

CHRYSLER\Select from vehicle\Asia\300\2009-	Read pin code,Add key,Delete key,Key
CHRYSLER\Select from vehicle\Asia\300\2011-	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Asia\300C\2005-	Add new key,Add old key,Add remote,Delete
CHRYSLER\Select from vehicle\Asia\300C\2006-	Add key,Delete key,Key count,Add remote,Read
CHRYSLER\Select from vehicle\Asia\300C\2008\F	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\Asia\300C\2009-	Read pin code,Add key,Delete key,Key
CHRYSLER\Select from vehicle\Asia\300C\2011-	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Asia\300C\2011-	Add smart key,Delete smart key,Read PIN code,
CHRYSLER\Select from vehicle\Asia\300M\1998-	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Asia\300M\2001-	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Asia\300M\2001-	Add remote,
CHRYSLER\Select from vehicle\Asia\300M\2004-	Add new key,Add old key,Add remote,Delete
CHRYSLER\Select from vehicle\Asia\Aspen\2007-	Add key,Delete key,Key count,Add remote,Read
CHRYSLER\Select from vehicle\Asia\Concorde\199	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Asia\Concorde\200	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Asia\Concorde\200	Add remote,
CHRYSLER\Select from vehicle\Asia\LHS\1999-	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Asia\Neon\2000\lm	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Asia\Neon\2001-	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Asia\Neon\2001-	Add remote,



CHRYSLER\Select from vehicle\Asia\Pacifica\2004-	Add key,Delete key,
CHRYSLER\Select from vehicle\Asia\PT	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Asia\PT	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Asia\Sebring\2001-	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Asia\Sebring\2007-	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Asia\Town &	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Asia\Town &	Add key,Delete key,
CHRYSLER\Select from vehicle\Asia\Town &	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\Asia\Town &	Read pin code,Add key,Delete key,Key
CHRYSLER\Select from vehicle\Asia\Town &	Sync smart function,
CHRYSLER\Select from vehicle\Asia\Voyager\2001	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Asia\Voyager\2004	Add key,Delete key,
CHRYSLER\Select from vehicle\Asia\Grand	Add key,Delete key,
CHRYSLER\Select from vehicle\Asia\Grand	Add remote,
CHRYSLER\Select from vehicle\Asia\Grand	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\Asia\Grand	Sync smart function,
CHRYSLER\Select from vehicle\Europe\200\2011-	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Europe\200\2014-	Read PIN code,Add smart key,Delete smart key,
CHRYSLER\Select from vehicle\Europe\300\2005-	Add new key,Add old key,Add remote,Delete
CHRYSLER\Select from vehicle\Europe\300\2006-	Add key,Delete key,Key count,Add remote,Read

CHRYSLER\Select from vehicle\Europe\300\2008\F	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\Europe\300\2009-	Read pin code,Add key,Delete key,Key
CHRYSLER\Select from vehicle\Europe\300\2011-	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Europe\300\2011-	Add smart key,Delete smart key,Read PIN code,
CHRYSLER\Select from vehicle\Europe\300C\2005-	Add new key,Add old key,Add remote,Delete
CHRYSLER\Select from vehicle\Europe\300C\2006-	Add key,Delete key,Key count,Add remote,Read
CHRYSLER\Select from vehicle\Europe\300C\2008\	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\Europe\300C\2009-	Read pin code,Add key,Delete key,Key
CHRYSLER\Select from vehicle\Europe\300C\2011-	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Europe\300C\2011-	Add smart key,Delete smart key,Read PIN code,
CHRYSLER\Select from vehicle\Europe\300M\1998	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Europe\300M\1998	Add remote,
CHRYSLER\Select from vehicle\Europe\300M\2001	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Europe\300M\2001	Add remote,
CHRYSLER\Select from vehicle\Europe\Aspen\200	Add key,Delete key,Key count,Add remote,Read
CHRYSLER\Select from vehicle\Europe\Concorde\1	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Europe\Concorde\1	Add remote,
CHRYSLER\Select from vehicle\Europe\Concorde\2	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Europe\Concorde\2	Add remote,
CHRYSLER\Select from vehicle\Europe\LHS\1999-	Add key,Delete key,Key count,Read PIN

CHRYSLER\Select from vehicle\Europe\LHS\1999-	Add remote,
CHRYSLER\Select from vehicle\Europe\Neon\2000\	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Europe\Neon\2001-	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Europe\Neon\2001-	Add remote,
CHRYSLER\Select from vehicle\Europe\Pacifica\20	Add key,Delete key,
CHRYSLER\Select from vehicle\Europe\PT	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Europe\PT	Add remote,
CHRYSLER\Select from vehicle\Europe\PT	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Europe\Sebring\20	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Europe\Sebring\20	Add remote,
CHRYSLER\Select from vehicle\Europe\Sebring\20	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Europe\Town &	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Europe\Town &	Add remote,
CHRYSLER\Select from vehicle\Europe\Town &	Add key,Delete key,
CHRYSLER\Select from vehicle\Europe\Town &	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\Europe\Town &	Read pin code,Add key,Delete key,Key
CHRYSLER\Select from vehicle\Europe\Town &	Sync smart function,
CHRYSLER\Select from vehicle\Europe\Voyager\20	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Europe\Voyager\20	Add key,Delete key,
CHRYSLER\Select from vehicle\Europe\Grand	Add key,Delete key,Key count,Read PIN

CHRYSLER\Select from vehicle\Europe\Grand	Add remote,
CHRYSLER\Select from vehicle\Europe\Grand	Add key,Delete key,
CHRYSLER\Select from vehicle\Europe\Grand	Add remote,
CHRYSLER\Select from vehicle\Europe\Grand	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\Europe\Grand	Sync smart function,
CHRYSLER\Select from vehicle\Europe\300M\2004	Add new key,Add old key,Add remote,Delete
CHRYSLER\Select from vehicle\Europe\Voyager\20	Add remote,
CHRYSLER\Select from vehicle\South	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\South	Read PIN code,Add smart key,Delete smart key,
CHRYSLER\Select from vehicle\South	Add new key,Add old key,Add remote,Delete
CHRYSLER\Select from vehicle\South	Add key,Delete key,Key count,Add remote,Read
CHRYSLER\Select from vehicle\South	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\South	Read pin code,Add key,Delete key,Key
CHRYSLER\Select from vehicle\South	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\South	Add smart key,Delete smart key,Read PIN code,
CHRYSLER\Select from vehicle\South	Add new key,Add old key,Add remote,Delete
CHRYSLER\Select from vehicle\South	Add key,Delete key,Key count,Add remote,Read
CHRYSLER\Select from vehicle\South	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\South	Read pin code,Add key,Delete key,Key
CHRYSLER\Select from vehicle\South	Read PIN code,Add new key,Delete key,Key

CHRYSLER

CHRYSLER\Select from vehicle\South	Add smart key,Delete smart key,Read PIN code,
CHRYSLER\Select from vehicle\South	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\South	Add remote,
CHRYSLER\Select from vehicle\South	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\South	Add remote,
CHRYSLER\Select from vehicle\South	Add key,Delete key,Key count,Add remote,Read
CHRYSLER\Select from vehicle\South	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\South	Add remote,
CHRYSLER\Select from vehicle\South	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\South	Add remote,
CHRYSLER\Select from vehicle\South	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\South	Add remote,
CHRYSLER\Select from vehicle\South	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\South	Add remote,
CHRYSLER\Select from vehicle\South	Add key,Delete key,
CHRYSLER\Select from vehicle\South America\PT	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\South America\PT	Add remote,
CHRYSLER\Select from vehicle\South America\PT	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\South	Add key,Delete key,Key count,Read PIN

CHRYSLER\Select from vehicle\South	Add remote,
CHRYSLER\Select from vehicle\South	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\South	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\South	Add remote,
CHRYSLER\Select from vehicle\South	Add key,Delete key,
CHRYSLER\Select from vehicle\South	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\South	Read pin code,Add key,Delete key,Key
CHRYSLER\Select from vehicle\South	Sync smart function,
CHRYSLER\Select from vehicle\South	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\South	Add key,Delete key,
CHRYSLER\Select from vehicle\South	Add key,Delete key,
CHRYSLER\Select from vehicle\South	Add remote,
CHRYSLER\Select from vehicle\South	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\South	Sync smart function,
CHRYSLER\Select from vehicle\South	Add new key,Add old key,Add remote,Delete
CHRYSLER\Select from vehicle\Middle	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Middle	Read PIN code,Add smart key,Delete smart key,
CHRYSLER\Select from vehicle\Middle	Add new key,Add old key,Add remote,Delete
CHRYSLER\Select from vehicle\Middle	Add key,Delete key,Key count,Add remote,Read
CHRYSLER\Select from vehicle\Middle	Read pin code,Add key,Delete key,Key count,

CHRYSLER\Select from vehicle\Middle	Read pin code,Add key,Delete key,Key
CHRYSLER\Select from vehicle\Middle	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Middle	Add smart key,Delete smart key,Read PIN code,
CHRYSLER\Select from vehicle\Middle	Add new key,Add old key,Add remote,Delete
CHRYSLER\Select from vehicle\Middle	Add key,Delete key,Key count,Add remote,Read
CHRYSLER\Select from vehicle\Middle	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\Middle	Read pin code,Add key,Delete key,Key
CHRYSLER\Select from vehicle\Middle	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Middle	Add smart key,Delete smart key,Read PIN code,
CHRYSLER\Select from vehicle\Middle	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Middle	Add remote,
CHRYSLER\Select from vehicle\Middle	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Middle	Add remote,
CHRYSLER\Select from vehicle\Middle	Add key,Delete key,Key count,Add remote,Read
CHRYSLER\Select from vehicle\Middle	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Middle	Add remote,
CHRYSLER\Select from vehicle\Middle	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Middle	Add remote,
CHRYSLER\Select from vehicle\Middle	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Middle	Add remote,

CHRYSLER\Select from vehicle\Middle	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Middle	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Middle	Add remote,
CHRYSLER\Select from vehicle\Middle	Add key,Delete key,
CHRYSLER\Select from vehicle\Middle East\PT	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Middle East\PT	Add remote,
CHRYSLER\Select from vehicle\Middle East\PT	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Middle	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Middle	Add remote,
CHRYSLER\Select from vehicle\Middle	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Middle East\Town	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Middle East\Town	Add remote,
CHRYSLER\Select from vehicle\Middle East\Town	Add key,Delete key,
CHRYSLER\Select from vehicle\Middle East\Town	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\Middle East\Town	Read pin code,Add key,Delete key,Key
CHRYSLER\Select from vehicle\Middle East\Town	Sync smart function,
CHRYSLER\Select from vehicle\Middle	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Middle	Add key,Delete key,
CHRYSLER\Select from vehicle\Middle East\Grand	Add key,Delete key,
CHRYSLER\Select from vehicle\Middle East\Grand	Add remote,



CHRYSLER\Select from vehicle\Middle East\Grand	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\Middle East\Grand	Sync smart function,
CHRYSLER\Select from vehicle\Middle	Add new key,Add old key,Add remote,Delete
CHRYSLER\Select from vehicle\Australia\200\2011-	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Australia\200\2014-	Read PIN code,Add smart key,Delete smart key,
CHRYSLER\Select from vehicle\Australia\300\2005-	Add new key,Add old key,Add remote,Delete
CHRYSLER\Select from vehicle\Australia\300\2006-	Add key,Delete key,Key count,Add remote,Read
CHRYSLER\Select from vehicle\Australia\300\2008\	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\Australia\300\2009-	Read pin code,Add key,Delete key,Key
CHRYSLER\Select from vehicle\Australia\300\2011-	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Australia\300\2011-	Add smart key,Delete smart key,Read PIN code,
CHRYSLER\Select from vehicle\Australia\300C\200	Add new key,Add old key,Add remote,Delete
CHRYSLER\Select from vehicle\Australia\300C\200	Add key,Delete key,Key count,Add remote,Read
CHRYSLER\Select from vehicle\Australia\300C\200	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\Australia\300C\200	Read pin code,Add key,Delete key,Key
CHRYSLER\Select from vehicle\Australia\300C\201	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Australia\300C\201	Add smart key,Delete smart key,Read PIN code,
CHRYSLER\Select from vehicle\Australia\300M\199	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Australia\300M\199	Add remote,
CHRYSLER\Select from vehicle\Australia\300M\200	Add key,Delete key,Key count,Read PIN

CHRYSLER\Select from vehicle\Australia\300M\200	Add remote,
CHRYSLER\Select from vehicle\Australia\Aspen\20	Add key,Delete key,Key count,Add remote,Read
CHRYSLER\Select from vehicle\Australia\Concorde	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Australia\Concorde	Add remote,
CHRYSLER\Select from vehicle\Australia\Concorde	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Australia\Concorde	Add remote,
CHRYSLER\Select from vehicle\Australia\LHS\1999	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Australia\LHS\1999	Add remote,
CHRYSLER\Select from vehicle\Australia\Neon\200	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Australia\Neon\200	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Australia\Neon\200	Add remote,
CHRYSLER\Select from vehicle\Australia\Pacifica\2	Add key,Delete key,
CHRYSLER\Select from vehicle\Australia\PT	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Australia\PT	Add remote,
CHRYSLER\Select from vehicle\Australia\PT	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Australia\Sebring\2	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Australia\Sebring\2	Add remote,
CHRYSLER\Select from vehicle\Australia\Sebring\2	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Australia\Town &	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Australia\Town &	Add remote,

CHRYSLER\Select from vehicle\Australia\Town &	Add key,Delete key,
CHRYSLER\Select from vehicle\Australia\Town &	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\Australia\Town &	Read pin code,Add key,Delete key,Key
CHRYSLER\Select from vehicle\Australia\Town &	Sync smart function,
CHRYSLER\Select from vehicle\Australia\Voyager\2	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Australia\Voyager\2	Add key,Delete key,
CHRYSLER\Select from vehicle\Australia\Grand	Add key,Delete key,
CHRYSLER\Select from vehicle\Australia\Grand	Add remote,
CHRYSLER\Select from vehicle\Australia\Grand	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\Australia\Grand	Sync smart function,
CHRYSLER\Select from vehicle\Australia\300M\200	Add new key,Add old key,Add remote,Delete
CHRYSLER\Select from vehicle\Africa\200\2011-	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Africa\200\2014-	Read PIN code,Add smart key,Delete smart key,
CHRYSLER\Select from vehicle\Africa\300\2005-	Add new key,Add old key,Add remote,Delete
CHRYSLER\Select from vehicle\Africa\300\2006-	Add key,Delete key,Key count,Add remote,Read
CHRYSLER\Select from vehicle\Africa\300\2008\FO	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\Africa\300\2009-	Read pin code,Add key,Delete key,Key
CHRYSLER\Select from vehicle\Africa\300\2011-	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Africa\300\2011-	Add smart key,Delete smart key,Read PIN code,
CHRYSLER\Select from vehicle\Africa\300C\2005-	Add new key,Add old key,Add remote,Delete

CHRYSLER\Select from vehicle\Africa\300C\2006-	Add key,Delete key,Key count,Add remote,Read
CHRYSLER\Select from vehicle\Africa\300C\2008\F	Read pin code,Add key,Delete key,Key count,
CHRYSLER\Select from vehicle\Africa\300C\2009-	Read pin code,Add key,Delete key,Key
CHRYSLER\Select from vehicle\Africa\300C\2011-	Read PIN code,Add new key,Delete key,Key
CHRYSLER\Select from vehicle\Africa\300C\2011-	Add smart key,Delete smart key,Read PIN code,
CHRYSLER\Select from vehicle\Africa\300M\1998-	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Africa\300M\1998-	Add remote,
CHRYSLER\Select from vehicle\Africa\300M\2001-	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Africa\300M\2001-	Add remote,
CHRYSLER\Select from vehicle\Africa\Aspen\2007-	Add key,Delete key,Key count,Add remote,Read
CHRYSLER\Select from vehicle\Africa\Concorde\19	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Africa\Concorde\19	Add remote,
CHRYSLER\Select from vehicle\Africa\Concorde\20	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Africa\Concorde\20	Add remote,
CHRYSLER\Select from vehicle\Africa\LHS\1999-	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Africa\LHS\1999-	Add remote,
CHRYSLER\Select from vehicle\Africa\Neon\2000\I	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Africa\Neon\2001-	Add key,Delete key,Key count,Read PIN
CHRYSLER\Select from vehicle\Africa\Neon\2001-	Add remote,
CHRYSLER\Select from vehicle\Africa\Pacifica\200	Add key,Delete key,

CHRYSLER>Select from  
vehicle

