

CHANGAN

Benben

Benben mini

Remote system

Remote number

Remote program

New Benben

Remote system

Remote number

Remote program

Benben 2013

Integrated BCM(B501)

Add remote

Erase remote

Live data

Benben(Old)

Chongqing integrated Immobiliser

Basic function

Identification data

Fault codes

Erase DTC

System state

Program function

Set security code

Program date

Program VIN

Erase keys

Program keys

Reset immobiliser

Reset engine ECU

Replace engine ECU

Replace immobiliser ECU

CM8

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

- Erase keys
 - Erase all keys
 - Erase key 1
 - Erase key 2
 - Erase key 3
 - Erase key 4
 - Erase key 5
- Replace immobiliser ECU
- Replace engine ECU
- Program immobiliser VIN
- Program engine VIN
- Reset engine ECU
- Reset immobiliser

Jiexun

- STEC Immobiliser
 - ECU identification
 - Fault codes
 - Erase DTC
 - Live data
 - Set security code
 - Set security code
 - Input security code
 - Program function
 - Program new system
 - Program keys
 - Erase keys
 - Erase all keys
 - Erase key 1
 - Erase key 2
 - Erase key 3
 - Erase key 4
 - Erase key 5
 - Replace immobiliser ECU
 - Replace engine ECU
 - Program immobiliser VIN
 - Program engine VIN
 - Reset engine ECU
 - Reset immobiliser

Leimeng

- STEC Immobiliser
 - ECU identification
 - Fault codes
 - Erase DTC
 - Live data

Set security code
Set security code
Input security code
Program function
Program new system
Program keys
Erase keys
Erase all keys
Erase key 1
Erase key 2
Erase key 3
Erase key 4
Erase key 5
Replace immobiliser ECU
Replace engine ECU
Program immobiliser VIN
Program engine VIN
Reset engine ECU
Reset immobiliser

Yuexiang

V3/V5

Integrated BCM(B501)
Add remote
Erase remote
Live data

Atech BCM

Add remote
Erase remote
Live data

V7

Integrated BCM(C201)
Add remote
Erase remote
Live data
Read password
Remote system(Smart key)
Erase DTC
Program remotes
Key number
Smart key system
Erase DTC
Program smart keys
Key number

Zhixiang

Atech BCM

- Add remote
- Erase remote
- Live data

Delphi Immobiliser

- ECU identification
- Fault codes
- Erase DTC
- Live data
- Set security code
 - Input security code
 - Set security code
- Program function
 - Program new system
 - Replace immobiliser ECU
 - Replace engine ECU
 - Program keys
 - Program engine VIN
 - Program immobiliser VIN
 - Reset engine ECU
 - Reset immobiliser
 - Erase keys

Ruipin

Integrated BCM(C201)

- Add remote
- Erase remote
- Live data
- Read password

Remote system

- Erase DTC
- Program remotes
- Read key number

Smart key system

- Erase DTC
- Program smart keys
- Read key number

B301

Atech BCM

- Add remote
- Erase remote
- Live data

CX20

Atech BCM

- Add remote

Erase remote

Live data

Integrated BCM(B501)

Add remote

Erase remote

Live data

CX30

Atech BCM

Add remote

Erase remote

Live data

Delphi Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Input security code

Set security code

Program function

Program new system

Replace immobiliser ECU

Replace engine ECU

Program keys

Program engine VIN

Program immobiliser VIN

Reset engine ECU

Reset immobiliser

Erase keys

Integrated BCM(B501)

Add remote

Erase remote

Live data

CS35

Delphi BCM

Program keys

Erase keys

Add remote

Erase remote

Enter sleep mode

Data configuration

VIN modify

PIN modify

K Line immobiliser enable

enable

disable

With the speed of automatic locking function

On

Off

CS75

Integrated BCM(C201)

Add remote

Erase remote

Live data

Read password

Remote system

Erase DTC

Program remotes

Read key number

Smart key system

Erase DTC

Program smart keys

Read key number

CV7

STEC Immobiliser

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

CV9

STEC Immobiliser

- ECU identification
- Fault codes
- Erase DTC
- Live data
- Set security code
 - Set security code
 - Input security code
- Program function
 - Program new system
 - Program keys
 - Erase keys
 - Erase all keys
 - Erase key 1
 - Erase key 2
 - Erase key 3
 - Erase key 4
 - Erase key 5
 - Replace immobiliser ECU
 - Replace engine ECU
 - Program immobiliser VIN
 - Program engine VIN
 - Reset engine ECU
 - Reset immobiliser

EADO

Integrated BCM(C201)

- Add remote
- Erase remote
- Live data
- Read password

EADO Hybrid

Integrated BCM(C201)

- Add remote
- Erase remote
- Live data
- Read password

EADO Pure electric

Integrated BCM(C201)

- Add remote
- Erase remote
- Live data
- Read password

EADO XT

Integrated BCM(C201)

- Add remote
- Erase remote
- Live data
- Read password

Honor

Delphi Immobiliser

- ECU identification
- Fault codes
- Erase DTC
- Live data
- Set security code
 - Input security code
 - Set security code
- Program function
 - Program new system
 - Replace immobiliser ECU
 - Replace engine ECU
 - Program keys
 - Program engine VIN
 - Program immobiliser VIN
 - Reset engine ECU
 - Reset immobiliser
 - Erase keys

Atech BCM

- Add remote
- Erase remote
- Live data